



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRENDNET TK-803R. You'll find the answers to all your questions on the TRENDNET TK-803R in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TRENDNET TK-803R
User guide TRENDNET TK-803R
Operating instructions TRENDNET TK-803R
Instructions for use TRENDNET TK-803R
Instruction manual TRENDNET TK-803R



[You're reading an excerpt. Click here to read official TRENDNET TK-803R user guide](http://yourpdfguides.com/dref/3182143)
<http://yourpdfguides.com/dref/3182143>

Manual abstract:

Before You Start 2. How to Install 3. Operation Technical Specifications Troubleshooting 1 1 2 4 7 8 Version 08.14.2009 1. Before You Start ENGLISH Package Contents ? TK-803R/TK-1603R ? Multi-Language Quick Installation Guide ? kii Rack mount ?Adapter (9V DC, 1A) AC Power FRANAIS System Requirements ? Keyboard PS/2 or USB DEUTSCH ? Mouse PS/2 or USB ? VGA Compatible Monitor ? KVM cables (e.g. TK-CU06, TK-CU10, TK-CU15) USB/ VGA ? @@How to Install 1. @@@@TK-1603R shown) FRANAIS 3. Connect the included AC Power Adapter to the KVM switch and then to a power outlet.

4. Use the KVM cables to connect each computer to the KVM switch. 5. Turn ON the connected computers one-by-one and wait until each computer's desktop appears. PC 1, 2, 3, 4, 5, 6, 7, 8 (TK-803R) PC 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16 (TK-1603R) 2 ESPAOL DEUTSCH ENGLISH Rack Mount ENGLISH FRANAIS The KVM Switch can be mounted in an EIA standard-size, 19-inch rack, which can be placed in a wiring closet with other equipment. Note: If you would like to mount the KVM switch to a EIA 19" equipment rack, install the included mounting brackets to the sides of the KVM switch, secure them with the screws provided, and then mount the KVM switch to the equipment rack with the hardware provided by the equipment rack manufacturer. DEUTSCH 1. Attach the mounting brackets to both sides of the KVM switch and secure them with the provided screws. ESPAOL 2. Carefully position the KVM switch onto the rack.

Align the bracket to the screw holes on the rack, then use the screws provided with the equipment rack to mount the KVM switch. Your installation is now complete. Register Your Product To ensure the highest level of customer service and support, please take a moment to register your product Online at: www.trendnet.com/register Thank you for choosing TRENDnet. 3 3. Operation Note: To switch between computers, you can use the front-panel push buttons or the Hot Key commands. LED Indicators Red LED light: KVM cable is connected and PC is powering the KVM switch. Green LED light: Indicates the selected PC port is active, whether the computer is turned on or off. FRANAIS Push Buttons Press the push buttons to switch between computers.

4 ESPAOL DEUTSCH ENGLISH ENGLISH FRANAIS Hot Key Commands A keyboard hot key command consists of three keystrokes: Hot Key command = Scroll Lock + Scroll Lock + Command key(s) After pressing the Scroll Lock key, you have 2 seconds to press the Scroll Lock key again. You then have another 2 seconds to press a command key. A beep confirms that the KVM switch is in "Hot Key" mode. If you do not press a key within 2 seconds, the switch will exit hot key mode. To select a specific PC port: For TK-803R Select PC= Scroll Lock + Scroll Lock + Y DEUTSCH For example, to Select Port 1 on the TK-803R you hit the following key sequence: Select PC= For TK1603R Select PC= Scroll Lock + Scroll Lock + 1 Scroll Lock + Scroll Lock + Y + Z ESPAOL For example, to select Port 1 on the TK-1603R you hit the following key sequence: Select PC = Scroll Lock + Scroll Lock + 0 + 1 To select port 10 on the TK-1603, hit the following key sequence: Select PC = Scroll Lock + Scroll Lock + 1 + 0 MAC USERS Standard PC Keyboard to MAC Keyboard mapping information: Scroll Lock + Scroll Lock + Scroll Lock + Scroll Lock + Scroll Lock + Scroll Lock + Scroll Lock + C F10 F11 F12 = = = F13 F14 F15 CD/DVD drive eject key For a list of all the Hot Key commands, please see the Quick Reference Sheet. 5 Quick Reference Sheet for TK-803R/TK-1603R Command TK-803R Hot Keys Front-Panel Buttons Description Scroll Lock + Scroll Lock + Y Select PC TK-1603R Press the Push Button for a specific port to switch to that port Select the active PC channel Scroll Lock + Scroll Lock + Y + Z Next lower channel Scroll Lock + Scroll Lock + (Arrow up) --- (Arrow down) Select the next lower PC channel Next higher channel Scroll Lock + Scroll Lock + Select the next higher PC channel Mouse/Keyboard Reset KVM Restore to Factory Defaults Define Hotkey Sequence (default = Scroll Lock + Scroll Lock) Scroll Lock + Scroll Lock + Scroll Lock + Scroll Lock + END R ----- Resets Mouse/Keyboard Restore to Factory Defaults Scroll Lock + Scroll Lock + H + Y Y = Scroll Lock, Caps Lock, Esc, F12 or Num Lock Select the hotkey preceding sequence among 5 options Autoscan through every connected channel for quick screen browsing of each channel Autoscan Scroll Lock + Scroll Lock + S Scroll Lock + Scroll Lock + S + X (X) = 0~9 1 = 10 seconds 2 = 20 seconds 3 = 30 seconds 4 = 40 seconds 5 = 50 seconds 6 = 60 seconds 7 = 70 seconds 8 = 80 seconds 9 = 90 seconds 0 = 100 seconds Stop Autoscan Press any key on keyboard Press any button Terminate Autoscan activity Note: If you have defined a different hot key preceding sequence key (e.g. Caps Lock, Esc, F12), press that button instead of scroll lock. For example, if you want to turn off beep and have defined the hotkey preceding sequence key as F12, press F12 + F12 + B. 6 Autoscan with Programmable Delay Time --- Autoscan through every connected channel for quick screen browsing of each channel in intervals of X seconds ESPAOL DEUTSCH Autoscan Beep Sound On/Off Scroll Lock + Scroll Lock + B --- Toggle On/Off beep sound during Autoscan mode.

FRANAIS (YZ)= 2-digit channel number ENGLISH Technical Specifications TK-803R: 8 computers TK-1603R: 16 computers 1 x USB keyboard Type A 1 x USB mouse Type A 1 x PS/2 keyboard 6-pin mini din female 1 x PS/2 mouse 6-pin mini din female 1 x VGA HDB 15-pin female TK-803R: 8 x VGA HDB 15-pin female TK-1603R: 16 x VGA HDB 15-pin female 2048 x 1536 Push Button and Hot Key Commands Per Port : PC Link (Green) ; PC Active (Red) Save and restore 10 ~ 100 seconds PS/2 Interface Power USB Interface Power External AC Power Adapter : 9V DC, 1A 1U 405 x 163 x 44 mm (15.94 x 6.42 x 1.74 in.) TK-803R : 1.

84 kg (4.05 lbs) TK-1603R : 2.04 kg (4.5 lbs) 0C ~ 40C (32F ~ 104F) -20C ~ 60C (-4F ~ 140F) 0%~90%, Non-Condensing FCC and CE Management: Console Port Connectors: PC Port Connectors: Video Resolution: Port Selection: LED: Keyboard Status: Auto-Scan Intervals: Power: Size (19" Rack mount): Dimensions: Weight: Operating Temperature: Storage Temperature: Humidity: Certifications: 7 Troubleshooting Do I need to use the included external AC adapter? @@@@1. @@2.

@@3. @@@@Go to Section 3 Operation for more information. How to upgrade new firmware to my KVM switch? @@@@All products that are replaced become the property of TRENDnet. Replacement products may be new or reconditioned. TRENDnet does not issue refunds or credit. Please contact the point-of-purchase for their return policies.



[You're reading an excerpt. Click here to read official TRENDNET](#)

[TK-803R user guide](#)

<http://yourpdfguides.com/dref/3182143>

@@There are no user serviceable parts inside the product. Do not remove or attempt to service the product by any unauthorized service center. This warranty is voided if (i) the product has been modified or repaired by any unauthorized service center, (ii) the product was subject to accident, abuse, or improper use (iii) the product was subject to conditions more severe than those specified in the manual. Warranty service may be obtained by contacting TRENDnet within the applicable warranty period and providing a copy of the dated proof of the purchase.

Upon proper submission of required documentation a Return Material Authorization (RMA) number will be issued. An RMA number is required in order to initiate warranty service support for all TRENDnet products. Products that are sent to TRENDnet for RMA service must have the RMA number marked on the outside of return packages and sent to TRENDnet prepaid, insured and packaged appropriately for safe shipment. Customers shipping from outside of the USA and Canada are responsible for return shipping fees. Customers shipping from outside of the USA are responsible for custom charges, including but not limited to, duty, tax, and other fees. 9 WARRANTIES EXCLUSIVE: IF THE TRENDNET PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, THE CUSTOMER'S SOLE REMEDY SHALL BE, AT TRENDNET'S OPTION, REPAIR OR REPLACE. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. TRENDNET NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION MAINTENANCE OR USE OF TRENDNET'S PRODUCTS. @@@@Governing Law: This Limited Warranty shall be governed by the laws of the state of California. Some TRENDnet products include software code written by third party developers. These codes are.



[You're reading an excerpt. Click here to read official TRENDNET TK-803R user guide](http://yourpdfguides.com/dref/3182143)
<http://yourpdfguides.com/dref/3182143>