



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TRENDNET TV-IP121W. You'll find the answers to all your questions on the TRENDNET TV-IP121W in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TRENDNET TV-IP121W
User guide TRENDNET TV-IP121W
Operating instructions TRENDNET TV-IP121W
Instructions for use TRENDNET TV-IP121W
Instruction manual TRENDNET TV-IP121W



[You're reading an excerpt. Click here to read official TRENDNET TV-IP121W user guide](http://yourpdfguides.com/dref/3182099)
<http://yourpdfguides.com/dref/3182099>

Manual abstract:

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....

. 1. Before You Start ...

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

... 2. Hardware Installation

.....
.....
.....

.....
.....
.....
.....

.....
.....

.. 3. Configure the Internet Camera ..

.....

.....
.....
.....
.....

.....
.....

. 1 1 3 4 Troubleshooting

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... 9 Version 05.

13.2009 1. Before You Start Package Contents TV-IP121W ? ? Utility CD-ROM ? Quick Installation Multi-Language Guide ? 1 x 2dBi Detachable Antenna ? AC Power Adapter (5V, 2.5A) ? Camera Stand ? RJ-45 Cable System Requirements 10/100Mbps ? Ethernet Adapter CD-ROM Drive ? ? CPU: 350MHz or above / 800MHz (Windows Vista) ? Memory: 256MB RAM or above / 512MB RAM or above (Windows Vista) ? Windows 2000/XP/Vista ? VGA Resolution: 800 x 600 or above ? Web Browser: Internet Explorer (6.0 or higher) ? Wireless Router or Access Point ? DHCP Server routers usually have a built-in DHCP server An Available 1 English Application SecurView Wireless Day/Night Internet Camera (TV-IP121W) Internet Notebook with Wireless G PC Card (TEW-421PC) 54Mbps Wireless G Firewall Router (TEW-432BRP) Modem 2 English 2.

Hardware Installation 1. Attach the Antenna. 2. Connect a RJ-45 network cable from a Switch/Router to the Ethernet port on the IP Camera. 3. Connect the AC Power Adapter to the IP Camera and then to a power outlet. 4. Verify the Power and Link LEDs are on. 3 English 3. Configure the Internet Camera Note: 1.

It is recommended that you configure the IP Camera from a wired computer. 2. If you would like to use SecurView software, please refer to the User's Guide on the CD for more information. 1. @@@@Please skip to step 8. @@Select the IP camera and click Change IP. 5. Configure the IP address to be in the same subnet as your network, type in the Administrator ID and Password and click Change. By default: ID: admin Password: admin 6. Click OK and wait 30 seconds.

7. Click OK. 5 English 8. Double click the IP camera to access the browser configuration. 9.

Enter the User name and Password, and then click OK. By default: User Name: admin Password: admin 10. Right click on the Internet Explorer Information Bar and select Install ActiveX Control. 11. Click Install.

6 English 12. Click Setup, Network and then click Wireless. 13. Click Site Survey. Select your wireless network. If encryption is enabled, select the proper Authentication type, enter the Pre-Shared Key and then click Apply. (Example shows WPA2-PSK. If your wireless network does not support WPA, select open or shared instead. Contact your network administrator for more 14. Disconnect the RJ-45 cable and unplug the power.

Then plug the power back in. Note: The TV-IP121W will not work wirelessly until you disconnect the Ethernet cable from the back of the camera. 7 English 15. Verify the Power and Link LEDs are on. 16. Click Live View. Your installation is now complete. Note: For detailed information regarding the TV-IP121W configuration and advanced settings, please refer to the Troubleshooting section, User's Guide on the Utility CD-ROM, or TRENDnet's website at <http://www.trendnet.com>.

Register Your Product To ensure the highest level of customer service and support, please take a moment to register your product Online at: www.trendnet.com/register Thank you for choosing TRENDnet 8 English Troubleshooting Q1: IP Setup is unable to detect my camera. What should I do? A1: First, verify that you have followed all the steps in the Section 2: Hardware Installation. Second, disable any software firewall programs such as ZoneAlarm or Norton Internet Security.

If you are using Windows XP or Windows Vista, disable the built in firewall. Third, click on Search in the IPSetup setup wizard. Q2: I do not have a DHCP server or DHCP is disabled on my network and I am unable to configure the TV-IP121W. What should I do? A2: First, go to the TCP/IP settings on your computer and assign a static IP address on your computer's network adapter in the subnet of 192.168.

10.x. Since the default IP address of the TV-IP121W is 192.168.10.30, do not assign a static IP address of 192.168.10.30 on your computer's network adapter. Second, run the IPSetup wizard and double click on the TVIP121W to access the browser configuration.

Q3: The Image is blurry. How can I adjust the focus on the Internet camera? A3: You can adjust the Internet Camera's focus by rotating the lens. Q4: When I click on Live View the image does not load? A4: First, make sure that you are using a browser that supports ActiveX. Second, make sure that you have added the ActiveX component. See step 10 and 11 in Section 2: Configure the Internet Camera. Q5: How do I connect the TV-IP121W to my wireless router or access point? @@@@Q7: I forgot my password. What should I do? @@This will return settings back to factory defaults. The default IP address is 192.168.10.

30. The default administrator ID and password is admin. @@@@TRENDnet does not provide technical support for these codes. @@@@You could also request the source codes by contacting TRENDnet. @@@@TRENDnet ne fournit pas d'assistance technique pour ces codes.

@@@20675 Manhattan Place, Torrance, CA 90501, USA. @@Sie haben durch den Erwerb dieses Produktes keinerlei Gewährleistungsansprüche gegen die Berechtigten an der oben genannten Software erworben; weil diese die Software kostenfrei lizenzieren gewähren sie keine Haftung gemäß unten abgedruckten Lizenzbedingungen. Die Software darf von jedermann im Quell-und Objektcode unter Beachtung der Lizenzbedingungen der GNU General Public License Version 2, und GNU Lesser General Public License (LGPL) vervielfältigt, verbreitet und verarbeitet werden. Die Lizenz ist unten im englischsprachigen Originalwortlaut wiedergegeben. Eine nichtoffizielle Übersetzung in die deutsche Sprache finden Sie im Internet unter (<http://www.gnu.de/documents/gpl-2.0.de.html>).

Eine allgemeine öffentliche GNU Lizenz befindet sich auch auf der mitgelieferten CD-ROM. Sie können Quell-und Objektcode der Software für mindestens drei Jahre auf unserer Homepage www.trendnet.com im Downloadbereich (http://trendnet.com/langen/downloads/list_gpl).

asp) downloadend. Sofern Sie nicht über die Möglichkeit des Downloads verfügen können Sie bei TRENDnet, 20675 Manhattan Place, Torrance, CA 90501 -U.S.A -, Tel.: +1-310-961-5500, Fax: +1-310-961-5511 die Software anfordern. Información general sobre la GPL/LGPL Este producto de TRENDnet incluye un programa gratuito desarrollado por terceros. Estos códigos están sujetos a la Licencia pública general de GNU ("GPL") o la Licencia pública general limitada de GNU ("LGPL"). Estos códigos son distribuidos SIN GARANTÍA y están sujetos a las leyes de propiedad intelectual de sus desarrolladores. TRENDnet no ofrece servicio técnico para estos códigos.

Los detalles sobre las licencias GPL y LGPL de GNU se incluyen en el CD-ROM del producto. Consulte también el (<http://www.gnu.org/licenses/gpl.txt>) ó el (<http://www.gnu.org/licenses/lgpl.txt>) para ver las cláusulas específicas de cada licencia.



[You're reading an excerpt. Click here to read official TRENDNET TV-IP121W user guide](http://yourpdfguides.com/dref/3182099)

<http://yourpdfguides.com/dref/3182099>

Los códigos fuentes están disponibles para ser descargados del sitio Web de TRENDnet (http://trendnet.com/downloads/list_gpl.asp) durante por lo menos tres años a partir de la fecha de envío del producto. También puede solicitar el código fuente llamando a TRENDnet. 20675 Manhattan Place, Torrance, CA 90501, USA. Tel: +1-310-961-5500 Fax: +1-310-961-5511 GPL/LGPL TRENDnet, . @ @ . TRENDnet . GNU GPL LGPL -, . @ @ @ @ , TRENDnet. 20675 Manhattan Place, Torrance, CA 90501, USA. @ @ Estes códigos estão sujeitos ao GPL (GNU General Public License) ou ao LGPL (GNU Lesser General Public License).

Estes códigos são distribuídos SEM GARANTIA e estão sujeitos aos direitos autorais dos desenvolvedores. TRENDnet não presta suporte técnico a estes códigos. Os detalhes do GNU GPL e do LGPL estão no CD-ROM do produto. Favor acessar <http://www.gnu.org/licenses/gpl.txt> ou <http://www.gnu.org/licenses/lgpl.txt> para os termos específicos de cada licença.

Os códigos fonte estão disponíveis para download no site da TRENDnet (http://trendnet.com/langen/downloads/list_gpl.asp) por pelo menos três anos da data de embarque do produto. Você.



[You're reading an excerpt. Click here to read official TRENDNET TV-IP121W user guide](http://yourpdfguides.com/dref/3182099)
<http://yourpdfguides.com/dref/3182099>