



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH COUNTING FUN ELEPHANT. You'll find the answers to all your questions on the VTECH COUNTING FUN ELEPHANT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual VTECH COUNTING FUN ELEPHANT
User guide VTECH COUNTING FUN ELEPHANT
Operating instructions VTECH COUNTING FUN ELEPHANT
Instructions for use VTECH COUNTING FUN ELEPHANT
Instruction manual VTECH COUNTING FUN ELEPHANT



Counting Fun Elephant™



© 2010 VTech
Printed in China
91-112000-000-000



[You're reading an excerpt. Click here to read official VTECH COUNTING FUN ELEPHANT user guide](http://yourpdfguides.com/dref/3398260)
<http://yourpdfguides.com/dref/3398260>

Manual abstract:

TM VTEch®'s Counting Fun Elephant combines learning with fun as your child distributes colorful balls through a ball popper. Twist the elephant's ear and watch the balls pop! It's up to a little bird perched nearby to decide which path the balls can take, either through the fountain or over the piano keys.

While the toy teaches numbers and counting, the elephant's hand lights up and the piano plays music that keeps your child engaged for endless play time.

TWISTING EAR BIRD SLIDER FOUR PIANO KEYS MODE SELECTOR Introduction INCLUDED IN THIS PACKAGE One VTEch® Counting Fun Elephant

One user's manual TM WARNING: All packing materials, such as tape, plastic Unlock the packing locks: Rotate the packing locks 90 degrees counter-clockwise Pull out the packing locks WARNING: For your child's safety, please do not put anything but the balls included with the product into the fountain or the elephant's trunk. Included In This Package sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety. GETTING

STARTED BATTERY INSTALLATION 1. Make sure the unit is turned OFF. 2. Locate the battery cover on the bottom of the unit. Use a coin or a screwdriver to loosen the screw.

3. @@@@4. Replace the battery cover and tighten the screw to secure. BATTERY NOTICE @@Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged (if removable).

Rechargeable batteries are only to be charged under adult supervision (if removable). Do not mix old and new batteries. Do not mix batteries of different types: alkaline, standard (carbonzinc) or rechargeable (nickel-cadmium). Only batteries of the same or equivalent type as recommended are to be used.

Batteries are to be inserted with the correct polarity.

Exhausted batteries are to be removed from the toy. The supply terminals are not to be short-circuited. Getting Started . . The toy is not to be connected to more than the recommended number of power supplies. Do not dispose of batteries in fire. ASSEMBLY INSTRUCTIONS With the VTEch® Counting Fun Elephant safety comes first. To ensure your child's safety, adult assembly is required. TM Back Tray To attach the back tray to the front unit, insert the back tray into the two slots on the front unit. You will hear a `click` sound, this indicates that the back tray is securely fixed into the front unit. Front Unit

PRODUCT FEATURES 1. MODE SELECTOR To turn the unit ON, slide the MODE SELECTOR to the Learning Mode () or Music Mode position ().

@@@@@@@The light will flash with the sounds. 2. @@The light will flash with the sounds. 3. @@Hear fun melodies as the balls pop up in the air. The light will flash with the sounds. 4. @@@@@@@Flyingupandrollingdown,untilthey'redone. Twisttheear,watchthempop,highintheair. Popping, rolling, spinning, going, all with such flair! @@Keep the unit clean by wiping it with a slightly damp cloth.

2. @@3. @@4. @@Please turn the unit OFF. 2.

Interrupt the power supply by removing the batteries. 3. Let the unit stand for a few minutes, then replace the batteries. 4. Turn the unit ON.

@@@If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you. For information on this product's warranty, please call our Consumer Services Department at 1-800-521-2010 in the

U.S. or 1-877-352-8697 in Canada. IMPORTANT NOTE: Creating and developing Infant Learning products is accompanied by a responsibility that we at

VTEch® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.

S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you. FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. @@@@ THIS DEVICE COMPLIES WITH PART 15

OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION. THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA. Other Info 10 .



[You're reading an excerpt. Click here to read official VTECH COUNTING FUN ELEPHANT user guide](http://yourpdfguides.com/dref/3398260)
<http://yourpdfguides.com/dref/3398260>