



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE. You'll find the answers to all your questions on the VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE

User guide VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE

Operating instructions VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE

Instructions for use VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE

Instruction manual VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE



Learn & Discover Globe



© The Baby Einstein Company, LLC. All Rights Reserved.
Little Einsteins and the Little Einsteins Logo are trademarks
of The Baby Einstein Company, LLC. All Rights Reserved.
EINSTEIN and ALBERT EINSTEIN are trademarks of The
Hebrew University of Jerusalem. All Rights Reserved.
www.albert-einstein.org

© 2008 Vtech Printed in China



[You're reading an excerpt. Click here to read official VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE user guide](http://yourpdfguides.com/dref/2832080)
<http://yourpdfguides.com/dref/2832080>

Manual abstract:

To help prepare preschoolers for this important event, VTech® has developed the Preschool Learning™ series of interactive toys. Preschool Learning™ features fun characters and inviting school themes that use technology to capture a child's attention and teach important preschool skills like spelling, counting and the alphabet. @@@@With Preschool Learning™, learning is fun from day one! @@@@We thank you for trusting VTech® with the important job of helping your child learn and grow! Sincerely, Julia Fitzgerald Vice President, Marketing Vtech Electronics, NA To learn more about the Preschool Learning™ and other VTech® toys, visit www.vtechkids.com Movable Rocket ON/OFF button Interactive joystick Mode selector Introduction Detector and magnifying glass INCLUDED IN THIS PACKAGE · One Learn & Discover Globe · One User's Manual WARNING: All packing materials such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety. GETTING STARTED 1. Make sure the unit is turned OFF. 2. Locate the battery cover on the bottom of the unit. 3.

Open the battery cover. 4. Install 4 new "AA" batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance.) 5.

Replace the battery cover. BATTERY NOTICE Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged (if removable). Rechargeable batteries are only to be charged under adult supervision (if removable). Different types of batteries or new and used batteries are not to be mixed.

Only batteries of the same or equivalent type as recommended are to be used. Getting Started BATTERY INSTALLATION Batteries are to be inserted with the correct polarity. Exhausted batteries are to be removed from the toy. The supply terminals are not to be short-circuited. The toy is not to be connected to more than recommended number of power supplies. Do not dispose of batteries in fire. WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES. 1. ON/OFF BUTTON To turn the unit on, press the ON/OFF BUTTON. You will hear a friendly greeting.

Press the ON/OFF BUTTON again to turn the unit off. 2. INTERACTIVE JOYSTICK Move the JOYSTICK left or right to fly Rocket left or right. Move the joystick forward or backward to fly Rocket up or down. Release the joystick to stop Rocket. Product Features PRODUCT FEATURES 3. MODE SELECTOR Slide the MODE SELECTOR to choose a mode of play. 4. ROCKET 5. @@@@Slide the MODE SELECTOR to enter this mode.

2. You will be asked to find a continent or ocean. @@@@5. @@Slide the MODE SELECTOR to enter this mode. 2.

You will be asked to fly to a certain geographic location. @@@@Then the unit will play an encouraging phrase. 4. @@5. @@Slide the MODE SELECTOR to enter this mode.

2. Control the joystick to fly Rocket anywhere on the globe. @@@@Slide the MODE SELECTOR to enter this mode. 2. You will be asked to find a certain instrument. @@@@5. @@Slide the MODE SELECTOR to enter this mode. 3. @@Then you will hear "Let's fly to the Sydney Opera House, then the Eiffel Tower!" 4. If you fly to an incorrect location, the unit will identify that location first, and then ask you to keep searching for the correct one.

5. If you answer incorrectly after three consecutive times, the unit will ask you a new question. Activities 10 2. You will be asked to find a series of locations in order. For example, you will hear, "Let's fly to the Great Pyramid, then the Sydney Opera House, then the Eiffel Tower!" CARE & MAINTENANCE 1. Keep the unit clean by wiping it with a slightly damp cloth. 2. Keep the unit out of direct sunlight and away from any direct heat source. 3. Remove the batteries when the unit is not in use for an extended period of time.

4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water. TROUBLESHOOTING If for some reason the program/activity stops working or malfunctions, please follow these steps: 1. Please turn the unit OFF. 2.

Interrupt the power supply by removing the batteries. 3. Let the unit stand for a few minutes, then replace the batteries. 4. Turn the unit ON.

The unit should now be ready to play again. 5. If the product still does not work, replace with a new set of batteries. If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada and a service representative will be happy to help you. Care & Maintenance 11 IMPORTANT NOTE Creating and developing Preschool Learning™ products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-5212010 in the U.

S. @@@@However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Note 1 · Reorient or relocate the receiving antenna · Increase the separation between the equipment and receiver · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected · Consult the dealer or an experienced radio/TV technician for help Caution : Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 91-002317-000-000 Note 1 .



[You're reading an excerpt. Click here to read official VTECH LITTLE EINSTEINS LEARN AND DISCOVER GLOBE user guide](http://yourpdfguides.com/dref/2832080)
<http://yourpdfguides.com/dref/2832080>