



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH SIT-TO-STAND LEARNING WALKER. You'll find the answers to all your questions on the VTECH SIT-TO-STAND LEARNING WALKER in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual VTECH SIT-TO-STAND LEARNING WALKER
User guide VTECH SIT-TO-STAND LEARNING WALKER
Operating instructions VTECH SIT-TO-STAND LEARNING WALKER
Instructions for use VTECH SIT-TO-STAND LEARNING WALKER
Instruction manual VTECH SIT-TO-STAND LEARNING WALKER

vtech[®]
Baby

User's Manual

**Sit-to-
Stand**[™] **Learning
Walker**



© 2007 VTech
Printed in China
91-02232-003-000



[You're reading an excerpt. Click here to read official VTECH SIT-TO-STAND LEARNING WALKER user guide](http://yourpdfguides.com/dref/1305402)
<http://yourpdfguides.com/dref/1305402>

Manual abstract:

To help fulfill them, VTech® created the Infant Learning series of toys. These unique interactive learning toys directly respond to what children do naturally play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, VTech®'s Infant Learning toys develop baby's mental and physical abilities by inspiring, engaging and teaching. At VTech®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow! Sincerely, Your Friends at VTech® To learn more about Infant Learning and other VTech® toys, visit www.vtechkids.com

INTRODUCTION Thank you for purchasing the VTech® Sit-to-Stand Learning Walker learning toy. **TM TM** The Sit-to-Stand Learning Walker is part of the Sit-to-Stand series of toys developed to grow with baby. Little ones can play with the standalone activity panel on the floor while discovering animals, colors, music, shapes and numbers.

1. Make sure the unit is turned OFF. 2. Use a coin or a screwdriver to loosen the screw. 3. Replace the battery cover and tighten the screw to secure.

Getting Started BATTERY NOTICE Install batteries correctly observing the polarity (+, -) signs to avoid leakage. Do not mix old and new batteries. Do not mix batteries of different types: alkaline, standard (carbozinc) or rechargeable (nickel-cadmium). Remove the batteries from the equipment when the unit will not be used for an extended period of time. Always remove exhausted batteries from the equipment.

Do not attempt to recharge ordinary batteries. The supply terminals are not to be short-circuited. Only batteries of the same and equivalent type as recommended are to be used. **WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.** To ensure your child's safety, please only assemble by an adult. Please ensure that the legs, handle and activity panel are securely locked into position to avoid injury. The activity panel can be used alone for floor play (6+ months) or while attached to the walker (12+ months). Floor Play (6+ months) Walker (12+ months) Getting Started Do not dispose of batteries in fire. **ASSEMBLY INSTRUCTIONS** 1. Push in and unscrew the two fasteners at the top of the walker.

2. Insert the legs into the slots with the wheels facing outward, as shown in the diagram. 3. Gently pull the legs back until they click into place. Please ensure the legs are fully inserted into the slots. **Assembly Instructions** 4. Stand the walker upright and insert the handle into the slots on the top to secure the legs. **Attaching/Removing the Activity Panel** 1. To attach the activity panel, align the bottom of the activity panel to the bottom of the walker, then push it back until the blue release lock located above the On/ Off/Volume Control switch clicks. Please ensure the activity panel is attached securely to the walker. **Assembly Instructions** 5. Push and screw in the fasteners at the top of the walker to secure the handle and legs. 2. To remove the activity panel, locate the blue release lock above the On/Off/ Volume Control Switch. 3. You will hear a rooster's call and then an upbeat nursery song. 4. In both modes, pick up the phone to hear animals singing. 4. In Music Mode, press the piano keys to play piano notes. Old MacDonald Had a Farm 2. The Glow Worm 3. Pop! Goes the Weasel 4. Oh Susanna! 5. Mary Had a Little Lamb 6. Hey Diddle Diddle 7. Turkey in the Straw 8.

Polly Wolly Doodle 9. Alouette 10. Home on the Range 11. B-I-N-G-O **SUNG SONG LYRICS** (Tune of "Old MacDonald Had a Farm") Welcome to our learning farm, We have lots to show you. Shapes and colors, music, too -There's so much to do! **Activities** 11 **CARE & MAINTENANCE** 1. Keep the unit clean by wiping it with a slightly damp cloth. 2. Keep the unit out of direct sunlight and away from any direct heat source. 3. Remove the batteries when the unit is not in use for an extended period of time.

4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water. **Care & Maintenance** 1 **TROUBLESHOOTING** If for some reason the program/activity stops working or malfunctions, please follow these steps: 1. Please turn the unit OFF. 2. Interrupt the power supply by removing the batteries. 3. Let the unit stand for a few minutes, then replace the batteries. 4. Turn the unit ON. The unit should now be ready to play again. 5. If the product still does not work, replace with a new set of batteries. If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you. For information on this product's warranty, please call VTech® at 1-800521-2010 in the U.S. or 1-877-352-8697 in Canada. **Troubleshooting** 1 **IMPORTANT NOTE:** Creating and developing Infant Learning® products is accompanied by a responsibility that we at VTech® take very seriously.

We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S. A service representative will be happy to help you. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: . . . Reorient or relocate the receiving antenna Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the receiver is connected Consult the dealer or an experienced radio/TV technician for help **Other Info** 1 **THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIREED OPERATION. THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003. CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.**



[You're reading an excerpt. Click here to read official VTECH SIT-TO-STAND LEARNING WALKER user guide](http://yourpdfguides.com/dref/1305402)
<http://yourpdfguides.com/dref/1305402>