



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH SPIN N LEARN TOP. You'll find the answers to all your questions on the VTECH SPIN N LEARN TOP in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual VTECH SPIN N LEARN TOP
User guide VTECH SPIN N LEARN TOP
Operating instructions VTECH SPIN N LEARN TOP
Instructions for use VTECH SPIN N LEARN TOP
Instruction manual VTECH SPIN N LEARN TOP

vtech[®] User's Manual

Spin 'n Learn Top[™]



© 2004 VTech
Printed in China
91-02060-000



[You're reading an excerpt. Click here to read official VTECH SPIN N LEARN TOP user guide](http://yourpdfguides.com/dref/1305426)

<http://yourpdfguides.com/dref/1305426>

Manual abstract:

To help fulfill them, VTech® created the Infant Learning series of toys. These unique interactive learning toys directly respond to what children do naturally - play! @@@@That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting VTech® with the important job of helping your child learn and grow! Sincerely, Your Friends at VTech® To learn more about Infant Learning and other VTech® toys, visit www.vtech.com INTRODUCTION Thank you for purchasing the VTech® Spin 'n Learn Top™. The

VTech® Spin 'n Learn Top™ is an interactive toy for toddlers aged 9 months and up. Randomly select the learning activity by pressing the center push button and watch as the top turns while playing phrases, sounds and melodies. Four modes of play make for lots of discoveries while the friendly animal characters encourage babies to play. ANIMAL CHARACTER BUTTONS CENTER PUSH BUTTON ON/OFF/VOLUME CONTROL SWITCH LIGHT-UP BUTTONS Introduction 2 INCLUDED IN THIS PACKAGE - One VTech® Spin 'n Learn Top™ - One instruction manual WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety. BATTERY INSTALLATION 1.

Make sure the unit is turned OFF. 2. Locate the battery cover on the bottom of the unit. Use a screwdriver to loosen the screw. 3. Install 2 new "AA" (UM-3/LR6) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.) 4. Replace the battery cover and tighten the screw to secure the battery cover. Getting Started 3 GETTING STARTED BATTERY NOTICE Install batteries correctly observing the polarity signs (+, -) to avoid leakage.

Do not mix old and new batteries. Do not use batteries of different types. Remove exhausted or new batteries from equipment when the unit will not be used for an extended period of time. Do not dispose of batteries in fire. Do not attempt to recharge ordinary batteries. The supply terminals are not to be short-circuited. Only batteries of the same and equivalent type as recommended are to be used. WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES. Battery Notice 4 PRODUCT FEATURES 1. @@@@It can be turned on again by pressing any of the buttons.

3. @@@@In the music mode, press an animal to hear a melody. @@@@2. 3. 4. 5. 6. 7. 8. 9.
10. @@Keep the unit clean by wiping it with a slightly damp cloth. 2. @@3. @@4. @@2. 3. 4. 5. Please turn the unit OFF.

Interrupt the power supply by removing the batteries. Let the unit stand for a few minutes, then replace the batteries. Turn the unit ON. The unit should now be ready to play again. @@If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you. For information on this product warranty, please call VTech® at 1-800521-2010 in the U.S. or 1-877-352-8697 in Canada.

IMPORTANT NOTE: Creating and developing Infant Learning products is accompanied by a responsibility that we at VTech® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1800-521-2010 in the U.S. or 1-877-352-8697 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you. Troubleshooting 8 Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. @@@@Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Other Info 9 .



[You're reading an excerpt. Click here to read official VTECH SPIN N LEARN TOP user guide](http://yourpdfguides.com/dref/1305426)
<http://yourpdfguides.com/dref/1305426>