



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH SPLASHING SONGS DUCKY. You'll find the answers to all your questions on the VTECH SPLASHING SONGS DUCKY in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual VTECH SPLASHING SONGS DUCKY**  
**User guide VTECH SPLASHING SONGS DUCKY**  
**Operating instructions VTECH SPLASHING SONGS DUCKY**  
**Instructions for use VTECH SPLASHING SONGS DUCKY**  
**Instruction manual VTECH SPLASHING SONGS DUCKY**



## **Splashing Songs Ducky™**



© 2011 VTech  
Printed in China  
91-002554-006-000



[You're reading an excerpt. Click here to read official VTECH SPLASHING SONGS DUCKY user guide](http://yourpdfguides.com/dref/3830535)  
<http://yourpdfguides.com/dref/3830535>

**Manual abstract:**

To help fulfill them, VTech® created the Infant Learning® series of toys. @@@@We thank you for trusting VTech® with the important job of helping your child learn and grow! Sincerely, Your friends at VTech® To learn more about the Infant Learning® series and other VTech® toys, visit [www.vtechkids.com](http://www.vtechkids.com) INTRODUCTION Thank you for purchasing the VTech® Splashing Songs Ducky™ learning toy. Rubber duckies have gone high-tech with the VTech® Splashing Songs Ducky™. This cute little ducky floats in a little ring and interacts with toddlers through playful phrases, fun sounds, sing-along songs and music. Equipped with a water sensor, the ducky knows if it is in or out of the water. Rub-a-dub-dub, ducky's in the tub! waTER sEnsOR lighT-uP buTTON On/Off swiTCh Introduction INCLUDED IN THIS PACKAGE One VTech® Splashing Songs Ducky™ learning toy One instruction manual All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety. @@Make sure the unit is turned Off. 2.

locate the battery cover on the bottom of the unit. use a screwdriver to loosen the screw. 3. @@@@Replace the battery cover and tighten the screw to secure. 5.

@@@non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged (if removable). Rechargeable batteries are only to be charged under adult supervision (if removable). Do not mix batteries of different types: alkaline, standard (carbozinc) or rechargeable (nickel-cadmium). Only batteries of the same or equivalent type as recommended are to be used.

batteries are to be inserted with the correct polarity. Exhausted batteries are to be removed from the toy. The supply terminals are not to be short-circuited. The toy is not to be connected to more than the recommended number of power supplies. @@ON/OFFBUTTON To turn the unit ON, press the ON/OFF ( ) button. @@@@The unit can be turned on again by pressing any button. @@@@This product cannot be used in salt water. @@@@To prevent drowning, never leave a child unattended in the bath. @@@@Rinse the unit with clean water and wipe with a dry cloth. @@Press the on/off button to turn the unit on.

You will hear a sound, sung song and fun phrase. The light will flash with the sound. 3. @@The lights will flash with the sound. SUNGSONGLYRICS sOng 1 One little ducky, swimming fast, floating and making a splash! One little ducky, in the water, it's a blast! Instructions & Activities 2. Press the light-up button to hear playful sounds, fun phrases and melodies. The light will flash with the sound. CARE & MAINTENANCE 1. Keep the unit clean by wiping it with a slightly damp cloth. 3.

@@4. Make sure to dry all the elements of the unit before storing. 5. @@6. @@Please turn the unit OFF.

2. interrupt the power supply by removing the batteries. 3. let the unit stand for a few minutes, then replace the batteries. 4.

Turn the unit ON. The unit should now be ready to play again. 5. @@@@or 1-877-352-8697 in Canada, and a service representative will be happy to help you. for information on this product's warranty, please call VTech® 1-800521-2010 in the u.s., or 1-877-352-8697 in Canada. Care & Maintenance/Troubleshooting 2. Keep the unit out of direct sunlight and away from any direct heat source. IMPORTANT NOTE: Creating and developing Infant Learning products is accompanied by a responsibility that we at VTech® take very seriously.

we make every effort to ensure the accuracy of the information, which forms the value of our products. however, errors sometimes can occur. it is important for you to know that we stand behind our products and encourage you to call our Consumer services Department at 1-800-521-2010 in the u.s., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. a service representative will be happy to help you.

@@@@@OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION. THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES003. CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA. Other Info 10 Caution : changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



[You're reading an excerpt. Click here to read official VTECH SPLASHING SONGS DUCKY user guide](http://yourpdfguides.com/dref/3830535)  
<http://yourpdfguides.com/dref/3830535>