



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH TOTE N GO LAPTOP. You'll find the answers to all your questions on the VTECH TOTE N GO LAPTOP in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual VTECH TOTE N GO LAPTOP**  
**User guide VTECH TOTE N GO LAPTOP**  
**Operating instructions VTECH TOTE N GO LAPTOP**  
**Instructions for use VTECH TOTE N GO LAPTOP**  
**Instruction manual VTECH TOTE N GO LAPTOP**

**vtech**<sup>®</sup>

User's Manual

**Tote 'n Go Laptop™**



© 2009 VTECH  
Printed in China  
91-002351-004(美)



[You're reading an excerpt. Click here to read official VTECH TOTE N GO LAPTOP user guide](http://yourpdfguides.com/dref/2705234)  
<http://yourpdfguides.com/dref/2705234>

**Manual abstract:**

vtechkids.com INTRODUCTION Thank you for purchasing the VTech® Tote n Go Laptop™ learning toy! The VTech® Tote n Go Laptop™ is a fun laptop that introduces age-appropriate curriculum through 30 engaging activities. A friendly squirrel character encourages children as they learn phonics, letters, numbers, mouse training and much more! @@@@Make sure the unit is OFF. 2. Locate the battery cover on the bottom of the unit. 3. @@(The use of new, alkaline batteries is recommended for maximum performance.) 4. Replace the battery cover. BATTERY NOTICE . . . . . Install batteries correctly observing the polarity (+, -) signs to avoid leakage.

Do not mix old and new batteries. Do not mix batteries of different types: alkaline, standard (carbon/zinc) or rechargeable (nickel-cadmium). Remove the batteries from the equipment when the unit will not be used for an extended period of time. Always remove exhausted batteries from the equipment. Do not dispose of batteries in fire.

Do not attempt to recharge ordinary batteries. The supply terminals are not to be short-circuited. GETTING STARTED 3 · Only batteries of the same and equivalent type as recommended are to be used. WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES. REMOVE DEMO TAG The demo tag should be removed automatically when the product is taken out of the packaging.

If the demo tag is still in position when you begin play, please remove it from the bottom of the unit to activate normal play mode. PRODUCT FEATURES Press the unit off. button to turn the unit on. Press it again to turn the 2. LETTER BUTTONS Press the 26 LETTER BUTTONS to input letters in letter related activities. 3. NUMBER BUTTONS Press the ten NUMBER BUTTONS to input numbers in number related activities. PRODUCT FEATURES 4 1. ON/OFF BUTTON 4. CATEGORY BUTTONS Press the four CATEGORY BUTTONS to select an activity in that category.

Use the mouse to choose a game. 5. REPEAT BUTTON Press the button to repeat the current question or instruction. 6. @@@@Press the Enter key or the mouse button to confirm. 8. @@Press the mouse to confirm an answer in related activities. 9. @@@@@Press it again to hear a word that begins with that letter. 2.

Letter Fishing Help the squirrel catch a fish. @@3. Missing Letters Find the missing letter to complete the word. 4. @@5.

Terrific Typist Type the word you see on the screen. 6. Hide & Seek Letters Identify the letter hiding behind the block. 7. Which is Different? One of these letters is in a different letter case than the others.

Which one is it? 8. @@Number Switch Four numbers will be covered by nuts and moved around. Watch carefully! Find the requested number. ACTIVITIES 6

2. Counting Shapes Count the number of shapes in the question. 3. @@4. Number Order Select the numbers in order. 5. Lightest or Heaviest?

@@@@What's Left? Some flowers will be shown on the screen.

Then some of them will disappear. Count the flowers that are left. 8. More or Less? Choose the side that has more of the given object. LOGIC 1. Odd One Out One object is different from the others. Can you find it? 2. @@3. Three of a Kind Shapes will be moving across the top of the screen. @@@@Shadow Search Find the shadow that matches the object on the left.

5. @@6. Picture Patch Complete the picture by choosing the missing half. 7. @@Fix It There are some holes in the bridge.

Fix the bridge by choosing the shape that matches the hole. 3. @@Help him to get in shape by following the moves of his fitness instructor. Repeat the instructor's moves in the correct order. 4.

Find the Tallest Which of these three objects is the tallest? 5. Forest Flight Guide the squirrel's plane along its journey across the forest. Avoid the obstacles to make it to the end. 6. Tic Tac Toe Place three pieces in a row before the squirrel does. ACTIVITIES 8 1. Clean Sweep Some leaves are flying into the squirrel's house. Sweep the leaves away by moving the mouse in the direction of the leaves. 7. Musical Fun Press a number to hear a melody, and the squirrel will dance, sing or conduct the music.

CARE & MAINTENANCE 1. Keep the unit clean by wiping it with a slightly damp cloth. 2. Keep the unit out of direct sunlight and away from any direct heat source. 3. Remove the batteries when the unit is not in use for an extended period of time. 4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water. TROUBLESHOOTING If for some reason the program/activity stops working or malfunctions, then please follow these steps: 1. Turn the unit OFF.

2. Interrupt the power supply by removing the batteries. 3. Let the unit stand for a few minutes, then replace the batteries. 4.

Turn the unit back ON. The unit will now be ready to play again. 5. If the unit still does not work, replace with an entire set of new batteries. If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.

S. @@@@However, errors sometimes can occur. @@or 1-877-352-8697 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you. CARE & MAINTENANCE 9 .



[You're reading an excerpt. Click here to read official VTECH TOTE N GO LAPTOP user guide](http://yourpdfguides.com/dref/2705234)  
<http://yourpdfguides.com/dref/2705234>