



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM. You'll find the answers to all your questions on the VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.


**User manual VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM**

**User guide VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM**

**Operating instructions VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM**

**Instructions for use VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM**

**Instruction manual VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM**



[You're reading an excerpt. Click here to read official VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM user guide](http://yourpdfguides.com/dref/1305494)

<http://yourpdfguides.com/dref/1305494>

**Manual abstract:**

*FLASHTM combines age-appropriate educational content with outstanding 3D graphics, fast-paced game play, real video and pictures, and three unique modes of play to provide a state of the art experience that kids and parents will both love. Also, V.FLASHTM can play all of your standard music CDs, making it both a cool video game system as well as your own personal stereo! V.FLASHTM works with a full library of V.DISCTM, each of them featuring some of your kids' favorite characters. Best of all, every V.DISCTM comes with three modes of play, so your child is free to explore, play and learn in any way that they choose. Game Zone offers fast-paced video game fun, with all the action but none of the violence. Knowledge World features a virtual encyclopedia of pictures, videos and facts. Creative Workshop lets kids work in a cool 3D environment on creative projects such as model building and custom animations. Best of all, the library of software will continue to grow, as VTech® seeks to provide parents with an almost endless selection of wholesome video games that meet the individual needs and likes of their children. At VTech® we are proud to provide you with a much-needed solution to the video game dilemma, as well as another innovative way for your child to learn while having fun. We thank you for trusting VTech® with the important job of helping your child explore a new world of learning! Sincerely, Your Friends at VTech® To learn more about V.FLASHTM and other VTech® toys, visit: [www.vtechkids.com](http://www.vtechkids.com)*

**com CONTENT · INTRODUCTION .....**

.....

.....

.....

.....

.....

.....

.....

.....

**1 Packaging Contents .....**

.....

.....

.....

.....

.....

.....

.....

**... 1 Product Features .....**

.....

.....

.....

.....

.....

.....

.....

.....

**2 · GETTING STARTED .....**

.....

.....

.....

.....

.....

.....

**..... 4 AC Adaptor .**

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

*4 Connecting to a TV .....*

.....  
.....  
.....  
.....

.....  
.....

*.... 5 Connecting to a VCR .*

.....  
.....  
.....  
.....

.....  
.....  
.....

*6 Connecting the V.FLASHTM Controller .....*

.....  
.....  
.....

*..... 6 · SYSTEM OPERATION ..*

.....  
.....  
.....  
.....

.....  
.....  
.....

*.... 7 To begin play .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 7 To change a V.DISCTM .*

.....  
.....  
.....

.....  
.....  
.....  
.....

*..... 7 To play an audio CD .*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.. 8 To stop an audio CD ...

.....  
.....  
.....  
.....  
.....

.....  
.... 8 · ACCESSING THE MAIN MENU.

.....  
.....  
.....  
.....

..... 9 Icon descriptions ....

.....  
.....  
.....  
.....  
.....  
.....  
.....

.... 9 Memory Card management .....

.....  
.....  
.....  
.....  
.....

..... 10 V.FLASHTM CD Player ....

.....  
.....  
.....  
.....  
.....  
.....

..... 11 Picture viewer ....

.....  
.....  
.....  
.....  
.....  
.....

..... 11 Media player .

.....  
.....  
.....  
.....



.....  
.....  
.....  
.....  
.....

... 16 INTRODUCTION Thank you for purchasing the VTech® V.FLASHTM Home Edutainment System! V.FLASHTM is a video game system that combines the fast-paced action and outstanding graphics of great video game play with unique educational and creative elements. With V.FLASHTM, kids can choose to embark on fun gaming adventures, explore an interactive encyclopedia of videos, pictures, and facts, or create their own 3D models and animations. They play, learn and explore at their own pace, so the experience is never the same twice. Educational curriculum is woven seamlessly into the game play, so while they're having fun attempting to finish the race or save the world, real learning is occurring.

With V.FLASHTM, a world of fun and discovery opens up with each new experience. USER'S MANUAL V.FLASHTM MAIN UNIT AV CABLE INTRODUCTION AC ADAPTOR CONTROLLER V.DISCTM SHEATH V.DISCTM AUDIO CD DISC TRAY The package contents · V.FLASHTM Home Edutainment System Main Unit · One V.FLASHTM Controller · One V.DISCTM · One audio CD disc tray · One AC adaptor · One AV cable · One instruction manual · One V.DISCTM sheath 1 INTRODUCTION If any items are missing, contact our technical support line number on your warranty card for assistance.

WARNING: · This product requires an undisturbed environment to operate properly. Make sure it is placed on a hard flat surface (carpet is not recommended) with sufficient space between the product and other items. Do not tap or hit the product while it is operating. · Do not lift or move the product during operation. · All packing materials such as tape, plastic sheets, wire ties and tags are not part of this toy and should be discarded for your child's safety.

PRODUCT FEATURES Main Unit Front RESTART button MEMORY CARD slot CONTROLLER port EJECT button OFF button ON button MAIN UNIT cover PLAY button STOP button VOLUME button NEXT button HEADPHONE port MICROPHONE port VOLUME CONTROL Main Unit Rear AV output port DC input connector (DC 9V IN) Heat ventilation grill RESTART button MEMORY CARD slot Press this button when the unit is ON to start the game over from the beginning. Insert a V.FLASHTM Memory Card into this slot. (card sold separately) Please refer to ACCESSING THE MAIN MENU section and then Memory Card management for specific information on how to save game information to a memory card. CONTROLLER port EJECT button Plug the V.FLASHTM Controller into PLAYER 1 port. Press this button to open the disc cover. 2 INTRODUCTION ON button OFF button VOLUME button NEXT button STOP button PLAY button HEADPHONE port MICROPHONE port Press this button to turn on the unit. Press this button to turn the unit OFF. Always do this before removing a V.DISCTM. Control the volume of a V.DISCTM, audio CD, or headphones. Press this button to play the next track on an audio CD. Press this button to stop an audio CD.

Press this button to play an audio CD. Insert standard headphones into this port. Insert a standard microphone into this port. (not included) INTRODUCTION MIC VOLUME CONTROL Use this to control the volume of the microphone. AV output port Connect the AV cable jacks to this port. AC-DC adaptor jack Connect the AC Adaptor to this jack. CAUTION The V.FLASHTM has intake/exhaust vents at the bottom and on the backsides designed to maintain adequate ventilation. Do not operate the console in any location where these vents become covered or obstructed. Controller LEFT button HELP button MENU button EXIT button RIGHT button RED button YELLOW button JOYSTICK GREEN button BLUE button ENTER button 4 ABCD buttons RELEASE button ENTER button Press this button to make a selection, or to perform certain game actions.

3 GETTING STARTED JOYSTICK Use this to control on-screen character movement, or scroll through menus on certain screens. Use these buttons to choose answers in certain activities, or to perform certain game actions. Press this button to hear helpful hints in certain games. Press this button to enter the Menu screen. Press this button to exit or pause a game.

Enter / Confirm Back / Cancel 4 SELECTION buttons HELP button MENU button EXIT button GREEN button RED button The V.FLASHTM Controller accommodates both right-and left-handed players. To switch the controller for let or right-handed use: · Pull the RELEASE button on the underside of the controller as shown, to release the lock. · The center part of controller will pop up. Turn it around so that the JOYSTICK is on the side you prefer. · Press it down until you hear a locking sound. GETTING STARTED AC ADAPTOR · · · · Use a VTech® DC 9V 1200mA AC/DC adaptor.(included) Make sure the unit is turned OFF.



[You're reading an excerpt. Click here to read official VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM user guide](http://yourpdfguides.com/dref/1305494)

<http://yourpdfguides.com/dref/1305494>



3. Remove the CD from the CD tray; check for contamination, dirt, scratches, or other irregularities.

If necessary, clean the disc by wiping with a soft cotton cloth (don't use paper) from the middle to the outside edge. TROUBLESHOOTING \ TECHNICAL SUPPORT An error occurs when loading a V. D I S C T M or playing a game The V.FLASH T M is sitting on an unstable surface. 1. Turn Off the unit. 2. Move the V.FLASH T M to a stable surface and press ON again. 3.

If this does not work, the V.DISCTM may be dirty or damaged. Please refer to the V.DISCTM User's Manual for CD cleaning procedure. TECHNICAL SUPPORT If you have a problem that cannot be solved by using this manual, we encourage you to visit us online or contact our Consumer Services Department with any problems and/or suggestions that you might have.

A support representative will be happy to assist you. Before requesting support, please be ready to provide or include the information below: · The name of your product or model number (the model number is typically located on the back or bottom of your product). · The actual problem you are experiencing. · The actions you took right before the problem occurred. If you wish to buy additional controllers for your V.

FLASH T M Home Edutainment System, please visit us online, or contact our Consumer Services Department. Internet : Phone : www.vtechkids.com 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada 15 OTHER INFO OTHER INFO DISCLAIMER AND LIMITATION OF LIABILITY VTech® Electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss resulting from the use of this handbook. VTech® Electronics North America, L.

L.C. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. VTech® Electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss. Company: VTech® Electronics North America, L.L.C. Address: 1155 West Dundee Road, Suite 130, Arlington Heights, IL 60004 USA NOTICE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

16 OTHER INFO Phone : 1-800-521-2010 in the U.S. or 1-800-267-7377 in Canada 2006 © VTech Printed in China 91-02177-000-000 .



[You're reading an excerpt. Click here to read official VTECH V.FLASH HOME EDUTAINMENT LEARNING SYSTEM user guide](http://yourpdfguides.com/dref/1305494)  
<http://yourpdfguides.com/dref/1305494>