




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH V.READER TOY STORY 3. You'll find the answers to all your questions on the VTECH V.READER TOY STORY 3 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual VTECH V.READER TOY STORY 3
User guide VTECH V.READER TOY STORY 3
Operating instructions VTECH V.READER TOY STORY 3
Instructions for use VTECH V.READER TOY STORY 3
Instruction manual VTECH V.READER TOY STORY 3



[You're reading an excerpt. Click here to read official VTECH V.READER TOY STORY 3 user guide](http://yourpdfguides.com/dref/3253391)
<http://yourpdfguides.com/dref/3253391>

Manual abstract:

We want to introduce children to reading in a dynamic, engaging way that will make them readers for life. That's why we created V.Reader™, where reading comes alive with animated storytelling! In these animated books, stories come to life through colorful scenes, voices, sounds and music. V.Reader™ creates a magical world that keeps children interested in the story while they learn letters, words, comprehension, and more! Watching their favorite characters in fun-loving stories engages children in play, as they gain the tools to grow from a pre-reader into a fluent and confident reader. As their reading skills grow, their self-esteem grows, and their appetite for reading will, too! With a USB connection to a computer, you can even track your child's reading progress, and download and print awards for each completed story. At VTech®, we are dedicated to helping kids discover the magic of reading. We thank you for trusting VTech® with the job of helping your child learn and grow! @ @ He's leaving for college soon. What will happen to all of his toys? Join Buzz, Woody and the gang as they end up at Sunnyside Daycare. @ @ Soon the toys realize that they have to escape! @ @ @ Il's ne font pas partie du jouet Note: Please keep the user's manual as it contains important information.

GETTING STARTED STEP 1: Insert the Book Cartridge Insert the book cartridge into the top of the unit as shown in the below image. **STEP 2:** Select the Book Icon Touch the book icon to enter the book. Book icon **STEP 3:** Choose How You Want to Play There are three ways to play: Watch the Story, Reading Games, and Story Dictionary. Touch an icon to choose. Watch the Story: Read or listen to the whole story while watching the animations. Reading Games: Play 8 story-related reading games. Story Dictionary: Learn the definitions of vocabulary words in the story. Touch the Settings icon to turn the background music and vocabulary highlight feature on or off. **FEATURES PLAY/PAUSE BUTTON REPLAY BUTTON** Play or pause the story narration in Watch the Story. Repeat the story narration of the current page in Watch the Story, or repeat the question in Reading Games. **HELP BUTTON MENU KEY** Replay instructions, or ask for a hint in Reading Games. Exit out to the unit's main menu. **BOOKMARK BUTTON GAME KEY** Save a bookmark for the current page in Watch the Story. Play the built-in game. **EXIT BUTTON MUSIC KEY** Exit to the previous menu. Turn the background music on/off. **PREVIOUS PAGE ARROW** Turn to the previous page. **QWERTY KEYPAD NEXT PAGE ARROW** Turn to the next page. Press the keys to type in your user name, write a welcome message, or enter answers for some reading game questions. **BACKPACK KEY** Go directly to the Backpack.

ACTIVITIES Watch the Story: There are two ways to start Watch the Story. You can choose Whole Story to enjoy the entire story narration from the beginning, or touch Bookmark to go right to your bookmarked page. If you have not saved a bookmarked page, this submenu will be deactivated and you will automatically enter Whole Story when you choose Watch the Story. You can press or touch anywhere on the screen to pause the story narration or enter Free Play, respectively. When the story narration of each book page has finished, you will enter Free Play mode automatically. To pause the story narration, press continue the story narration, press . To again. Free Play To stop the automatic story narration and enter Free Play, touch anywhere on the screen. In Free Play, you can touch the words one by one to read the story at your own pace, touch highlighted vocabulary words to hear their definitions, or touch images in the art to see animations and hear fun voices and sounds. If you don't touch the screen for a while, the story narration will continue automatically from the next page.

@ @ @ @ @ @ @ @ The other 7 games teach a variety of age-appropriate reading skills. Choose the game you wish to play from the Reading Games menu. Listen to the instructions and questions carefully. @ @ @ @ What's That Sound? Capital Idea Left and Right At The End Big Or Small What Comes Next? @ @ Touch any word in the Story Dictionary menu to hear its definition. @ @ @ @ Never use solvents or abrasives.

2. Keep it out of direct sunlight and away from direct sources of heat. 3. @ @ 4. Avoid dropping it.

NEVER try to dismantle it. 5. @ @ @ @ @ @ @ @ @ @ @ @ @ @ A support representative will be happy to assist you. @ @ . The actual problem you are experiencing. @ @ @ @ All Rights Reserved. VTech and the VTech logo are registered trademarks of VTech. V.Reader™ is trademark of VTech Electronics North America, L.L.C.

All other trademarks are property of their respective owners. **IMPORTANT NOTE:** Creating and developing V.Reader™ Interactive e-Reading System products is accompanied by a responsibility that we at Vtech® take very seriously. We make every effort to ensure the accuracy of the information that forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-5212010 in the U.S. or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you. **OTHER INFO DISCLAIMER AND LIMITATION OF LIABILITY** Vtech® Electronics North America, L.

L.C. and its suppliers assume no responsibility for any damage or loss resulting from the use of this handbook. Vtech® Electronics North America, L.L.C. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. Vtech® Electronics North America, L.L.C.

and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss. CoMPANY: Vtech® Electronics North America, L.L.C. ADDRess: 1155 West Dundee Rd, Suite 130, Arlington Heights, IL 60004 USA teL No.: 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. @ @ @ @ @ @ @ @ . Increase the separation between the equipment and receiver.

· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 10 10 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



[You're reading an excerpt. Click here to read official VTECH V.READER TOY STORY 3 user guide](http://yourpdfguides.com/dref/3253391)
<http://yourpdfguides.com/dref/3253391>

*This Class B digital apparatus complies with Canadian ices-003. Cet appareil numérique de la classe b est conforme à la norme nmb-003 du Canada.
Disney/Pixar elements © Disney/Pixar Slinky® Dog © Poof-Slinky, Inc. © 2010 VTech Printed in China 91-002462-039-000 11 .*



[You're reading an excerpt. Click here to read official VTECH
V.READER TOY STORY 3 user guide
http://yourpdfguides.com/dref/3253391](http://yourpdfguides.com/dref/3253391)