



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH V.SMILE MOTION - SHREK 4. You'll find the answers to all your questions on the VTECH V.SMILE MOTION - SHREK 4 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.


User manual VTECH V.SMILE MOTION - SHREK 4

User guide VTECH V.SMILE MOTION - SHREK 4

Operating instructions VTECH V.SMILE MOTION - SHREK 4

Instructions for use VTECH V.SMILE MOTION - SHREK 4

Instruction manual VTECH V.SMILE MOTION - SHREK 4



[You're reading an excerpt. Click here to read official VTECH V.SMILE MOTION - SHREK 4 user guide](http://yourpdfguides.com/dref/2714976)
<http://yourpdfguides.com/dref/2714976>

Manual abstract:

At the same time, we understand the hesitation of most parents to expose their children to the inappropriate content of many popular video games. How can parents responsibly allow their children to play these games, and still educate and entertain them in a healthy, age-appropriate manner? Our answer to this question is V.Smile® Motion™ Active Learning System! A big breakthrough for junior gamers, V.Smile® Motion™ takes educational video gaming to a whole new level with a motion-activated gaming system that engages both active minds and bodies. V.Smile® Motion™ plugs directly into the TV to provide kids with a high-tech gaming experience using thrilling, age-appropriate learning games and a motion-activated, intuitive wireless controller. The V.Smile® Motion™ Active Learning System engages children with two modes of play: the Learning Adventure - an exciting exploratory journey in which learning concepts are seamlessly integrated, and the Learning Zone - a series of games designed to focus on specific skills in a fun, engaging way. Each Smartridge™ game encourages active gaming while giving kids' minds a workout, too, as they learn basic math, reading, science, spelling and more. At VTech®, we are proud to provide parents with a much-needed solution to the video game dilemma, as well as another innovative way for children to learn while having fun. We thank you for trusting VTech® with the important job of helping your child explore a new world of learning! @@@@ Press the ENTER button when you have finished. 1. Board Game Choose this mode to play a virtual board game with Shrek and friends. You can choose your own character to play with, and toss swamp mud at a rotating wheel to see how many places you move each turn. Each move may result in a fun surprise or the unlocking of a special game.

The one who gets to the end first is the winner. When you turn the unit off, V.Smile® Motion™ remembers your place in the Board Game mode. To continue your game, simply turn the unit back and select Continue under the Board Game menu. Please note that you can only do this if Shrek Forever After has not been removed from the unit and power has not been turned off.

Continue New game - Start the adventure from the point you reached before exiting the game. Start the adventure from the beginning. 2. Free Play In Free Play mode, all seven of the games are available for you to play in any order you'd like. The seven games are divided into two groups: Ogre Adventures and Ogre Brain Games. Highlight the group you want and press ENTER to begin play. Note: For game details, please see the Activities Free Play section. 3. Options Move the joystick up and down to move the cursor between Control Methods or Music. Music On/Off Selection To turn the background music on or off, move the joystick left or right to highlight On or Off.

Press the ENTER button to make your choice. Control Methods Selection To choose between Joystick Mode and Motion Controller Mode, move the joystick left or right to highlight Joystick Mode or Motion Controller Mode. Press the ENTER button to make your choice. @@ Choose one-player or two-player mode in the selection menu. @@ A window will pop up to make sure that you really want to quit. @@@@ When you press the LEARNING ZONE button, the game will pause. A window will pop up to make sure that you really want to quit. @@@@ You can select it to download your game score to the V.Link™.

@@@@@ Curriculum: Addition Easy Level: There will be 6 pins.

Difficult Level: There will be 10 pins. @@ on a witch's broom! Hang on for a wild ride and learn some new words along the way. Watch out for the witches; they have some surprises in store. @@@@ Difficult Level: More difficult speed and patterns. Operations: Motion Controller Mode Move Tilt the controller backward or forward, or left or right Joystick Mode Ogre Brain Games Memory Madness Game Play There's a lot of artwork hanging inside the palace.

Pay close attention, because soon one will be covered up. Remember which one is missing and find the matching picture. Curriculum: Memory Easy Level: 2 paintings on the wall. Difficult Level: 3 paintings on the wall. Operations: Motion Controller Mode Select Steer the controller left or right Joystick Mode Answer ENTER ENTER No Weigh! Game Play It's time for some fun with Gingy and his friends.

Watch the scales closely and figure out which item in the bakery weighs the most. Curriculum: Logic Thinking Easy Level: 1 scale. Difficult Level: 2 scales, with more complex combinations. Operations: Motion Controller Mode Select Steer the controller left or right Joystick Mode Answer ENTER ENTER Counting Fun Game Play The Ogre babies are playing with some toys, and some of the pieces have broken off. Listen for the clues and count up the correct number of pieces on the table. Curriculum: Observation, Counting Easy Level: Colors, Shapes. Difficult Level: More complex shapes. Operations: Motion Controller Mode Select Steer the controller left or right Joystick Mode Answer ENTER ENTER Baby Brain Game Play There are a lot of toys in the Ogre babies' room. Let's take a look at some of the toy piles and figure out which one has the most toys in it. Curriculum: Number Comparison Easy Level: Each group only has 1-5 object(s).

Difficult Level: Each group only has 1-9 object(s). 10 Operations: Motion Controller Mode Joystick Mode Select Steer the controller left or right Answer ENTER ENTER 11 CARE & MAINTENANCE 1. 2. 3. 4. 5. Keep your V.Smile® Motion™ clean by wiping it with a slightly damp cloth. Never use solvents or abrasives. Keep it out of direct sunlight and away from direct sources of heat.

Remove the batteries when not using it for an extended period of time. Avoid dropping it. Never try to dismantle it. @@@@ Before requesting support, please be ready to provide or include the information below:

· The name of your product or model number (the model number is typically located on the back or bottom of your product).

· The actual problem you are experiencing.

· The actions you took right before the problem occurred. Internet: www.vtechkids.com Phone: 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada OTHER INFO DISCLAIMER AND LIMITATION OF LIABILITY vTech® electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss resulting from the use of this handbook. vTech® electronics North America, L.L.C. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. vTech® electronics North America, L.L.C.

C. and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss. COMPANY: vTech® electronics North America, L.L.C. ADDRESS: 1155 West Dundee, Suite 130, Arlington Heights, IL 60004 USA TeLNO.: 1-800-521-2010 in the U.



[You're reading an excerpt. Click here to read official VTECH V.SMILE MOTION - SHREK 4 user guide](http://yourpdfguides.com/dref/2714976)
<http://yourpdfguides.com/dref/2714976>

S.or1-877-352-8697inCanada.

1 NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular area.



[You're reading an excerpt. Click here to read official VTECH V.SMILE MOTION - SHREK 4 user guide](#)
<http://yourpdfguides.com/dref/2714976>