



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH V.SMILE V-MOTION THOMAS AND FRIENDS. You'll find the answers to all your questions on the VTECH V.SMILE V-MOTION THOMAS AND FRIENDS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.


User manual VTECH V.SMILE V-MOTION THOMAS AND FRIENDS

User guide VTECH V.SMILE V-MOTION THOMAS AND FRIENDS

Operating instructions VTECH V.SMILE V-MOTION THOMAS AND FRIENDS

Instructions for use VTECH V.SMILE V-MOTION THOMAS AND FRIENDS

Instruction manual VTECH V.SMILE V-MOTION THOMAS AND FRIENDS



USER'S MANUAL



[You're reading an excerpt. Click here to read official VTECH V.SMILE V-MOTION THOMAS AND FRIENDS user guide](http://yourpdfguides.com/dref/2315462)
<http://yourpdfguides.com/dref/2315462>

Manual abstract:

At the same time, we understand the hesitation of most parents to expose their children to the inappropriate content of many popular video games. How can parents responsibly allow their children to play these games, and still educate and entertain them in a healthy, age-appropriate manner? Our answer to this question is V-Motion™ Active Learning System! A big breakthrough for junior gamers, V-Motion™ takes educational video gaming to a whole new level with a motionactivated gaming system that engages both active minds and bodies. V-Motion™ plugs directly into the TV to provide kids with a high-tech gaming experience using thrilling, age-appropriate learning games and a motion-activated, intuitive wireless controller. The V-Motion™ Active Learning System engages children with two modes of play: the Learning Adventure - an exciting exploratory journey in which learning concepts are seamlessly integrated, and the Learning Zone - a series of games designed to focus on specific skills in a fun, engaging way. Each Smartridge™ game encourages active gaming while giving kids' minds a workout, too, as they learn basic math, reading, science, spelling and more. In addition to the action-packed Smartridge™ game play, the V-Motion™ includes the V.link™ (USB drive) that connects kids to VTech®'s secure online site to unlock bonus games and track their scores against other gamers. At VTech®, we are proud to provide parents with a much-needed solution to the video game dilemma, as well as another innovative way for children to learn while having fun. We thank you for trusting VTech® with the important job of helping your child explore a new world of learning! @@@@Press the ENTER button when you have finished. Learning Adventure Learning Zone Sing Along Engine Depot Options Learning Adventure In this play mode, you can help Thomas and his friends do their jobs.

New Game: Choose this to start a new game from the beginning. Continue Game: Choose this to keep playing the game you started. Your old game settings will be kept. Learning Zone In this play mode, you can play one of three fun games that each focuses on a specific learning skill. To change the level between Easy/Difficult, move the joystick up or down to highlight Easy or Difficult.

Press ENTER to confirm. Move the joystick to highlight the Learning Zone Game you wish to play, then press ENTER to start. Sing Along In this play mode, you can sing one of two songs for Thomas and his friends. Move the joystick to choose the song, characters and the settings for volume and voice. Move the joystick to highlight the ENTER icon, then press ENTER to start.

Engine Depot In this mode, you can visit and read the profiles of ten Thomas & Friends™ characters. Move the joystick to highlight the character you want to visit, press ENTER to start. Music On/Off Selection The Options menu can be accessed to change settings for music and the V.link™ functions. To turn the background music On or Off, move the joystick left or right to highlight "Music On" or "Music Off". V.Link™ Connection Select this to update your game record to the V.link™. STEP : Choose Your Game Settings 1. Follow the voice instructions to choose your game settings.

2. Move the joystick up or down and press ENTER to confirm. Press the EXIT button to cancel the settings and begin again. Note: Two-player mode is not available when played on the V.Smile Pocket™ or V.Smile Cyber Pocket™. STEP : Game Control Method After selecting the game you want, you can choose two different control methods to play. Move the joystick left or right to choose Joystick or Motion Controller and press the ENTER button to confirm.

For the details of Joystick and Motion Controller, please refer to the "Activities - Learning Adventure" and "Activities - Learning Zone" sections of this manual. STEP : Start Your Game · · For Learning Adventure, please go to the "Activities Learning Adventure" section.

For Learning Zone, please go to the "Activities Learning Zone" section. FEATURES Color Buttons In the Learning Adventure game - Bertie Beats the Clock, help Bertie to answer the questions by using the colored buttons. Help Button When you press the HELP button, you will hear the help instruction or helpful hints for that game. Exit Button When you press the EXIT button, the game will pause. Use the joystick to select YES to quit the game or NO to keep on playing the game.

Press ENTER to confirm. Learning Zone Button The LEARNING ZONE button is a shortcut that takes you to the Learning Zone Menu screen. When you press the LEARNING ZONE button, the game will pause. An Exit box will pop up to make sure you want to quit. @@@@You can select it to update your game record to the V.

link™. @@@@Total score reaches 260 in Learning Adventure. Total score reaches 400 in Learning Adventure. @@@@Watch out for the obstacles that might roll into your path. @@@@Press ENTER to carry out the rescue. @@Watch out for the dark clouds!

@@@@Press ENTER to load the cargo. Move Harold up to avoid the buildings. @@Watch out for the flying objects! Curriculum: Colors Easy level: Cargo in 5 colors. @@@@Avoid all the obstacles along the way to keep the children safe. Drop off the correct amount of school children at each station by following the number at the top of screen and press ENTER to stop.

Keep an eye on the time, otherwise the children will miss the train! Curriculum: Counting & Numbers Easy level: Drop off 3-7 students at each station.

Difficult level: Drop off 4-9 students at each station. Operation in Game : Joystick Joystick up Joystick down Joystick left Joystick right Enter Motion Controller Tilt forward Tilt backward Tilt left Tilt right Enter Description Control Bertie; speed up Control Bertie; stop Move Bertie; left Move Bertie; right Confirm the number of school children; stop Mini Game: Take a Break While Bertie is waiting, Trevor and Terence will ask him some questions. Help Bertie to answer the questions by using the colored buttons. A shortcut to the station will be rewarded to you if you answer correctly. Note: Sometimes, Trevor and Terence will ask Bertie to write a number, if the V.Smile™ controller with pen is inserted into the console. Help Bertie answer the questions by moving the pen on the writing pad. Learning Zone Learning Zone Game Menu Screen The Learning Zone play mode features three different learning games. Use the joystick to select a game and press ENTER to begin.

How to Play Please refer to the "Learning Adventure" section. Learning Zone Game Status Bar In all three games, the status bar will show your score or your current game status. Zone 1: Recycle Challenge Game Play Fill up the Troublesome Trucks by selectproblems and/or suggestions that you might have. A support representative will be happy to assist you. Before requesting support, please be ready to provide or include the information below: · · The name of your product or model number (the model number is typically located on the back or bottom of your product).



[You're reading an excerpt. Click here to read official VTECH V.SMILE V-MOTION THOMAS AND FRIENDS user guide http://yourpdfguides.com/dref/2315462](http://yourpdfguides.com/dref/2315462)

The actual problem you are experiencing. · The actions you took right before the problem occurred. Internet: www.vtechkids.com Phone: 1-800-521-2010 in the U.

S. or 1-877-352-8697 in Canada 1 OTHER INFO DISCLAIMER AND LIMITATION OF LIABILITY VTech® Electronics North America, L.L.C. and its suppliers assume no responsibility for any damage or loss resulting from the use of this handbook. VTech® Electronics North America, L.L.C. and its suppliers assume no responsibility for any loss or claims by third parties that may arise through the use of this software. VTech® Electronics North America, L.

L.C. and its suppliers assume no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of important data on other media to protect against data loss. COMPANY: VTech® Electronics North America, L.L.C.

@@@@@@@However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. 1 © 2008 HIT Entertainment Limited. HIT and the HIT logo are trademarks of HIT Entertainment Limited.

© 2008 Vtech PRINTED in China 91-02211-000-000 .



[You're reading an excerpt. Click here to read official VTECH V.SMILE V-MOTION THOMAS AND FRIENDS user guide](http://yourpdfguides.com/dref/2315462)
<http://yourpdfguides.com/dref/2315462>