



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for VTECH VT 910 ADL. You'll find the answers to all your questions on the VTECH VT 910 ADL in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

## User manual VTECH VT 910 ADL User guide VTECH VT 910 ADL Operating instructions VTECH VT 910 ADL Instructions for use VTECH VT 910 ADL Instruction manual VTECH VT 910 ADL

### USER'S MANUAL VTECH 910 / 915 ADL 9308660000000000 TELEPHONE



#### IMPORTANT SAFETY INSTRUCTIONS

- When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:
1. Read and understand all instructions.
  2. Follow all warnings and instructions included on the product.
  3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or abrasive cleaners. Use a damp cloth for cleaning.
  4. Do not use this product near water. For example, near a bath tub, kitchen sink, or swimming pool.
  5. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
  6. Slots and openings in the cabinet and the back of the unit are provided for ventilation. To prevent fire or overheating, these openings must not be blocked by placing the product on a bed, sofa, rug, or other similar surface. The product should never be placed near or over a radiator or heat register. The product should not be placed in a built-in installation unless proper ventilation is not provided.
  7. The product should be operated only from the type of power source indicated on the label. Do not use a power source that does not meet the rating on the label or that is not approved by your local power company.
  8. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it.
  9. These products should not be used near water.
  10. Do not use this product if you have been exposed to rain or water.
  11. Do not use electrical wall outlets and extension cords as this can result in the risk of fire or electric shock.
  12. Unplug this product from the wall outlet when the power supply cord is damaged or frayed.
  13. If a liquid has been spilled into the product:
    - a. If the product does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions. In case of any other adjustments or repairs, contact your retailer or service center. These may be a service mark of an authorized service center.
    - b. If the product has been dropped and the cabinet has been damaged.
    - c. If the product exhibits a distinct change in performance.
  14. Avoid using a telephone either as a cordless phone during an electrical storm. There may be a remote risk of electrocution if lightning strikes nearby.
  15. Do not use the telephone reports gas leaks in the vicinity of the base.
- SAVE THESE INSTRUCTIONS**

#### INTRODUCTION

- Parts Check List:
1. Handset
  2. Base Unit
  3. Telephone line cord
  4. AC adapter
  5. Battery pack
  6. Wall mounting bracket



#### REPLACING THE HANDSET BATTERIES

1. Remove the battery cover by turning the ringed rim around and sliding it down.
  2. Insert the old battery pack. Do not put the old battery pack in a fresh compartment unless it is a duplicate.
  3. Place the new battery pack in the battery compartment. Make sure the metal contacts on the underside of the battery are aligned with the corresponding contacts in the battery compartment.
  4. Replace the battery cover by sliding it into place.
  5. The new battery pack must be charged before using your telephone. Place the handset in the cradle of the base and allow it to charge for 24 hours. A maximum battery life between charges is more than 7 hours of continuous talk time on 8 day and standby.
- CAUTION:** To reduce the risk of fire or injury, please read the following instructions:
1. Use only VTECH battery.
  2. Do not open or mutilate the battery. Released electrolyte is corrosive and may cause damage to the system also. It may be toxic if swallowed.
  3. Exercise care in handling the battery or when it is shorted by battery with conducting materials such as wire, tweezers, and keys. The battery or conductor may overheat and cause burns.
  4. Do not dispose of the battery in a fire. The cell may explode.

#### CHARGING THE BATTERY PACK

- IMPORTANT:** Do not dispose of this battery in the environment. Use a recycling program or other means for recycling or proper disposal. Contact your local waste disposal collection or disposal representative.
- CHARGING THE BATTERY PACK**
1. Charge the base unit battery by connecting the power supply cord to the base unit. The charging indicator lights will always indicate a charged battery available without your handset battery discharge during normal use.
  2. Contact your local VTECH dealer or call VTECH Customer Service for purchase a spare battery pack.
- DO NOT REMOVE THE BATTERY PACK (NOT INCLUDED)**
1. Do not remove the base unit battery compartment.
  2. Place the spare battery pack in the battery compartment. Make sure the metal contacts on the underside of the battery are aligned with the charging contacts in the battery compartment.
  3. Replace the battery compartment cover.
  4. When the battery is installed properly, the spare battery LED on the base unit will be illuminated.
  5. The spare battery will be fully charged after 24 hrs. Please refer to the spare battery LED will always be illuminated when a spare battery is installed.



[You're reading an excerpt. Click here to read official VTECH VT 910 ADL user guide](http://yourpdfguides.com/dref/1305660)  
<http://yourpdfguides.com/dref/1305660>

**Manual abstract:**

Base Unit 3. Telephone line cord 4. AC adapter 5. Battery Pack 6. @@Printed in China. @@R e a d a n d u n d e r s t a n d a l l instructions. 2. Follow all warnings and instructions marked on the product. 3. Unplug this product from the wall outlet before cleaning.

Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. 4. @@5. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product. 6. Slots and openings in the cabinet and the back or bottom are provided for ventilation. To protect it from overheating, these openings must not be blocked by placing the product on the bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register.

This product should not be placed in a built-in installation where proper ventilation is not provided. 7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company. 8. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it. 9. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.

10. To reduce the risk of electric shock, do not disassemble this product. If service or repair work is required, contact VTech Customer Service at 1-800-624-5688. Opening or removing cabinet parts other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the appliance is subsequently used. 11. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock. 12. Unplug this product from the wall outlet: a) When the power supply cord or plug is damaged or frayed. b) If liquid has been spilled into the product.

c) If the product has been exposed to rain or water. d) If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions because improper adjustment of other controls may result in damage and will often require extensive work to restore the product to normal operation. e) If the product has been dropped and the cabinet has been damaged. f) If the product exhibits a distinct change in performance.

13. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning. 14. Do not use the telephone to report a gas leak in the vicinity of the leak.

... P E W O R U S I N C H A R S P A R E B T A T E G E P A E G TELEPHONE LINE CORD AC ADAPTER BATTERY PACK WALL MOUNT BRACKET REPLACING THE HANDSET BATTERIES 1. Remove the battery case by pressing on the ridged lines and sliding downward. 2. Discard the old battery pack.

Don't put the old battery pack in a trash compactor or a fire - it could burst. IMPORTANT: Do not dispose of this battery in household garbage. For information on recycling or proper disposal, consult your local solid waste collection or disposal organization. 3. Place the new battery pack in the battery compartment. Make sure the metal contacts on the underside of the battery are aligned with charging contacts in battery compartment.

4. Replace the battery cover by sliding it into place. 5. The new battery pack must be charged before using your telephone. Place the handset in the cradle of the base unit to allow it to charge for 24 hours. Maximum battery life between charges is more than 7 hours of continuous talk time or 6 days of standby. CAUTION: To reduce the Risk of Fire or Injury to Persons, Read and Follow these instructions: 1. Use only VTECH battery. 2. Do not open or mutilate the battery.

Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed. 3. Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.

4. Do not dispose of the battery in a fire. The cell may explode. SPARE BATTERY CHARGER Your VTech 910 ADL is equipped with a spare battery charger built-in to the base unit. The spare battery charger allows you to always have a charged battery available, should your handset battery discharge during normal use.

Contact your local VTech dealer, or call VTech Customer Service to purchase a spare battery pack. To install the Spare Battery Pack (NOT INCLUDED): 1. Open the battery compartment. 2. Place the spare battery pack in the battery compartment. Make sure the metal contacts on the underside of the battery are aligned with charging contacts in battery compartment. 3. Replace the battery compartment cover. 4. When the battery is installed properly, the spare battery LED on the base unit will be illuminated.

5. The spare battery will be fully charged after 24 hrs. Please note that the spare battery LED will always be illuminated when a spare battery is installed. SAVE THESE INSTRUCTIONS GETTING STARTED WALL MOUNTING AC ELECTRICAL OUTLET en od wotud s oa rd wa ll b TON E PU LSE TONE PULSE TELEPHONE WALL JACK Setting Up Your VTECH 910 ADL 1. Choose an area near an electrical outlet and a telephone wall jack. 2. Connect the telephone line cord. Insert one end of the telephone line cord into the jack at the rear of the base unit. Plug the other end into a telephone wall jack. Make sure the plugs snap securely into place.

3. Plug the AC power adapter into an electrical outlet and the DC connector to the back of the base unit. CAUTION: Use only the AC adapter shipped with your 910ADL. This is a Class 2 A C a d a p t e r, s p e c i f i c a l l y designed for use with the 910 ADL. NOTE: Connect power to the base unit before placing the handset in the cradle.

4. Set the TONE/PULSE switch on the base unit. If you have touch tone service on your phone line, set the switch to TONE. If you have rotary service, set the switch to PULSE. 5.

CHARGE THE HANDSET BATTERIES BEFORE USE. The batteries recharge automatically whenever the handset is in the base unit cradle. The batteries must be charged for 24 hours before using your phone for the first time. 6. CHECK FOR A DIAL TONE. After the batteries are charged, pick up the handset and press the PHONE key. The PHONE indicator should light up, and you should hear a dial tone. If not, see IN CASE OF DIFFICULTY. CAUTION: 1. Never install telephone wiring during a lightning storm.

2. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations. 3. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface. 4. Use caution when installing or modifying telephone lines.



[You're reading an excerpt. Click here to read official VTECH VT 910](#)

[ADL user guide](#)

<http://yourpdfguides.com/dref/1305660>

1. Choose a spot near an electrical outlet and a telephone jack. Your phone requires a modular telephone jack and a standard electrical outlet (120v AC). The power cord is six feet long; make sure there is an electrical outlet within reach of the base. The outlet should not be controlled by a wall switch. If the switch is ever turned off, the phone will not operate. 2. Position the wall mount adapter on the base. Line up the tabs on the wall mount adapter with the holes on the bottom of the base. Snap the wall mount adapter firmly in place. 3. Mount the base on the wall. Position the base so the mounting studs will fit into the holes on the bottom of the base. Position the power cord to extend down the wall the phone is to be mounted on. Slide the base down on the mounting studs until it locks into place. 4. Connect the telephone cord. The telephone line cord has a snap-in plug at each end. Insert one of the plugs into the jack on the bottom of the base. Insert the other end of the plug into the wall jack. 5. Connect the power cord. Plug the DC connector into the DC jack at the rear of the base unit. Plug the AC power adapter into an electrical outlet.

6. Set the dial mode switch on the base unit. If you have touch tone service on your phone line, set the switch to TONE. If you have rotary service, set the switch to PULSE. **HANDSET FEATURES IN USE LED VOLUME SWITCH PHONE KEY/ FLASH KEY IN USE PHONE BASE UNIT FEATURES IN USE LED** \* Immediately after placing the handset in the base cradle, the IN USE LED flashes to indicate that the initialization (assigning a new security code and channel) is in progress \* The IN USE LED will stop flashing and light off when the initialization is complete. \* The IN USE LED illuminates whenever the handset is being used. \* This LED also flashes with the cadence of the incoming ring. **BATT LOW OFF CHAN 1 4 GHI 7PQRS BATT LOW LED OFF KEY CHAN KEY 2 ABC 5 JKL 8 TUV 0OPER MEM 3 DEF 6 MNO 9 WXYZ # REDIAL TONE/ KEY PROG KEY TONE PROG MEM KEY REDIAL KEY CHARGE LED** \* The CHARGE LED illuminates steadily when the handset is in the base cradle to indicate that the handset battery is being charged. **IN USE LED** \* The IN USE LED lights when the phone line is being used by the handset. \* It flashes in cadence with an incoming ring.

\* It flashes quickly during PROG mode. **BATT LOW LED** \* The BATT LOW LED will flash when the handset battery is getting low and needs to be recharged. **PHONE KEY/ FLASH KEY** \* Press the PHONE key to make a call. \* If you are currently on a call, pressing PHONE flashes the line. This would be used with a feature like call waiting to answer your second call.

**CHAN KEY** \* Pressing the CHAN key when the handset is in use will activate a channel change to the next free channel. \* This is used if you are experiencing noise or interference on the current channel. **OFF KEY** \* Press the OFF key to exit all modes of operation. **MEM KEY** \* Press the MEM key to enter MEMORY mode. \* The sequence for dialing out a speed dial number in memory is: PHONE, MEM, Number Button (0-9).

**PROG KEY** \* Press PROG key to enter PROGRAM mode. See Programming Speed Dial Numbers for more details. **REDIAL KEY** \* When you hear the dial tone, pressing the REDIAL key will dial out the last number that was called on your phone. \* It can also be used to store the last number dialed into the speed dial memory. See Storing a Redial Number into Speed Dial for details. **@@VOLUME SWITCH** \* Slide switch UP for High Volume (H) setting. **@@@** \* Press it a second time to cancel a page. **@@@** \* The In Use LED on the base unit will flash during the initialization. Making Calls Pick up the handset and press PHONE. When you hear a example, to change the number stored in memory position 7 to 555-1111, you would press PROG, 7, 555-1111, MEM.

**@@@** Hold the number key down until it beeps twice. The pause is 2 seconds in length. **@@@** Each additional beep indicates an additional 2 second pause.

**@@@** Press PROG 2. Press 8 3. Press and hold 9 until it beeps at least twice. 4. Dial 555-1234 5. **@@@** The phone will automatically dial the number.

**@@@** To end the page at the base, press PAGE again.

To end the page at the handset, press OFF. **@@@** In Canada Call: VTECH Electronics at 1-800-267-7377. **THE PHONE DOESN'T WORK AT ALL.** \*

Make sure the power cord is plugged in. **@@@** Make sure the batteries are properly charged.

If the BATT LOW indicator is on, the battery needs charging. **@@@** \* First check all the suggestions above. **@@@** Call your local telephone company.

**@@@** Then press PHONE to get a line. **@@** Try moving the appliance or the base unit to another outlet.

**@@@** You may be out of range. Either move closer to the base, or relocate the base unit. \* The layout of your home may be limiting the range. Try moving the base unit to the second or third floor, or to some other location. **THE HANDSET DOES NOT RING WHEN YOU RECEIVE A CALL.** \* Ensure that the ringer is turned on. \* Make sure the telephone line cord is plugged firmly into the base unit and the telephone jack. Make sure the power cord is plugged in. \* You may be too far from the base unit. \* You may have too many extension phones on your telephone line to allow all of them to ring.

Try unplugging some of the other phones. **YOUR CALLER FADES IN AND OUT.** You may be nearly out of range. Move closer, or relocate the base. **YOU HEAR OTHER CALLS WHILE USING YOUR PHONE.** \* Replace the handset in the base cradle, wait a few moments and try again. \* Disconnect your base unit from the telephone jack, and plug in a regular telephone. If you still hear other calls, the problem is probably in your wiring or local service. Call your local telephone company. **YOU HEAR NOISE IN THE HANDSET, AND NONE OF THE KEYS OR BUTTONS WORK.**

\* Make sure the power cord is plugged in. \* Your base unit and handset may not be operating on the same channel or security code. Place the handset in the cradle for a few moments to reload the security code and reset the channel. **COMMON CURE FOR ELECTRONIC EQUIPMENT** Electronics, like people, can sometimes get confused. If the unit does not seem to be responding normally, then try putting the handset in the cradle to re-initialize the unit.

If it still does not seem to respond, perform the following steps (in the order listed): 1. Disconnect the power to the base. 2. Disconnect the handset battery. 3.

Wait a few minutes. 4. Connect power to the base. 5. Connect the handset battery. 6. Put the handset in the base to reinitialize. **WARRANTY STATEMENT**

**WHAT DOES OUR WARRANTY COVER?** \* Any defect in material or workmanship. **FOR HOW LONG AFTER THE ORIGINAL PURCHASE?** \* One Year.

**WHAT WILL VTECH DO?** \* At our option, repair or replace your unit.

**HOW DO I SEND MY UNIT, IN OR OUT OF WARRANTY?** \* Call VTECH Communications customer service for Return Authorization at: 1-800-624-5688 \*

Properly pack your unit. Include any cables & accessories which were originally provided with the product. We recommend using the original carton and packing materials. \* Include in the package a copy of the sales receipt or other evidence of date of original purchase (if the unit was purchased within the last twelve months).



[You're reading an excerpt. Click here to read official VTECH VT 910](http://yourpdfguides.com/dref/1305660)

[ADL user guide](http://yourpdfguides.com/dref/1305660)

<http://yourpdfguides.com/dref/1305660>

) \* Print your name and address, along with a description of the defect, and include this in the package. \* Include payment for any service or repair not covered by the warranty, as determined by VTECH Communications. \* In the US, ship the unit via UPS Insured, or equivalent to: VTECH COMMUNICATIONS 8770 SW NIMBUS AVENUE BEAVERTON, OREGON 97008 VTECH Communications assumes no responsibility for units sent without prior Return Authorization. MAINTENANCE TAKING CARE OF YOUR TELEPHONE. Your VTECH 910 ADL cordless telephone contains sophisticated electronic parts so it must be treated with care. Avoid rough treatment Place the handset down gently.

Save the original packing materials to protect your telephone if you ever need to ship it. Avoid Water Your telephone can be damaged if it gets wet. Do not use the handset outdoors in the rain, or handle it with wet hands. Do not install your base unit near a sink, bathtub or shower. Remember that electrical appliances can cause serious injury if used when you are wet or standing in water.

If your base unit should fall into water, DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD AND TELEPHONE LINE CORDS FROM THE WALL. Then pull the unit out by the unplugged cords. Electrical Storms Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, use caution when using electric appliances during storms. Cleaning your telephone Your telephone has a durable plastic casing that should retain its luster for many years.

Clean it only with a soft cloth slightly dampened with water or a mild soap. Do not use excess water or cleaning solvents of any kind. TECHNICAL SPECIFICATIONS FREQUENCY CONTROL Crystal Controlled Dual PLL Synthesizer TRANSMIT FREQUENCY Handset: 925.05 Mhz to 927.75 MHz (All ten channels within this range) Base: 902.3 MHz to 905.0 MHz (All ten channels within this range) RECEIVE FREQUENCY Handset: 902.3 MHz to 905.0 MHz (All ten channels within this range) Base: 925.05 MHz to 927.

75 MHz (All ten channels within this range) NOMINAL EFFECTIVE RANGE Maximum power allowed by FCC and IC. Actual operating range may vary according to environmental conditions at the time of use. SIZE Handset: 18.2cm x 6.2cm x 3.8cm (L x W xT) maximum (antenna excluded) Base: 21.0cm x 14.2cm x 5.0cm (L x W x T) maximum (antenna excluded) WEIGHT Handset: 250 grams Base: 415 grams POWER REQUIREMENTS Handset: Self-contained nickelcadmium rechargeable battery supply, 3.6V nominal, 600mAh capacity.

Power Adapter: 9V DC @ 300mA SPECIFICATIONS ARE TYPICAL AND MAY CHANGE WITHOUT NOTICE. WHAT DOES OUR WARRANTY NOT COVER? \* Batteries \* Damage from misuse, neglect, or acts of nature (lightning, floods, power surges. etc.) \* Products which may have been modified or incorporated into other products \* Products purchased outside the USA \* Products serviced by the owner or a service facility not expressly authorized by VTECH Communications \* Products purchased more than 12 months from current date HOW DOES STATE LAW RELATE TO THIS WARRANTY? \* This warranty gives you specific rights. You may also have other rights which vary from state to state.

IF YOU PURCHASED YOUR TELEPHONE IN CANADA Please call: 1-800-267-7377 Ship to: VTECH ELECTRONICS 200-7671 ALDERBRIDGE WAY RICHMOND, BC V6X 1Z9 FCC AND IC REGULATIONS FCC AND IC REGULATIONS This equipment complies with Parts 15 and 68 of the Federal Communications Commission (FCC) rules for the United States. It also complies with regulations RSS-210 and CS-03 of Industry Canada (IC). A label is located on the underside of the base unit containing either the FCC registration number and Ringer Equivalence Number (REN) or the IC registration number and Load Number. You must, upon request, provide this information to your local telephone company. This equipment is compatible with inductively coupled hearing aids.

FCC Part 15 Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The equipment has been tested and found to comply with part 15 of the FCC rules. @@@@\* Increase the separation between the equipment and receiver. \* Connect the equipment into an outlet or on a circuit different from that to which the receiver is connected. \* Consult the dealer or an experienced radio/TV technician for help. FCC Part 68 The FCC requires that you connect your cordless telephone to the nationwide telephone network through a modular telephone jack (USOC RJ11C or RJ11W). Your telephone company may discontinue your service if your equipment causes harm to the telephone network. They will notify you in advance of disconnection, if possible. During notification, you will be informed of your right to file a complaint with the FCC. If it is determined that your telephone equipment is malfunctioning, the FCC requires that it not be used and that it be unplugged from the modular jack until the problem has been corrected.

Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents or by others who may be authorized by the FCC. For repair procedures, follow the instructions outlined under the VTECH Limited Warranty. The REN is useful in determining the number of devices you may connect to your telephone line and still enable the devices to ring when you receive a call. The general rule is that the REN value should not exceed 5.0 total; however, contact your local telephone company for the specific number in your area. FCC AND IC REGULATIONS IC (Industry Canada) This telephone is registered for use in Canada. Notice: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network, protective, operational and safety requirements. Industry Canada does not guarantee the equipment will operate to the user's satisfaction. Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company.

The equipment must also be installed using an acceptable method of connections. The customer should be aware that compliance with the above conditions may not prevent degradation of service in situations. Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment. Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together.

This precaution may be particularly important in rural areas. Caution: Users should not attempt to make such connections themselves, but should contact appropriate electric inspection authority, or electrician, as appropriate. The Load Number (LN) assigned to this device denotes the percentage of the total load to be connected to a telephone loop which is used by the device to prevent overloading.



[You're reading an excerpt. Click here to read official VTECH VT 910](http://yourpdfguides.com/dref/1305660)

[ADL user guide](http://yourpdfguides.com/dref/1305660)

<http://yourpdfguides.com/dref/1305660>

*The termination on a loop may consist of any combination of devices subject only to the requirement that the total of the load numbers of all devices does not exceed 100. This device complies with RSS-210 of Industry Canada.*

*Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. .*



[You're reading an excerpt. Click here to read official VTECH VT 910](#)

[ADL user guide](#)

<http://yourpdfguides.com/dref/1305660>