



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for WHIRLPOOL ARC 4950. You'll find the answers to all your questions on the WHIRLPOOL ARC 4950 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual WHIRLPOOL ARC 4950  
User guide WHIRLPOOL ARC 4950  
Operating instructions WHIRLPOOL ARC 4950  
Instructions for use WHIRLPOOL ARC 4950  
Instruction manual WHIRLPOOL ARC 4950

TEMPERATURE CONTROL AND OTHER USEFUL TIPS

**COLDEST ZONE INSIDE THE REFRIGERATOR**

The symbol at the side indicates the coldest zone in the refrigerator.

The coldest zone usually goes from the glass shelf of the crisper drawer at the bottom of the refrigerator to the symbol or rack positioned at the same height.

To maintain the temperature in this zone, be careful not to change the position of the rack.

The coldest zone symbol is not indicated in refrigerators with forced air system (No-Frost), as the temperature is even throughout the entire refrigerator.

**TEMPERATURE INDICATOR**

For optimum temperature adjustment, the refrigerator is provided with a temperature indicator to allow you to control the average temperature in the coldest zone.

**IMPORTANT!** The indicator is designed to operate with this refrigerator only. Do not use it with any other refrigerator (the coldest zone is not the same) or for any other use.

If the refrigerator is provided with a storage compartment, the temperature indicator is located inside the compartment.

**CHECKING THE TEMPERATURE IN THE COLDEST ZONE**

- After the appliance has been switched on for at least 24 hours, you can carry out regular checks to ensure the temperature in the coldest zone is correct and, if necessary, adjust the thermostat as indicated in the user instructions (chapter "temperature adjustment").

The internal temperature of the refrigerator depends on various factors such as the ambient temperature of the room, the amount of food stored and how often the door is opened. These factors should be taken into account when setting the appliance.

To maintain the required temperature inside the appliance, and to preserve your food better, check that the indicator shows the message OK. If the message OK does not appear, this means that the desired temperature has not been reached. In this case, adjust the thermostat setting and wait for 12 hours before checking the indicator again. When fresh food has been introduced or the door has been left open for some time, it is normal for the message OK on the indicator to fade.

**OK**  
Correct setting

**Temperature not optimal, adjust the thermostat.**



[You're reading an excerpt. Click here to read official WHIRLPOOL ARC 4950 user guide](http://yourpdfguides.com/dref/4857877)

<http://yourpdfguides.com/dref/4857877>

**Manual abstract:**

The coldest zone symbol is not indicated in refrigerators with forced air system (No-Frost), as the temperature is even throughout the entire refrigerator. **TEMPERATURE INDICATOR** For optimum temperature adjustment, the refrigerator is provided with a temperature indicator to allow you to control the average temperature in the coldest zone. **IMPORTANT:** The indicator is designed to operate with this refrigerator only. Do not use it with any other refrigerator (the coldest zone is not the same) or for any other use. If the refrigerator is provided with a storage compartment, the temperature indicator is located inside the compartment. @@@@ @@@@ @@@@ • Rinse the interior and dry with a soft cloth. • Do not use abrasive products.

@@@@ @@@@@ @@@@@ • Store liquids in closed containers. @@ • Arrange the food leaving sufficient space around it for the air to circulate. • Do not place food in direct contact with the rear wall of the refrigerator compartment.

**STORING FOODSTUFFS IN THE REFRIGERATOR** • Store each foodstuff in the most appropriate zone: Temperate zone: Beverages, butter, industrial and homemade sauces, cooked cheeses, fresh fruit and vegetables. Cool zone: Dairy products, desserts made with milk, fatty foods, fresh cheeses. @@ The tables below are indicative only. .



[You're reading an excerpt. Click here to read official WHIRLPOOL](#)

[ARC 4950 user guide](#)

<http://yourpdfguides.com/dref/4857877>