



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for WHIRLPOOL ART 476/R. You'll find the answers to all your questions on the WHIRLPOOL ART 476/R in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual WHIRLPOOL ART 476/R  
User guide WHIRLPOOL ART 476/R  
Operating instructions WHIRLPOOL ART 476/R  
Instructions for use WHIRLPOOL ART 476/R  
Instruction manual WHIRLPOOL ART 476/R

79621-gb.fm5 Page 66 Friday, March 6, 1998 8:47 AM

<b>GB</b>	<b>CONTENTS</b>	
	BEFORE USING THE APPLIANCE	PAGE 67
	SAFEGUARDING THE ENVIRONMENT	PAGE 67
	PRECAUTIONS AND GENERAL RECOMMENDATIONS	PAGE 68
	HOW TO USE THE REFRIGERATOR COMPARTMENT	PAGE 69
	HOW TO USE THE FREEZER COMPARTMENT	PAGE 70
	HOW TO DEFROST THE FREEZER COMPARTMENT	PAGE 72
	HOW TO CLEAN THE REFRIGERATOR COMPARTMENT	PAGE 72
	CARE AND MAINTENANCE	PAGE 73
	TROUBLE-SHOOTING GUIDE	PAGE 73
	AFTER-SALES SERVICE	PAGE 74
	INSTALLATION	PAGE 74
	ELECTRICAL CONNECTION	PAGE 75

66



[You're reading an excerpt. Click here to read official WHIRLPOOL ART 476/R user guide](http://yourpdfguides.com/dref/4834943)  
<http://yourpdfguides.com/dref/4834943>



*In this case, the wire which is coloured GREEN AND YELLOW must be connected to the EARTH contact, and the two wires to the two pins, irrespective of colour. The supply to the socket must be fitted with a 16 amp fuse. Connection to a rewirable plug If the fitted plug is not suitable for your socket outlet, then it should be cut off and disposed of in order to avoid a possible shock hazard should it be inserted into a 13A socket elsewhere. A suitable alternative plug should then be fitted to the cable. 75 .*



[You're reading an excerpt. Click here to read official WHIRLPOOL ART 476/R user guide](#)

<http://yourpdfguides.com/dref/4834943>