



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for WHIRLPOOL AWE 7529. You'll find the answers to all your questions on the WHIRLPOOL AWE 7529 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual WHIRLPOOL AWE 7529
User guide WHIRLPOOL AWE 7529
Operating instructions WHIRLPOOL AWE 7529
Instructions for use WHIRLPOOL AWE 7529
Instruction manual WHIRLPOOL AWE 7529

GB

A. Programme selector
 B. Time display
 C. "Start delay" button
 D. "Variable spin" button
 E. "Start(Pause)" button
 F. Programme sequence indicator

G. "Reset" button
 H. "Door open" indication

PROGRAMME CHART

This washing machine is equipped with automatic safety functions which detect and diagnose faults at an early stage and react appropriately:

1. "Service" indication
 J. "Water tap closed" indication
 K. "Clean pump" indication

1) Do not use liquid detergent for main wash if you have activated prewash option.
 2) Do not use liquid detergent.
 3) For improved garment care, spin speed is restricted in these programmes.

Programme	Care Labels	Max. Load kg	Type of wash / Notes <i>- for temperature selection, respect the manufacturer's recommendations on the care label</i>	Detergents and Additives				Special options					Max. Spin Speed rpm
				Pre-wash	Main Wash	Softener	Half load	Eco	Pre-wash	Start delay	Intensive rinse	Rinse Hold	
Cotton / Antibacterial 40 - 60 - 95°C		5.0	Normally to heavily soiled bed linen, table linen and underwear, towels, shirts etc. made of cotton and linen. Selecting "Cotton 95", this programme eliminates bacteria, ensuring sanitization of your laundry. The bacteria removal efficiency has been tested following a similar methodology to the NF EN 13697 standard of Nov. 2001.	*	Yes ¹⁾	*	*	*	*	*	*	*	max.
Jeans 40°C		5.0	Normally soiled cotton jeanswear and garments made of jeanslike material such as trousers and jackets.	*	Yes ¹⁾	*	*	-	*	*	*	*	max.
Synthetics 30 - 40 - 60°C		2.5	Normally soiled blouses, shirts, overalls etc. made of polyester (Diolen, Trevira), polyamide (Perlon, Nylon).	*	Yes ¹⁾	*	*	*	*	*	*	*	1000 ³⁾
Delicates 30 - 40°C		1.5	Curtains and delicate clothing, dresses, skirts, shirts and blouses.	*	Yes ¹⁾	*	-	-	*	*	*	*	1000 ³⁾
Daily load 40°C		3.0	Slightly to normally soiled textiles made of cotton and/or synthetics.	-	Yes	*	-	-	*	*	*	*	max.
Quick wash 15' 30°C		3.0	Refreshes briefly worn outer clothing made of cotton, artificial fibers and blends with cotton. Use lowest recommended detergent amount.	-	Yes	*	-	-	*	-	*	*	max.
Wool Cold 40°C		1.0	Only woollens with a felt-free finish, labelled with the woolmark and identified as machine washable. This programme (40°C) is tested and approved by The Woolmark Company for machine washable wool.	-	Yes	*	-	-	*	-	*	*	1000 ³⁾
Handwash 40°C		1.0	Textiles made of silk, linen, wool and viscose marked as "handwashable". This programme (40°C) is tested and approved by The Woolmark Company for handwashable wool. A very gentle spin is used in this programme.	-	Yes	*	-	-	*	-	*	*	400 ³⁾
SuperEco 60°C		5.0	Heavily soiled and robust laundry made of cotton, synthetics and their blends. Economical energy consumption by prolonged wash duration - ideal to be run overnight to profit from more favourable energy rates. Avoid noise of spinning at night by setting the spin speed to "0" and start spin programme in the morning, or by defining programme start with "Start delay" accordingly. For garments with a high share of synthetic fibres, we recommend to use a laundry net.	-	Yes	*	-	-	*	*	*	*	max.
Rinse & Spin		5.0	Same as the last rinse and the final spin in the "Cotton" programme.	-	-	*	-	-	*	*	*	*	max.
Spin		5.0	In this programme spinning is intensive. Same as the spin cycle in the "Cotton" programme.	-	-	-	-	-	*	-	-	*	max.
Drain		-	Drain only - no spinning. Alternative method of terminating programme after "Rinse Hold".	-	-	-	-	-	-	-	-	-	-

N.B. This machine is controlled by sensors. Please avoid excessive detergent dosing
 Yes = dosing required / * = optional

The wool and handwash cycles of this machine have been tested and approved by The Woolmark Company for the washing of Woolmark garments labelled as "machine wash" or "hand wash" provided that the garments are washed according to the instructions on the garment label and those issued in this programme chart. M0703

Whirlpool is a registered trademark of Whirlpool USA.
5019 312 11049*



[You're reading an excerpt. Click here to read official WHIRLPOOL AWE 7529 user guide](http://yourpdfguides.com/dref/4912284)
<http://yourpdfguides.com/dref/4912284>

Close the lid. 4.

Turn the programme selector to the desired programme and temperature. The time display shows the duration of the chosen programme (in hours and minutes), and the lamp next to the "Start (Pause)" button flashes. The indication lamp of the predefined spin speed lights up. **SELECT THE DESIRED OPTION(S)** Selecting or deselecting an option can be done at any time during the programme. The option will be applied as long as the corresponding programme phase has not been executed yet. "Half load" button • Reduces water consumption, above all during rinsing. • Suitable for lightly soiled laundry and small loads (max. 3 kg). @@Increases the cycle time by approximately 20 min. @@@@• This option is particularly recommended for the

"Synthetics", "Daily load" and "Delicates" programmes.

• It is useful if you want to postpone spinning to a later time, or if you want to drain out only. • If you select "Rinse Hold", do not leave items to soak for too long. • As soon as the appliance stops in the rinse hold, the "Rinse hold" lamp of the sequence indicator lights up and the lamp next to the "Start(Pause)" button flashes. Terminate the "Rinse Hold" option: • Press the "Start(Pause)" button; the programme will terminate automatically with the final spin cycle for the present wash programme. • If you .



[You're reading an excerpt. Click here to read official WHIRLPOOL AWE 7529 user guide](http://yourpdfguides.com/dref/4912284)
<http://yourpdfguides.com/dref/4912284>