



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for WHIRLPOOL AWT 2256. You'll find the answers to all your questions on the WHIRLPOOL AWT 2256 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual WHIRLPOOL AWT 2256  
 User guide WHIRLPOOL AWT 2256  
 Operating instructions WHIRLPOOL AWT 2256  
 Instructions for use WHIRLPOOL AWT 2256  
 Instruction manual WHIRLPOOL AWT 2256

**GB AWT 2256**

⏻ "On/Off"

Programme duration figures (guideline) are valid for maximum temperature wash with no special functions.

⊛ : option / Yes: dosing required  
<sup>1)</sup> Do not use liquid detergents.

Programme	Type of wash / Notes	Max. load kg	Detergents and additives				Options		Temperature °C	Maximum Spin Speed rpm	Programme time approx. min.
			Prewash	Main Wash	Softener	Bleach	Half Load	Intensive Wash 90°			
Cotton with Prewash	Heavily soiled sheets, tablecloths, underclothes, shirts etc. in hard wearing and high temperature resistant cotton. <i>The maximum load for heavily soiled washing is 3.5 kg.</i>	5.0	Yes <sup>1)</sup>	Yes	⊛	⊛	⊛	⊛	60/90*	500	130
Cotton	Moderately soiled sheets, tablecloths, underclothes, towels etc. in hard wearing and high temperature resistant cotton.	5.0	— <sup>1)</sup>	Yes	⊛	⊛	⊛	⊛	60/90*	500	115
Coloured	Average soiled blouses, shirts etc. made of polyester (Dolien, Trevira); polyamide (Perlon, Nylon), or cotton blends.	2.0	— <sup>1)</sup>	Yes	⊛	—	⊛	—	60	500	100
Synthetics	Lightly soiled shirts, blouses etc., made of polyester (Dolien, Trevira), polyamide (Perlon, Nylon) or cotton blends.	2.0	— <sup>1)</sup>	Yes	⊛	—	⊛	—	40	500	70
Rinse + Spin	This programme allows starch or softener to be added. It is followed by an intensive spin cycle.	5.0	— <sup>1)</sup>	—	⊛	—	⊛	—	Cold	500	20
Spin	Programme for intensive spin cycle.	5.0	— <sup>1)</sup>	—	—	—	—	—	—	500	15
Delicate	Delicate fabrics and curtains (dresses, skirts, shirts, blouses, etc.).	1.5	— <sup>1)</sup>	Yes	⊛	—	—	—	40	500	55
Wool	Machine washable woollens with pure new wool label. <i>If the "Rinse Hold" option is selected don't leave the wash to soak for too long.</i>	1.0	— <sup>1)</sup>	Yes	⊛	—	—	—	40	500	45
Rinse + Spin	This programme allows starch or softener to be added. It is followed by a gentle spin cycle.	1.5	— <sup>1)</sup>	—	⊛	—	—	—	Cold	500	15
Spin	Programme for gentle spin cycle.	1.5	— <sup>1)</sup>	—	—	—	—	—	—	500	10
Drain	Drain only, without spin cycle. <i>Alternative way to end programmes after a "Rinse Hold".</i>	—	— <sup>1)</sup>	—	—	—	—	—	—	—	5

\* For obtaining the 90° C temperature, press the "Intensive Wash" option button.  
**N.B. This machine is controlled by sensors. Please avoid excessive detergent dosing.**

Whirlpool is a registered trademark of Whirlpool USA.  
**5019 312 10010**



[You're reading an excerpt. Click here to read official WHIRLPOOL AWT 2256 user guide](http://yourpdfguides.com/dref/4829266)  
<http://yourpdfguides.com/dref/4829266>

