



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for WHIRLPOOL WWDC 6400. You'll find the answers to all your questions on the WHIRLPOOL WWDC 6400 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual WHIRLPOOL WWDC 6400  
 User guide WHIRLPOOL WWDC 6400  
 Operating instructions WHIRLPOOL WWDC 6400  
 Instructions for use WHIRLPOOL WWDC 6400  
 Instruction manual WHIRLPOOL WWDC 6400

**GB**

**A. "Door open" indication**  
 This washing machine is equipped with automatic safety functions which detect and diagnose faults at an early stage and react appropriately, e.g.:

**B. "Service" indication**

**C. "Water tap closed" indication**

**D. "Clean pump" indication**

**PROGRAMME CHART**

**E. Programme selector**

**F. "Start(Pause)" button**

**G. Programme sequence indicator**

**H. "Reset" button**

Programme	Care Labels	Max. Load kg	Type of wash / Notes <i>- respect the manufacturer's recommendations on the care label</i>	Detergents and Additives			Special options		Max. Spin Speed rpm
				Pre-wash	Main Wash	Softener	Spin speed reduction X100 rpm	Rinse hold	
<b>Cotton with prewash</b> 95 °C		6.0	Heavily soiled, long wearing and temperature stable textiles in cotton and linen (bed linen, table linen, underwear, shirts etc.).	Yes	Yes <sup>1)</sup>	⊗	⊗	⊗	Max.
<b>Cotton</b> 95 °C		6.0	Normally to heavily soiled and robust white cotton laundry. In case of heavy soiling or stains, you can add an oxygenbased bleach additive which can be used at 95 °C. This programme eliminates bacteria, ensuring sanitization of your laundry.	-	Yes	⊗	⊗	⊗	Max.
<b>Cotton</b> 40 - 60 °C		6.0	Normally to heavily soiled bed linen, table linen and underwear, towels, shirts etc. made of cotton and linen.	-	Yes	⊗	⊗	⊗	Max.
<b>Rapid</b> 60 °C		6.0	Normally to heavily soiled cotton laundry washable at 60 °C. Faster alternative to "Cotton" programme for washing your cotton laundry at 60 °C.	-	Yes	⊗	⊗	⊗	Max.
<b>Synthetics with prewash</b> 60 °C		3.0	Heavily soiled laundry made of artificial fibres (like polyester, polyacryl, viscose etc.) or their blends with cotton.	Yes	Yes <sup>1)</sup>	⊗	⊗	⊗	Max.
<b>Synthetics</b> 30 - 40 - 60 °C		3.0	Normally soiled garments made of artificial fibres (like polyester, polyacryl, viscose etc.) or their blends with cotton.	-	Yes	⊗	⊗	⊗	Max.
<b>Delicates</b> 30 °C		1.5	Curtains and delicate clothing, dresses, skirts, shirts and blouses.	-	Yes	⊗	⊗	⊗	1000 <sup>2)</sup>
<b>Quick wash</b> 30 °C		3.0	Shortly worn clothing made of cotton, polyester, polyamide and blends with cotton. Brief programme to refresh your laundry.	-	Yes	⊗	⊗	⊗	Max.
<b>Wool</b> Cold - 40 °C		1.0	Only woollens, labelled with the Woolmark and identified as machine washable. This programme (40°C) is tested and approved by The Woolmark Company for machine washable wool.	-	Yes	⊗	⊗	⊗	1000 <sup>2)</sup>
<b>Handwash</b> 40 °C		1.0	Textiles made of silk, linen, wool and viscose marked as "handwashable". This programme (40°C) is tested and approved by The Woolmark Company for handwashable wool.	-	Yes	⊗	⊗	⊗	400 <sup>2)</sup>
<b>Rinse &amp; Spin</b>	-	6.0	Same as the last rinse and the final spin in the "Cotton" programme.	-	-	⊗	⊗	⊗	Max.
<b>Spin</b>	-	6.0	In this programme spinning is intensive. Same as the spin cycle in the "Cotton" programme.	-	-	-	⊗	-	Max.
<b>Short Spin</b>	-	1.0	In this programme spinning is gentle. Same as the spin cycle in the "Wool" programme.	-	-	-	⊗	-	1000 <sup>2)</sup>
<b>Drain</b>	-	-	Drain only - no spinning. Alternative method of terminating programme after "Rinse hold"	-	-	-	-	-	-

<sup>1)</sup> option / Yes : dosing required  
<sup>2)</sup> Do not use liquid detergents.  
 For improved garment care spin speed is restricted in these programmes.

The wool and handwash cycles of this machine have been tested and approved by The Woolmark Company for the washing of Woolmark garments labelled as "machine wash" or "hand wash" provided that the garments are washed according to the instructions on the garment label and those issued in this programme chart. M0619

Whirlpool is a registered trademark of Whirlpool USA.  
**5019 301 01315**



You're reading an excerpt. [Click here to read official WHIRLPOOL WWDC 6400 user guide](http://yourpdfguides.com/dref/4843522)

**Manual abstract:**

“Door open” indication This washing machine is equipped with automatic safety functions which detect and diagnose faults at an early stage and react appropriately, e.g.: B. “Service” indication C. “Water tap closed” indication D. “Clean pump” indication Care Labels Max. @@Normally to heavily soiled and robust white cotton laundry. In case of heavy soiling or stains, you can add an oxygenbased bleach additive which can be used at 95°C. @@@made of cotton and linen. Normally to heavily soiled cotton laundry washable at 60°C.

Faster alternative to “Cotton” programme for washing your cotton laundry at 60°C. Heavily soiled laundry made of artificial fibres (like polyester, polyacryl, viscose etc.) or their blends with cotton. Normally soiled garments made of artificial fibres (like polyester, polyacryl, viscose etc.) or their blends with cotton. Curtains and delicate clothing, dresses, skirts, shirts and blouses. Shortly worn clothing made of cotton, polyester, polyamide and blends with cotton. Brief programme to refresh your laundry. Only woollens, labelled with the Woolmark and identified as machine washable. @@@@@@In this programme spinning is intensive.

Same as the spin cycle in the “Cotton” programme. In this programme spinning is gentle. Same as the spin cycle in the “Wool” programme. Drain only - no spinning. Alternative method of terminating programme after “Rinse hold” The wool and handwash cycles of this machine have been tested and approved by

The Woolmark Company for the washing of Woolmark garments labelled as “machine wash” or “hand wash” provided that the garments are washed according to the instructions on the garment label and those issued in this programme chart. M0619 Special options Spin Rinse speed hold reduction X00 rpm  
iiiiiiiiiiii-iiiiiiiiMax. Spin Speed rpm 6.0 6.0 6.0 6.

0 3.0 3.0 1.5 3.0 1.0 1.0 ----- Yes --- Yes ----- Yes 1) Yes Yes Yes Yes 1) Yes Yes Yes Yes Yes -----iiiiiiiiii---Max. Max. Max. Max.  
Max. Max. 1000 2) Max. 1000 2) 400 2) Max. Max.

1000 2) - 40 - 60 °C Cotton Rapid 60 °C Synthetics with prewash 60 °C 30 - 40 - 60 °C Synthetics Delicates 30 °C 30 °C Quick wash Wool Cold - 40 °C  
Handwash 40 °C Rinse & Spin Spin Short Spin Drain i : 1) 2) 6.0 6.0 1.0 - i --- option / Yes : dosing required Do not use liquid detergents.  
@@@@@@@@@1.

Turn the programme selector to the “Off/O” position. 2. Close the water tap. 3. Open the door and unload the machine.

@@@@@@@@@@@@@@@@@ “Water tap closed” The washing machine has no or insufficient water supply; the water tap might be closed or the water inlet hose kinked. “Clean pump” Waste water is not pumped out. The drain hose may be kinked or the filter must be cleaned (see “Cleaning the filter” in your Instructions for Use). 1. Press the “Start(Pause)” button to pause the programme.

The light blinks. 2. Select the new programme (with temperature), and any options if you want. 3. Press the “Start(Pause)” button again. The new programme continues at the same position where the previous programme was interrupted. @@@@ Any existing water is drained out. @@@@ • The indication lamp next to “Start(Pause)” button blinks. SELECT ANY DESIRED OPTION “Rinse hold” button • The laundry remains in the last rinse water without progressing to the final spin cycle to avoid creasing and prevent colours from changing. • Particularly useful if you want to postpone spinning to a later time, or if you want to drain only.

Note: The programme stops to “Rinse hold” at the time the “Rinse hold” light in the programme sequence indication is on. The indication lamp next to the “Start(Pause)” button blinks. @@@@@Unsuitable combinations of options are deselected automatically. “Spin speed reduction” button • Reduces the predetermined automatic maximum spin speed to treat your laundry more gently. Whirlpool is a registered trademark of Whirlpool USA.  
5019 301 01315 .



[You're reading an excerpt. Click here to read official WHIRLPOOL WWDC 6400 user guide](http://yourpdfguides.com/dref/4843522)  
<http://yourpdfguides.com/dref/4843522>