



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for XEROX WORKCENTRE 5665. You'll find the answers to all your questions on the XEROX WORKCENTRE 5665 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.


User manual XEROX WORKCENTRE 5665
User guide XEROX WORKCENTRE 5665
Operating instructions XEROX WORKCENTRE 5665
Instructions for use XEROX WORKCENTRE 5665
Instruction manual XEROX WORKCENTRE 5665

Version 3.0
02/10
604E50662



Xerox® Common Access Card

Xerox® WorkCentre 5632/5638/ 5655/5665/5675 and 5687
Xerox® WorkCentre 5735/5740/ 5755/5765/5775 and 5790
Xerox® WorkCentre 5135/5150
Xerox® WorkCentre 5030/5050 (software version 05.004.xx.xxx)



[You're reading an excerpt. Click here to read official XEROX WORKCENTRE 5665 user guide](http://yourpdfguides.com/dref/3681092)
<http://yourpdfguides.com/dref/3681092>

..... Locating the Serial Number

.....
.....
.....
.....
.....
.....
.....

... Troubleshooting Tips

.....
.....
.....
.....
.....
.....

. During Installation:

.....
.....
.....
.....
.....
.....

.. After Installation:

.....
.....
.....
.....
.....
.....

..... 30 30 31 31 32 A B Retrieving the Certificate from a Domain Controller or OCSP Server Determining the Domain in which your Card is Registered
Xerox Common Access Card Common Access Card Installation Guide 3 4 Xerox Common Access Card Common Access Card Installation Guide Introduction
1 The Xerox Common Access Card solution brings an advanced level of security to sensitive information. Organizations can restrict access to the walk-up
features of a Xerox device. This ensures only authorized users are able to copy, scan, e-mail and fax information. The key benefit of this solution is its two-
factor identification requirement. Users must insert their access card and enter a unique Personal Identification Number (PIN) at the device.

This provides added security in the event that a card is lost or stolen. Once validated, a user is logged into the Xerox device for all walk-up features. The
system allows for functions to be tracked for an added layer of security. The Xerox Common Access Card enablement kit integrates with Xerox multifunction
printers and existing common access and personal identity verification cards and readers. This guide explains how to install and configure the Common
Access Card solution. It identifies the resources and equipment required to complete a successful installation. @@Please contact your Xerox Representative
for details. @@@@2. Press the Machine Status button on the control panel. Information about the machine is displayed.

@@The following card readers are compatible with the solution: · Gemplus GemPC USB SL · Gemplus GemPC Twin · SCM Micro SCR3310 · SCM Micro
SCR3311 · OmniKey Cardman 3021 USB · OmniKey Cardman 3121 USB · ActivCard USB Reader V2 with SCR-331 firmware Other CCID compliant readers
may function with the solution, but have not been validated. Note: Information about CCID compliant card readers can be obtained from various websites, for
example www.pcslite.alioth.debian.org/ccid.

org/ccid.This site is not a Xerox website and is not endorsed by Xerox. Supported Card Types The customer is also responsible for purchasing and
configuring the access cards. The following card types are recommended: · Axalto Pegasus 64K / V2 · Axalto Cyberflex 32K / V1 · Axalto Cyberflex 64K / V2 ·
Gemplus GemXpresso 64K / V2 · Oberthur 72K / V2 · Oberthur CosmopoiIC 32K / V1 · Oberthur D1 72K / V2 (contact-less and PIV) Other card types may
function with the solution, but have not been validated. Additional information from your System Administrator may be required to validate which card reader
works best in your environment.

Note: Information about CCID compliant card types can be obtained from various websites, for example www.pcslite.alioth.debian.org/ccid.This site is not a
Xerox website and is not endorsed by Xerox. Xerox Common Access Card Common Access Card Installation Guide 7 Introduction Documentation and
Support For information specifically about your Xerox product, the following resources are available: · System Administrator Guide provides detailed

instructions and information about connecting your device to the network and installing optional features. This guide is intended for System/Machine Administrators. · User Guide provides detailed information about all the features and functions on the device. This guide is intended for general users.

Most answers to your questions will be provided by the support documentation supplied on disc with your product. Alternatively you can contact the Xerox Support Center or access the Xerox website at www.xerox.com. 8 Xerox Common Access Card Common Access Card Installation Guide Preparation 2 Supplier Customer Customer Xerox Xerox Customer Customer Customer Customer This section explains the preparation and resources required to install the Common Access Card. The installation will take approximately one hour for each device. The following items are required in order to complete the installation: Item Compatible Card Reader (refer to Supported Card Readers on page 7) Compatible Access Card (refer to Supported Card Types on page 7) Common Access Card enablement kit 498K17544 (one for each Xerox device) Feature Enable Key TCP/IP enabled on the device DNS Host name or static IP address assigned Network Settings to be checked to ensure network is fully functional Domain Controller (DC) information: · Domain Controller authentication environment · IP address or Host Name · Domain information · Domain Controller Root and Intermediate certificates · Check that all certificates are in 64 bit X.509 format · Determine if the DC is registered with the OCSP at this site Online Certificate Status Protocol (OCSP) Server Information: · OCSP Server URL · OCSP - Root and Intermediate Certificates · Check that all certificates are in 64 bit X.



[You're reading an excerpt. Click here to read official XEROX WORKCENTRE 5665 user guide](#)
<http://yourpdfguides.com/dref/3681092>

509 format Proxy Server configuration details Customer Customer To set up the Domain Controller (DC) validation, you will need to determine if your site validates the DC against the Online Certificate Status Protocol (OCSP) server. Many sites use OCSP to validate individuals, but do not register the DC with it.

If you set up the Xerox device to validate the DC and it isn't registered, the procedure will fail. If your site does register the DC with OCSP, you will need to decide whether: · to validate the DC against OCSP before validation of the user, or · to validate the DC after validation of the user Xerox Common Access Card Common Access Card Installation Guide 9 Preparation The first method requires installation of the DC certificate as part of this procedure and is the more accepted method for validation. The second method retrieves the DC certificate automatically for each authentication and doesn't require installation of the DC certificate onto the Xerox device. @@@@There are 4 main installation procedures to follow in sequence. @@@@The device will obtain the time from the NTP server.

@@At the Xerox WorkCentre, press the Access button on the control panel. b. Input your User Name and/or Password. c. Select Go to Tools. d. Select System Settings. e. Select Time and Date. f. Select Set Date and Time. g. Select Set Time. h. Observe the time and if it is not correct, validate that the GMT offset is correct for your region.

Note: If any changes are made, the device wie Trusted Certificates Authorities screen, select Add. c. Browse to the previously retrieved certificates and add them one at a time. d. Select the certificate then select the Upload Certificate Authority button to add each one. e. Repeat the process until all certificates are installed. f. Select Close. Xerox Common Access Card Common Access Card Installation Guide 19 Installation 8.

Check the Proxy Server details are configured a. If required by your network environment, ensure the Proxy Server details have been configured. b. Select the Properties tab, then Connectivity, Protocols and Proxy Server and enter the details. c.

Select Apply. d. The Common Access Card settings are now configured. The Common Access Card settings are now configured. You are now ready to install the Common Access Card hardware using the instructions starting on the next page.

20 Xerox Common Access Card Common Access Card Installation Guide Installation Hardware Installation Install the card reader device using the following instructions. 1. Unpack the Common Access Card Enablement Kit The kit contains the following items: · Xerox Common Access Card Enablement Guide · Four Dual Lock Fastener pads (Velcro) · Three Cable Ties Ensure you have read the licence agreement and agree to the terms and conditions specified prior to installation. Xerox Common Access Card Common Access Card Installation Guide 21 Installation 2. Locate the card reader device being installed · There are two types of card reader available, an upright model or a slimline model. · Locate the device being installed and ensure it has been configured. Note: The System Administrator should configure the cards prior to the card reader being installed on the machine. 4 5 22 Xerox Common Access Card Common Access Card Installation Guide Installation 3. Attach the fasteners to the card reader device · Fasteners have been provided to secure the card reader to the Xerox device. · Peel back the fastener backing strip.

· Position the fastener on the under-side of the card reader, as shown. · Repeat for each of the fasteners supplied. 4 5 Xerox Common Access Card Common Access Card Installation Guide 23 Installation 4. Remove the fastener backing strips When all the fasteners have been attached to the card reader, remove the backing strips on each of the fasteners. 24 Xerox Common Access Card Common Access Card Installation Guide Installation 5. Place the card reader on the Xerox device · Gently place the card reader on the device (do not fix in place at this point). · Position the card reader in a suitable location, ensure it does not obstruct the opening of the document handler side cover. · Check the cable has sufficient length to connect to the rear of the network controller. · Once it is in a suitable location, press firmly on the card reader to fix it in place. Xerox Common Access Card Common Access Card Installation Guide 25 Installation 6.

Connect the card reader to the Xerox device · Insert the USB connection into the slot provided on the rear of the network controller. · Use the cable ties provided to ensure the cabling is neat and tidy. The hardware installation is now complete. 26 Xerox Common Access Card Common Access Card Installation Guide Installation 7. Confirm the installation · When the card reader and the software has been installed and configured, the Card Reader Detected screen displays on the Xerox WorkCentre local user interface.

· Select OK. Common Access Card is now ready for use. Note: If the card reader is not detected, refer to Troubleshooting Tips on page 31 for information. Xerox Common Access Card Common Access Card Installation Guide 27 Installation Using Common Access Card Once the Common Access Card has been enabled, each user must insert a valid card and enter their Personal Identification Number (PIN) on the touch screen. When a user has finished using the Xerox WorkCentre, they are then required to remove their card from the card reader to end the session.

@@Follow the instructions below to use the Common Access Card: 1. 2. 3. @@Insert your card into the card reader. @@If the card and PIN are authenticated, access is granted. @@Complete the job. To end the session, remove your card from the card reader. 4. @@@@For problems with the card reader device, contact the manufacturer for further assistance. · For problems relating to the Xerox device, contact the Xerox Welcome and Support Center.

The Welcome and Support Center will want to know the nature of the problem, the Machine Serial number, the fault code (if any) plus the name and location of your company. Contact Xerox using the numbers 1-800-ASK-XEROX or 1-800-275-9376. Locating the Serial Number 1. 2. Press the Machine Status button on the control panel. Information about the machine is displayed. If necessary, select Machine Details to display the Customer Support Number for the Welcome and Support Center and the Machine Serial Number. The serial number can also be found on a label inside the front door. 30 Xerox Common Access Card Common Access Card Installation Guide Troubleshooting Troubleshooting Tips The table below provides a list of problems and the possible cause and a recommended solution. @@@@ · Contact the System Administrator.



[You're reading an excerpt. Click here to read official XEROX WORKCENTRE 5665 user guide](http://yourpdfguides.com/dref/3681092)
<http://yourpdfguides.com/dref/3681092>

· Check the cable is plugged in correctly. Refer to Hardware Installation on page 21 for instructions. · Unplug the card reader cable then plug back in. · Plug the card reader into a different USB port. @@@@If problem persists, contact the System Administrator for advice.

· Contact Registration Authority to reload or to get a new card. · Card is locked due to too many failed PIN attempts. · Unable to find identity certificate. · Identity certificate has been revoked. · Authentication with Domain Controller Failed.

· Unable to validate server certificate. · Smart Card Authentication System Failed. · Authentication Failed. · System Administrator has not selected All Features or Scanning Service Only. Time for date mismatch error · There is a mismatch between the time and date setting on the Xerox WorkCentre and the authentication server time or date setting. · Check network cable is firmly connected. · Contact the System Administrator. · Contact the System Administrator. Verify that Network Time Protocol is properly set up. · Verify that GMT offset is correct for your region, refer to Configure the date and time to update automatically on page 13.

· Verify that GMT offset is correct for Daylight Savings Time. · Contact your System Administrator. · Check the IP Address printed on the configuration report. Ensure the DHCP settings match your site settings. · To print a configuration report at the Xerox WorkCentre. Cannot see the Internet Services web page after software upgrade · IP Address incorrect or has been reset. 32 Xerox Common Access Card Common Access Card Installation Guide Retrieving the Certificate from a Domain Controller or OCSP Server 1. Access the Domain Controller using a web browser using the following syntax: https://IP Address of the Domain Controller:636 For example: https://111.222.33.44:636 where 111.222.33.44 is the IP address of the appropriate server. @@Click on View Certificate to proceed. @@@@Select the Copy to File button. 5. The Certification Export Wizard is displayed. Select Next. 6. 7. Select Base-64 encoded X.509 (.CER). Select Next. 34 Xerox Common Access Card Common Access Card Installation Guide Retrieving the Certificate from a Domain Controller or OCSP Server Select Browse. Browse to a directory to save the Certificate. 9. Enter a filename for the Certificate and select Save. 10.

Select Next. 8. 11. Select Finish. The Certificate is retrieved from the server and saved in the selected directory. A pop-up message will confirm that the Certificate has been successfully saved. Once saved the Certificate can be loaded onto the device. This process can be repeated to retrieve the Certificates from each of the required servers. Xerox Common Access Card Common Access Card Installation Guide 35 Retrieving the Certificate from a Domain Controller or OCSP Server 36 Xerox Common Access Card Common Access Card Installation Guide Determining the Domain in which your Card is Registered 1. 2.

B 3. 4. From your PC, click the Start menu and right click on My Computer. From the drop down list, select Properties. When the System Properties window opens, click on the Computer Name tab.

Beneath the Full Computer name is the Domain Name. Copy and paste the Domain Name directly into the CAC setup page on the Internet Services user interface. Refer to Configuring Common Access Card on page 13 for instructions. Select Cancel to close the System Properties window. Xerox Common Access Card Common Access Card Installation Guide 37 Determining the Domain in which your Card is Registered 38 Xerox Common Access Card Common Access Card Installation Guide .



[You're reading an excerpt. Click here to read official XEROX WORKCENTRE 5665 user guide](http://yourpdfguides.com/dref/3681092)
<http://yourpdfguides.com/dref/3681092>