




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for YAMAHA DGX-650. You'll find the answers to all your questions on the YAMAHA DGX-650 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual YAMAHA DGX-650
User guide YAMAHA DGX-650
Operating instructions YAMAHA DGX-650
Instructions for use YAMAHA DGX-650
Instruction manual YAMAHA DGX-650



[You're reading an excerpt. Click here to read official YAMAHA DGX-650 user guide](http://yourpdfguides.com/dref/5127429)
<http://yourpdfguides.com/dref/5127429>

Manual abstract:

□ MIDI Master Tuning • System exclusive messages for changing the Reverb Type, Chorus Type and DSP Type. 2 Messages for these control change numbers cannot be transmitted from the instrument itself. However, they may be transmitted when playing the accompaniment, Song or using the Harmony effect. @@@@ (Values for “l” are ignored. @ □ The values of “dd” are used for XG Master Tuning. @@@@ <Chorus Type> F0H, 43H, 1nH, 4CH, 02H, 01H, 20H, mmH, llH, F7H • mm : Chorus Type MSB • ll : Chorus Type LSB Refer to the Effect Type List on the Data List. <DSP Type> F0H, 43H, 1nH, 4CH, 02H, 01H, 40H, mmH, llH, F7H • mm: DSP Type MSB • ll: DSP Type LSB Refer to the Effect Type List on the Data List. 4 When the accompaniment is started, an FAH message is transmitted. When accompaniment is stopped, an FCH message is transmitted. @@.



[You're reading an excerpt. Click here to read official YAMAHA DGX-650 user guide](http://yourpdfguides.com/dref/5127429)
<http://yourpdfguides.com/dref/5127429>