



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for YAMAHA PSR-E243/YPT-240. You'll find the answers to all your questions on the YAMAHA PSR-E243/YPT-240 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.


User manual YAMAHA PSR-E243/YPT-240

User guide YAMAHA PSR-E243/YPT-240

Operating instructions YAMAHA PSR-E243/YPT-240

Instructions for use YAMAHA PSR-E243/YPT-240

Instruction manual YAMAHA PSR-E243/YPT-240



[You're reading an excerpt. Click here to read official YAMAHA PSR-E243/YPT-240 user guide](http://yourpdfguides.com/dref/5065652)

<http://yourpdfguides.com/dref/5065652>

Manual abstract:

0 Remarks 0 - 127 : True voice ***** Note ON Note OFF Key's Ch's 0 9nH,v=1-127 *2 x x x x o o o o o o o o x o x x Control Change Prog Change o 0 - 127 ***** o x x x o o x x x x o x System Exclusive Common : Song Pos. : Song Sel. @@to #6 on page 3. OMNI ON , POLY OMNI OFF, POLY Mode 2 : OMNI ON , MONO Mode 4 : OMNI OFF, MONO o : Yes x : No PSR-E243/YPT-240 MIDI Reference MIDI Data Format NOTE: 1 By default (factory settings) the instrument ordinarily functions as a 16-channel multi-timbral tone generator, and incoming data does not affect the panel voices or panel settings. However, the MIDI messages listed below do affect the panel voices, auto accompaniment, and songs. @@@@However, they may be transmitted when playing the accompaniment, song or using the Harmony effect. @@@@4 When the accompaniment is started, an FAH message is transmitted. When accompaniment is stopped, an FCH message is transmitted. @@@@@However, the velocity of the accompaniment and Song playback does change in response to performance data received via MIDI. 3 Exclusive <GM System ON> F0H, 7EH, 7FH, 09H, 01H, F7H • This message automatically restores all default settings for the instrument, with the exception of MIDI Master Tuning.

@@ • The values of "mm" is used for MIDI Master Volume. @@ • The values of "nm" and "ll" are used for MIDI Master Tuning. @@Any values can be used for "n" and "cc". Effect map * When a Type LSB value is received that corresponds to no effect type, a value corresponding to the effect type (coming the closest to the specified value) is automatically set. .



[You're reading an excerpt. Click here to read official YAMAHA PSR-E243/YPT-240 user guide](http://yourpdfguides.com/dref/5065652)
<http://yourpdfguides.com/dref/5065652>