



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for YAMAHA RS-500. You'll find the answers to all your questions on the YAMAHA RS-500 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual YAMAHA RS-500  
User guide YAMAHA RS-500  
Operating instructions YAMAHA RS-500  
Instructions for use YAMAHA RS-500  
Instruction manual YAMAHA RS-500

**YAMAHA**

**DTX**  
drums

ELECTRONIC DRUM RACK  
**RS500**  
**RS700**

Owner's Manual  
Bedienungsanleitung  
Mode d'emploi  
使用说明书  
取扱説明書

English  
Deutsch  
Français  
中文  
日本語  
EN  
DE  
FR  
ZH  
JA



[You're reading an excerpt. Click here to read official YAMAHA RS-500 user guide](http://yourpdfguides.com/dref/3878046)  
<http://yourpdfguides.com/dref/3878046>

**Manual abstract:**

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich. Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.  
YAMAHA NORTH AMERICA CANADA Yamaha Canada Music Ltd. @ @90620, U.S.A. @ @ @ @Ctra. de la Coruna km. @ @The Music House 147 Skiathou Street, 112-55 Athens, Greece Tel: 01-228 2160 Yamaha Scandinavia AB J. A.

Wettergrens Gata 1, Box 30053 S-400 43 Göteborg, Sweden Tel: 031 89 34 00 YS Copenhagen Liaison Office Generatorvej 6A, DK-2730 Herlev, Denmark Tel: 44 92 49 00 F-Musiikki Oy Kluuvikatu 6, P.O. Box 260, SF-00101 Helsinki, Finland Tel: 09 618511 Norsk filial av Yamaha Scandinavia AB Grini Næringspark 1, N-1345 Østerås, Norway Tel: 67 16 77 70 Skifan HF Skeifan 17 P.O. Box 8120, IS-128 Reykjavik, Iceland Tel: 525 5000 Yamaha Music (Russia) Room 37, bld.

7, Kievskaya street, Moscow, 121059, Russia Tel: 495 626 5005 Yamaha Music Europe GmbH Siemensstraße 22-34, 25462 Rellingen, Germany Tel: +49-4101-3030 HONG KONG ITALY Tom Lee Music Co., Ltd. 11/F., Silvercord Tower 1, 30 Canton Road, Tsimshatsui, Kowloon, Hong Kong Tel: 2737-7688 Yamaha Music India Pvt. Ltd.

@ @ Yamaha Musik Indonesia (Distributor) PT. Nusantik Gedung Yamaha Music Center, Jalan Jend. Gatot Subroto Kav. 4, Jakarta 12930, Indonesia Tel: 021-520-2577 Yamaha Music Korea Ltd. 8F, 9F, Dongsung Bldg. @ @ @ @ Puyat Avenue, P.O. @ @ @ @ 3F, #6, Sec.2, Nan Jing E. Rd.

Taipei, Taiwan 104, R.O.C. Tel: 02-2511-8688 Siam Music Yamaha Co., Ltd. 4, 6, 15 and 16th floor, Siam Motors Building, 891/1 Rama 1 Road, Wangmai, Pathumwan, Bangkok 10330, Thailand Tel: 02-215-2622 Yamaha Corporation, Asia-Pacific Sales & Marketing Group Nakazawa-cho 10-1, Naka-ku, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2313 INDIA U.S.A. SPAIN/PORTUGAL INDONESIA CENTRAL & SOUTH AMERICA MEXICO Yamaha de México S.

A. de C.V. Calz. Javier Rojo Gómez #1149, Col.

Guadalupe del Moral C.P. 09300, México, D.F., México Yamaha Musical do Brasil Ltda.

Rua Joaquim Floriano, 913 - 4' andar, Itaim Bibi, CEP 04534-013 Sao Paulo, SP. BRAZIL Tel: 011-3704-1377 Yamaha Music Latin America, S.A. Sucursal de Argentina Olga Cossettini 1553, Piso 4 Norte Madero Este-C1107CEK Buenos Aires, Argentina Tel: 011-4119-7000 GREECE SWEDEN KOREA Tel: 55-5804-0600 BRAZIL DENMARK MALAYSIA ARGENTINA FINLAND PHILIPPINES NORWAY PANAMA AND OTHER LATIN AMERICAN COUNTRIES/ CARIBBEAN COUNTRIES SINGAPORE Yamaha Music Latin America, S.A. @ @ Ltd. @ @ Oddzial w Polsce ul. @ @ Ltd. @ @ @ @ Always assemble this product with adult supervision. @ @ The sharp holder ends may result in injury.

@ @ @ @ @ @ Always set the product on a flat and solid surface. @ @ Do not alter the product. Doing so may result in injury or damage/deterioration to the product. Do not sit or step on the rack. The rack may overturn or be damaged, resulting in injury. @ @ They may become pinched, resulting in injury. Be careful around pipe ends, inside the pipe and screw ends. Metal shavings, etc. may injure your fingers. Do not attach acoustic drums to the electronic drum rack.

@ @ It may result in damage. @ @ @ @ When cleaning the product, do not use benzine, thinner or alcohol as it may result in discoloration or deformation. Please wipe with a soft cloth or a damp cloth that has been wrung out thoroughly. If the product is soiled or sticky, use a neutral detergent on a cloth then wipe with a damp cloth that has been wrung out thoroughly to remove any remaining detergent. Also pay close attention so as not to let the water and detergent come into contact with the cushions used in the product; doing so may result in deterioration.

RS500/RS700 Owner's Manual 1 Setting up RS500 1. @ @ @ @ @ @ @ @ @ @ Loosen the bolt r, and as shown in Figure 3, raise up the cymbal holder located on the left. Following this, retighten the bolt r. When tightening the bolt, ensure that the black sleeve is positioned inside the clamp's mounting hole. 6. Loosen the bolts t, and as shown in Figure 3, rotate upward the cymbal holder located on the right. Following this, retighten the bolts t. 7. Loosen the bolts e and open up the pipe q to position it as shown in Figure 3. Then, rotate the snare clamp rod to the position shown in Figure 3. Retighten the bolts e. 8. Loosen the bolts of the tom holders and rotate the three tom holders into the positions shown in Figure 3. @ @ @ @ Yamaha Corp. @ @ @ @ Remove the rack from its box and stand it up with the drum trigger module clamp positioned on the right as shown in Figure 1.

2. With the rack standing up, loosen the bolts q located on the right and rotate the right leg clockwise from the left until it comes fully around as shown in Figure 1 Top view. The bolts q can be found on the rear of the clamp on the right pillar, which is located behind the left leg. Left pillar Right pillar Right pillar Left leg Bolts q 2 Drum trigger module clamp Right leg Right pillar Right leg Left leg Left pillar.



[You're reading an excerpt. Click here to read official YAMAHA](#)

[RS-500 user guide](#)

<http://yourpdfguides.com/dref/3878046>