



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ZENITH ZN411. You'll find the answers to all your questions on the ZENITH ZN411 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual ZENITH ZN411**  
**User guide ZENITH ZN411**  
**Operating instructions ZENITH ZN411**  
**Instructions for use ZENITH ZN411**  
**Instruction manual ZENITH ZN411**



ZN411  
Front Cover Art



[You're reading an excerpt. Click here to read official ZENITH ZN411 user guide](http://yourpdfguides.com/dref/435793)  
<http://yourpdfguides.com/dref/435793>

*Manual abstract:*

.....  
.....  
.....

.....  
.....  
.....

*... 3 Setup .....*

.....  
.....  
.....

.....  
.....  
.....

*..... 4 Battery Installation ....*

.....  
.....  
.....

*..... 4 Battery Saver .....*

.....  
.....  
.....

.....  
.....  
.....

*.. 4 Code Saver .....*

.....  
.....  
.....

*. 4 Power-On default ....*

.....  
.....

.....  
.....  
.....

*. 5 TV Punch Through .....*

.....  
.....  
.....

*5 VCR Punch Through .....*

.....  
.....  
.....

*..... 5 Code Setup ....*

.....  
.....  
.....

.....  
.....  
.....  
..... 5 Button Functions .....

.....  
.....  
.....  
.....

.....  
..... 6 Advanced DVD Button Functions ...  
.....  
.....

..... 8 TV/VCR Punch-Through .....

..... 9 TV/VCR and TV/DVD Combo units ...  
.....  
.....  
..... 9 Code Entry .....

.....  
.....  
.....  
.....

.....  
.....  
..... 10 Direct Code Entry .....

.....  
.....  
.....  
.....

..... 10 Code Search .....

.....  
.....  
.....  
.....

..... 11 Code Identification .

.....  
.....  
.....

.....  
.....  
..... 12 Sleep Timer .....

.....  
.....  
.....  
.....

..... 13 Code List ..

.....  
.....  
.....  
.....  
.....

.....

.....

... 13 Product Operation .....

.....

.....

.....

.....

.....

18 Troubleshooting .....

.....

.....

.....

.....

.....

19 Introduction Congratulations on your purchase of a Zenith Universal Remote Control. Zenith Universal Remotes let you replace a broken or lost remote or combine more than one remote into one. This remote control operates the common features of most but not all models and brands of IR Infrared Controlled Video Equipment. This remote may provide functions that are not available on your equipment. Some functions of your particular equipment (e.g. menu functions) may not be controlled by this remote. In such cases, use the original remote control for your equipment. @@@@ On the back of the remote, push down on the tab and lift the cover off.

2. @@3. @@@@ You can either setup the remote using the code for your brand of product, from the code tables, or you can search through the library of codes until you find a code that works for your product. NOTE: You can store any kind of code under any mode (except TV). I.

E. you can store a VCR code under the CBL key, or a DVD code under the VCR key, etc. However, you can only store TV codes under the TV key. Code Saver You will have up to 10 minutes to change the batteries in your remote without losing codes you have programmed. However, do not press any buttons until batteries are installed in the remote.

If buttons are pressed without batteries in the remote, all codes will be lost. Code Search. 4 5 Button Functions Some buttons on the remote might have functions that are referred to by different names on the device you are controlling. E.G. Prev. Ch. may be called RECALL, or ENTER may be called DISPLAY. These differences depend on the brand and model of your product. Also, this remote can only operate features that exist on your product.

E.G., your product must be equipped with Prev. Ch. ability for the Prev. Ch. button to operate this feature. TV, VCR, DVD, CBL Selects product to be operated. @@MENU In/Out Toggles in and out of menu mode. Accesses the Menu functions of the device you are controlling.

Prev. Ch. Returns to the previously selected channel, or DVD repeat toggle. @@ Use for OK/Select in Menu mode. Code Search For setup.

@@NUMBERS Enter numbers for direct channel selection. @@Note: The REC button must be pressed TWICE to record from your VCR.

@@@CHAPTER +/controls DVD track selection i.e. DVD Track Skip Up/Down (in DVD mode).

Note the DVD Transport keys also control DVD when in DVD Mode. @@Also operates DVD Scan +/- Advanced Button Functions DVD Scan+ and Scan- buttons control the speed of Fast Forward and Reverse Playback respectively. Chapter+ and Chapter- buttons respectively locate the succeeding or preceding Chapters or Tracks on a disc. Repeat button performs DVD players "A-B Repeat" (or RPT A.B) function for repeat play of current Chapter or Track. Play button is used to start Disc playback and for Menu selection on some DVD players. Stop button stops Disc playback. Pause button will pause Disc playback - press Play to resume. Note - in DVD Mode the INPUT button activates the DVD Player's SETUP Menu.

MENU IN/OUT The Menu In/Out button allows you to toggle in and out of Menu Mode. Pressing Menu In/Out brings up your device Menu. While in Menu mode the remote's red indicator light blinks continuously. The remote will exit Menu Mode after 20 seconds if no keys are pressed. While Menu Mode is active, the Menu, Channel, Volume, Mute and Mode keys perform the following functions: MENU IN/OUT Exits/Enters Menu mode. CHANNEL UP/DOWN Up/Down commands for onscreen Menu navigation. VOLUME UP/DOWN Right/Left commands for onscreen Menu navigation. MUTE OK/Select command for on-screen Menu selection. @@@@ Release the Code Search button. 2.

Press and release the desired mode button (TV, VCR, etc.). The red indicator blinks, then stays lit. 3. Enter the 3 digit code from the code tables.

Note: after a valid code entry, the red indicator turns off. For an invalid code, the red indicator flashes. 4. With your device on, press CHANNEL Up. If the device responds, no further programming is required.

@@2. Programming with Code Search 1. Manually turn on the device (TV, VCR, etc.) to be controlled. 2. Press and hold Code Search button until the red indicator stays on. Release the Code Search button. 3. Press and release the desired mode button (TV, VCR, etc.).

The red indicator blinks, then stays lit. 4. @@The red indicator blinks, then stays lit. @@Pressing Channel Up changes direction to forward again. Press and release the Mute button to install the code. @@@@press DVD in step 2, page 10, and then enter ANY VCR code. Then follow the steps above.

@@@This simplifies the process if you find that several preprogrammed codes operate your device by allowing you to bypass codes already tried. 1. 3.

Write your codes down here for easy reference later. Type TV VCR DVD CBL Type stored TV 2. Code 3. 4. 10 11 Code Identification Code Identification 1. Press and hold Code Search button until the red indicator stays on. Release the Code Search button. 2. Press and release the desired mode button (TV, VCR, etc.).

The red indicator blinks, then stays lit. 3. Press and release the Code Search button. The indicator light blinks off. 4. To find the first digit for the code stored under the mode key pressed in step 2, press each numeric key from 0-9 in turn. When the indicator light blinks off the number you pressed is the first digit for the code you are searching for. 5. @@6. @@Remote is to be in TV mode to set a Sleep Timer.

This feature works even if your TV does not have this feature. 1. Press and release the TV Mode key. 2. @@2-3 seconds). 3. Release Sleep button. 4. Press and release the numeric keys (01-99) for the time required. @@5.

TV Sleep Timer now set. 6. Leave the Remote pointing towards the TV with an unobstructed path. @@ADMIRAL ..

.....  
.....

701 ADVENTURA .....

.....  
.. AIKO ..  
.....

.....  
.....  
.....  
. AIWA .....

.....  
.....  
.. 121 ALLERON ...  
.....

.....  
. AMARK ....  
.....  
.....

.....  
AMTRON .....

.....  
..... AKAI ....  
.....  
.....

..... AMSTRAD .  
.....  
.....

... ANAM NATIONAL . 104 .....  
.....  
.....

... 901 906 AOC .....

.....  
002 003 102 ....  
.....

..... 217 302 502 ARCHER ....  
.....  
.....

... AUDIOVOX .....

.....  
.....  
..... BANG & OLUFSEN .....

... BELCOR .....

.. BELL & HOWELL .....

.....  
.....  
.....  
.... 601 BRADFORD .  
.....

.....  
. BROKSONIC ....  
..T C ..  
.....

..... 002 003 102 ..  
.....  
.....  
.....

..... 112 502 512 MULTITECH ...  
.....  
.....  
..... 906 MULTIVISION ....

.....  
... 010 NAD ..  
.....  
..... 002 120 502 512 NEC .....

..... 002 102 110 111 ..  
.....  
.....  
..... 502 510 602 901 NIKEI .

.....  
.....  
.....  
.....

. 805 NIKKO .....

.....  
. 002 407 502 NTC ....  
.....

.....  
.....  
.....  
. 407 ONKING .....

.....  
.....  
.... 805 ONWA .  
.....

.....  
... 805 906 OPTIMUS ..  
.....  
.....

. 120 618 OPTONICA .....

.....  
. 111 918 ORION ....  
.....

.. 105 115 713 PANASONIC ..... 007 107 416 ..  
... 516 608 618 718 807 901 PHILCO ..  
.... 002 009 102 109 .

.....

.....  
309 402 408 502 .....  
.....  
.....  
. 508 807 901 914 PHILIPS ..... 002 009 020 109 ....  
.....  
.... 122 202 209 210 222 .  
.....  
. 310 322 402 408 422 .....  
.... 508 510 807 822 901 .  
.....  
.....  
..... 914 917 919 922 PHILIPS/MAGNAVOX ... 020 ..  
.....  
.....  
.....  
..... 422 919 922 PILOT ...  
.....  
.....  
.....  
..... 002 PIONEER ..  
.....  
.....  
..... 002 120 ...  
.....  
.....  
.....  
..... 502 519 610 PORTLAND ....  
.....  
.....  
002 102 .....  
.....  
.....  
.....  
.....  
.. 407 502 PRECISION ...  
.....  
.....  
.....  
218 PRICE CLUB .....  
.....  
.....  
.....  
112 PRISM .....  
.....  
.....  
.....  
.. 107 PROSCAN .. 312 601 704 719 PROTON .....  
.....  
.. 002 119 220 ....  
.....  
.....  
.....  
.....  
502 820 910 PULSAR .



[You're reading an excerpt. Click here to read official ZENITH ZN411 user guide](#)





....  
.....

.....  
... 713 PULSER ..

....  
.....

.....  
.. 002 QUASAR ...

. 007 107 416 516 ....

..... 608 618 718 807 901 RADIO SHACK/REALISTIC .

.....  
... 002 021 111 117 406 ..

.....  
..... 502 506 601 618 704 ....

..... 705 805 818 906 914 RCA .

... 002 021 011 102 211 .

.....  
..... 302 312 318 320 406 ...

.. 409 411 420 502 511 514 ..... 519 601702 711 719 809 ..

... 811 901 909 911 912 914 RHAPSODY ..

....  
.....

..... 003 RUNCO .....

....  
....  
.....

..... 713 SAMPO .....

.. 002 119 502 818 SAMSUNG .. 002 012 102 103 .

.... 112 212 502 512 818 914 SAMSUX .

.....  
.....

.....  
.. 502 SANSUI ....

.....  
.....

..... 115 215 SANYO .

....  
....  
.... 002 412 506 .....

.....  
.....  
522 612 619 902 SCOTCH .....

.....  
..... 002 502 SCOTT ....

....  
....  
. 002 004 105 .....

.....  
.. 206 502 805 906 SEARS ...

.....  
. 002 112 206 312 .....

.... 502 506 512 520 601 ..... 612 619 704 719 902 914 SHARP 002 013 014 111 502 .

.... 509 712 812 813 913 918 SHOGUN .

....  
.....

.....  
002 SIGNATURE .....  
. 601 701 903 SIMPSON ...  
.....

.....  
.. 402 SONIC ...  
.....  
.....

.....  
... 003 SONY ..  
.....  
... 202 414 708 801 SOUNDESIGN ... 002 206 402 ....

.....  
.....  
.....  
..... 502 805 906 SPECTRAVISION .....

..... 921 SQUAREVIEW ...  
.....  
.....  
.... 520 SSS .....

.....  
.....  
.. 002 805 906 STARLITE ...  
.....

.....  
. 906 SUPREMACY ....  
.....  
.....

019 SUPREME .....

.....  
.....  
..... 801 SYLVANIA .....

.... 002 009 109 .....

.....  
.. 209 309 402 408 502 ...  
.....

508 717 807 914 917 SYMPHONIC ..... 520 904 906 TANDY .....

.....  
.....  
.....  
.... 918 TATUNG .....

.....  
.....  
.....  
. 901 TECHNICS .....

.....  
.....  
249 550 847 PACE .....

.....  
.....  
.....  
... 854 PANASONIC .....

..... 452 647 PARAGON ...

.....  
.....  
.....

. 250 PHILIPS ..... 150 549 650 748 ....

.....  
.....

..... 750 848 850 948 PIONEER ...

..... 051 451 950 PULSAR ..

.....  
.....  
.....

..... 250 RADIO SHACK . 055 152 154 RCA ...

.....  
.....  
.....

..... 352 647 REALISTIC ....

.....  
.....

..... 548 REGAL .

.....  
.....  
.....

..... 849 REGENCY .

.....  
.....  
.....

... 349 REMBRANDT .....

.....

.. 947 RUNCO ...

.....  
.....

.....

.. 250 SAMSUNG ...

.....  
.....

049 051 SCIENTIFIC ATLANTA 248 .....

.....  
.....

..... 251 351 451 SIGNAL .

.....  
.....  
.....

. 049 449 SIGNATURE .....

.....

.. 947 SL MARX ...

.....  
.....

..... 049 SPRUCER ..

.....  
.....  
.....

... 647 STANDARD COMPONENTS .....

.....  
.....

.....  
.....  
.....  
... 551 STARCOM ..  
..... 348 449 747 STARGATE ...

.....  
... 049 449 STAR SIGHT ..  
.....  
.....  
.... 653 STAR SIGHT CABLE SERVICE .....

.....  
.....  
.....  
.. 352 STARQUEST .....

.....  
.....  
.. 449 STAR TRAK .....

.....  
... 253 TANDY ..  
.....  
.....

.....  
.. 651 TELEVIEW ...  
.....  
.....

.... 049 TELEWEST .....

.....  
.....  
..... 854 TEXSCAN .....

.....  
.....  
.....  
551 TOCOM .....

.... 048 751 952 TOSHIBA .....

.....  
.....  
.....  
.....  
250 TUSA .....

.....  
... 449 TV86 .....

.....  
.....  
.....

..... 350 UNIKA ...  
.....  
.....  
.. 448 548 748 UNITED ARTISTS .....

.. 847 UNITED CABLE .....

.....  
747 UNIVERSAL .....

..... 448 548 .

.....  
.....  
.....  
..... 648 748 851 VIDEOWAY ..

.....  
.....  
.....  
052 VIEWSTAR 149 150 350 651 VIDEO TECH .....

..... 656 ZENITH .

.....  
.....  
.. 054 154 250 .....

.... 353 354 450 553 653 .....

.....  
... 753 853 951 953 954 VCR ADMIRAL ..

.....  
.....  
.. ADVENTURA ...

.....  
.....  
.....  
AIKO .....

.....  
.....  
.....  
... AIWA .....

.....  
... 126 324 528 224 726 826 726 AKAI ..

.....  
.....  
.... 524 624 724 924 ALLEGRO .

.....  
.... 326 534 925 AMERICAN HIGH .... 130 226 ASHA ..

.....  
.....  
.....  
.....  
. 425 AUDIO DYNAMICS . 025 436 AUDIOVOX .....

.....  
.....  
.... 525 DAEWOO .....

.....  
.....  
.... 529 BELL & HOWELL .

.....  
.....  
..... 428 BEAUMARK .

.....  
.....  
.... 425 BROKSONIC .

.....  
.....  
... 227 325 .....

.....  
.....  
.....  
.....  
.. 530 626 632 CALIX .....

.....

.....  
.....  
... 525 CANDLE .....  
.....  
025 026 425 .....  
.....  
..... 525 625 725 825 CANNON ... 130 226 535 635 CAPEHART .  
.....  
.....  
... 135 534 CARVER .....  
.....  
.....  
.....  
.. 330 CCE .....  
.....  
.....  
.....  
. 230 826 CITIZEN ... 025 026 425 525 .....  
.....  
.....  
. 625 725 825 826 COLORTYME ....  
.....  
.....  
... 025 COLT .....  
.....  
.....  
.....  
..... 230 CRAIG ...  
.....  
. 230 425 426 525 CURTIS MATHES ....  
..... 025 ...  
.....  
.....  
... 124 130 226 324 ..  
.....  
.....  
..... 425 526 635 725 CYBERNEX .  
.....  
.....  
.....  
. 425 DAEWOO .. 026 135 625 626 .....  
.....  
.....  
... 726 825 826 926 DAYTRON .....  
.....  
.....  
.....  
... 135 DBX ..  
.....  
.....  
.....  
. 025 436 DIMENSIA ....  
.....  
.....  
.....  
124 DYNATECH .....  
.....  
..... 324 726 ELECTROHOME ..... 027 525 ELECTROPHONIC .

..... 525 EMERSON ..  
.....  
.. 027 028 127 ...  
.. 128 130 226 227 228 324 ..... 325 327 427 428 525 526 ...  
.. 527 528 625 626 627 628 ..... 630 634 724 726 727 735 ...  
.....  
.....  
.....  
..... 827 828 927 FISHER .....  
.. 025 029 129 328 ...  
.....  
.....  
... 330 426 428 928 FUJI .....  
.....  
.....  
.... 130 226 524 FUNAI .....  
.....  
324 726 924 GARRARD 7 .....  
.....  
.....  
.... 2 6 GE .....  
.....  
.....  
124 130 136 226 .....  
.....  
. 425 429 635 835 GOLDSTAR ....  
.... 025 236 525 GRADIENTE .  
.....  
..... 726 GO-VIDEO .  
.....  
... 139 438 537 HARLEY DAVIDSON ..  
... 726 HARMAN KARDON 025 930 HARWOOD .....  
.....  
.....  
. 230 HEADQUARTER ....  
..... 428 HITACHI .  
... 136 235 324 336 .....  
.....  
. 538 629 638 829 834 HI-Q ....  
.....  
.....  
.....  
.....  
. 426 INSTANT REPLAY .....  
.....  
130 .....  
.....  
.....  
.....  
..... 226 924 INTEQ ...  
.....  
.....  
.....  
..... 525 JCL ..

.....  
.....  
.....

..... 130 226 JC PENNEY ..

.....  
025 130 235 .....

..... 425 428 436 525 ....

.....  
.....  
..... 629 635 834 935 JENSEN ...

.....  
.....  
.... 235 629 JVC .

.....  
.....  
. 025 235 239 ....

.....  
.....  
.. 326 339 428 436 KENWOOD .....

.....  
.....  
.. 025 235 ...

.....  
.....  
. 428 436 725 KLH ....

.....  
.....  
..... 230 237 KODAK .

.....  
.....  
..... 130 226 525 LLOYD ..

.....  
.....  
. 324 726 LOGIK .....

.....  
.....  
..... 230 LXI .....

.....  
.....  
..... 525 MAGNAVOX .

.....  
.....  
130 226 330 5 .....

.....  
.....  
... 34 536 635 734 MAGNIN .....

.....  
.....  
425 MARANTZ 025 130 226 330 .....

.....  
.....  
... 428 436 530 535 725 MARTA .....

.....  
.....  
.....



.....  
.. 525 MATSUSHITA .....  
... 130 226 MEI ..  
.....  
.....

.....  
.. 130 226 MEMOREX ...  
.....  
130 224 226 .....

.....  
. 324 335 425 426 ....  
.....  
.....

.. 428 525 534 726 MGA .....  
.....  
.....  
.....

027 630 MGN TECHNOLOGY ..... 425 MIDLAND .....

.....  
.....  
.....  
..... 429 MINOLTA .

.....  
.....  
.. 629 834 MITSUBISHI ...  
.. 027 031 131 .....

..... 229 231 329 431 436 .....  
.....  
... @@631 MOTOROLA ..  
... 130 224 226 M T C .....

.....  
... 324 425 726 MULTITECH ..  
.....  
..... 324 425 .....

.....  
.....  
.....  
..... 726 429 230 NEC ..... 025 235 428 526 530 .

.....  
.. 725 731 831 931 436 NIKKO ...  
.....  
.....

.....  
.. 525 NOBLEX ...  
.....  
.....

..... 425 OLYMPUS .  
.....  
.....  
..... 130 226 OPTIMUS ....

..... 035 224 525 ....  
.....  
.....  
..... 537 737 837 937 OPTONICA ...

.....  
.. 537 631 ORION ...

.....  
.....

.....  
... 227 PANASONIC ..  
.... 035 039 130 .

.....

.. 226 635 636 937 938 PENTAX .... 136 629 725 834 PENTEX RESEARCH ....

. 025 PHILCO ....

.. 130 226 330 635 PHILIPS ...

.. 130 226 330 430 .....

.....  
... 434 439 536 631 ..

.....  
.....

.... 734 738 934 937 PHILIPS/MAGNAVOX ... 434 ...

.....  
.....  
.....

.....  
.....  
.....

. 934 PILOT 5 .....

.....  
.....  
.....

.. 2 5 PIONEER ... @@ 124 PROTEC .....

.....  
.....  
.....

.. 230 PULSAR .....

.....  
.....  
.....

534 QUARTER .....

.....  
.... 428 QUARTZ .

.....  
.....

.....  
. 428 QUASAR ....

.....  
.....

. 039 130 .....

.....  
.....  
.....

635 636 937 RCA ..... 033 124 130 133 136 .....

... 226 233 332 424 425 ..

.....

. 432 532 629 636 732 .....

.... 832 834 835 837 932 RADIOSHACK .

. 027 029 035 ....  
. 124 129 130 224 226 324 ..... 335 425 426 428 525 631 ...

. 635 726 737 835 837 937 RADIX .....  
.....  
.....  
.....

.. 525 RANDEX .....  
.....  
.....  
..... 525 REALISTIC .

..... 027 029 035 ...  
.. 124 129 130 224 226 324 ...  
.. 335 425 426 428 525 631 ...  
.....

635 726 737 837 937 REPLAY .....  
.....  
.....  
..... 938 RICOH ..

.....  
.....  
.....  
..... 936 RUNCO .

.....  
.....  
.....  
..... 534 SAMSUNG .

. 037 335 425 427 .....  
... 429 537 624 625 629 SANKY .  
.....  
.....

..... 224 534 SANSUI .....  
.....  
.....

235 333 436 SANYO ..... 328 425 426 428 SCOTT ...

... 325 327 433 625 .....  
.....  
.....  
..... 626 630 735 927 SEARS .....

... 029 129 130 226 .....  
.....  
.....  
..... 330 426 428 525 .....

.....  
.....  
.....  
..... 629 834 928 935 SHARP ....  
..... 027 224 324 338 .....

.....  
.....  
..... 631 637 737 825 SHINTOM .....

... 230 337 .....  
.....  
.....  
.....

.. 524 629 936 SHOGUN .....

.....

.....

..... 425 SIGNATURE .

.....

.....

.....

324 SINGER .....

.... 130 226 230 SONY .....

.....

.....

.. 034 038 138 .....

.....

.... 238 524 838 936 STS .

.....

..... 130 226 629 834 SYLVANIA ..

..... 130 324 330 ...

.....

.....

..... 536 630 635 726 SYMPHONIC ..

.. 225 324 726 TANDY .....

.....

.....

.. 324 428 TASHIKO .....

.....

.....

.... 525 TATUNG .

.....

.....

.....

. 235 TEAC .....

.....

.... 235 324 726 TECHNICS .....

.. 035 130 226 TEKNIKA ..

.....

.. 130 134 226 .....

.....

.....

.....

.. 324 525 726 TiVo .....

.....

.....

.....

738 838 TOSHIBA .....

. 029 330 433 .....

.....

.....

.. 625 629 630 735 TOTEVISION .....

.... 425 525 T M K .....

.....

.....

.. 425 526 828 UNITECH .....

.....

.....

.....  
... 425 VECTOR RESEARCH ..  
... 025 .....

.....  
.....  
.....  
.. 436 625 725 VICTOR .....

.....  
.....  
.....  
. 436 VIDEO CONCEPTS .. 025 027 .....

.....  
.....  
.....  
.. 436 625 725 VIDEOSONIC .....

.....  
. 425 WARDS ....  
... 027 130 224 226 ..  
... 230 234 324 425 426 525 ..... 625 629 631 726 735 834 WHITE WESTINGHOUSE ..

.....  
.....  
.....  
.....

..... 324 924 XR-1000 ..  
... 130 226 230 726 YAMAHA ..  
. 025 235 428 436 ZENITH ....  
. 030 036 125 326 ..... 436 437 524 525 534 632 ....

. 638 729 824 925 929 936 16 17 Product Operation After the batteries are installed and you have programmed the remote for the codes that operate your products, you can use your remote to operate a TV, VCR, Cable Box, etc. Troubleshooting Remote does not operate your product. . . . Press the mode button of the product you want to control. Program the remote with a new code. Install new batteries. (You might have to reprogram your remote after installing new batteries.) Remote may not be compatible with your product. Remote does not operate some features of your product. . . Program remote with a new code.

Remote may not be able to operate all features of your product or button names might be different than your product. TV (Press TV First) Indicator light blinks after you program a product code. . . VCR (Press VCR First) DVD Player (Press DVD first) Remote did not accept the code. Try to program the code again or try a different code. Cable Box (Press CBL first) CD Player (Press CD first) To Operate: 1.

Press the TV, VCR, DVD, CBL, etc. button (depending on which product you want to operate). 2. Aim the remote at the product. 3.

Press POWER to turn on the product. 4. Press other buttons to operate the features of your product. @@@@ @@@@ @@@@ @@@@ IN NO EVENT SHALL ZENITH BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER IN CONTRACT, TORT OR NEGLIGENCE. Some States do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some States do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific rights and you may also have other rights, which vary from State to State.



[You're reading an excerpt. Click here to read official ZENITH ZN411 user guide](http://yourpdfguides.com/dref/435793)  
<http://yourpdfguides.com/dref/435793>