Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 31P700 TO 31P799. You'll find the answers to all your questions on the BRIGGS & STRATTON 31P700 TO 31P799 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 31P700 TO 31P799
User guide BRIGGS & STRATTON 31P700 TO 31P799
Operating instructions BRIGGS & STRATTON 31P700 TO 31P799
Instructions for use BRIGGS & STRATTON 31P700 TO 31P799
Instruction manual BRIGGS & STRATTON 31P700 TO 31P799

FORM MS–5766–11/05/2007
REPLACES FORM MS–5766–06/26/2007
FILE IN SECT. 2 OF SERVICE MANUAL
31P700

Illustrated Parts List

Model Series

31P700

TYPE NUMBERS
0115 through 0602.

TABLE OF CONTENTS

Air Cleaner 5
Alternator 7
Blower Housing 5
Camshaft 2
Carburetor 4
Controls 7
Crankshaft 2
Cylinder 2
Cylinder Head 3
Electric Starter 7
Engine Sump 2
Exhaust System 5
Flywheel 6
Fuel Supply 4
Gasket Set – Engine 2
Gasket Set – Valve 3
Governor Spring 7
Ignition 7
Intake Manifold 3
Kit – Carburetor Overhaul 4
Lubrication 3
Operator's Manual 2
Piston, Rings, Connecting Rod 2
Valves 3
Warnining Label 2

PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

You're reading an excerpt. Click here to read official BRIGGS & STRATTON 31P700 TO 31P799 user guide
http://yourpdfguides.com/dref/3640134

Manual abstract:

2 OF SERVICE MANUAL 31P700 Illustrated Parts List Model Series 31P700 TYPE NUMBERS 0115 through 0602. TABLE OF CONTENTS Air Cleaner . . .

. . . . . .
. . . . .
. . . . .
. . . . . 5 Alternator . . . .

. . . . . .
. . . . .
. . . . .
. . 7 Blower Housing . . . . . .

. . . . . .
. . . 5 Camshaft . .
. . . . .
. . . . . .

. . . . . .
2 Carburetor . . . . .
. . . . .
. . . . . .

. . . . . 4 Controls . . . .
. . . . .
. . . . .
. . . . . .

. . . . 7 Crankshaft . . . . . .
. . . . .
. . . . .
. . . . . 2 Cylinder .

. . . . . .
. . . . .
. . . . .
. . . . . 2 Cylinder Head . . .

. . . . . .
. . . . .
. . . . 3 Electric Starter .
. . . . . .

. . . . . .
. 7 Engine Sump . . . .
. . . . .
. . . . . .

. . . . 2 Exhaust System . . . . . .
. . . . .
. . . . .
. . . . 5 Flywheel . . . . . .

. . . . . .
. . . . .
. . . . .
. 6 Fuel Supply . . . . . .

. . . . . .
. . . . .
. 4 Gasket Set - Engine . . . .
. . . . . .

. . . 2 Gasket Set - Valve . . . . . .
. . . . .
. . . . .
. 3 Governor Spring . . . . . .

. . . . . .
. 7 Ignition . . . .
. . . . .
. . . . . .

. . . . . .
7 Intake Manifold . . . . .
. . . . .
. . . . . .

. 3 Kit - Carburetor Overhaul . . . . . .
. . . 4 Lubrication . .
. . . . .
. . . . . .

. . . . . 3 Operator's Manual . .
. . . . .
. . . . .
. . . . . 2 Piston, Rings, Connecting Rod . . . .

. . . 2 Valves . . . . . .
. . . . .
. . . . .
. . . . . .

. . . 3 Warnining Label . . . . . .
. . . . .
. . . . .
. . . 2 PRINTED IN U.S.A. COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation. 31P700 1058 OPERATOR'S MANUAL 29 32 1319 WARNING LABEL 28 27 REQUIRED when replacing parts with warning labels affixed. 43 11 25 27 10 584 850 9 26 306 1264 1263 307 1 2 358 ENGINE GASKET SET 3 12 883 943 7 20 51 9 524 617 4 4A 552 691 842 868 1022 1266 16 46 45 24 1017 146 718 691 3 15 12 12 741 758 22 1270 757 759 20 20 415 5766-2 Assemblies include all parts shown in frames.

2 11/05/2007 31P700 847 523 842 1095 VALVE GASKET SET 7 525 51 868 1022 524 965 943 750 1024 238 1024A 51 7 35 635 383 1022 617 36 5 1027 33 42 34 868 42 13 1026 337 45 883 1034 850 1022 914 1023 50 617 50A 617 192 1029 830 51 51 186 54 53 654 5766-3 Assemblies include all parts shown in frames. 3 11/05/2007 31P700 125 131 141A 108A 634A 987 93 98 692 94 51 94A 125A 131A 130A 95A 987A 108B 634B 98A 141B 117A 118A 130 95 51 142 LMT / PART NUMBER LOCATIONS 105 133 104 117 106 127 187B 105A 1091 118 133A 104A 127A 135 137A 975A 137A 601 975 137 947 276A 276 950 WALBRO 276 137 142 617 634A 987 947A 1127 NIKKI 121 CARBURETOR OVERHAUL KIT 51 93 95 104 105 106 117 121A CARBURETOR OVERHAUL KIT 51 617 634B 137A 987A 1266A 127A 1266 1266 95A 104A 105A 977 CARBURETOR GASKET SET 51 137 276 240 240A 187B 918 601 601 385 387 385A 387A 1266 344 431 1266A 5766-4 Assemblies include all parts shown in frames. 4 11/05/2007 31P700 304 968 1267 305A 1040B 643 967 445 305 1036 EMISSIONS LABEL 300A 883 613B 81 613 864 883 823 676 676A 677 677 5766-5 Assemblies include all parts shown in frames. 5 11/05/2007 31P700 74 73 1005A 1070 415A 1005B 73A 1070A 1005 78 37 363 1044 23 1051 783 5766-6 Assemblies include all parts shown in frames. 6 11/05/2007 31P700 DUAL CIRCUIT 474A 877 1059 474B 877B TRI CIRCUIT 1059 474C 877C 10 AMP 1059 5/9 AMP REGULATED 878 878A 501A 526A 578 10/16 AMP REGULATED 501 526 NOTE: All stators use a No. 1119mounting screw. NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information. 789 309 1051 510 783 513 803 1090 462 579 797 802 616 404 227 505 614 562 216 202 232 268 269 271 222 209 311 310 801 789A 334 333 729 851 544 729B 729A 697 521 1054 503 356 188 265 559 270 267 5766-7 Assemblies include all parts shown in frames. 7 11/05/2007 31P700 REF.
NO. 1 2 3 4 PART NO. DESCRIPTION REF. NO. 15 PART NO.
DESCRIPTION REF. NO. PART NO. @@0123, 0124, 0126, 0130, 0131, 0132, 0136. @@@@------ Note ------ 697113 Tube-Breather (Used Before Code Date 07071900).
K697110 Gasket-Crankcase (.015" Thick) (Standard) 793988 Screw (Cylinder Head) (Used After Code Date 07011400). ------ Note ------ 690360 Screw (Cylinder Head) (Used Before Code Date 07011500). 691680 Plug-Oil Drain (Flush) Used on Type No(s). 0115, 0293. ------ Note ------ 690946 Plug-Oil Drain (Square Head) Used on Type No(s). 0116, 0117, 0120, 0121, 0122, 0123, 0124, 0125, 0126, 0130, 0131, 0132, 0133, 0134, 0136, 0137, 0296, 0299, 0337, 0348, 0366, 0367, 0371, 0378, 0492, 0565, 0581, 0602, 0899. 697127 Crankshaft ------ Note ------ 697516 Crankshaft Used on Type No(s). 0117, 0137, 0367. K791892 Seal-Oil (PTO Side) 692125 Screw (Crankcase Cover/Sump) 693557 Flywheel Used on Type No(s).

0293, 0296, 0299, 0337, 0378, 0492, 0565, 0581, 0602. ------ Note ------ 693556 Flywheel Used on Type No(s). 0115, 0116, 0120, 0121, 0122, 0125, 0133, 0134, 0136, 0137, 0348, 0349, 0366, 0371, 0899. 698282 Flywheel Used on Type No(s). 0117, 0123, 0124, 0126, 0130, 0131, 0132, 0367. 24 222698S Key-Flywheel 25 792507 Piston Assembly (Standard) ------ Note ------ 792648 Piston Assembly (.020" Oversize) 791937 Piston Assembly (Standard) Used on Type No(s). 0124, 0130, 0131, 0132, 0133, 0134, 0136, 0137. 793019 Piston Assembly (.020" Oversize) Used on Type No(s).
0124, 0130, 0131, 0132, 0133, 0134, 0136, 0137. 26 791936 Ring Set (Standard) (Used After Code Date 06010100). ------ Note ------ 792649 Ring Set (.020" Oversize) (Used After Code Date 06010100). 699051 Ring Set (Standard) (Used Before Code Date 06010200).
697559 Ring Set (.020" Oversize) (Used Before Code Date 06010200). 27 698469 Lock-Piston Pin 28 697099 Pin-Piston (Standard) 29 791631 Rod-Connecting (Standard) ------ Note ------ 794571 Rod- Connecting (Standard) Used on Type No(s). @@No. 358.

D Included in Carburetor Overhaul Kit-Ref. No. 121, or 121A. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No. 1095. Illustrations cover a range of engines.

@@8 11/05/2007 31P700 REF. NO. 32 PART NO. DESCRIPTION REF. NO. 81 93 94 94A 95 95A PART NO. @@NO. 135 PART NO. @@@@34 791935 Valve-Intake (Used After Code Date 06021200). @@@@0131.
@@73A 794437 Screen-Rotating (Used After Code Date 07040800). 74 697897 Screw (Rotating Screen) (Used Before Code Date 07040900). @@0131. @@0115. 691795 Spring- Governor Used on Type No(s).
0126, 0130, 0134. 690480 Spring- Governor Used on Type No(s). 0120, 0121, 0349. 260902 Spring- Governor Used on Type No(s). 0122.
@@No. 358. D Included in Carburetor Overhaul Kit-Ref. No. 121, or 121A. z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No.

1095. Illustrations cover a range of engines. @@9 11/05/2007 31P700 REF. NO. PART NO. DESCRIPTION REF. NO. 309 PART NO. DESCRIPTION REF. NO.
404 415 415A PART NO. @@@@@@@@@@0116, 0136. @@0123, 0131, 0132.

You're reading an excerpt. Click here to read official BRIGGS & STRATTON 31P700 TO 31P799 user guide
http://yourpdfguides.com/dref/3640134

690323 Screw (Starter Motor) ------ Note ------ 691263 Screw (Starter Motor) Used on Type No(s). 0123, 0131, 0132.
497608 Brush Set 795315 Armature-Magneto 691061 Screw (Magneto Armature) 491055S Plug-Spark Used on Type No(s). 0115, 0116, 0117, 0120, 0121, 0123, 0124, 0126, 0131, 0132, 0136, 0293, 0349, 0367, 0492, 0581, 0602. ------ Note ------ 691043 Plug-Spark Used on Type No(s). 0122, 0125, 0133, 0134, 0137, 0296, 0299, 0337, 0348, 0366, 0371, 0378, 0565. 792015 Plug-Spark Used on Type No(s).
0130. 693675 Screw (Cable Clamp) Used on Type No(s). 0120, 0121, 0122, 0137, 0299, 0337, 0565. 697089 Wire-Stop 794150 Gasket Set-Engine 19203 Puller-Flywheel 89838S Wrench-Spark Plug 694476 Screw (Fuel Pump) 690297 Screw (Fuel Pump) 697090 Pump-Fuel 808656 Pump-Fuel 691691 Washer (Governor Crank) 690283 Plug (Sump) 794129 Plug (Cover/Retainer) (Used After Code Date 07040800). 697122 Elbow-Intake 698083 Filter-Air Cleaner Cartridge (Non Washable) --634B 635 643 654 676 526A 823 544 830 842 676A 677 K Included in Engine Gasket Set-Ref. No. 358. D Included in Carburetor Overhaul Kit-Ref. No. 121, or 121A.

z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No. 1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 5766-11 Assemblies include all parts shown in frames. 11 11/05/2007 31P700 REF.
NO. 847 PART NO. DESCRIPTION REF. NO. 968 PART NO.
DESCRIPTION REF. NO. 1051 1054 1058 PART NO. DESCRIPTION 790442 Dipstick/Tube Assembly Used on Type No(s). @@------ Note ------ 790443 Dipstick/Tube Assembly Used on Type No(s).
@@100100 Sealant-Liquid (Rocker Cover Gasket and Breather Gasket) (Used After Code Date 07071800). 692424 Terminal-Spark Plug 697346 Adapter-Muffler Used on Type No(s). 0116, 0136. K690968 Seal-Valve 393456 Wire/Connector- Alternator (Dual Circuit) 393537 Wire/Connector- Alternator (Tri Circuit) 399916 Wire/Connector- Alternator (10 Amp Circuit) 398661 Harness-Alternator (Dual Circuit) 691955 Harness-Alternator (Tri Circuit) K692236 Gasket-Exhaust 691108 Screw (Rocker Cover) 791851 Hose-Vacuum K690589 Seal-O Ring (Oil Pump Cover) 694393 Solenoid-Fuel 699915 Solenoid-Fuel 691657 Screw-Float Bowl 499613 Cover-Oil Pump 697015 Filter-Pre Cleaner 699848 Cover-Air Cleaner (Red) ------ Note ------ 699986 Cover-Air Cleaner (Black) 975 495933 Bowl-Float 975A 699502 Bowl-Float 977 690192 Gasket Set-Carburetor 987 D691326 Seal-Throttle Shaft 987A D698777 Seal-Throttle Shaft 1005 794438 Fan-Flywheel (Used After Code Date 07040800). 1005A 794436 Fan-Flywheel (Used Before Code Date 07040900). @@@@@@1024A 794644 Pump-Oil (Used After Code Date 07051600). 1026 692003 Rod-Push (Intake) ------ Note ------ 692011 Rod-Push (Exhaust) 1027 492932S Filter-Oil 1029 691751 Arm-Rocker 1034 690822 Guide-Push Rod 1036 Label-Emissions (Available From A Briggs & Stratton Authorized Dealer) 1040B 699852 Plate-Trim Used on Type No(s). 0117, 0123, 0124, 0126, 0130. 1044 698139 Screw (Flywheel) 691265 Ring-Retaining 280275 Tie-Cable 276344 Manual-Operator's ------ Note ------ MS3787 Manual- Operator's Used on Type No(s). 0136, 0293, 0602.

MS3788 Manual- Operator's Used on Type No(s). 0117, 0123, 0124, 0125, 0126, 0133, 0134, 0137, 0367. 698516 Kit-Screw/Washer 690372 Screw (Flywheel Fan) (Used Before Code Date 07040900). 690363 Screw (Flywheel Fan) (Used After Code Date 07040800). 691293 Retainer-Brush 691333 Cap-Limiter 690190 Gasket Set-Valve 691183 Screw (Alternator) 695407 Screw (Float Bowl) 697124 Reed-Breather 697104 Screw (Breather Reed) KD691917 Seal-O Ring (Intake Elbow) D697123 Seal-O Ring (Intake Elbow) 697424 Latch-Blower Housing (Red) ------ Note ------ 697419 Latch-Blower Housing (Black) 697156 Plug-AVS Counterweight 794467 jLabel-Warning 1059 1070 850 1070A 851 864 1090 1091 1095 1119 1127 1263 1264 1266 1266A 1267 868 877 877B 877C 878 878A 883 914 918 943 947 947A 950 965 967 1270 1319 K Included in Engine Gasket Set-Ref. No. 358. D Included in Carburetor Overhaul Kit-Ref. No. 121, or 121A.
z Included in Carburetor Gasket Set-Ref. No. 977. Included in Valve Gasket Set-Ref. No.
1095. Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine. 5766-12 Assemblies include all parts shown in frames. 12 11/05/2007 .

You're reading an excerpt. Click here to read official BRIGGS & STRATTON 31P700 TO 31P799 user guide
http://yourpdfguides.com/dref/3640134