Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DAEWOO DTQ-20U9SC. You'll find the answers to all your questions on the DAEWOO DTQ-20U9SC in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual DAEWOO DTQ-20U9SC**
**User guide DAEWOO DTQ-20U9SC**
**Operating instructions DAEWOO DTQ-20U9SC**
**Instructions for use DAEWOO DTQ-20U9SC**
**Instruction manual DAEWOO DTQ-20U9SC**

DAEWOO ELECTRONICS

# INSTRUCTION MANUAL

COLOR TELEVISION

MODEL: DTQ-20U9SC

You're reading an excerpt. Click here to read official DAEWOO DTQ-20U9SC user guide
http://yourpdfguides.com/dref/3405144

***Manual abstract:***

*REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk electric shock. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and servicing instructions in the literature accompanying the appliance. WARNING TO REDUCE THE RISK OF FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE. CAUTION CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE MANUFACTURER COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT. NOTE TO CATV SYSTEM INSTALLER THIS REMINDER IS PROVIDED TO CALL THE CATV SYSTEM INSTALLER'S ATTENTION TO ARTICLE 820-40 OF THE NEC THAT PROVIDES GUIDELINES FOR PROPER GROUNDING AND, IN PARTICULAR, SPECIFIES THAT THE CABLE GROUND SHALL BE CONNECTED TO THE GROUNDING SYSTEM OF THE BUILDING, AS CLOSE TO THE POINT OF CABLE ENTRY AS PRACTICAL. CAUTION The AC power cord provided with this product is polarized (one blade wider than the other). To prevent electrical shock, match wide blade of plug to wide slot, fully insert the AC plug into a standard 120V~, 60Hz polarized outlet. NOTE Never connect the plug to an electrical source other than one providing 120V~, 60Hz power. Use only the attached power cord.*

*If the polarized AC cord does not fit into a non-polarized outlet, do not cut or file the blade. You are responsible for having the obsolete outlet replaced with a polarized outlet. If you feel a static discharge when touching the unit, and the unit does not function, simply unplug the unit from the outlet. When you plug the unit back in, it should work normally. Do not install power cords near any heating element or cooking appliances.*

*SAFETY IMPORTANT SAFEGUARDS PLEASE READ ALL THESE INSTRUCTIONS REGARDING YOUR TELEVISION EQUIPMENT AND RETAIN FOR FUTURE REFERENCE. FOLLOW ALL WARNINGS AND INSTRUCTIONS MARKED ON THE TV RECEIVER. 1 2 3 Read all of these instructions. Save these instructions for later use. Unplug this television equipment from the wall outlet before cleaning.*

*Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. Do not use attachments not recommended by the television equipment manufacturer as they may result in the risk of fire, electric shock or other personal injury. @@@@@@@@Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer. 8 7 Slots and openings in the cabinet and the back or bottom are provided for ventilation and to ensure reliable operation of the television equipment; and to protect it from overheating, these openings, must not be blocked or covered. The openings should never be blocked by placing the television equipment on a bed, sofa, rug, or other similar surface. (This equipment should never be placed near or over a radiator or heat register.) This television equipment should not be placed in a built-in installation, such as a bookcase, unless proper ventilation is provided. This television equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied to your home, consult your television dealer or local power company.*

*This television equipment is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. 4 5 6 9 6A An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn. PORTABLE CART WARNING 10 Do not allow anything to rest on the power cord. Do not locate this television equipment where the cord will be abused by persons walking on it.*

*@@@@@@@@@@@Never spill liquid of any kind on the television equipment. @@Refer all servicing to qualified service personnel. @@@@(c) If the television equipment has been exposed to rain or water. @@@@@@@@@@@@@@@would like to thank you for choosing this color television receiver. @@@@@@If for any reason it does not, we want to hear about it.*

*Please write to us at the address above. Daewoo always welcomes comments and suggestions on this or any of our other products. On the other hand, when you discover the enjoyment, reliability and ease of use that is built into it, we hope that you will tell your friends, and consider Daewoo when you make your next purchase of home entertainment equipment. In addition to TV receivers, Daewoo produces a full line of audiovisual products built to the same high design, engineering, and manufacturing standards as this unit. Here are a few tips that will keep your TV receiver looking great and performing for years to come.*

*. Avoid putting it in excessively hot locations. Damage to the cabinet or premature component failures can result. . There are ventilation holes in the bottom and rear of the cabinet. Make sure that they remain unobstructed. Do not place the receiver on top of a thick cloth. . If you don't plan to use the receiver for several days, it's a good idea to unplug it from the power outlet. .*

*Many common household cleaning agents, sprays, solvents, and polishes will cause permanent damage to the surface of the cabinet. The best cleaning agents are mild soap and a damp cloth. Again, thank you for choosing this Daewoo product. We have employed advanced engineering techniques in its design, and manufactured it in one of the world's most up-to-date production facilities. The result is a TV receiver that we know you will be as proud to own as we were to create. Very truly yours, Daewoo Electronics America Inc. Antennas with two sets of leads You might have two sets of leads from your antenna system, especially if you have one antenna for VHF signals and one antenna for UHF signals. If your antenna system has both a coaxial lead and twin 300-ohm leads, you must obtain a combiner (available at your local electronics store). Press or screw the coaxial lead onto the combiner; place the twin leads underneath the screws on the combiner and tighten the screws. @@@@Do the same with the other set of twin leads.*

*@@@@You will need to keep your TV tuned to channel 3 or 4 and change channels using the converter box. If your cable system only requires you to use a converter box for some channels (i. e. pay-TV channels), follow these steps: Find the primary incoming coaxial cable. Plug this cable into a splitter (available at your local electronics store).*

*Connect one coaxial cable between one OUT terminal on the splitter and the IN terminal on the converter box.*

You're reading an excerpt. Click here to read official DAEWOO DTQ-20U9SC user guide
http://yourpdfguides.com/dref/3405144

*Connect another coaxial cable between the other OUT terminal on the splitter and the B-IN terminal on an A/B switch (available at your local electronics store.) Connect a third coaxial cable between the OUT terminal on the converter box and the A-IN terminal on the A/B switch. Finally, connect a coaxial cable between the OUT terminal on the A/B switch and the antenna terminal on the back of your TV. When the A/B switch is in the A position, you need to change channels on the converter box (and your TV should be tuned to channel 3 o.*

You're reading an excerpt. Click here to read official DAEWOO DTQ-20U9SC user guide
http://yourpdfguides.com/dref/3405144