Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for YAMAHA PSR-E343/YPT-340. You'll find the answers to all your questions on the YAMAHA PSR-E343/YPT-340 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual YAMAHA PSR-E343/YPT-340
User guide YAMAHA PSR-E343/YPT-340
Operating instructions YAMAHA PSR-E343/YPT-340
Instructions for use YAMAHA PSR-E343/YPT-340
Instruction manual YAMAHA PSR-E343/YPT-340



You're reading an excerpt. Click here to read official YAMAHA PSR-E343/YPT-340 user guide
http://yourpdfguides.com/dref/5065654

Manual abstract:

*: Song Sel. : Tune System : Clock Real Time: Commands Aux :All Sound OFF :Reset All Cntrls :Local ON/OFF :All Notes OFF Mes- :Active Sense sages:Reset *1 Refer to #2 on page 3. Mode 1 : OMNI ON , POLY Mode 3 : OMNI OFF, POLY 2 PSR-E343/YPT-340 MIDI Reference MIDI Data Format NOTE: 1 By default (factory settings) the instrument ordinarily functions as a 16-channel multi-timbral tone generator, and incoming data does not affect the panel voices or panel settings. @@@@2 Messages for these control change numbers cannot be transmitted from the instrument itself. @@@@@@4 When the accompaniment is started, an FAH message is transmitted. When accompaniment is stopped, an FCH message is transmitted. @@@@@@• The values of "mm" is used for MIDI Master Volume. (Values for "ll" are ignored.) <MIDI Master Tuning> F0H, 43H, 1nH, 27H, 30H, 00H, 00H, mm, ll, cc, F7H • This message simultaneously changes the tuning value of all channels. @@@@Any values can be used for "n" and "cc".*

*Effect map * When a Type LSB value is received that corresponds to no effect type, a value corresponding to the effect type (coming the closest to the specified value) is automatically set. .*

You're reading an excerpt. Click here to read official YAMAHA PSR-E343/YPT-340 user guide

http://yourpdfguides.com/dref/5065654