



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SANYO FPW-EXA025. You'll find the answers to all your questions on the SANYO FPW-EXA025 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SANYO FPW-EXA025
User guide SANYO FPW-EXA025
Operating instructions SANYO FPW-EXA025
Instructions for use SANYO FPW-EXA025
Instruction manual SANYO FPW-EXA025

Think GAIA
For Life and the Earth

SANYO

Multi-Deck Self Service
Fresh Meat Merchandiser

FPW-EXA085
FPW-EXA025

**INSTALLATION AND SERVICE MANUAL
REMOTE TYPE DISPLAY CASE**



[You're reading an excerpt. Click here to read official SANYO FPW-EXA025 user guide](http://yourpdfguides.com/dref/3335417)

<http://yourpdfguides.com/dref/3335417>

Manual abstract:

..... 4 DIMENSIONS...

.....

.....

. 5 2.1 2.2 EXTERNAL DIMENSIONS.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 5 FOOTPRINT.....

..... 5 3 UNLOADING AND CARPENTRY PROCEDURES

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 6 3.1 3.2 3.3 3.

4 3.5 3.6 3.7 NSF CERTIFICATION. 6 LOCATION

.....

.... 6 SHIPPING DAMAGE .

. 6 UNLOADING INSTRUCTIONS & PRECAUTIONS

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.... 6 ALIGNING CASES.

..... @@@@8 Connecting cases. @9 3.7.1 3.7.

2 3.8 INSTALLING PATCH ENDS.....

.....

.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... *10 INSTALLING PRICE TAG MOLDING*

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... *11 INSTALLING KICKPLATE* .

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... *11 INSTALLING HANDRAIL AND BUMPER*

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

9.3.10.3.11.4 REFRIGERATION, PLUMBING & ELECTRICAL PROCEDURES...

.....

.....

.....

.....

.....

.....

.... 13.4.

1 PIPING (PLUMBING, REFRIGERATION)

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.... 13.4.2 ELECTRICAL DATA.... 14.4.

3.4.4 ELECTRICAL GUIDELINES & PRECAUTIONS

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 14 WIRING..

.....

.....

14 Wiring Color Code.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

... 14 Wiring Diagram ..

.....

.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
. 15 4.4.1 4.4.
2 5 OPERATION
..... 16 5.

1 5.2 LOAD LIMITS
16 INSTALLING FDA/NSF THERMOMETER

.....
.....

.....
.....
.....

.....
.....
.....

.....
.... 17 2 6 CARE AND CLEANING GUIDELINES.

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

. 18 6.1 6.2 6.3 6.4 6.5 6.6 EXTERIOR PANELS (DAILY CLEANING)...

.....
.....
.....

.....
.....
.....

.....

.....
.....
.....

.... 18 ACRYLIC SHELF GUARD & PRICE TAG MOLDING (DAILY CLEANING)

.....
.....
.....

.....
.....
.....

..... 18 SHELF SURFACES (DAILY CLEANING)..

.....
.....
.....

.....
.....
.....

.....
.....
.....

..... 19 SHELF ASSEMBLIES (WEEKLY CLEANING)

.....
.....
.....

.....
.....
.....

.....
.....
.....

..... 19 MIRRORS, FLUORESCENT LAMPS, DRAIN TRAP (MONTHLY CLEANING) ...

.....
.....
.....

.....
.....
.....

..... 20 HONEYCOMB ASSEMBLIES (AT LEAST EVERY 3 MONTHS)

.....
.....
.....

.....
.....
.....

..... 20 7 SERVICE

.....
.....

It is the responsibility of the purchaser/end user of this product to determine the location within the food storage area that best meets these code requirements . 17.6 Care and Cleaning Guidelines In order to keep merchandisers sanitary and in good working order, we recommend thorough periodic cleaning as follows: 6.1 Exterior Panels (Daily Cleaning) a. b.

c. d. Exterior panels should be cleaned with water only. Wet a soft cloth and wring it out to wipe down panels. You should follow by wiping down with If required, you may use a mild detergent and warm water to remove stains. water only in order to prevent discoloration. Take particular care to clean areas that may be exposed to salt or saline solutions. DO NOT use scrapers, blades or other sharp objects to remove adhesive, as you may damage panels. rubbing alcohol to remove adhesive if water and mild detergents alone are insufficient. You may use 6.

2 Acrylic Shelf Guard & Price Tag Molding (Daily Cleaning) a. b. c. d. Grasp shelf guard firmly and pull up.

Keep your eye on the price tag molding, as it may come loose. You may use a mild detergent, but should complete cleaning Carefully wipe the shelf guard using a soft, damp cloth. by wiping down each shelf guard with water only. You may remove the price tag molding easily when the shelf guards are removed.

Wipe down the entire price tag molding, taking care to remove food particles, drips, garbage, dust and any other foreign substances.

18.6.3 Shelf Surfaces (Daily Cleaning) a. b. Clean the entire shelf surface, preferably with water only. If required, you may use a mild detergent and warm water to remove stains. You should follow by wiping down with water only in order to prevent discoloration. Make sure to clean under mats or objects resting on the shelf surfaces. 6.4 a. b.

c. d. e. f. Shelf Assemblies (Weekly Cleaning) Start shelf assembly cleaning by turning all fluorescent lamps off. Remove all shelf guards and price tag molding (see Section 6.2 above). Disconnect all fluorescent lamp plugs, pulling by the terminals. DO NOT PULL ON CORDS. Remove shelves (see drawings below).

Thoroughly check the underside of each shelf for drips or other foreign substances and clean. Clean the entire shelf surface, preferably with water only. If required, you may use a mild detergent and warm water to remove stains. You should follow by wiping down with water only in order to prevent discoloration. Reset shelves by following the steps above in reverse order.

g. WARNING: MAKE SURE ALL FLUORESCENT LAMP PLUGS ARE PLACED FIRMLY IN THEIR SOCKETS. 19.6.5 1. 2.

Mirrors, Fluorescent Lamps, Drain Trap (Monthly Cleaning) Turn off the fluorescent lamps prior to cleaning. DO NOT place your weight on the shelves. means to reach them. If mirrors or lamps are difficult to reach, use a stepladder or other When cleaning mirrors and fluorescent lamps, Clean mirrors with a mild detergent and water, then dry with a non-abrasive cloth. Wipe fluorescent lamps with a soft, dry cloth. If required you may use a water-dampened cloth that has been squeezed well to remove most moisture. At this time you may also wish to check for lamps needing replacing. Please make sure to check and clean the drain trap at least once a month. Remove any material that has gathered in the drain trap and dispose of it. Clean the drain trap and put it back in its original position.

6.6 Honeycomb Assemblies (At least every 3 months) Because honeycomb assemblies may deform under pressure, DO NOT use vacuum cleaners to clean them. a. b. c. When merchandise is in place under the honeycomb assemblies, first cover the merchandise with a cloth or other material to keep dust from falling. Remove honeycomb assemblies by pulling down on the wire clips attached to the assemblies. Rinse honeycombs in running water in order to flush out dust, etc. @@@@ Unplug the fan motor harness and push through hole in plenum. @@@@ -a -b Part Name Cap nut Fan motor Model SSC2B12CNHVB1

SSC2B12BVHVB1 Fan blade Bracket #128 #117 Part Code 9FL-2-6450-001-00 8FC-4-M110-000-10 8FC-4-M110-000-20 9FL-2-4230-001-00 9FL-2-4230-002-00 9FL-2-1750-017-01 FPW-EXA025 Quantity used 5 3 2 3 2 10 FPW-EXA085 Quantity used 3 3 3 6 23 7.

2 Replacing Electronic Ballasts To replace electronic ballasts: Remove the Exterior Top Panel. Unplug the electronic ballast harness(es). Remove the electronic ballast(s). Electronic Ballast Part Codes FPW-EXA025 Quantity used 3 FPW-EXA085 Quantity used 2 Type 4-lamp Model QHE4X32T8/UNV ISN-SC-1-CC-B Part Code 8FC-0-5400-000-40-1 3-lamp QHE3X32T8/UNV ISN-SC-1-CC-B 8FC-0-5400-000-30-1 1 - 2-lamp QHE2X32T8/UNV ISN-SC-1-CC-B 8FC-0-5400-000-20-1 - 1 24 7.3 Replacing Fluorescent Lamps The unit comes with covers placed over each fluorescent lamp.

Ensure that these covers are placed over the new lamps before reinstallation. LAMP COVER END CAP LAMP NOTICE! Always use Sanyo lamp covers and end caps when replacing lamp covers and end caps. Using non-Sanyo brand replacement parts can result in decreased performance and/or part lifetime. 25 26 27 MDMN 001.04 July 2008 .



[You're reading an excerpt. Click here to read official SANYO FPW-EXA025 user guide](http://yourpdfguides.com/dref/3335417)

<http://yourpdfguides.com/dref/3335417>