



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SHARP AN-3DG10S. You'll find the answers to all your questions on the SHARP AN-3DG10S in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual SHARP AN-3DG10S**  
**User guide SHARP AN-3DG10S**  
**Operating instructions SHARP AN-3DG10S**  
**Instructions for use SHARP AN-3DG10S**  
**Instruction manual SHARP AN-3DG10S**

**SHARP**

**AN-3DG10-S**  
**AN-3DG10-R**  
**AN-3DG10-A**

**3D GLASSES FOR SHARP 3D AQUOS**  
**OPERATION MANUAL**

**ENGLISH**



These 3D Glasses (AN-3DG10-S/R/A) are only for use with Sharp AQUOS LCD TVs supporting 3D. For details of how to make adjustments for 3D functions and to fully enjoy 3D viewing, refer to the operation manual of your TV.

## **IMPORTANT INFORMATION**

This product contains a CR Coin Lithium Battery which contains Perchlorate Material - special handling may apply, California residents, See [www.dtsc.ca.gov/hazardouswaste/perchlorate/](http://www.dtsc.ca.gov/hazardouswaste/perchlorate/)

**U.S.A. ONLY**

Printed in China  
10P08-CH-NM

EN-1



[You're reading an excerpt. Click here to read official SHARP AN-3DG10S user guide](http://yourpdfguides.com/dref/4176751)  
<http://yourpdfguides.com/dref/4176751>

**Manual abstract:**

For details of how to make adjustments for 3D functions and to fully enjoy 3D viewing, refer to the operation manual of your TV. **IMPORTANT INFORMATION** This product contains a CR Coin Lithium Battery which contains Perchlorate Material special handling may apply, California residents, See [www.dtscc.ca.gov/hazardouswaste/perchlorate/](http://www.dtscc.ca.gov/hazardouswaste/perchlorate/) U.S.A. ONLY Printed in China 10P08-CH-NM EN-1 DEAR SHARP CUSTOMER Thank you for your purchase of the 3D Glasses for Sharp 3D AQUOS. To ensure safety and many years of trouble-free operation of your product, please read the Important Safety Instructions carefully before using this product. **IMPORTANT SAFETY INSTRUCTIONS** 3D Glasses Prevention of accidental ingestion · Keep the batteries and band accessory out of the reach of small children.

Small children can accidentally swallow these parts. If a child accidentally swallows any of these parts, seek immediate medical attention. Do not disassemble · Do not disassemble or modify the 3D Glasses. Caution for lithium battery · Batteries must not be exposed to excessive heat such as direct sunlight or fire. · Replace only with the same or equivalent type of battery.

The battery may explode if improperly replaced. · Take care not to reverse the battery poles (+ and -) when loading the battery. Follow the correct procedure when loading the battery. Loading the battery incorrectly may damage the battery or cause it to leak battery fluid, which could result in a fire, injury or damage. Handling the 3D Glasses · Do not drop, exert pressure on, or step on the 3D Glasses.

Doing so may damage the glass section, which may result in injury. · Doing so may result in injury. Pay special attention when children are using this product. · Use the 3D Glasses only for the specified purpose. · Do not move around while wearing the 3D Glasses. · Remove dust and soil from the cloth. Any dust or other soiling on the cloth may result in scratches on the product. Do not use solvents such as benzene or thinners as doing so may cause the coating to peel off. · When cleaning the 3D Glasses, take care not to allow water or other fluids to come into contact with the glasses. · Do not use the 3D Glasses if they are cracked or broken.

EN-2 Using the 3D Glasses CAUTION · Not all consumers can experience and enjoy 3D TV. Some people suffer from stereo blindness which prevents them from perceiving the intended depth of 3D entertainment. Also, some people who watch 3D programming may experience initial feelings of motion sickness as they adjust to the picture. Others may experience headaches, eye fatigue or continued motion sickness. Like a roller coaster, the experience is not for everyone. · The 3D Glasses are precision equipment. Handle them with care. · Improper use of the 3D Glasses or failure to follow these instructions can result in eye strain. · If you experience dizziness, nausea, or other discomfort while viewing 3D images, immediately discontinue use of the 3D Glasses. Using the binocular disparity 3D system of the TV with incompatible 3D broadcasts or software can make images appear with a cross talk blur or create overlapping images.

The 3D Glasses can be worn over eyeglasses. · Be careful of your surroundings when viewing 3D images. · This may cause you to misjudge the distance to the TV screen and possibly result in injury if you accidentally hit the screen or surrounding objects. · The 3D Glasses are only recommended for people ages 5 and older. · When children are viewing 3D images, be sure a parent or guardian is present.

Monitor children viewing 3D images, and if they show signs of discomfort, immediately discontinue use of the 3D Glasses. · People with a known history of photosensitivity and people with heart problems or poor health should not use the 3D Glasses. This can worsen existing health conditions. · Do not use the 3D Glasses for other purposes (such as general eyeglasses, sunglasses, or protective goggles). · LED light · Blinks 3 times when the power is turned on.

· Blinks 2 times when 2D mode is selected. · Blinks 3 times when 3D mode is selected. · Blinks 6 times when the battery power is low. · Lights for 2 seconds when the power is turned off. Service terminal This terminal is for service use only. Please do not connect any other device to this terminal. Infrared receiver Receives an infrared signal sent from the TV. · Nose pad mount The dedicated nose pad can be mounted here. · Loosen the screw used to secure the battery cover. 2 Remove the battery cover.

7 Close the battery cover. Viewing 2D images When you press the power button twice while viewing 3D images, the LED light blinks 2 times and the 3D images switch to 2D images. Viewing 3D images When you press the power button twice while viewing 2D images, the LED light blinks 3 times and the 2D images switch to 3D images. Usage Range of the 3D Glasses The 3D Glasses can be used by receiving an infrared signal sent from the TV. 1 2 3 4 5 6 8 7 · Take care not to reverse the battery poles (+ and -) when loading the battery. · Used batteries should be disposed of strictly in accordance with the applicable local laws and regulations. EN-5 Using the 3D Glasses · These 3D Glasses are only for use with Sharp LCD TVs supporting 3D. 3D Glasses lenses · Do not apply pressure to the lenses of the 3D Glasses. Also, do not drop or bend the 3D Glasses. · Do not scratch the surface of the lenses of the 3D Glasses with a pointed instrument or other object.

Doing so may damage the 3D Glasses and reduce the quality of the 3D image. · Use only the cloth provided with the 3D Glasses to clean the lenses. 3D Glasses infrared receiver · Do not allow the infrared receiver to become dirty, and do not attach stickers to or otherwise cover the infrared receiver. Doing so may prevent the receiver from operating normally. · Doing so may cause the 3D Glasses to malfunction.

· Please use them within the specified usage temperature range. · Wear the 3D Glasses correctly. · If you lie on your side while watching the TV with 3D Glasses, the picture may look dark or may not be visible. · Be sure to stay within the warranty does not apply to any appearance items of the Product or if the serial number or model number affixed to the Product has been removed, defaced, changed, altered or tampered with. This warranty does not cover installation or signal reception problems.

This limited warranty will not apply if the Product has been or is being used in a commercial setting or application; this warranty is meant solely for the non-commercial, household use of the Product by consumers in their home or residence. If you intend to or already use this Product for commercial purposes or in a commercial setting, there are warranties available to cover your use of this Product, the terms of which may vary.



[You're reading an excerpt. Click here to read official SHARP](#)

[AN-3DG10S user guide](#)

<http://yourpdfguides.com/dref/4176751>

Please contact 1-888-GO-SHARP for further information. In order to enforce your rights under this limited warranty, you should follow the steps set forth below. @@@@IF, UNDER APPLICABLE STATE LAW, IMPLIED WARRANTIES MAY NOT VALIDLY BE DISCLAIMED OR EXCLUDED, THE DURATION OF SUCH IMPLIED WARRANTIES IS LIMITED TO THE PERIOD(S) FROM THE DATE OF PURCHASE SET FORTH BELOW. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE. The warranties given herein shall be the sole and exclusive warranties granted by Sharp and shall be the sole and exclusive remedy available to the purchaser and only for the time periods set forth herein. No other representations or promises made by anyone are permitted. Correction of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of Sharp to the purchaser with respect to the Product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict liability or otherwise.

@@@@AND PUERTO RICO. @@User replaceable batteries are not covered by this Limited Warranty. Warranty service is available from a Sharp Authorized Service Center located in the United States. To receive repair handling instructions, please contact Sharp toll free at 1-800-BE-SHARP (1-800-237-4277). If it is necessary to ship the Product for servicing, please ensure it is shipped prepaid, insured and packaged securely. Sharp shall not be responsible for lost, stolen or misdirected mail or for damage to the product incurred during shipping. Please have proof of purchase available when requesting warranty service. Warranty Period for this Product: Additional Exclusions: What to do to Obtain Service: TO OBTAIN PRODUCT INFORMATION OR PURCHASE ACCESSORIES, CALL 1-800-BE-SHARP OR VISIT [www.SharpUSA.com](http://www.SharpUSA.com) SHARP ELECTRONICS CORPORATION Sharp Plaza, Mahwah, New Jersey 07495-1163 SHARP CORPORATION SHARP CORPORATION .



[You're reading an excerpt. Click here to read official SHARP AN-3DG10S user guide](http://yourpdfguides.com/dref/4176751)  
<http://yourpdfguides.com/dref/4176751>