



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SILVERCREST KH 2355. You'll find the answers to all your questions on the SILVERCREST KH 2355 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SILVERCREST KH 2355  
User guide SILVERCREST KH 2355  
Operating instructions SILVERCREST KH 2355  
Instructions for use SILVERCREST KH 2355  
Instruction manual SILVERCREST KH 2355

B+C



**BLUETOOTH HANDS-FREE SET KH2355**  
 Operating instructions

**ΕΓΚΑΤΑΣΤΑΣΗ ΑΝΟΙΚΤΗΣ ΑΚΡΟΑΣΗΣ**  
 **BLUETOOTH KH2355**  
Οδηγίες χρήσης

**BLUETOOTH HÅNDFRI TIL BILEN**  
Betjeningsvejledning

KOMPERNASS GMBH · BURGSTRASSE 21 · D-44867 BOCHUM  
www.kompernass.com  
ID No.: KH2355-08/08-V2



[You're reading an excerpt. Click here to read official SILVERCREST KH 2355 user guide](http://yourpdfguides.com/dref/3956846)  
<http://yourpdfguides.com/dref/3956846>

**Manual abstract:**

Closely heed this information when operating the appliance. Should you have any further questions regarding use, please contact the service department responsible for your country. Keep these operating instructions in a safe place and pass them on to whomsoever might later acquire the appliance. When driving, your hands must ALWAYS be free to operate the vehicle safely. Traffic safety must ALWAYS take priority whilst driving. Only manipulate the hands-free appliance on those occasions in which the traffic situation permits it and in which you will not endanger, injure, obstruct or cause annoyance to other road users. Do not permit your concentration on the road traffic to be compromised by the manipulation and displays of the handsfree appliance! Become familiar with the operation of it before driving off and practice the safe operation of the facility! Install the hands-free appliance in the vehicle such that your view is not obstructed and that the appliance is not located in an impact zone in the passenger compartment or in the inflation area of airbags. Should you do so, appliance safety can no longer be assured and the warranty becomes void. Do not allow children and people subject to supervision play with the appliance, they could injure themselves or cause damage to the appliance. Do not connect it to a product that is not compatible.

The handsfree phone system uses both Bluetooth radio technology as well as a digital signal processor (DSP) to carry out telephone functions. This device may be used ONLY for private domestic purposes, not for industrial or commercial applications. The product at hand is, by default, NOT intended for use in medicinal, lifesaving or life support applications. All of the additional connecting cables and external devices used MUST match the safety-related, electromagnetic compatibility and shielding quality standards of the device at hand. With regard to CE Conformity, this device fulfills all of the relevant norms and guidelines.

In the event of modifications being made to the device without agreement from the manufacturer, compliance with these norms and guidelines can no longer be assured. Use only the accessories specified by the manufacturer. If you are using the device outside the territory of the Federal Republic of Germany you must pay heed to the national regulations resp. The laws of the country in which it is being used. Bluetooth is a wireless communication system with a short range.

It makes possible wireless connections between Bluetooth appliances, such as for example mobile telephones, PDA and PCs. The disturbance susceptibility through other users of the ISM Frequency Range, such as for example microwaves, WLAN (802.11b) or garage door openers, is minimised by so-called, "Frequency-Hopping". With Frequency-Hopping, a change of frequency levels takes place at up to 1600 times per second, thereby Bluetooth is also reckoned to be relatively tap-proof. The HSP (Headset-Profile) makes possible standard functions such as voice transference, as well as the acceptance and rejection of calls. The HFP (Handsfree-Profile) makes possible the hands-free call functions of a mobile telephone, for example with the help of voice commands. So that the hands-free appliance can function correctly, it is connected to the vehicle cigar lighter socket and provided with electricity from there. Ensure that the hands-free appliance engages completely and that the operation of the vehicle is not negatively influenced. It is possible that the cigar lighter only functions when the vehicle ignition is switched on. Use the hands-free appliance only when the motor is running.

Otherwise, the vehicle batteries could become discharged over an extended period of time. Press and hold the multi-function button 4 for 3 seconds, until a short and high signal tone is heard. Press and hold the multi-function button 4 for 3 seconds, until a long and deep signal tone is heard. Coupling the hands-free appliance with a mobile telephone The hands-free appliance has been especially developed for mobile telephones that support the Bluetooth Profile "Handsfree (HFP) and Headset (HSP)". Further information about Bluetooth radio technology is to be found in the operating instructions for your mobile telephone. Check to make sure the mobile telephone is switched on. You can now use the hands-free appliance. However, it can only be connected with one mobile telephone. After successful coupling, the following functions are available to you. Some of the described functions are only possible with a mobile telephone that supports the Handsfree Profile (HFP).

Use your mobile telephone in the usual way to make a call. Voice dialing is only available with mobile telephones that support this function. Further information regarding voice dialing is to be found in the operating instructions for your mobile telephone. Accepting and ending a call When you receive a call the LED status display 6 blinks and you hear a call tone from the hands-free appliance. If the ringing tone is switched off on your mobile phone, a call tone will not be emitted by the hands-free appliance.

Press the multi-function button 4 shortly once, to accept the call. You can also accept and terminate the call over the mobile telephone. Automatic call acceptance If automatic call acceptance is activated in the mobile telephone, it accepts the incoming call after a determined time period and then passes it on to the hands-free appliance. Further information regarding automatic call acceptance is to be found in the operating instructions for your mobile telephone. rejection of a call Press the multi-function button 4 for 3 seconds to reject an incoming telephone call.

Adjusting the volume of the hands-free appliance You can adjust the volume of the hands-free appliance with the assistance of the volume controller 3. During a call, turn the volume controller 3 until the desired volume level is heard. If you cannot connect the hands-free appliance with a compatible mobile telephone, proceed as follows: If you use several Bluetooth appliances, ensure that a previously created Bluetooth connection of the mobile telephone is separated. Ensure that the hands-free appliance is distanced a maximum of 10 metres from the mobile telephone and that there are no barriers or electronic devices between them. If these measures do not correct the problem, please contact the appropriate service partner for your country. Before cleaning, always separate the electricity supply from the appliance! NEVER submerge the appliance in water or other liquids! Do not permit liquids to permeate into the housing! Do not use strong detergents, solvents or abrasive cleaning agents to clean the appliance. Clean the housing surfaces with a slightly moist soft cloth. Do not dispose of the appliance in your normal domestic waste. This product is subject to the European guideline 2002/96/EC.



[You're reading an excerpt. Click here to read official SILVERCREST](#)

[KH 2355 user guide](#)

<http://yourpdfguides.com/dref/3956846>

*Dispose of the appliance through an approved dis-posal centre or at your community waste facility.*

*observe the currently applicable regulations. In case of doubt, please contact your waste disposal centre. The warranty for this appliance is for 3 years from the date of purchase. @@Please retain your receipt as proof of purchase date. @@Only in this way can a post-free despatch for your goods be assured. @@@@The warranty will become void in the event of abusive and improper handling, use of force and internal tampering not carried or approved by our authorized service branch. Your statutory rights are not restricted in any way by this warranty. We, Kompernaß GmbH, declare that the product KH 2355 Bluetooth® Vehicle Hands-Free Phone System complies with the fundamental requirements and other relevant regulations of the Vehicle Directive 2004/104/EC and the R&TTE Directive 99/5/EC from the Council of the European Union. The complete Conformity Declaration can be viewed at the Importers premises. Kompernaß GmbH does not accept, neither emphatically nor tacitly, any guarantee for the correctness or completeness of the content of this document.*

*Kompernaß GmbH retains for itself the right, at any time and without previous notice, to make amendments to this document or to withdraw it completely. .*



[You're reading an excerpt. Click here to read official SILVERCREST KH 2355 user guide](http://yourpdfguides.com/dref/3956846)  
<http://yourpdfguides.com/dref/3956846>