



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SILVERCREST SBTF 10 B2. You'll find the answers to all your questions on the SILVERCREST SBTF 10 B2 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SILVERCREST SBTF 10 B2
User guide SILVERCREST SBTF 10 B2
Operating instructions SILVERCREST SBTF 10 B2
Instructions for use SILVERCREST SBTF 10 B2
Instruction manual SILVERCREST SBTF 10 B2

SILVERCREST®

Bluetooth® Hands-Free Kit SBTF 10 B2

Bluetooth® Hands-Free Kit
Operating instructions

Bluetooth® handsfree
Návod k obsluze

Handsfree sada s funkciou Bluetooth®
Návod na obsluhu



KOMPERNASS GMBH
BURGSTRASSE 21 · D-44867 BOCHUM
www.kompernass.com
ID-Nr.: SBTF 10 B2-06/11-V2
IAN: 69169



[You're reading an excerpt. Click here to read official SILVERCREST SBTF 10 B2 user guide](http://yourpdfguides.com/dref/4225688)
<http://yourpdfguides.com/dref/4225688>

Manual abstract:

Closely heed this information when operating the appliance. Should you have any further questions regarding use, please contact the service department responsible for your country. Keep these operating instructions in a safe place and pass them on to whomsoever might later acquire the appliance. : This symbol points out the particular risks associated with handling, operation or manipulation. When driving, your hands must ALWAYS be free to operate the vehicle safely. Traffic safety must ALWAYS take priority whilst driving. Only manipulate the hands-free appliance on those occasions in which the traffic situation permits it and in which you will not endanger, injure, obstruct or cause annoyance to other road users. Do not permit your concentration on the road traffic to be compromised by the manipulation and displays of the handsfree appliance! Become familiar with the operation of it before driving off and practice the safe operation of the facility! Install the hands-free appliance in the vehicle such that your view is not obstructed and that the appliance is not located in an impact zone in the passenger compartment or in the inflation area of airbags. Should you do so, appliance safety can no longer be assured and the warranty becomes void. @@@@Do not connect it to a product that is not compatible.

@@@The Bluetooth® Hands-Free Kit SBTf 10 B2 is designed for use in vehicles with a voltage of 12-24 V. The handsfree phone system uses both Bluetooth® radio technology as well as a digital signal processor (DSP) to carry out telephone functions. In addition, mobile devices with an operating voltage of 5V (MP3 players, cell phones, etc.) can be charged via the USB port. This device may be used ONLY for private domestic purposes, not for industrial or commercial applications.

The product at hand is, by default, NOT intended for use in medicinal, lifesaving or life support applications. all of the additional connecting cables and external devices used MUST match the safety-related , electromagnetic compatability and shielding quality standards of the device at hand. With regard to CE Conformity, this device fulfills all of the relevant norms and guidelines. In the event of modifications being made to the device without agreement from the manufacturer, compliance with these norms and guidelines can no longer be assured. use only the accessories specified by the manufacturer.

If you are using the device outside the territory of the Federal Republic of Germany you must pay heed to the national regulations resp. The laws of the country in which it is being used. Bluetooth® is a wireless communication system with a short range. It makes possible wireless connections between Bluetooth® appliances, such as for example mobile telephones, PDA and PCs. The disturbance susceptibility through other users of the ISM Frequency Range, such as for example microwaves, WLAN (802. 116) or garage door openers , is minimised by so-called ,Frequency-Hopping". With Frequency-Hopping, a change of frequency levels takes place at up to 1600 times per second, thereby Bluetooth® is also reckoned to be relatively tap-proof. The HSP (Headset-Profil) makes possible standard functions such as voice transference, as well as the acceptance and rejection of calls. The HFP (Handsfree-Profil) makes possible the hands-free call functions of a mobile telephone, for example with the help of voice commands. So that the hands-free appliance can function correctly, it is connected to the vehicle cigar lighter socket or on-board power socket and provided with electricity from there.

Ensure that the hands-free appliance engages completely and that the operation of the vehicle is not negatively influenced. The LED status indicator 6 blinks twice every 3 seconds and a short high signal tone sounds once. It is possible that the cigar lighter only functions when the vehicle ignition is switched on.

Use the hands-free appliance only when the motor is running. Otherwise, the vehicle batteries could become discharged over an extended period of time. When you are not using the hands-free equipment remove it from the vehicles cigarette lighter socket. Store it in a dry, dust free location protected from direct sunlight. Press and hold the multi-function button 7 for 3 seconds, until a short and high signal tone is heard. Press and hold the multi-function button 7 for 3 seconds, until a long and deep signal tone is heard. @@@@ Check to make sure the mobile telephone is switched on.

@@@@@ You can now use the hands-free appliance. @@@@@@ However, it can only be connected with one mobiletelephone. @@@@Should a connection not be possible, the hands-free appliance nonetheless remains recognisable for other mobile telephones. To use the hands-free appliance with a linked mobile phone that is not the last used mobile phone, the connection must be made via the Bluetooth® menu of the mobile phone. If you wish separate the mobile telephone from the hands-free appliance, for example, to connect it to another Bluetooth® appliance: · You need not erase the coupling with the hands-free appliance in the Bluetooth® menu to separate the connection.

If you want to reconnect the hands-free appliance with the last used mobile phone: · Check to see that Bluetooth® is activated in the mobile telephone, then switch the hands-free appliance on. When connecting to a previously coupled mobile telephone it is not necessary to enter a pass-code. You can set your mobile telephone so that when the hands-free equipment is switched on a connection with the mobile telephone is automatically established. As soon as the hands-free equipment is connected to the previously coupled mobile telephone a short, high signal tone is emitted confirming the connection. Further information regarding automatic coupling can be found in your mobile telephone's operating instructions.

After successful coupling, the following functions are available to you. Some of the described functions are only possible with a mobile telephone that supports the Handsfree Profile (HFP). call function · Use your mobile telephone in the usual way to make a call. Voice dialing is only available with mobile telephones that support this function. Further information regarding voice dialing is to be found in the operating instructions for your mobile telephone. Accepting and ending a call When you receive a call the LED status display 6 blinks and you hear a call tone from the hands-free appliance. If the call signal in your mobile phone is switched off, the ringing tone is nonetheless sounded via the hands-free appliance. Press the multi-function button 7 shortly once, to accept the call. You can also accept and terminate the call over the mobile telephone. Automatic call acceptance If automatic call acceptance is activated in the mobile telephone, it accepts the incoming call after a determined time period and then passes it on to the hands-free appliance.



[You're reading an excerpt. Click here to read official SILVERCREST SBTf 10 B2 user guide](http://yourpdfguides.com/dref/4225688)

<http://yourpdfguides.com/dref/4225688>

Further information regarding automatic call acceptance is to be found in the operating instructions for your mobile telephone. rejection of a call · Press the multi-function button 7 for 3 seconds to reject an incoming telephone call. Adjusting the volume of the hands-free appliance You can adjust the sound volume level of the hands free device with the +/- buttons 3. During a call, repeatedly press the + resp. - buttons 3 until the desired sound volume level is obtained.

The attainment of the maximum sound volume level is indicated by a short signal tone. Power input (1000 mA) of the device which you want to charge.

Connect the device to be charged with the USB port 4 on the hands free device. The device now receives its power supply from the hands free device. If the device is equipped with a charging indicator light, this will indicate that the device is being charged.

@@@@@@@@ nEVER submerge the appliance in water or other liquids! Do not permit liquids to permeate into the housing! Do not use strong detergents, solvents or abrasive cleaning agents to clean the appliance. Clean the housing surfaces with a slightly moist soft cloth. Do not dispose of the appliance in your normal domestic waste. This product is subject to the European guideline 2002/96/EC. Dispose of the appliance through an approved disposal centre or at your community waste facility.

observe the currently applicable regulations. In case of doubt, please contact your waste disposal centre. The warranty for this appliance is for 3 years from the date of purchase. The appliance has been manufactured with care and meticulously examined before delivery. Please retain your receipt as proof of purchase.

In the event of a warranty claim, please make contact by telephone with our Service Department. Only in this way can a post-free despatch for your goods be assured. The warranty covers only claims for material and manufacturing defects, but not for trans.



[You're reading an excerpt. Click here to read official SILVERCREST SBTf 10 B2 user guide](http://yourpdfguides.com/dref/4225688)

<http://yourpdfguides.com/dref/4225688>