



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for KYOCERA TASKALFA 520I. You'll find the answers to all your questions on the KYOCERA TASKALFA 520I in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual KYOCERA TASKALFA 520I**

**User guide KYOCERA TASKALFA 520I**

**Operating instructions KYOCERA TASKALFA 520I**

**Instructions for use KYOCERA TASKALFA 520I**

**Instruction manual KYOCERA TASKALFA 520I**

OPERATION GUIDE

TASKalfa 420i/520i



TASKalfa 

 KYOCERA



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 520I user guide](http://yourpdfguides.com/dref/3409430)  
<http://yourpdfguides.com/dref/3409430>

**Manual abstract:**

@@A label shown in the illustration assures that the supplies are our own brand. In this Operation Guide, TASKalfa 420i/520i are referred to as 42 ppm model and 52 ppm model respectively. Included Guides The following guides are supplied with the machine. Refer to them as necessary. Operation Guide (This Guide) Describes how to load paper, basic copy, print and scan operations, and troubleshooting. Safety Conventions in This Guide The sections of this guide and parts of the machine marked with symbols are safety warnings meant to protect the user, other individuals and surrounding objects, and ensure correct and safe usage of the machine. The symbols and their meanings are indicated below. WARNING: Indicates that serious injury or even death may result from insufficient attention to or incorrect compliance with the related points. CAUTION: Indicates that personal injury or mechanical damage may result from insufficient attention to or incorrect compliance with the related points. Symbols The symbol indicates that the related section includes safety warnings.

Specific points of attention are indicated inside the symbol. ....

[General warning] .... [Warning of danger of electrical shock] .

... [Warning of high temperature] The symbol indicates that the related section includes information on prohibited actions. Specifics of the prohibited action are indicated inside the symbol. .... [Warning of prohibited action] .

... [Disassembly prohibited] The symbol indicates that the related section includes information on actions which must be performed. Specifics of the required action are indicated inside the symbol. .... [Alert of required action] .

... [Remove the power plug from the outlet] ..

.. [Always connect the machine to an outlet with a ground connection] Please contact your service representative to order a replacement if the safety warnings in this Operation Guide are illegible or if the guide itself is missing (fee required). NOTE: An original which resembles a bank note closely may not be copied properly in some rare cases because this machine is equipped with a counterfeiting prevention function. OPERATION GUIDE i Contents Contents

Quick Guide .

.....

.....

.....

.....

.....

.....

.....

.....

... vi Caution / Warning Labels . . . . .

.....

.....

.....

.....

.....

.....

... ix Installation Precautions .

.....

.....

.....

.....

.....

.....

.....

... x Precautions for Use . . .

.....

.....

.....

.....

.....

.....

.....

... xii Laser Safety . . .

.....

.....

.....

.....



.....  
.....  
.....  
..... 2-5 Power On/Off.....

.....  
.....  
.....

.....  
.....  
.....  
..... 2-7 Sleep and Auto Sleep .

.....  
.....  
.....

.....  
.....  
.....  
..... 2-9 Adjusting the Operation Panel Angle . . . .

.....  
.....  
.....

.....  
2-10 Switching the Language for Display [Language].....  
.....

.....  
.....

. 2-10 Setting Date and Time . . . .  
.....

.....  
.....  
.....

.....  
. 2-11 Network Setup (LAN Cable Connection) . . . .  
.....

.....  
.....  
.....

. . . 2-12 Installing Software.....

.....  
.....  
.....

.....  
.....  
.....  
.. 2-15 COMMAND CENTER (Settings for E-mail).....

.....  
.....

.....  
.....

.. 2-16 Sending E-mail .....

.....  
.....  
.....

.....  
.....  
.....  
.....

... 2-17 Loading Paper .....

.....  
.....  
.....

.....  
.....  
.....  
.....

..... 2-19 Loading Originals .....

.....  
.....  
.....

.....  
.....  
.....  
.....

..... 2-30 Basic Operation Login/Logout .....

.....  
.....  
.....

.....  
.....  
.....  
.....

..... 3-2 Enter key and Quick No. Search key.

.....  
.....  
.....

.....  
.....  
.....

..... 3-3 Touch Panel Display .....

.....  
.....  
.....  
.....

.....  
.....  
.....

.. 3-4 Original Preview .....

.....  
.....  
.....  
.....

.....  
.....  
.....  
... 3-5 Copying .....

.....  
.....  
.....

.....  
.....  
.....

. 3-6 Printing - Printing from Applications .....

.....  
.....  
.....

.....  
.....  
... 3-21 Sending .....

.....  
.....  
.....  
.....

.....  
.....  
.....

... 3-23 Confirmation Screen of Destinations .....

.....  
.....  
.....

..... 3-29 Specifying Destination. .

.....  
.....  
.....

.....  
.....  
.....

.... 3-30 Using Document Box .....

.....  
.....  
.....

.....  
.....  
.....

3-33 Basic Operation for Document Box .....

.....  
.....  
.....  
.....



.....  
.....  
.....  
..... 4-7 Original Orientation .  
.....

.....  
.....  
.....

.....  
.....  
..... 4-10 Output Destination ...  
.....

.....  
.....  
.....

.....  
.....  
..... 4-12 Combine Mode .....  
.....

.....  
.....  
.....

.....  
.....  
..... 4-13 Margin/Centering Mode....  
.....

.....  
.....  
.....

.....  
..... 4-15 Border Erase ....  
.....

.....  
.....  
.....

.....  
..... 4-17 Booklet from Sheets .  
.....

.....  
.....  
.....

.....  
..... 4-19 Cover Mode....  
.....



.....  
.....  
.....  
.....

.....  
.....  
*4-21 Form Overlay . . . . .*  
.....

.....  
.....  
.....  
.....

.....  
.....  
*.. 4-22 Page Numbering . . .*  
.....

.....  
.....  
.....  
.....

.....  
.....  
*.. 4-23 Memo Mode . . .*  
.....

.....  
.....  
.....  
.....

.....  
.....  
*4-25 Image Repeat/Double Copy . . . . .*  
.....

.....  
.....  
.....  
.....

.....  
.....  
*. 4-27 EcoPrint . . . . .*  
.....

.....  
.....  
.....  
.....

.....  
.....  
*... 4-29 Sharpness Adjust . .*  
.....

.....  
.....  
.....  
.....

.....  
.....

.. 4-30 Continuous Scan ..

.....

.....

.....

.....

.....

.....

.....

.. 4-31 Auto Image Rotation ..

.....

...



[You're reading an excerpt. Click here to read official KYOCERA](#)

[TASKALFA 520I user guide](#)

<http://yourpdfguides.com/dref/3409430>

.....  
.....  
.....  
.....

.....  
... 4-32 Negative Image .

.....  
.....  
.....  
.....  
.....

.....  
4-32 Mirror Image .....

.....  
.....  
.....  
.....

.....  
... 4-33 Job Finish Notice .

.....  
.....  
.....  
.....

.....  
... 4-34 File Name .

.....  
.....  
.....  
.....

.....  
... 4-35 Priority Override .....

.....  
.....  
.....  
.....

.....  
... 4-35 Repeat Copy .....

.....  
.....  
.....  
.....  
.....

..... 4-36 5 Sending Functions Original Size Selection .....

.....  
.....  
.....  
.....

.....  
.....  
.....

.. 5-2 Sending Size Selection .....

.....  
.....  
.....

.....  
.....

... 5-3 Zoom ...

.....

.....  
.....  
.....

.....  
.....  
.....

..... 5-5 Centering ..

.....  
.....  
.....

.....  
.....  
.....

..... 5-6 Mixed Sized Originals .....

.....  
.....  
.....

.....  
.....  
.....

.. 5-7 1-sided/2-sided Selection .....

.....  
.....  
.....

.....  
.....  
.....

..... 5-10 Original Orientation .....

.....  
.....  
.....  
.....



.....  
.....  
.....

.....  
*8-26 Sending Settings* .....

.....  
.....

.....  
.....  
.....  
.....

.....  
*8-29 Document Box Settings* .....

.....  
.....

.....  
.....  
.....  
.....

..... *8-32 Printer Settings* .....

.....  
.....  
.....

.....  
.....  
.....  
.....

..... *8-34 Printing Reports/Sending Notice* .....

.....  
.....  
.....

.....  
.....  
.....

..... *8-39 Adjustment/Maintenance* .....

.....  
.....  
.....  
.....

.....  
.....

... *8-42 Date/Timer* ..

.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.. *8-47 Editing Destination (Address Book/Adding One Touch Keys)* .....

.....  
.....

... *8-51 Internet Browser Setup* ..

.....  
.....  
.....  
.....

.....  
... 8-58 Applications...  
.....

.....  
.....  
.....

.....  
.. 8-60 System Initialization ...  
.....

.....  
.....  
.....

.....  
... 8-63 Restarting the System.  
.....

.....  
.....  
.....

.....  
8-63 Network Setup. ....  
.....

.....  
.....  
.....

.....  
.. 8-64 Secure Protocol...  
.....

.....  
.....  
.....

.....  
... 8-69 Interface Block Setting ...  
.....

.....  
.....  
.....

..... 8-72 Security Level (Security Level setting) ..

.....  
.....  
.....

.....  
.....  
.....

. 8-73 Document Guard Setting. ....

.....  
.....  
.....

.....  
.....

8-73 Optional Functions .....

.....  
.....  
.....  
.....

... 8-75 Accessibility Display (Enlarged Touch Panel Display) ..

.....  
.....

.... 8-77 Maintenance Cleaning .

.....  
.....  
.....  
.....

.....  
.....  
.....

. 9-2 Toner Container and Waste Toner Box Replacement .....

.....  
.....  
.....

.... 9-8 Troubleshooting Solving Malfunctions .....

.....  
.....  
.....

.....  
.....  
.....

. 10-2 Responding to Error Messages. ....

.....  
.....  
.....

10-6 Clearing Paper Jams. ....



.....  
.....

.....  
.....  
.....

..... 10-15 Management User Login Administration .....

.....  
.....  
.....

.....  
.....  
.....

..... 11-2 Job Accounting .

.....  
.....  
.....

.....  
.....  
.....

..... 11-14 Data Security Kit Operations.

.....  
.....  
.....

.....  
.....

.... 11-27 Appendix Optional Equipment.

.....  
.....  
.....  
.....

.. Appendix-2 8 9 10 11 iv OPERATION GUIDE Contents Character Entry Method ...

.....  
.....  
.....  
.....  
.....

Appendix-10 Paper. ....

.....  
.....  
.....  
.....  
.....  
.....

... Appendix-13 Specifications .....

.....  
.....  
.....

.....  
.....  
.....  
.....Appendix-21 Glossary .

.....  
.....  
.....  
.....  
.....  
.....  
.....Appendix-27 Index .

.....  
.....  
.....  
.....  
.....  
.....

..... .Index-1 OPERATION GUIDE v Quick Guide Be sure to read Precautions for Use before using this machine. Administrator tasks To make copies It copies. To print It prints. Simply press the Start key to make copies.

You can also fine-tune the copy settings by changing the paper size, adjusting the density, etc. You can print via a network or print a PDF file directly from USB memory. What you want to do Copying with specific settings Printing Documents Stored in Removable USB Memory Print via a network Connecting Cables Network Setup (LAN Cable Connection) Install the printer driver on your computer \*1 Setup Loading Paper...

2-19 Placing Originals on the Platen...2-30 Operation Copying Functions ..

.4-1 Printing Documents Stored in Removable USB Memory... 6-20 Printing Printing from Applications ...3-21 \*1: For more information, refer to the Printer Driver User Guide. vi OPERATION GUIDE Administrator tasks To send documents It sends. You can send scanned images via a network.

Or, you can also store scanned images in USB memory. What you want to do Send as E-mail Send to Folder (SMB) Saving Documents to USB Memory Connecting Cables Network Setup (LAN Cable Connection) Plug the USB memory Create a shared folder on the destination computer. Setup Editing Destination (Address Book/Adding One Touch Keys)...8-51 Place the originals on the platen Operation Sending...3-23 \*1 Sending Functions..

.5-1 Saving Documents to USB Memory (Scan to USB)...6-22 \*1: If the destination is not stored in the address book, you can send by entering the address directly.

OPERATION GUIDE vii Administrator tasks To send a FAX As well as sending a FAX via the telephone lines, you can also send a FAX via a network. It faxes. NOTE: For more information on setting up and sending a FAX, refer to the FAX System (S) Operation Guide. What you want to do Send a FAX FAX directly from a computer FAX without using the telephone line (Internet FAX (i-FAX)) Connect the modular cord for the telephone line to this machine. Selection of Telephone Line (Inch version only) Network Setup (LAN Cable Connection) Install the Network FAX Driver on your computer \*1 Setup Selection of Transmit Terminal Identification (TTI).

..2-3 on the FAX System (S) Operation Guide Loading Paper...2-19 \*2 Operation FAX Operation (Basic)...3-1 on the FAX System (S) Operation Guide About Network FAX..

.9-1 on the FAX System (S) Operation Guide Internet Fax (i-FAX) (Optional).



[You're reading an excerpt. Click here to read official KYOCERA](#)

[TASKALFA 520I user guide](#)

<http://yourpdfguides.com/dref/3409430>

..8-1 on the FAX System (S) Operation Guide \*1:For more information, refer to the Network FAX Driver Operation Guide. \*2: If the destination is not stored in the address book, you can send the FAX by entering the address directly. viii OPERATION GUIDE Caution / Warning Labels Caution / Warning labels have been attached to the machine at the following locations for safety purposes. Be sufficiently careful to avoid fire or electric shock when removing a paper jam or when replacing toner. High temperature inside. Do not touch parts in this area, because there is a danger of getting burned.

High temperature inside. Do not touch parts in this area, because there is a danger of getting burned. Do not incinerate toner and toner container. Dangerous sparks may cause burn. Label inside the machine (Laser radiation warning) Moving parts inside.

May cause personal injury. Do not touch moving parts. High temperature inside. Do not touch parts in this area, because there is a danger of getting burned.

NOTE: Do not remove these labels.

OPERATION GUIDE ix Installation Precautions Environment CAUTION Avoid placing the machine on or in locations which are unstable or not level. Such locations may cause the machine fall down or fall over. This type of situation presents a danger of personal injury or damage to the machine. Avoid locations with humidity or dust and dirt. If dust or dirt become attached to the power plug, clean the plug to avoid the danger of fire or electrical shock. Avoid locations near radiators, heaters or other heat sources, or locations near flammable items to avoid the danger of fire. To keep the machine cool and facilitate changing of parts and maintenance, allow access space as shown below. Leave adequate space, especially around the rear cover, to allow air to be properly ventilated out of the machine. 3 15/16" 10 cm 11 13/16" 30 cm 11 13/16" 30 cm 39 3/8" 100 cm Other precautions The service environmental conditions are as follows:

· · Temperature: 50 to 90.5 Humidity: 15 to 80% F (10 to 32.

5 C) However, adverse environmental conditions may affect the image quality. Avoid the following locations when selecting a site for the machine. . . . Avoid locations near a window or with exposure to direct sunlight. Avoid locations with vibrations. Avoid locations with drastic temperature fluctuations. x OPERATION GUIDE . . . Avoid locations with direct exposure to hot or cold air. Avoid poorly ventilated locations. If the floor is delicate against casters, when this machine is moved after installation, the floor material may be damaged. During copying, some ozone is released, but the amount does not cause any ill effect to one's health. If, however, the machine is used over a long period of time in a poorly ventilated room or when making an extremely large number of copies, the smell may become unpleasant.

To maintain the appropriate environment for copy work, it is suggested that the room be properly ventilated. Power supply/Grounding the machine

WARNING Do not use a power supply with a voltage other than that specified. Avoid multiple connections in the same outlet. These types of situations present a danger of fire or electrical shock. Plug the power cord securely into the mains power outlet and the power socket on the machine.

A buildup of dust around the prongs on the plug or contact between the prongs and metallic objects may cause a fire or electric shock. Incomplete electrical contact could cause overheating and ignition. Always connect the machine to an outlet with a ground connection to avoid the danger of fire or electrical shock in case of an electric short. If an earth connection is not possible, contact your service representative. Other precautions Connect the power plug to the closest outlet possible to the machine.

Handling of plastic bags WARNING Keep the plastic bags that are used with the machine away from children. The plastic may cling to their nose and mouth causing suffocation. OPERATION GUIDE xi Precautions for Use Cautions when using the machine WARNING Do not place metallic objects or containers with water (flower vases, flower pots, cups, etc.) on or near the machine. This type of situation presents a danger of fire or electrical shock should they fall inside. Do not remove any of the covers from the machine as there is a danger of electrical shock from high voltage parts inside the machine. Do not damage, break or attempt to repair the power cord. Do not place heavy objects on the cord, pull it unnecessarily or cause any other type of damage. These types of situations present a danger of fire or electrical shock. Never attempt to repair or disassemble the machine or its parts as there is a danger of personal injury, fire, electrical shock or exposure to the laser.

If the laser beam escapes, there is a danger of it causing blindness. If the machine becomes excessively hot, smoke appears from the machine, there is an odd smell, or any other abnormal situation occurs, there is a danger of fire or electrical shock. Turn the main power switch off immediately, be absolutely certain to remove the power plug from the outlet and then contact your service representative. If anything harmful (paper clips, water, other fluids, etc.) falls into the machine, turn the main power switch off immediately. Next, remove the power plug from the outlet to avoid the danger of fire or electrical shock. Then contact your service representative. Do not remove or connect the power plug with wet hands, as there is a danger of electrical shock. Always contact your service representative for maintenance or repair of internal parts. xii OPERATION GUIDE CAUTION Do not pull the power cord when removing it from the outlet. If the power cord is pulled, the wires may become broken and there is a danger of fire or electrical shock. (Always grasp the power plug when removing the power cord from the outlet.) Always remove the power plug from the outlet when moving the machine. If the power cord is damaged, there is a danger of fire or electrical shock. Always hold the designated parts only when lifting or moving the machine.

If this machine will be left unused for an extended period (e.g. overnight), turn it off at the main power switch. If the machine will not be used for an even longer period of time (e.g.

vacation), remove the power plug from the outlet as a safety precaution. If the optional Fax kit is installed, note that turning the machine off at the main power switch disables fax transmission and reception. For safety purposes, always remove the power plug from the outlet when performing cleaning operations. If dust accumulates within the machine, there is a danger of fire or other trouble. It is therefore recommended that you consult with your service representative in regard to cleaning of internal parts. This is particularly effective if accomplished prior to seasons of high humidity.



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 520I user guide](http://yourpdfguides.com/dref/3409430)  
<http://yourpdfguides.com/dref/3409430>





KPDL is a trademark of Kyocera Corporation. Microsoft, MS-DOS, Windows, Windows NT and Internet Explorer are registered trademarks of Microsoft Corporation in the U.S.A. and/or other countries. Windows Me, Windows XP and Windows Vista are trademarks of Microsoft Corporation. PCL is a trademark of Hewlett-Packard Company. Adobe Acrobat, Adobe Reader and PostScript are trademarks of Adobe Systems, Incorporated. Ethernet is a registered trademark of Xerox Corporation.

Novell and NetWare are registered trademarks of Novell, Inc. IBM and IBM PC/AT are trademarks of International Business Machines Corporation. Power PC is a trademark of IBM in the U.S.A. and/or other countries. AppleTalk is a registered trademark of Apple Computer, Inc. This machine has been developed using embedded real-time operating system Tornado™ by Wind River Systems, Inc. TrueType is a registered trademark of Apple Computer, Inc. TypeBankG-B, TypeBankM-M and Typebank-OCR are trademarks of TypeBank®.

All European language fonts installed in this machine are used under licensing agreement with Monotype Imaging Inc. Helvetica, Palatino and Times are registered trademarks of Linotype-Hell AG. ITC Avant Garde Gothic, ITC Bookman, ITC ZapfChancery and ITC ZapfDingbats are registered trademarks of International Type-face Corporation. UFST™ MicroType® fonts by Monotype Imaging Inc. are installed in this machine.

This machine contains the NF module developed by ACCESS Co., Ltd. This machine contains the software having modules developed by Independent JPEG Group. This product contains NetFront Browser of ACCESS CO., LTD.

ACCESS, ACCESS logo and NetFront are trademarks or registered trademarks of ACCESS CO., LTD. in the United States, Japan and other countries. © 2009 ACCESS CO., LTD. All rights reserved. This software is based in part on the work of the Independent JPEG Group. All other brands and product names are registered trademarks or trademarks of their respective companies. The designations TM and ® will not be used in this Operation Guide. OPERATION GUIDE xxi GPL Firmware of this machine is using in part the GPL applied codes ([www.fsf.org/copyleft/gpl.html](http://www.fsf.org/copyleft/gpl.html)).

Please access "<http://www.kyoceramita.com/gpl>" for more information on how to make GPL applied codes available. Open SSL License Copyright (c) 1998-2006 The OpenSSL Project. All rights reserved. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: 1 2 3 Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (<http://www.openssl.org/>)" The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact [openssl-core@openssl.org](mailto:openssl-core@openssl.org). Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project. Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)" 4 5 6 THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.

IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. xxii OPERATION GUIDE Original SSLeay License Copyright (C) 1995-1998 Eric Young ([eyay@cryptsoft.com](mailto:eyay@cryptsoft.com)) All rights reserved. This package is an SSL implementation written by Eric Young ([eyay@cryptsoft.com](mailto:eyay@cryptsoft.com)). The implementation was written so as to conform with Netscape's SSL. This library is free for commercial and non-commercial use as long as the following conditions are adhered to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson ([tjh@cryptsoft.com](mailto:tjh@cryptsoft.com)).

com). Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met: 1 2 3 Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes cryptographic software written by Eric Young ([eyay@cryptsoft.com](mailto:eyay@cryptsoft.com))" The word 'cryptographic' can be left out if the routines from the library being used are not cryptographic related :-). If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgment: "This product includes software written by Tim Hudson ([tjh@cryptsoft.com](mailto:tjh@cryptsoft.com))" 4 THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.

IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 520I user guide](http://yourpdfguides.com/dref/3409430)  
<http://yourpdfguides.com/dref/3409430>



The licence and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.

J OPERATION GUIDE xxiii Monotype Imaging License Agreement 1 2 Software shall mean the digitally encoded, machine readable, scalable outline data as encoded in a special format as well as the UFST Software. You agree to accept a non-exclusive license to use the Software to reproduce and display weights, styles and versions of letters, numerals, characters and symbols (Typefaces) solely for your own customary business or personal purposes at the address stated on the registration card you return to Monotype Imaging. Under the terms of this License Agreement, you have the right to use the Fonts on up to three printers. If you need to have access to the fonts on more than three printers, you need to acquire a multiuser license agreement which can be obtained from Monotype Imaging. Monotype Imaging retains all rights, title and interest to the Software and Typefaces and no rights are granted to you other than a License to use the Software on the terms expressly set forth in this Agreement.

To protect proprietary rights of Monotype Imaging, you agree to maintain the Software and other proprietary information concerning the Typefaces in strict confidence and to establish reasonable procedures regulating access to and use of the Software and Typefaces. You agree not to duplicate or copy the Software or Typefaces, except that you may make one backup copy. You agree that any such copy shall contain the same proprietary notices as those appearing on the original. This License shall continue until the last use of the Software and Typefaces, unless sooner terminated. This License may be terminated by Monotype Imaging if you fail to comply with the terms of this License and such failure is not remedied within thirty (30) days after notice from Monotype Imaging. When this License expires or is terminated, you shall either return to Monotype Imaging or destroy all copies of the Software and Typefaces and documentation as requested. You agree that you will not modify, alter, disassemble, decrypt, reverse engineer or decompile the Software.

Monotype Imaging warrants that for ninety (90) days after delivery, the Software will perform in accordance with Monotype Imaging-published specifications, and the diskette will be free from defects in material and workmanship. Monotype Imaging does not warrant that the Software is free from all bugs, errors and omissions. The parties agree that all other warranties, expressed or implied, including warranties of fitness for a particular purpose and merchantability, are excluded.

3 4 5 6 7 8 Your exclusive remedy and the sole liability of Monotype Imaging in connection with the Software and Typefaces is repair or replacement of defective parts, upon their return to Monotype Imaging. In no event will Monotype Imaging be liable for lost profits, lost data, or any other incidental or consequential damages, or any damages caused by abuse or misapplication of the Software and Typefaces. 9 Massachusetts U.S.A. law governs this Agreement. written consent of Monotype Imaging. 10 You shall not sublicense, sell, lease, or otherwise transfer the Software and/or Typefaces without the prior 11 Use, duplication or disclosure by the Government is subject to restrictions as set forth in the Rights in Technical Data and Computer Software clause at FAR 252-227-7013, subdivision (b)(3)(ii) or subparagraph (c)(1)(ii), as appropriate. Further use, duplication or disclosure is subject to restrictions applicable to restricted rights software as set forth in FAR 52.227-19 (c)(2).

12 You acknowledge that you have read this Agreement, understand it, and agree to be bound by its terms and conditions. Neither party shall be bound by any statement or representation not contained in this Agreement. No change in this Agreement is effective unless written and signed by properly authorized representatives of each party. By opening this diskette package, you agree to accept the terms and conditions of this Agreement. xxiv OPERATION GUIDE Energy Saving Control Function The device comes equipped with a Sleep where printer and fax functions remain in a waiting state but power consumption is still reduced to a minimum when there is no activity with the device within a set amount of time since the device was last used.

Sleep The device automatically enters Sleep when 8 minutes have passed since the device was last used. The amount of time of no activity that must pass before Sleep is activated may be lengthened. For more information see Sleep and Auto Sleep on page 2-9. Automatic 2-Sided Copy Function This device includes 2-sided copying as a standard function. For example, by copying two 1-sided originals onto a single sheet of paper as a 2-sided copy, it is possible to lower the amount of paper used.

For more information see Duplex Copying on page 3-11. Paper Recycling This device supports the recycled paper which reduces the load on the environment. Your sales or service representative can provide information about recommended paper types. Energy Star (ENERGY STAR®) Program We have determined as a participating company in the International Energy Star Program that this product is compliant with the standards laid out in the International Energy Star Program. OPERATION GUIDE xxv About this Operation Guide This Operation Guide contains the following chapters. Chapter 1 - Part Names Identifies machine parts and operation panel keys. Chapter 2 - Preparation before Use Explains adding paper, placing originals, connecting the machine, and necessary configurations before first use. Chapter 3 - Basic Operation Describes the procedures for basic copying, printing and scanning. Chapter 4 - Copying Functions Describes the functions you can use when copying. Chapter 5 - Sending Functions Describes the functions you can use when sending originals.

Chapter 6 - Document Box Provides a basic guide to using document boxes. Chapter 7 - Status / Job Cancel Explains how to check the job status and job history and how to cancel jobs being printed or waiting to print. Also explains how to check the remaining paper and device status and how to cancel fax transmission Chapter 8 - Default Setting (System Menu) Describes the System Menu options for general machine operation. Chapter 9 - Maintenance Describes cleaning and toner replacement. Chapter 10 - Troubleshooting Explains how to handle error messages, paper jams and other problems. Chapter 11 - Management Explains user login administration and job accounting. Appendix Explains how to enter characters, and lists the machine specifications. Introduces the convenient optional equipment available for this machine. Provides information on media types and paper sizes. Also includes a glossary of terms.

xxvi OPERATION GUIDE Conventions in This Guide The following conventions are used depending on the nature of the description.



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 520I user guide](http://yourpdfguides.com/dref/3409430)  
<http://yourpdfguides.com/dref/3409430>

*Convention Bold [Regular] Italic Description Indicates the operation panel keys or a computer screen. Indicates the touch panel keys. Indicates a message displayed on the touch panel. Used to emphasize a key word, phrase or references to additional information.*

*Note Indicates supplemental information or operations for reference. Indicates items that are required or prohibited so as to avoid problems. Indicates what must be observed to prevent injury or machine breakdown and how to deal with it. Example Press the Start key. Press [OK].*

*Ready to copy is displayed. For more information refer to Sleep and Auto Sleep on page 2-9. NOTE: Important IMPORTANT: Caution CAUTION: Description of Operation Procedure In this Operation Guide, continuous operation of the keys on the touch panel is as follows: Actual procedure Press [Copy]. Press [Next] of Quick Setup. Press [ ] twice. Press [Change] of Original Image. Description in this Operation Guide Press [Copy], [Next] of Quick Setup, [ ] twice, and then [Change] of Original Image. OPERATION GUIDE xxvii Originals and Paper Sizes This section explains the notation used in this guide when referring to sizes of originals or paper sizes. As with A4, B5 and Letter, which may be used either in the horizontal or vertical direction, horizontal direction is indicated by an additional letter R in order to indicate the orientation of the original/paper. Placement direction Vertical direction Indicated size \* A4, B5, A5, B6, A6, 16K, Letter, Statement B B A A Original Paper For the originals/paper, dimension A is longer than B.*

*Horizontal direction B A B A4-R, B5-R, A5-R, B6-R, A6-R, 16KR, Letter-R, Statement-R A Original Paper For the originals/paper, dimension A is shorter than B. \* The size of the original/paper that can be used depends on the function and source tray. For further details, refer to the page detailing that function or source tray. Icons on the Touch Panel The following icons are used to indicate originals and paper placement directions on the touch panel. Placement direction Vertical direction Originals Paper Horizontal direction xxviii OPERATION GUIDE 1 Part Names This chapter identifies the machine parts and operation panel keys. . . Operation Panel .....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.....1-2 Machine ...

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*.1-4 OPERATION GUIDE 1-1 Part Names Operation Panel Displays the Status/Job Cancel screen. Displays the System Menu. Displays number of sheets printed and number of pages scanned. Displays help guidance. Blinks during printing operation. Blinks while data is transmitted. Displays the Copy screen. Displays the screen for sending. You can also change this to show the address book screen.*

*Switches the touch panel display to enlarged display in the Copy screen or Send screen. Displays the Document Box screen. Displays the Application screen. Displays the Program screen. 1-2 OPERATION GUIDE Part Names Blinks while data is received.*

*Blinks while the machine is accessing the hard disk, fax memory or USB memory (general-purpose item). Lights or blinks when an error occurs and a job is stopped. Displays the Interrupt Copy screen. Ends operation (logs out) on the Administration screen. Puts the machine into Sleep.*

*Recovers from Sleep if in Sleep. Lit when the machine's main power is on. 1 Numeric keys. Enter numbers and symbols. Clears entered numbers and characters. Recalls already registered destinations and programs for sending. Finalizes numeric key entry, and finalizes screen during setting of functions. Operates linked with the on-screen [OK]. Returns settings to their default states. Cancels or pauses the printing job in progress.*

*Starts copying and scanning operations and processing for setting operations. OPERATION GUIDE 1-3 Part Names Machine 1 2 3 4 5 6 7 8 9 Original Cover (Option) Original Size Indicator Plates Clip Holder Slit Glass Attention Indicator... Lights or blinks when an error occurs and a job is stopped Receive Indicator... Blinks while data is received Left Cover 1 Left Cover 1 Lever Left Cover 2 10 Left cover 2 Handle 11 Platen 12 Operation Panel 13 Cassette 1 14 Cassette 2 1-4 OPERATION GUIDE Part Names 1 15 Toner Container Stopper 16 Toner Container 17 Waste Toner Box 18 Paper Feed Unit (A2) 19 Paper Feed Unit Cover (A3) 20 Green Knob OPERATION GUIDE 1-5 Part Names OPT2 DP A2 B1 OPT1 21 USB Memory Slot (A1) 22 Front Cover 23 Paper Width Adjusting Tab 24 Paper Length Guide 25 Top Tray 26 Main Power Switch 27 Paper Width Guide 28 Multi Purpose Tray 29 Option Interface Slot (OPT2) 30 USB Memory Slot (A2) 31 USB Interface Connector (B1) 32 Network Interface Connector 33 Option Interface Slot (OPT1) 1-6 OPERATION GUIDE 2 Preparation before Use This chapter explains the preparations before using this equipment for the first time as well as the procedures for loading paper and originals. . . . . . Check the Accessories ..*

.....



.....  
.....

.....  
.....  
.....

.....  
.....

*....2-2 Determining the Connection Method and Preparing Cables.*

.....

*....2-3 Connecting Cables.....*

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

*..2-5 Power On/Off .....*

.....  
.....  
.....  
.....

.....  
.....  
.....

.....  
.....

*...2-7 Sleep and Auto Sleep ..*

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.2-9 Adjusting the Operation Panel Angle .....*

.....  
.....  
.....

.....  
.....

*....2-10 Switching the Language for Display [Language].*

.....

.....  
.....  
.....

*2-10 Setting Date and Time .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*2-11 Network Setup (LAN Cable Connection) .....*

.....  
.....  
.....

*..2-12 Installing Software...*

.....  
.....  
.....  
.....  
.....  
.....

*.....2-15 COMMAND CENTER (Settings for E-mail) .*

.....  
.....  
.....  
.....

*.....2-16 Sending E-mail...*

.....  
.....  
.....  
.....  
.....  
.....

*.....2-17 Loading Paper.*

.....  
.....  
.....  
.....  
.....  
.....  
.....

*..2-19 Loading Originals .....*

.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

2-30 OPERATION GUIDE 2-1 Preparation before Use Check the Accessories Check that the following accessories are included. · · Operation Guide (This Guide) CD-ROM (Product Library) Documents Contained in the Included CD-ROM The following documents are contained in the included CD-ROM (Product Library). Refer to them as necessary. Documents KYOCERA COMMAND CENTER Operation Guide Printer Driver User Guide Network FAX Driver Operation Guide TWAIN/WIA Driver Operation Guide KM-NET for Direct Printing Operation Guide KM-NET Viewer User Guide Scan to SMB (PC) Setup Guide PRESCRIBE Commands Technical Reference PRESCRIBE Commands Command Reference Data Security Kit (E) Operation Guide Fax System (S) Operation Guide 2-2 OPERATION GUIDE Preparation before Use Determining the Connection Method and Preparing Cables Check the method to connect the equipment to a PC or network, and prepare the necessary cables. Connection Example Determine the method to connect the equipment to a PC or network by referring to the illustration below.  
Connecting a scanner to your PC network with a network cable (100BASE-TX or 10BASE-T) COMMAND CENTER Administrator's PC 2 Network Send E-mail Sends the image data of scanned originals to the desired recipient as a file attached to an E-mail message. Network settings, Scanner default settings, User and destination registration Printing MFP Network USB Send SMB Saves the scanned image as a data file on your PC.



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 520I user guide](http://yourpdfguides.com/dref/3409430)  
<http://yourpdfguides.com/dref/3409430>

Network Network FAX (Option) Network Network Send FTP Sends the scanned image as a data file on the FTP. FAX (Option) FAX Network TWAIN Scanning WIA Scanning Network TWAIN and WIA are standardized interface for communication between software applications and image acquisition devices. OPERATION GUIDE 2-3 Preparation before Use Preparing Necessary Cables The following interfaces are available to connect the equipment to a PC.

Prepare the necessary cables according to the interface you use. Available Standard Interfaces Function Printer/Scanner /Network FAX\* Printer Interface Network interface USB interface Necessary Cable LAN (10Base-T or 100Base-TX, Shielded) USB2.0 compatible cable (Hi-Speed USB compliant, Max. 5.0 m, Shielded) \* Function available when using optional fax kit. For details on Network FAX, refer to the Fax Kit Operation Guide. 2-4 OPERATION GUIDE Preparation before Use Connecting Cables Connecting LAN Cable (Optional) Follow the steps below to connect a LAN cable to the machine. 2 1 When the machine is powered up, first press the Power key on the operation panel. Check that the Power indicator and the memory indicator are off. After this, turn off the main power switch.

Check that the indicators are off. DP 2 Connect the LAN cable to the network interface located on right side of the body. A2 B1 OP TI 3 4 Connect the other end of the cable to the hub. Configure the network. For details, refer to Network Setup (LAN Cable Connection) on page 2-12. OPERATION GUIDE 2-5 Preparation before Use Connecting USB Cable Follow the steps below to connect a USB cable to the machine. 1 When the machine is powered up, first press the Power key on the operation panel. Check that the Power indicator and the memory indicator are off. After this, turn off the main power switch. Check that the indicators are off.

2 DP A2 Connect the USB cable to the appropriate interface located on the right side of the body. B1 OP TI 3 Connecting the Power Cable Connect the other end of the cable to the PC. Connect one end of the supplied power cable to the machine and the other end to a power outlet. IMPORTANT: Only use the power cable that comes with the machine. 2-6 OPERATION GUIDE Preparation before Use Power On/Off Power On When the main power indicator is lit. .. Press the Power key. 2 When the main power indicator is off.

. Open the main power switch cover and turn the main power switch on. NOTE: If the optional Data Security Kit is installed, a message might display indicating the security function is being activated and time may be taken to start up when the power is turned on. IMPORTANT: When turning off the main power switch, do not turn on the main power switch again immediately. Wait more than 5 seconds, and then turn on the main power switch. OPERATION GUIDE 2-7 Preparation before Use Power Off Before turning off the main power switch, press the Power key on the operation panel to off. Make sure that the Power key and the memory indicator are off before turning off the main power switch. CAUTION: The hard disk may be operating when the Power key or Memory indicator is lit or blinking. Turning off the main power switch while the hard disk is operating may cause damage. Make sure that the indicators are off.

In case of not using the machine for an extended period of time CAUTION: If this machine will be left unused for an extended period (e.g. overnight), turn it off at the main power switch. If the machine will not be used for an even longer period of time (e.g. vacation), remove the power plug from the outlet as a safety precaution. If the optional Fax kit is installed, note that turning the machine off at the main power switch disables fax transmission and reception. CAUTION: Remove paper from the cassettes and seal it in the paper storage bag to protect it from humidity. 2-8 OPERATION GUIDE Preparation before Use Sleep and Auto Sleep Sleep To enter Sleep, press the Power key. Touch panel and all indicators on the operation panel will go out to save a maximum amount of power except the Main Power indicator.

This status is referred to as Sleep. If print data is received during Sleep, the print job is performed while the touch panel remains unlit. When using the optional fax, received fax data is printed out while the operation panel also remains unlit. To resume, press the Power key. The machine will be ready within 15 seconds.

Note that ambient environmental conditions, such as ventilation, may cause the machine to respond more slowly. Auto Sleep Auto Sleep automatically switches the machine into Sleep if left idle for a preset time. The default preset time is 8 minutes. 2 OPERATION GUIDE 2-9 Preparation before Use Adjusting the Operation Panel Angle Adjust the angle of the operation panel in two as shown by releasing the operation panel lock lever. Switching the Language for Display [Language] Select the language displayed on the touch panel.

Use the procedure below to select the language. 1 2 3 Press the System Menu key. Press [Common Settings] and then [Change] of Language. Press the key for the language you want to use. Common Settings - Language Set the language to use for the touch panel display. English Nederlands Deutsch Français Português Español Italiano Cancel Status OK 08/08/2009 10:10 4 Press [OK]. The touch panel language will be changed. 2-10 OPERATION GUIDE Preparation before Use Setting Date and Time Follow the steps below to set the local date and time at the place of installation. When you send an E-mail using the transmission function, the date and time as set here will be printed in the header of the E-mail message. Set the date, time and time difference from GMT of the region where the machine is used.

2 NOTE: If user login administration is enabled, you can only change the settings by logging in with administrator privileges. If user login administration is disabled, the user authentication screen appears. Enter a login user name and password, and press [Login]. Refer to Adding a User on page 11-5 for the default login user name and password. Be sure to set the time difference before setting the date and time. If you change Date/Time setting, trial functions will be unavailable. For details, refer to Optional Functions on page 8-75. 1 Press the System Menu key. 2 3 Press [ ], [Date/Timer] and then [Change] of Time Zone. Select the region.

] or [ ] to view the next region. Date/Timer - Time Zone Set time zone. Select the location nearest you. Time Zone -12:00 International Date Line West -11:00 Midway Island, Samoa -10:00 Hawaii 1/13 NOTE: Press [ 4 Summer Time Off On Press [Off] or [On] of Summer Time and press [OK]. -09:00 Alaska -08:00 Pacific Time (US & Canada) -07:00 Arizona Cancel Status OK 08/08/2009 10:10 NOTE: If you select a region that does not utilize summer time, the summer time setting screen will not appear.



[You're reading an excerpt. Click here to read official KYOCERA TASKALFA 520I user guide](http://yourpdfguides.com/dref/3409430)  
<http://yourpdfguides.com/dref/3409430>

5 Date/Timer - Date/Time Set the date and time. Press [Change] of Date/Time. Set the date and time. Press [+] or [-] in each setting. Press [OK].  
6 7 2008 Year 10 Month 10 Day Off 10 Hour 10 Minute 31 Second Cancel Status OK 08/08/2009 10:10 OPERATION GUIDE 2-11 Preparation before Use  
Network Setup (LAN Cable Connection) The machine is equipped with network interface, which is compatible with network protocols such as TCP/IP (IPv4),  
TCP/IP (IPv6), IPX/SPX, NetBEUI, IPsec, and AppleTalk. It enables network printing on the Windows, Macintosh, UNIX, NetWare and other platforms. This  
section explains the TCP/IP (IPv4) Setup and AppleTalk Setup procedures. For other network settings, refer to the Network Setup on 8-64. · · TCP/IP (IPv4)  
Setup...2-12 AppleTalk Setup...

2-14 NOTE: If user login administration is enabled, you can only change the settings by logging in with administrator privileges. If user login administration  
is disabled, the user authentication screen appears. Enter a login user name and password, and press [Login]. Refer to Adding a User on page 11-5 for the  
default login user name and password. TCP/IP (IPv4) Setup (by Entering IP Addresses) Set up TCP/IP to connect to the Windows network. Set the IP  
addresses, subnet masks, and gateway addresses. The default settings are "TCP/IP Protocol: On, DHCP: On, Bonjour: Off, Auto-IP: On". NOTE: Prior to the  
IP address entries, obtain permission from the network administrator. Use the procedure below. 1 2 3 4 5 System - IPv4 Set TCP/IP (IPv4).  
Press the System Menu key. Press [System], [Next] of Network and then [Next] of TCP/IP Setting. Press [Change] of TCP/IP. Press [On] and then press  
[OK]. Press [Change] of IPv4.

Press [DHCP]. 6 IP Address Subnet Mask On Default Gateway 0.0.0.0 0.  
0.0.0.0 0.0.0.0 On DHCP Off Bonjour On Auto-IP Cancel Status OK 08/08/2009 10:10 7 8 Press [Off] of DHCP and then press [OK]. Press [Bonjour]. 2-12  
OPERATION GUIDE Preparation before Use 9 Press [Off] of Bonjour and then press [OK]. numeric keys. 10 Press [IP Address] and enter the address using  
the 11 Press [Subnet Mask] and enter the address using the numeric keys.

2 12 Press [Default Gateway] and enter the address using the numeric keys. 13 Check if all the address entries are correct and press [OK]. 14 After changing  
the setting, restart the system or turn the machine OFF and then ON again. For detailed information on restarting the system, refer to Restarting the System  
on page 8-63. DHCP Settings Select whether or not to use the DHCP server. The default setting is On. Use the procedure below. 1 2 3 4 5 6 7 8 Press the  
System Menu key. Press [System], [Next] of Network and then [Next] of TCP/IP Setting. Press [Change] of TCP/IP.

Press [On] and then press [OK]. Press [Change] of IPv4. Press [DHCP]. Press [On] or [Off] of DHCP and then press [OK]. After changing the setting,  
restart the system or turn the machine OFF and then ON again.  
For detailed information on restarting the system, refer to Restarting the System on page 8-63. Bonjour Settings Select whether or not to use Bonjour. The  
default setting is Off. Use the procedure below. 1 2 Press the System Menu key.

Press [System], [Next] of Network and then [Next] of TCP/IP Setting. OPERATION GUIDE 2-13 Preparation before Use 3 4 5 6 7 8 Press [Change] of  
TCP/IP. Press [On] and then press [OK]. Press [Change] of IPv4. Press [Bonjour]. Press [On] or [Off] of Bonjour and then press [OK]. After changing the  
setting, restart the system or turn the machine OFF and then ON again. For detailed information on restarting the system, refer to Restarting the System on  
page 8-63. Auto-IP Settings Select whether or not to use Auto-IP. The default setting is On.

Use the procedure below. 1 2 3 4 5 6 7 8 Press the System Menu key. Press [System], [Next] of Network and then [Next] of TCP/IP Setting. Press [Change] of  
TCP/IP. Press [On] and then press [OK]. Press [Change] of IPv4. Press [Auto-IP]. Press [On] or [Off] of Auto-IP and then press [OK]. After changing the  
setting, restart the system or turn the machine OFF and then ON again. For detailed information on restarting the system, refer to Restarting the System on  
page 8-63.

AppleTalk Setup Select the Apple Talk network connection. The default setting is On. Use the procedure below. 1 2 3 Press the System Menu key. Press  
[System], [Next] of Network and then [Change] of AppleTalk.

Press [On] or [Off]. 2-14 OPERATION GUIDE Preparation before Use 4 5 Press [OK]. After changing the setting, restart the system or turn the machine  
OFF and then ON again. For detailed information on restarting the system, refer to Restarting the System on page 8-63. 2 Installing Software Install  
appropriate software on your PC from the included Product Library CD-ROM (Product Library) if you want to use the printer function of this machine or  
perform TWAIN / WIA transmission or FAX transmission from your PC.

NOTE: Installation on Windows XP, Windows 2000, Server 2003 and Windows Vista must be done by a user logged on with administrator privileges. Plug  
and Play is disabled on this device when in Sleep. Wake the device from Sleep before continuing. See Sleep and Auto Sleep on page 2-9. OPERATION GUIDE  
2-15 Preparation before Use COMMAND CENTER (Settings for E-mail) COMMAND CENTER is a tool used for tasks such as verifying the operating status  
of the machine and changing the settings for security, network printing, E-mail transmission and advanced networking. NOTE: Here, information on the FAX  
settings has been omitted. For more information on using the FAX, refer to the Fax Kit Operation Guide. The procedure for accessing COMMAND CENTER  
is explained below. 1 2 Launch your Web browser. In the Address or Location bar, enter the machine's IP address.

E.g.) <http://192.168.48.21/> The web page displays basic information about the machine and COMMAND CENTER as well as their current status. 3 Select a  
category from the navigation bar on the left of the screen. The values for each category must be set separately. If restrictions have been set for COMMAND  
CENTER, enter the correct user name and password to access pages other than the startup page. For details, refer to the KYOCERA COMMAND CENTER  
Operation Guide.

2-16 OPERATION GUIDE Preparation before Use Sending E-mail Specifying the SMTP settings allows you to send images loaded onto this machine as E-  
mail attachments. To use this function, this machine must be connected to a mail server using the SMTP protocol. Before sending images loaded onto this  
machine as E-mail attachments, check the following: · · · The network environment used to connect this machine to the mail server A full-time connection via a  
LAN is recommended. SMTP Settings Use COMMAND CENTER to register the IP address or host name of the SMTP server. If limits have been set on the  
size of E-mail messages, it may not be possible to send very large E-mails.



[You're reading an excerpt. Click here to read official KYOCERA  
TASKALFA 520I user guide  
<http://yourpdfguides.com/dref/3409430>](http://yourpdfguides.com/dref/3409430)