



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for M-AUDIO KEYSTATION PRO 88. You'll find the answers to all your questions on the M-AUDIO KEYSTATION PRO 88 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual M-AUDIO KEYSTATION PRO 88
User guide M-AUDIO KEYSTATION PRO 88
Operating instructions M-AUDIO KEYSTATION PRO 88
Instructions for use M-AUDIO KEYSTATION PRO 88
Instruction manual M-AUDIO KEYSTATION PRO 88

English -

Introduction

Congratulations on your purchase of the Keystation Pro 88, an 88-note, hammer-action, velocity-sensitive USB keyboard. The class-compliant Keystation Pro 88 can easily integrate with PC and Mac computer music environments. It can be used to play virtual instruments, external MIDI hardware synthesizers, sound modules, drum machines and samplers. The Pro 88 offers true plug-and-play functionality with class compliance in Windows XP and Mac OS X. Simply plug in the USB cable to begin installation—no driver is required.

Your Keystation Pro 88 is more than just a professional keyboard. It is a MIDI controller that gives you hands-on access for control of multiple MIDI parameters, such as MIDI Continuous Controller data (for CC), RPN/NRPN data, MIDI Bank Change LSB and MSB, and Program Changes on 16 different MIDI channels. You can easily control your studio using only the Keystation Pro 88. To familiarize yourself with installation and the features of the Keystation Pro 88, please spend a few minutes reviewing the Getting Started Guide to learn about basic operation. For advanced functions and programmability, please reference the Advanced User Guide.

Features

Ports:

- MIDI OUT
- MIDI IN
- USB port

Power:

- USB bus powered
- DC IN for external PSU

Keyboard:

- 88-note hammer-action keyboard
- 9 velocity curves

Controls:

- 24 programmable rotary dials
- 9 full-size programmable faders
- 22 programmable buttons
- MIDI-assignable Pitch Bend and Modulation Wheels
- 2 MIDI-assignable foot pedal inputs
- 1 MIDI-assignable expression pedal input

MIDI Data from Controllers:

- MIDI control number
- RPN/NRPN
- Program, Bank LSB, Bank MSB
- Pitch Bend
- GM1/GM2/XG SysEx Messages

MIDI Data from Buttons:

- Note On
- Note On/Off Toggle
- MIDI CC On/Off Toggle
- Program, Bank LSB, Bank MSB presets
- MIDI Machine Control functions
- GM1/GM2/XG SysEx Messages
- MIDI Controller Invert/Displacement

Performance Features:

- Program and bank changes
- Snap Shot sends current status for all controllers
- Drawbar Mode for faders
- Controller Mute mutes controller output to avoid parameter jumps

3



[You're reading an excerpt. Click here to read official M-AUDIO KEYSTATION PRO 88 user guide](http://yourpdfguides.com/dref/2822988)
<http://yourpdfguides.com/dref/2822988>

Manual abstract:

Your Keystation Pro 88 is more than just a professional keyboard, it is a MIDI controller that gives you hands-on access for control of multiple MIDI parameters, such as MIDI Continuous Controller data (or CCs), RPN/NRPN data, MIDI Bank Change LSB and MSB, and Program Changes on 16 different MIDI channels. You can easily control your studio using only the Keystation Pro 88. To familiarize yourself with installation and the features of the Keystation Pro 88, please spend a few minutes reviewing the Getting Started Guide to learn about basic operation. For advanced functions and programmability, please reference the Advanced User Guide. Features Ports: MIDI OUT MIDI IN USB port Power: USB bus powered DC IN for external PSU Keyboard: 88-note hammer-action keyboard 9 velocity curves Controls: 24 programmable rotary dials 9 full-size programmable faders 22 programmable buttons MIDI-assignable Pitch Bend and Modulation Wheels 2 MIDI-assignable foot pedal inputs 1 MIDI-assignable expression pedal input MIDI Data from Controllers: MIDI control number RPN/NRPN Program, Bank LSB, Bank MSB Pitch Bend GM/GM2/XG SysEx Messages MIDI Data from Buttons: Note On Note On/Off Toggle MIDI CC On/Off Toggle Program, Bank LSB, Bank MSB presets MIDI Machine Control functions GM/GM2/XG SysEx Messages MIDI Controller increment/decrement Performance Features: Program and bank changes Snap Shot sends current status for all controllers Drawbar Mode for faders Controller Mute mutes controller output to avoid parameter jumps 3 Other Features: Memory Dump via Sys Ex 10 memory locations store all settings Selective controller group recall and store MIDI Out USB interface 4 Zones for dividing up the keyboard Wheels and pedals can be assigned differently for each Zone What's In The Box? M-Audio Keystation Pro 88 USB keyboard controller M-Audio Software CD-ROM M-Audio Driver Installer CD-ROM USB cable This Getting Started Guide If any of the above listed items are missing, please contact the retailer from whom you purchased the keyboard. About The Manual This is the Getting Started manual, which covers the basic operation of the M-Audio Keystation Pro 88. You will find a graphic illustration of your keyboard on page 3. We have numbered the important sections of the keyboard in this illustration and used this numbering throughout the manual for easy reference. In-depth programming and advanced features are covered in the Keystation Pro 88 Advanced User Guide. The Advanced User Guide is provided in electronic documentation on the included Driver CD.

This Manual is in the Adobe Acrobat (.pdf) file format. You will need to install Acrobat Reader to either print or view the documentation. The Acrobat Reader program is provided for you on the CD-ROM. Controls and Connectors Top Panel Description: 1.

2. 3. 4. 5. 6.

7. 8. 9. 10. 11. 12. 88-key velocity-sensitive keyboard Pitch Bend and Modulation Wheels Numeric keypad (0-9) +/- Buttons (dual press function sends Snap Shot command) Backlit LCD display Nine function keys with single press functions for Global Channel, Channel Assign, Control Assign, Program, Data LSB, Data MSB, Store, Recall and Zone Range Dual press functions for Control Mute, Control Select, Drawbar, MIDI Out from USB, Velocity Curve, Device ID and Memory Dump. Octave +/- buttons (dual press function controls transpose) Zone/Group buttons enable/disable Zones or Groups MIDI-assignable 60mm faders (9) MIDI-assignable rotary controllers (24) MIDI-assignable buttons (22) Rear Panel Description: 4 13. USB In/Out connects to the USB port of your computer via the included USB cable 14. MIDI Out port connects the keyboard to other MIDI hardware via a standard MIDI 5-Pin DIN plug (not included) and can also be used as a USB-to-MIDI Out interface 15.

MIDI In connects other MIDI equipment to your computer 16. MIDI-assignable sustain pedal inputs (2) 17. MIDI-assignable volume pedal input for connection of an expression pedal (not included) 18. Power On/Off switch 19. DC power input Connecting Your Keyboard Before You Connect: Before you connect your keyboard, please note: While you can power the keyboard via either USB or optional external power supply, in order to avoid damaging the unit, use only one method at a time. Power Connection - USB or External Supply You can power the keyboard either via USB or using an external power supply. To power via USB: 1. Check that the on/off switch (18) on the back of the unit is set to "Off." 2 Plug the USB cable provided with the Keystation Pro 88 into a free USB port on your computer. 3.

Plug the other end of the USB cable into the USB socket on the Keystation Pro 88 (13). Note: The USB cable not only powers the keyboard, but also sends MIDI data to and from your computer system. To power using an external supply: 1. Use a power adapter (not included) with the following specifications: 9V DC output, 250-300mA, center positive. 2.

Make sure you are not already powering the Keystation Pro 88 via USB, and then simply plug the power supply into the jack labeled DC 9V (19) and switch the power on (18). Note: Do not leave the adapter plugged in for long periods of time if the unit is not in use. MIDI Connection - In and Out Ports On the rear panel of the keyboard you will find a MIDI Out port (14) that you can connect to an external sound module or MIDI keyboard. By default (when you switch the unit on), all controller data is sent out via the MIDI Out and the USB Out simultaneously. If you want the MIDI Out to function as a traditional USB-to-MIDI interface, engage the "MIDI Out from USB" mode by pressing dual function buttons (PROGRAM and DATA LSB) labeled for this action.

This is further explained in Advanced User Guide. The MIDI In port (15) can be used to connect external MIDI devices to the PC. The MIDI In port acts as a USB-to-MIDI interface. Both the MIDI In and MIDI Out ports and their functions are further explained in the Advanced User Guide. Windows XP and Mac OS X If you are running Windows XP or Mac OS X, connecting the class-compliant Keystation Pro 88 to your computer via USB cable will cause it to install automatically. You may now move the On/Off Switch on the back of the unit to the "On" position. Other Operating Systems Installing Drivers for Windows 98/ME 1. Power up your PC. 2. Insert the Keystation Pro 88 Installer CD into the CD drive of your PC.

The installer should open automatically. If not, select "Run" from the Start Menu, type "d:\setup.exe" (where "d" is your CD-ROM drive), and then press ENTER. 3. Click on "Drivers Installer." 4. Follow the onscreen instructions. 5. When finished, exit the setup. 6.

Switch on the Keystation Pro 88 (18). Windows will now proceed with the installation of both a USB driver and a MIDI driver. Once this has completed, the unit should be installed. Windows may ask you to restart your computer. 5 Installing Drivers for Windows 2000 1.

Power up your PC.



[You're reading an excerpt. Click here to read official M-AUDIO
KEYSTATION PRO 88 user guide
http://yourpdfguides.com/dref/2822988](http://yourpdfguides.com/dref/2822988)

2. Insert the Keystation Pro 88 Installer CD-ROM into the CD drive of your PC. The installer should open automatically. If not, select "Run" from the Start Menu, type "d:\setup.exe" (where "d" is your CD-ROM drive), and then press ENTER. 3. Click on "Drivers Installer." 4. Follow the onscreen instructions. 5. When finished, exit the setup. 6. Switch on the Keystation Pro 88 (18). Windows will automatically recognize the keyboard and ask for the Keystation Pro 88 Installer CD-ROM.

7. Select the CD-ROM drive and click "OK." Windows will then ask you to select the CD-ROM drive again for the MIDI driver. 8. If Windows reports the drivers have not been digitally signed, click on "Continue Installation." 9. Select the drive once more. 10. Click "OK." You have completed installation of the unit.

Installing Drivers for Apple Mac OS 9.x If you do not have OMS installed on your computer, please run the OMS installer first, as explained below. If OMS is already installed on your computer then please continue on to the driver installation instructions, "Installing the Keystation Pro 88 OMS Driver." To install OMS: Make sure that all programs are shut down before you begin the installation. Also, make sure you have removed any dongles (copy protection devices).

1. 2. 3. 4. 5.

6. Insert the Drivers Installer CD-ROM. Double click on the Keystation Pro 88 Installer CD icon on your desktop Double click on the OS 9 folder. Double click on "Install OMS 2.3.8." Follow the onscreen instructions. OMS will now take a few moments to install. When it has finished, it will ask you to restart the computer. Click "Restart."

"Installing the Keystation Pro 88 OMS Driver 1. 2. 3. 4. 6. 7. Click and drag the USB Drivers Installer to the desktop from the OS 9 window it currently resides in. Double click on the icon. If a window appears, click "Open". Double click on the newly created USB Drivers Installer on your desktop.

Click "Install." The installer automatically places the drivers in the correct system folders. Once the installer has finished installing the drivers, click "Restart." Switch on the Keystation Pro 88 (18). OMS Setup You now have to run the OMS Setup program: 1.

2. 3. 4. 5. Before beginning the setup, ensure that AppleTalk is off.

(This option is found in the chooser.) Open the Hard Drive, then the "Opcode" folder, the "OMS Applications folder," and then "OMS Setup." OMS will inform you that it has not yet been configured. Click "OK." The "Create A New Studio Setup" dialog box now appears. Click "OK." The "OMS Driver Search" box asks you to choose the port to which you have attached the Keystation Pro 88 (either Modem or Printer). DO NOT choose a port; simply click "Search," and OMS will begin searching. IMPORTANT: If the USB cable is not correctly hooked up to the keyboard, setup will fail. 6.

"OMS Driver Setup" shows the Keystation Pro 88 in a list when OMS successfully finds the driver. Click "OK." OMS will now define (shows "Identifying") the Keystation Pro 88 output port. 7. The "OMS MIDI Device Setup" dialog box will appear showing the Keystation Pro 88's output port with an open check box to the left of the port. Click on the open box to enable the output port and click on "OK." 8. Next, the "My Studio Setup" appears with a file save dialog box over it. You must name and save your new Studio Setup (or use the default name) before you can assign an instrument to the Keystation Pro 88's output.

Assign your instrument (this step is optional) and you are done.

9. Your Keystation Pro 88 is ready for use. You can run the OMS Test Studio utility by going to the Studio Menu and releasing the mouse on "Test Studio." Playing a note on your keyboard will give you an audio message from your computer, "MIDI received," while the arrow pointing to the keyboard icon flashes.

Clicking on the keyboard icon with the mouse pointer will send a tone cluster to the Keystation Pro 88's output port.

The LED will light, and the sound module connected to the Keystation Pro 88's MIDI Out port should play the chord. You may now exit OMS Setup by quitting the application. You must complete the configuration process from within your music software application. @@@@The procedure to check the MIDI input device in your software will differ from one program to another, so please refer piece of music in F you would need to press the TRANSPOSE buttons followed by 5 presses on the OCTAVE + button or 7 presses on the OCTAVE - button. Pitch Bend Wheel The Pitch Bend Wheel (2) is primarily used to "bend" the notes played on the keyboard, up or down (higher or lower).

@@@@The Pitch Bend on your Keystation Pro 88 has an even wider scope. @@@@@Each sustain foot pedal can be programmed to send out MIDI notes. @@@@@The two sustain foot pedals and the expression pedal can have a different MIDI assignment for each zone. To learn more about this function please read the "Programming and Editing" section in the Advanced User Guide. Saving and Organizing Presets Once you have familiarized yourself with the Keystation Pro 88's presets, you may want to save and reorganize them. Please note that the factory presets are stored in ROM within the keyboard and can therefore be restored at any time. To rearrange the presets use the following procedure: 1. 2. 3. 4.

Press the function button (7) RECALL. Type the preset number on the numerical keypad (3). Press the function button (6) STORE. Using the numerical keypad (3), enter in the preset memory number that you wish to store the preset to. If you want the Keystation Pro 88 to revert back to the factory defaults, simply hold down the "+/-" buttons while switching the keyboard on. Zones The Zone feature can be used to create up to four keyboards in one by splitting the keyboard into sections. Using Zone Edit Mode, you can assign each Zone an upper key limit and a lower key limit to specify which section of the keyboard should be assigned to a specific zone. To learn more about this function please read the "Programming and Editing" section in the Advanced User Guide. The Channel of a Zone The Zones of the Keystation Pro 88 can transmit data on different MIDI channels. You may have up to 4 different zones enabled at a time. Each range can be set to a different MIDI channel. For instance, you can set a two-octave zone at the bottom for bass transmitting on MIDI channel 1, and a Rhodes keyboard in the upper octaves transmitting on MIDI channel 2. To assign the channel of a Zone: 1. Press the Global Channel button twice 2. Press the Zone Select button (9), and select a Zone.

The LCD will flash the selected zone. 3. Enter the channel number, "00" to "16," for the Zone you selected by using the numeric keypad.



[You're reading an excerpt. Click here to read official M-AUDIO
KEYSTATION PRO 88 user guide
http://yourpdfguides.com/dref/2822988](http://yourpdfguides.com/dref/2822988)

Zone Range You can split the Keystation Pro 88 into a maximum of four Zones by limiting the range of each Zone. Zones may be discrete areas of the keyboard or they can overlap.

To change the range of Zone 1, press the ZONE RANGE button. You will see "ZONE 1" flashing on the LCD display, which indicates that you are editing Zone 1's range. Press the lowermost key on the keyboard, followed by the uppermost key. Now Zone 1's range covers the entire keyboard. Alternatively, you may select two different keys to demarcate the Zone of your choice. To learn more about this function please read the "Programming and Editing" section in the Advanced User Guide. 9 Sending a Snap Shot The Snap Shot feature sends out real-time MIDI data for each controller (on whichever MIDI channel the controller is assigned to), providing a "snap shot" of the settings for each hardware controller to the software parameter it is assigned to. When you send a Snap Shot, the LCD will display "SNAPSHOT." The data for each individual controller will then transmit on the channel that the controller has been assigned to. The parameters of the receiving software should change to mimic the adjustments that were made on the keyboard.

Snap Shot is an excellent way to synchronize the receiving device with the faders and rotary controllers on your keyboard. To send a Snap Shot of the current controller assignments and their values, press the +/- buttons (4) together. When the Snap Shot function is used, the LCD displays a camera symbol. The Snap Shot function can also be used as a creative tool, with interesting and surprising results. It can also be used in conjunction with the Control Mute function explained later in this guide. Draw Bar Mode When the Keystation Pro 88 is in Draw Bar Mode, the faders of the keyboard reverse so that 0 is at the top of the faders while 127 is at the bottom. (The default setting of the keyboard is 127 at the top and 0 at the bottom.) To engage Draw Bar Mode: 1. Press the dual press function buttons (7) (CHANNEL ASSIGN + CONTROLLER ASSIGN) labeled DRAW BAR. When the Draw Bar mode is engaged, the LCD display displays the below fader symbol.

Press the Channel Assign and Controller Assign buttons to disengage Draw Bar Mode. Muting Controllers The Control Mute feature allows you to alter the position of any fader or rotary controller without affecting the settings of your software. Control Mute does not affect any buttons, the foot switch or the keyboard. When Control Mute is engaged and an assignable button, a function key or the keyboard is pressed, the controllers are turned back on and Control Mute disengaged. While Control Mute is engaged, the LCD display reads "Off".

To mute all faders and rotary controllers, press the dual-press function buttons (DATA LSB + DATA MSB) labeled "CTRL MUTE" (7). This is a very useful feature if you are switching between presets and the controllers are out of position. This will allow the controller to be moved to a position relative to the software's controller value, rather than causing the software's controller value to jump. You can also use this feature for creative mixing. If you use the faders for a conventional volume mixer, try engaging the Controller Mute function, change the volume up or down on certain channels and press the Snap Shot buttons.

This will send your changes, in real time, to the software. This form of mixing is very dynamic and cannot be accomplished with a conventional mixer. Program Changes You can send a Program Change message to your sound card, sound module, instrument or any other device that receives standard MIDI messages. To send a Program Change on the Global MIDI Channel: 1. Press the "Program" button (6). 2. Type in the program number you wish to send, using the numerical keypad or the +/- keys (3 or 4). 10 For example, the LCD displays the "PROG" symbol in the right hand corner, indicating that the PROGRAM button has been pressed. The Program value sent on Global MIDI Channel 01 is 00. You can also program the assignable buttons to send out fixed Program messages to individual MIDI channels.

To learn more about this function, please read the "Programming and Editing" section in the Advanced User Guide. Bank Changes If your receiving device has more than 128 programs, you may be able to access the additional banks by sending out Bank Change LSB (Least Significant Bit) and MSB (Most Significant Bit) Messages. To send LSB and MSB Messages: 1. Press the DATA LSB or DATA MSB button (6). 2. Type in the Bank Number you wish to send, using the numerical keypad or the +/- keys (3). Please check the documentation for your receiving device to ensure that it will respond to these messages. To learn more about this function please read the "Programming and Editing" section in the Advanced User Guide. Editing MIDI Controllers Selecting a controller for editing To select one of the Keystation Pro 88 faders or rotary dials for editing, simply move the controller you wish to select. Initially, the LCD display will show the positional value for that controller.

Once you have stopped moving the controller and approximately three seconds have passed, the LCD screen will show two numerical values. The small two-digit number in the lower left corner of the LCD represents the number of the controller you have selected. The large three-digit display will show the controller number that specific controller is assigned to. Assigning MIDI CCs to a controller: 1. Press "Control Assign.

" The LCD will flash the CC symbol. The 3-digit display will indicate the currently assigned MIDI CC number. 2. @@@@ Switch off the unit and leave for 10 seconds. Then restart your computer and try again.

@@My drivers are listed in the Device Manager and are said to be working, but the keyboard is not recognized in any software. Windows 2000 and XP have a limitation to how many MIDI device drivers you can have installed at one time. However, the computer will not give any indication that you are using the maximum number of drivers and the drivers will install as if there is not a problem. To remedy this, go to the driver download section of our website at <http://www.m-audio.com/index.php?do=support.drivers> and download the MIDIFix utility. I have plugged a sustain pedal into my M-Audio keyboard, but it works the wrong way around. The polarity of the sustain pedal is calculated by the keyboard when it is powered up.

On power up, the sustain pedal is assumed to be in the off position. If you want the sustain pedal to be off when it is not pressed, make sure the pedal is not pressed when you power up. When I press a key, there is a delay before I hear any sound. This delay is known as latency. Latency with MIDI signals occurs as a result of the softsynth you are using. MIDI data is simply control data that is read by a softsynth, which must complete a large number of complex calculations in order to produce the sound you hear.



**[You're reading an excerpt. Click here to read official M-AUDIO
KEYSTATION PRO 88 user guide
http://yourpdfguides.com/dref/2822988](http://yourpdfguides.com/dref/2822988)**

This process takes time. If you are experiencing a noticeable delay between playing a note and hearing it, you are most likely using a software-based synthesizer and outputting audio through an audio card that is currently running on a less efficient driver. Try switching to the ASIO driver for your sound card. If your sound card allows you to adjust the buffer settings, lower them until the latency is acceptable.

Caution: Electrostatic Discharge, Electrical Fast Transient and Conducted RF interference may cause the unit to malfunction. In the case of such an occurrence, unplug the unit and plug in again to restore normal operation. Keystation Pro 88 Tested to comply with FCC standards FOR HOME OR STUDIO USE Warranty Information Warranty Terms M-Audio warrants products to be free from defects in materials and workmanship, under normal use and provided that the product is owned by the original, registered user. Visit www.m-audio.com/warranty for terms and limitations applying to your specific product. Warranty Registration Thank you for registering your new M-Audio product. Doing so immediately both entitles you to full warranty coverage and helps M-Audio develop and manufacture the finest quality products available. Register online at www.m-audio.com/register to receive FREE product updates and for the chance to win FREE M-Audio gear. 12 Contact M-Audio For additional files, help or drivers for this product, please visit the support section of our main website <http://www.m-audio.com>. If you have any questions, comments or suggestions about this product or any other M-Audio products, we invite you to contact us directly at: M-AUDIO U.S. 5795 Martin Road, Irwindale, CA 91706-6211, U.S.A. Sales Information: Sales Information (email): Tech Support: Tech Support (email): Fax: Internet Home Page: (626) 633-9050 info@m-audio.com.

com (626) 633-9055 techsupt@m-audio.com (626) 633-9060 <http://www.m-audio.com> M-AUDIO Deutschland (Germany) Kuhallmand 34, D-74613 Ohringen, Germany Sales Information: Sales Information (email): Technical Support: Technical Support (email): Fax: Internet Home Page: 49 7941 98 7000 info@m-audio.de 49 7941 98 70030 support@m-audio.de 07941 98 70070 <http://www.m-audio.de> M-AUDIO U.K. Floor 6, Gresham House, 53 Clarendon Road, Watford WD17 1LA Tel: 01923 204010 · Fax: 01923 204039 Sales Information (phone): Sales Information (fax): Sales Information (email): Technical Support (PC): Technical Support (Mac): Technical Support (email): Internet Home Page: 44 (0) 1442 416590 44 (0) 1442 246832 info@maudio.co.uk 44 (0) 1309 671301 44 (0) 1765 650072 support@maudio.co.uk <http://www.maudio.co.uk>

co.uk M-AUDIO Canada 1400 St-Jean Baptiste Ave. #150 Quebec City, QC G2E 5B7, Canada Tel: 418-872-0444 Fax: 418-872-0034 Email: midimancanada@m-audio.com Internet Home Page: <http://www.m-audio.com>.

ca M-AUDIO France Floor 6, Gresham House, 53 Clarendon Road, Watford WD17 1LA Tel: 01923 204010 · Fax: 01923 204039 Informations Commerciales: 0810 001 105 Informations Commerciales (email): info@m-audio.fr Assistance Technique: 0820 000 731 (PC) ou 0820 391 191 (Mac at général) support@m-audio.fr ou mac@m-audio.fr (email) Fax: +44 (0) 1442 246 832 Site Internet: <http://www.m-audio.fr> M-AUDIO Japan Annex Buliding 6F, 2-18-10 Marunouchi Naka-Ku, Nagoya 460-0002, Japan Tel: Fax: Technical Support: Email: Internet Home Page: 81 52 218 3375 81 52 218 0875 0820 00 731 info@m-audio.co.jp <http://www.m-audio.co>.

jp M71020QS-EN 13 .

jp M71020QS-EN 13 .

jp M71020QS-EN 13 .

jp M71020QS-EN 13 .



[You're reading an excerpt. Click here to read official M-AUDIO KEYSTATION PRO 88 user guide](http://yourpdfguides.com/dref/2822988)
<http://yourpdfguides.com/dref/2822988>