



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NETGEAR XAVB5601. You'll find the answers to all your questions on the NETGEAR XAVB5601 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual NETGEAR XAVB5601
User guide NETGEAR XAVB5601
Operating instructions NETGEAR XAVB5601
Instructions for use NETGEAR XAVB5601
Instruction manual NETGEAR XAVB5601

NETGEAR

Powerline 500 Nano
XAVB5101
User Manual



NETGEAR, Inc.
350 East Plumeria Drive
San Jose, CA 95134
USA

February 2012
202-10861-02
v1.0



[You're reading an excerpt. Click here to read official NETGEAR XAVB5601 user guide](http://yourpdfguides.com/dref/5324772)
<http://yourpdfguides.com/dref/5324772>

Manual abstract:

@@@And/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. @@Statement of Conditions To improve internal design, operational function, and/or reliability, NETGEAR reserves the right to make changes to the products described in this document without notice. NETGEAR does not assume any liability that may occur due to the use, or application of, the product(s) or circuit layout(s) described herein. 8 Use the Security Button to Set the Encryption Key . Getting Started 1 This chapter describes your Powerline 500 Nano XAVB5101, and how your adapters can fit into a home network. For more information about the topics covered in this manual, visit the Support website at <http://support>. Getting Started \ 4 Powerline 500 Nano XAVB5101 Product Details The following figure shows the adapter in detail: Power LED Powerline LED Ethernet LED Security button Ethernet port Figure 2. Adapter LEDs, buttons, and Ethernet port Factory Reset button Filtered AC Socket The filtered AC socket can remove some electrical noise that can affect powerline performance. Plugging the power plugs of nearby devices into the filtered AC socket may improve performance. LEDs Item Power LED Description Solid green. The electrical power is on. The adapter is sending or receiving data. Off. The adapter has not found any other compatible Powerline devices using the same encryption key.

The Pick A Plug feature lets you pick the electrical outlet with the strongest link rate, indicated by the color displayed by the LED: Green: Link rate > 80 Mbps (best) Amber: Link rate > 50 and < 80 Mbps (better) Red: Link rate < 50 Mbps (good) Ethernet LED Solid. The Ethernet port is linked, but there is no activity. Blinking. There is traffic on the Ethernet port. Getting Started \ 5 Powerline 500 Nano XAVB5101 Buttons Two buttons are located on the side of the adapter: Security.

After you plug in your new AV adapters, press the Security button for 2 seconds on both of the AV adapters. Both buttons must be pressed within 2 minutes. Note: The Security button does not work in power saving mode. The unit enters power saving mode if the Ethernet port is idle (not linked) for more than 10 minutes. Reset. Press the Reset button for 1 second, then release to return the Powerline adapter to its factory default settings. Ethernet Port Plug one end of the Ethernet cable that comes with the Powerline 500 Nano XAVB5101 into this port and the other end either into your router, or into the computer or other peripheral devices. Powerline Adapter Label The product label shows unique details specific to your adapter. The product label is located on the back of the adapter. The label contains the following information.

Model number MAC address Device password Serial number 6 \ Chapter 1. Getting Started Powerline 500 Nano XAVB5101 Powerline Adapter in a Home Network You can use Powerline adapters to extend your Ethernet network anywhere in your home using your existing electrical power lines. Here, an Ethernet cable connects the router to the Powerline network. In another room, an Ethernet cable connects a gaming console to the Powerline network. powerline communication Ethernet cables Figure 3. Powerline network with two Powerline adapters For best performance, plan the location of your Powerline devices (to make a Powerline network, you need at least two Powerline devices): Use an electrical outlet that is not controlled by a wall switch to avoid someone unknowingly turning off the power to the outlet. Do not plug in Powerline products to a power strip, extension cord, or surge protector as this might prevent them from working correctly, or reduce the network performance. Avoid plugging Powerline products into electrical outlets located near an appliance that uses a lot of power, such as a washer or dryer, or a refrigerator. This could potentially prevent the adapters from working correctly, or reduce network performance. Different Powerline adapter models can share the network.

Getting Started \ 7 Powerline 500 Nano XAVB5101 To set up your Powerline network: 1. Make sure that your home router is up and running and that Ethernet wired connections are working. 2. Install the first Powerline adapter based on the installation instructions that came in the package. 3. Install the second Powerline adapter, which finds the adapter you just installed. Install any additional Powerline adapters that you plan to use. 5. Test to make sure that the computer or peripheral can access the Powerline network. For example, on a computer, use the Internet.

Another way to test this is to install the Powerline Utility and use it to view all devices on the Powerline network. 6. NETGEAR recommends that you secure your Powerline network from unauthorized access, especially in settings such as apartment buildings. see Powerline Network Security . Powerline Network Security A Powerline network consists of two or more Powerline adapters using the same network encryption key. Securing your network protects the information you send over the Powerline network from unwanted access. If you do not set up security on your network, anyone nearby with a Powerline network can potentially use his or her connection to gain access to your network and information you send over the Internet. This is especially relevant in settings such as apartment buildings, office buildings, dorm rooms, and other populated areas. There are two ways to secure your Powerline network. Use the Security button to automatically generate a random encryption key.

Use the Powerline Utility to specify an encryption key for your Powerline network. If you already have a Powerline network, you need to use the Powerline Utility, which is located on your Resource CD. see Chapter 2 , Powerline Utility. To return the Powerline adapter to its factory default settings, press its Factory Reset button for 1 second, then release. Use the Security Button to Set the Encryption Key Note: An adapter can generate a private key only once. If you want to replace a private key, first reset the adapters to their factory settings. To do this either press the Reset button for 1 second, then release; or use the Powerline Utility factory defaults feature (see Reset a Device to Factory Settings on page 15). 8 \ Chapter 1. Getting Started Powerline 500 Nano XAVB5101 You can use the security button to change the default encryption key and set a private encryption key instead. The default encryption key is HomePlugAV.

1. Verify that all the Powerline adapters to be configured are plugged in. wARNING! Do not press the Security button on the Powerline adapter until installation is complete and all adapters on your network are plugged in and communicating with each other.



[You're reading an excerpt. Click here to read official NETGEAR](#)

[XAVB5601 user guide](#)

<http://yourpdfguides.com/dref/5324772>

Pressing the Security button too soon can temporarily disable Powerline communication. If this should occur, reset the Powerline adapter to its factory default settings (press the Reset button for 1 second, then release).

2. Press the Powerline adapter Security button for 2 seconds. The Power LED starts blinking after you release the button. The adapter automatically creates a new, randomly generated network encryption key that each Powerline adapter on the network will use. At this point, the other adapters in your network cannot communicate with each other.
3. Within 2 minutes of pressing the Security button on the Powerline adapter, press the security button on the second adapter for 2 seconds. In order to pair the devices, you need to press both buttons within 2 minutes. This securely configures your Powerline network with the same network encryption key. 4. If your network has more than two adapters, press the Security button on the next adapter for 2 seconds, then push the Security button on any additional adapters in your network for 2 seconds. The adapters retain security settings even if they are unplugged. Powerline Utility 2 This chapter explains how to install and use the Powerline Utility. The Powerline Utility works with many Powerline AV products. NETGEAR Powerline models XAV1004, XAV2001, XAV2101, and XAVN2001 are compatible and can share the same Powerline network.

You can use the Powerline Utility to access a local Powerline device that is connected to your computer with an Ethernet cable and also to access remote Powerline devices. Remote devices are on the Powerline network, but are not directly cabled to the computer on which you are using the Powerline Utility. You can use the NETGEAR Powerline Utility to:

- Change the name of a Powerline device
- Turn LEDs on or off
- Set encryption keys
- Set up Quality of Service (QoS)
- Restore a device to default configuration settings

Chapter 2. Powerline Utility \ 10 Powerline 500 Nano XAVB5101 Install the Powerline Utility This utility allows you to set your own unique Powerline network encryption key, and prioritize traffic passing through your Powerline network. All devices on a Powerline network can be managed from one computer. If you add another Powerline device to a Powerline network, you can install the Powerline Utility on the computer connected locally to the new adapter, or open the utility on the computer originally used to set up the Powerline network encryption key. You can use any computer to manage the network, but this procedure assumes that you are working from the computer that is connected to a Powerline adapter. To install the Powerline Utility: The Powerline utility is a free download available from the NETGEAR support website.

Scroll down to display the download instructions: 3. Click the Click here to download button and download the utility to your computer.

4. Run the file that you downloaded, and follow the wizard prompts to install the Powerline Utility. click Finish to complete the wizard. The Powerline Utility shortcut icon displays on your desktop. 5.

There are two ways to launch the Powerline Utility: 1. Click this icon located on your desktop. Powerline Utility \ 11 Powerline 500 Nano XAVB5101 Powerline Utility Screen When launched, the Powerline Utility opens to a screen that shows all the devices in your Powerline network.

1. select Device Name. Enter a new name for the Powerline device, and click OK. To do this, follow these steps: 1. Click the Powerline device icon on the Powerline Utility main screen. 2. The factory default encryption key is HomePlugAV. In locations such as apartment buildings or office buildings, oth the new device. 4. Click the device, and select Security from the drop-down list. 5. For most applications, this works fine. 6. The Powerline AV Ethernet Adapter supports the following: 1. MAC address IP port VLAN tags ToS bits (Type of Service routing) QoS settings are applied the Powerline devices on the Powerline network. to set up Quality of Service for Powerline devices: 1.

Start the Powerline Utility and wait for the utility to detect the Powerline AV Ethernet adapters connected to the network. 2. Either click the device, or click the Security icon . The following screen displays: You can use these methods to set up QoS: 1. Destination MAC address TCP/UPP port number 802. To set the traffic prioritization rule for the selected Powerline AV Ethernet Adapter device, click Priority and specify the priority in the QoS Setup section of the screen. 5. If applicable, select the VLAN tag or TOS field check box. These options apply only to QoS-configured networks. The deprecated ToS values range from 0 to 7. Troubleshooting 3 Basic Functioning After you plug in the Powerline adapter, the following sequence of events should occur: 1. The Power LED lights up. 2. After approximately 10 seconds, verify that: a. The Ethernet LED lights or blinks. Troubleshooting Tips The Reset and Security buttons are located on the side panel of the adapter.

Pressing the Reset button longer than 2 seconds does not reset the device. Pressing the Security button longer than 2 seconds does not activate security. LEDs The LEDs indicate activity, and can be used for troubleshooting. LEDs Are Off When the Adapter Is Plugged In 1. First check to make sure that the electrical outlet has power. If power is supplied and the LEDs stay off, someone might have used the Powerline Utility to turn off the LEDs. Use the Powerline Utility to see if that is the case. If so, then use the Powerline Utility to turn them back on. power LED Off: Make sure that power is supplied to the electrical outlet, and that the Powerline devices are not plugged into an extension cord, power strip, or surge protector. appendix \ 19 Powerline 500 Nano XAVB5101 Amber. Power saving mode occurs when the Ethernet LED is off. this can occur when: The Ethernet cable is unplugged. The device connected through the Ethernet cable is turned off. The adapter is idle for 10 minutes. The adapter returns to normal mode within 2 seconds once the Ethernet link is up.

powerline LED Off. The Powerline devices cannot find each other. Make sure that the Powerline devices are plugged into outlets with power, and that they use the same network encryption key. Move the Powerline device to a location closer to the computer or devices. If you have set up network security, make sure that all Powerline devices are using the same encryption key. If the problem occurred after you changed the network encryption key, reset each device to its factory default settings. Then you can customize the encryption key.



[You're reading an excerpt. Click here to read official NETGEAR](#)

[XAVB5601 user guide](#)

<http://yourpdfguides.com/dref/5324772>

amber or red. Move the Powerline device to a closer location. ethernet LED Does Not Blink There is no data traffic.

Make sure that: Your router and modem are switched on. the adapter's cable is securely connected to a router LAN port. The PC connected directly to the router can access the Internet. Press the Reset button on each Powerline device for 1 second to return the Powerline adapter to its factory default settings. If You Do Not See All Your Devices with the Powerline Utility If you click Refresh on the main screen of the Powerline Utility, and do not see all the devices you expect, it could be that a Powerline adapter is in power saving mode or is set to use a different encryption key.

Power saving mode. You might see a message at the bottom of the screen regarding the power saving feature. If a unit goes into power saving mode, the Powerline Utility does not find it. Keeping a connected Ethernet cable plugged into the device keeps it active so that it does not go in to power saving mode. encryption keys are different.

To fix this, you can do one of the following: Reset your Powerline adapters to their factory settings and default encryption key. Then set the encryption for all of your Powerline adapters. Connect your computer to each Powerline device and set up the network encryption key for one adapter at a time. 1kg) 0i° to 40i° C (32° to 104° F) 10% maximum relative humidity, noncondensing 5% maximum relative humidity, noncondensing 128-bit AES 64: number of nodes that can be added to a single network 500 Mbps Not HomePlug v1. Supplementary Information \ 21 Powerline 500 Nano XAVB5101 Safety Information Follow these safety guidelines to ensure your own personal safety and to help protect your system from potential damage. Do not service any product except as explained in your system documentation. Opening or removing covers that are marked with the triangular symbol with a lightning bolt may expose you to electrical shock. Only a trained service technician should service components inside these compartments. To help avoid damaging your system, be sure that the voltage selection switch (if provided) on the power supply is set to match the power available at your location: 110 volts (V), 60 hertz (Hz) in most of North and South America and some Far Eastern countries such as South Korea and Taiwan 100 V, 50 Hz in eastern Japan and 100 V, 60 Hz in western Japan 230 V, 50 Hz in most of Europe, the Middle East, and the Far East Be sure that attached devices are electrically rated to operate with the power available in your location. B Use the following safety guidelines to ensure your own personal safety and to help protect your product from potential damage.

To reduce the risk of bodily injury, electrical shock, fire, and damage to the equipment, observe the following precautions. The socket-outlet shall be installed near the equipment and shall be easily accessible Observe and follow service markings. If any of the following conditions occur, unplug the product from the electrical outlet and replace the part or contact your service provider/retailer: The power cable, extension cable, or plug is damaged. The product has been dropped or damaged. The product does not operate correctly when you follow the operating instructions. Keep your system away from radiators and heat sources. also , do not block cooling vents. Do not spill food or liquids on your system components, and never operate the product in a wet environment. Do not push any objects into the openings of your system. Doing so can cause fire or electric shock by shorting out interior components.

Operate the product only from the type of external power source indicated on the electrical ratings label. Also, be sure that attached devices are electrically rated to operate with the power available in your location. Use only approved power cables. If you have not been provided with a power cable for your system or for any AC powered option intended for your system, purchase a power cable that is approved for use in your country. The power cable must be rated for the product and for the voltage and current marked on the product's electrical ratings label.

appendix B. Notification of Compliance \ 24 Powerline 500 Nano XAVB5101 The voltage and current rating of the cable should be greater than the ratings marked on the product. To help prevent electric shock, plug the system and peripheral power cables into properly grounded electrical outlets. do not use adapter plugs. If you must use an extension cable, use a three-wire cable with properly grounded plugs.

observe extension cable and power strip ratings. Be sure that nothing rests on any cables. Do not modify power cables or plugs. Always follow your local and national wiring rules. Failure of the end-user to comply with the applicable requirements may result in unlawful operation and adverse action against the end-user by the applicable National regulatory authority. This product's firmware limits operation to only the channels allowed in a particular Region or Country. Therefore, all options described in this user's guide may not be available in your version of the product. FCC Requirements for Operation in the United States FCC Information to User This product does not contain any user serviceable components and is to be used with approved antennas only. Any product changes or modifications will invalidate all applicable regulatory certifications and approvals This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Guidelines for Human Exposure This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. , 350 East Plumeria Drive, San Jose, CA 95134, declare under our sole responsibility that the Powerline Nano500 Set XAVB5101 complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: This device may not cause harmful interference, and This device must accept any interference received, including interference that may cause undesired operation. FCC Radio Frequency Interference Warnings & Instructions This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.



[You're reading an excerpt. Click here to read official NETGEAR XAVB5601 user guide](http://yourpdfguides.com/dref/5324772)
<http://yourpdfguides.com/dref/5324772>

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following methods:

*Reorient or relocate the receiving antenna.
Increase the separation between the equipment and the receiver. Connect the equipment into an electrical outlet on a circuit different from that which the radio receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Modifications made to the product, unless expressly approved by NETGEAR, Inc. , could void the user's right to operate the equipment.*

Canadian Department of Communications Radio Interference Regulations This digital apparatus, the Powerline Nano500 Set XAVB5101, does not exceed the Class B limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications. European Union The Powerline Nano500 Set XAVB5101 complies with essential requirements of EU EMC Directive 2004/108/EC and Low Voltage Directive 2006/95/EC as supported by applying the following test methods and standards: EN 60950-1: 2006 +A11:2009 EN 55022:2006 w/A1:2007 EN 55024:1998 w/A1: 2001 and A2:2003 EN 61000-3-2:2006 EN 61000-3-3:2008 CISPR/I/257/CDV Opt B and EN 50412-2-1:2005 26 | Appendix B. .*



[You're reading an excerpt. Click here to read official NETGEAR XAVB5601 user guide](#)

<http://yourpdfguides.com/dref/5324772>