




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PENTAX OPTIO WG-2. You'll find the answers to all your questions on the PENTAX OPTIO WG-2 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

## User manual PENTAX OPTIO WG-2 User guide PENTAX OPTIO WG-2 Operating instructions PENTAX OPTIO WG-2 Instructions for use PENTAX OPTIO WG-2 Instruction manual PENTAX OPTIO WG-2



### Utilities Guide for GPS

**Before using GPS** ..... 2  
**Using the GPS** ..... 5

### Before using GPS

**About GPS**  
GPS means Global Positioning System. The camera receives signals from GPS satellites to determine its position and the time. This is called "positioning".

**Function of Optio WG-2 GPS**  
**Location of where images are shot can be recorded**  
The latitude and longitude etc. of still pictures or movies can be recorded. You can see the positions of images you shot on a map by using the provided software.

**Saving log files**  
The camera receives information from GPS satellites regularly and saves it to the SD Memory Card as a log file in KML format. The log files can be imported to Google Earth or Google Maps or other programs that can read KML files on your computer and you can display your locations on their maps.  
\*Google, Google Earth and Google Maps are trademarks of Google Inc.

**Correct the clock using GPS information**  
The camera corrects its clock automatically using time data received from GPS satellites.

**Precautions for using GPS**

- The GPS function is set to off as the default. To use it, set [GPS On/Off] to [On].
- GPS satellites always move. Depending on the situation (location, time etc.) positioning may take longer or be impossible.
- To use the GPS function, you must be in an open area, such as out of doors.
- Positioning may be difficult or impossible in the following situations:
  - Under the water
  - Under the ground or indoors
  - In tunnels
  - Among high-rise buildings
  - Under elevated or near high-voltage electrical power lines
- Among mobile phones that use the 1.5 GHz band
  - When the GPS function is set to on, the camera performs positioning regularly even if it is turned off. Make sure to set [GPS On/Off] to [Off] (p.5) before turning off the camera when taking it where using electronic products is prohibited, such as hospitals or airplanes.
  - Positioning may take few minutes when using the GPS function for the first time, after not positioning for a long while, or after changing the battery.
- The Geocentric system for this camera's GPS function uses the World Geodetic System 1984 (WGS 84).
- Using GPS or recording the positions of images you shot is prohibited in some countries or regions. Consult appropriate embassy or travel agent before traveling with a GPS camera.
- Do not carry the camera in a metal container during positioning. If the camera is covered with metal, the positioning function cannot work.
- In the following situations, the camera cannot receive GPS information. It starts positioning again immediately after being removed from the following situations:
  - When the alarm is set
  - When the camera is connected to a computer with a USB cable
  - When the camera is connected to AV equipment with an AV or HDMI cable
- For a minute after changing the battery
- GPS function of this camera was designed and manufactured for personal digital camera use only. Do not try to use it as a navigation instrument for an aircraft, motor vehicle, personal navigation or any other type of navigation, or for surveying. PENTAX will not be held liable for any damages caused by use of this camera for any of the purposes mentioned above.

**Recording the GPS information on captured images**

When [GPS On/Off] is set to [On], the received GPS information is recorded onto captured images.

**Displaying the GPS information recorded on captured image**

- Press the **OK** button after shooting still pictures or movies.  
The camera enters **INFO** mode and the image appears on the display.
- Press the **OK** button until the GPS information is displayed.  
If the camera did not receive GPS information, the values are displayed as --.

**Recording and Saving a Log**

Records GPS information with interval and duration you have set and records it to the camera as a log.  
The recorded log can be saved to the SD Memory Card as a log file (KML format).

**Recording a Log at a Set Interval and Duration**

- Use the four-way controller (**▲▼**) to select [GPS] on the [Setup] menu.  
The [GPS] screen appears.
- Press the four-way controller (**▶**).  
The [GPS On/Off] screen appears.
- Use the four-way controller (**▲▼**) to select [GPS Logging].  
If you cannot select this menu, set [GPS On/Off] to [On].
- Press the four-way controller (**▶**).  
The [GPS Logging] screen appears.
- Use the four-way controller (**▲▼**) to select [Record log], and press the four-way controller (**▶**).  
The [Recording] screen appears.
- Use the four-way controller (**▲▼**) to select [Logging Interval], and press the four-way controller (**▶**).  
A pull-down menu appears.



You're reading an excerpt. [Click here to read official PENTAX OPTIO WG-2 user guide](http://yourpdfguides.com/dref/4306578)

<http://yourpdfguides.com/dref/4306578>

**Manual abstract:**

The camera receives signals from GPS satellites to determine its position and the time. This is called "positioning". Precautions for using GPS · The GPS function is set to off as the default. To use it, set [GPS On/ Off] to [On]. · GPS satellites always move. Depending on the situation (location, time etc.), positioning may take longer or be impossible. · To use the GPS function, you must be in an open area, such as out of doors. · Positioning may be difficult or impossible in the following situations: - Under the water - Under the ground or indoors - In tunnels - Among high-rise buildings - Under elevated or near high-voltage electrical power lines - In the woods - Near mobile phones that use the 1.5 GHz band · When the GPS function is set to on, the camera performs positioning regularly even if it is turned off.

· The Geodetic system for this camera's GPS function uses the World Geodetic System 1984 (WGS 84). · Using GPS or recording the positions of images you shot is prohibited in some countries or regions. Consult appropriate embassy or travel agent before travelling with a GPS camera. · It starts positioning again immediately after being removed from the following situations: - When the alarm is set - When the camera is connected to a computer with a USB cable - When the camera is connected to AV equipment with an AV or HDMI cable - For a minute after changing the battery · GPS function of this camera was designed and manufactured for personal digital camera use only. Do not try to use it as a navigation instrument for an aircraft, motor vehicle, personal navigation or any 3 other type of navigation, or for surveying.

PENTAX will not be held liable for any damages caused by use of this camera for any of the purposes mentioned above. Using the GPS ....

.....  
.....  
.....  
.....  
.....

· \*Google, Google Earth and Google Maps are trademarks of Google Inc. Correct the clock using GPS information The camera corrects its clock automatically using time data received from GPS satellites. This manual describes how to use the Optio WG-2 GPS camera's GPS function and precautions when using it. Please read this manual before using the GPS function with this camera. 54565 R02BAB12 Printed in Indonesia 2 4 Using the GPS Record the GPS Information on Captured Images Preparation for Using GPS Function Set the [GPS On/Off] to [On] for receiving GPS information (latitude, longitude, altitude, date and time etc.). When the GPS information is recorded on captured images (p.6) and recorded to the camera as a log (p.8), saved to the SD Memory Card as a log file (p.

10) or the camera corrects its clock automatically (p.14), [GPS On/Off] need to be set to [On]. When [GPS On/Off] is set to [On], the received GPS information is recorded onto captured images. The following icons appear on the display. During receiving GPS information. [GPS On/Off] on the [GPS] setting is set to [On], and signals from GPS satellites are being received. Displaying the GPS information recorded on captured image Recording and Saving a Log Receives GPS information with interval and duration you have set and records it to the camera as a log. The recorded log can be saved to the SD Memory Card as a log file (KML format). · The camera enters Q mode and the image appears on the display.

· GPS information has not been received.

· GPS error. · If is still displayed, the built-in GPS unit may be malfunctioning. Contact your nearest PENTAX Service Center.

· When adding a title picture to a movie, the GPS information of the movie is displayed. · When shooting in (Interval Shot) mode, GPS information may not be recorded onto images. Use the four-way controller (23) to select [Off] or [On]. Off: Does not receive GPS information On: Receives GPS information The image on which the GPS information is recorded can be imported to the supplied software "MediaImpression 3.5 for PENTAX" and the position at which the image was shot can be displayed on the map (Windows only.) Select an image in the preview screen and click (position) on [Property] area to display map. \*To display map, you need to connect to the Internet.

I [Media Browser Interface] (Operating Manual p.209) Off 4 5 Press the four-way controller (5). The [GPS Logging] screen appears. GPS GPS On/Off GPS Logging GPS Time Sync MENU Cancel Off On Off OK Use the four-way controller (23) to select [Record log], and press the four-way controller (5). The [Record log] screen appears. GPS Logging Record log Save log data Discard log data MENU OK · The guide of battery life: Approx. 60 hr. · Logging Interval 30sec. 1min. · 1hr.

· Use the four-way controller (23) to select the logging duration, and press the 4 button. Record log Starts log recording Start Logging Interval 15sec. Logging Duration MENU OK 7 Press the 4 button. Returns to the [GPS Logging] screen. · The logs are saved in the SD Memory Card only (you cannot save them in the built-in memory).

· Up to 999 log files or to the capacity of the SD Memory Card can be saved. · The information saved in logs are latitude, longitude, altitude and date and time. · The logs cannot be displayed on the camera. · When the battery level indicator is red, logging stops. · (Interval Shot) and (Interval Movie) cannot be selected from the Capture Mode Palette while recording a log.

Off Use the four-way controller (23) to select [Discard]. Discards log data without saving it 4 5 Press the four-way controller (5). The [GPS Logging] screen appears. Discard Cancel OK OK Use the four-way controller (23) to select [Save log data], and press the 4 button. A confirmation screen appears. 7 Press the 4 button. 9 10 11 12 Deleting logs If 999 log files are saved, the camera cannot save a log file anymore. Insert a new SD Memory Card or delete logs according to the following procedures to save new ones. Correcting time automatically The camera corrects its clock automatically using time data received from GPS satellites. 1 2 Turn the camera on.

[Max # of logs already saved. Delete all existing logs and save current log as new?] message is displayed. 1 2 3 Use the four-way controller (23) to select [GPS] on the [WSetting] menu. Press the four-way controller (5). The [GPS] screen appears. Use the four-way controller (23) to select [Delete All]. Max # of logs already saved. Delete all existing logs and save current log as new? Delete All Cancel OK Use the four-way controller (23) to select.



[You're reading an excerpt. Click here to read official PENTAX](http://yourpdfguides.com/dref/4306578)

[OPTIO WG-2 user guide](http://yourpdfguides.com/dref/4306578)

<http://yourpdfguides.com/dref/4306578>