



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for APPLE NIKE PLUS IPOD SENSOR. You'll find the answers to all your questions on the APPLE NIKE PLUS IPOD SENSOR in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual APPLE NIKE PLUS IPOD SENSOR
User guide APPLE NIKE PLUS IPOD SENSOR
Operating instructions APPLE NIKE PLUS IPOD SENSOR
Instructions for use APPLE NIKE PLUS IPOD SENSOR
Instruction manual APPLE NIKE PLUS IPOD SENSOR



Nike + iPod Sensor



[You're reading an excerpt. Click here to read official APPLE NIKE PLUS IPOD SENSOR user guide](http://yourpdfguides.com/dref/3674014)
<http://yourpdfguides.com/dref/3674014>

Manual abstract:

© 2010 Apple Inc. All rights reserved. @ and other countries. Shuffle is a trademark of Apple Inc. iTunes Store is a service mark of Apple Inc., registered in the U.S. and other countries. NIKE and the Swoosh Design are trademarks of NIKE, Inc. and its affiliates, and are used under license.

The Nike + iPod Sport Kit is covered by one or more of U.S. @@@@All understandings, agreements, or warranties, if any, take place directly between the vendors and the prospective users. Every effort has been made to ensure that the information in this manual is accurate. Apple is not responsible for printing or clerical errors.

Contents 5 5 6 15 15 18 18 18 19 20 21 21 22 23 24 25 26 27 29 31 32 33 34 Welcome to Nike + iPod Your Personal Workout Assistant Quick Start Using Nike + iPod Calibrating Nike + iPod Setting the Unit of Distance Entering Your Weight Locking Your Device During a Workout Getting Spoken Feedback Using a PowerSong Pausing a Workout Receiving Calls During a Workout Changing Music During a Workout Sending Workouts to Nikeplus.com Automatically Reviewing Workouts on Your Device Creating Custom Workout Shortcuts Purchasing Nike+ Workouts Linking a Nike + iPod Compatible Remote or Heart Rate Monitor Working Out with iPod Nano (6th Generation) and a Heart Rate Monitor Linking to Another Sensor Putting the Nike + iPod Sensor to Sleep Important Safety Information Learning More, Service, and Support 3 Welcome to Nike + iPod Your Personal Workout Assistant Nike + iPod is a workout partner and coach all in one. Select the type of workout you want--open-ended, distance, time, or calorie-burning--choose music to keep you motivated, and then keep track of your progress every step of the way with spoken and onscreen feedback. Upload your workout data to nikeplus.com, where you can set goals and monitor your improvement from workout to workout.

Join the world's largest online running community, participating in challenges with runners from across the globe. Nike + iPod is supported by iPhone 3GS, iPhone 4, all iPod nano models, and iPod touch (2nd generation or later). iPod nano (all models) iPod touch (2nd generation or later) iPhone 3GS and iPhone 4 5 Quick Start Follow these instructions to get started using Nike + iPod right away. Step 1: Enable Nike + iPod on your device. mm iPod nano (5th generation or earlier): Attach the Nike + iPod receiver to iPod nano. Nike + iPod appears in the main menu. mm iPod nano (6th generation): Attach the Nike + iPod receiver to iPod nano. Tap Fitness to see the Nike + iPod icon. mm iPhone 3GS, iPhone 4, and iPod touch: Choose Settings > Nike + iPod and set it to On. A Nike + iPod icon appears on the Home screen.

Note: iPhone 3GS, iPhone 4, and iPod touch have an internal receiver; no external receiver is required. Step 2: Make sure you have the latest iPod and iTunes software. 1 Download and install the latest iTunes software to your computer from www.apple.com/itunes. 2 Connect the device to your computer, then select it in the iTunes sidebar and click Summary. 3 If iTunes indicates that your iPod needs an update, click 6 Update and follow the onscreen instructions. Step 3: Insert the Nike + iPod Sensor in your Nike+ ready shoe. mm Lift the insole of the left shoe, remove the foam insert from the pocket underneath, and replace it with the sensor, flat side up. Sensor You can leave the sensor in your shoe when you aren't working out, but if you plan to wear your shoes for a long time without working out, replace the sensor with the foam insert to save battery life.

The battery in the sensor is not replaceable or rechargeable, and has a life of over 1000 hours of active use. Battery life varies, depending on use and other factors. 7 Step 4: Choose a type of workout. An open-ended workout Â iPod nano (5th generation or earlier): Choose Nike + iPod > Nike + iPod > Basic. Â iPod nano (6th generation): Choose Fitness > Nike + iPod > Basic.

Â iPhone 3GS, iPhone 4, and iPod touch: Choose Nike + iPod > Basic. A workout with a time goal Â iPod nano (5th generation or earlier): Choose Nike + iPod > Nike + iPod > Time. Â iPod nano (6th generation): Choose Fitness > Nike + iPod > Time. Â iPhone 3GS, iPhone 4, and iPod touch: Choose Nike + iPod > Time. A workout with a distance goal Â iPod nano (5th generation or earlier): Choose Nike + iPod > Nike + iPod > Distance. Â iPod nano (6th generation): Choose Fitness > Nike + iPod > Distance. Â iPhone 3GS, iPhone 4, and iPod touch: Choose Nike + iPod > Distance. 8 A workout with a calorie-burning goal Â iPod nano (5th generation or earlier): Choose Nike + iPod > Settings > Weight and enter your weight. Then press the Menu button and choose Nike + iPod > Nike + iPod > Calorie. Â iPod nano (6th generation): Choose Settings > Nike + iPod > Weight and enter your weight. Choose Fitness > Nike + iPod > Calories. Â iPhone 3GS, iPhone 4, and iPod touch: Choose Settings > Nike + iPod > Weight and enter your weight. Then press the Home button and choose Nike + iPod > Calorie. Note: You need to enter your weight only the first time you start a calorie burning workout. 9 Step 5: Choose music for your workout.

To play A Nike+ Workout mix The currently playing song A Genius mix Songs from a playlist A podcast An audiobook Songs in random order A radio station Do this Choose the mix (see page 26). Choose Now Playing. Choose Genius Mixes (iPod nano 6th generation). Choose Playlists, then choose a playlist. Choose Podcast (iPod nano 6th generation). Choose Audiobook (iPod nano 6th generation). Choose Shuffle Songs. Using the Radio application, play the music from the radio station you want. Open the Nike + iPod application and begin a workout, then choose None as the music type in the music selection options (iPod nano 5th generation or later). Choose None.

No music Step 6: Start your workout. You next walk or run a few steps to activate your sensor. When your device detects and links to the sensor, you're ready to start the workout. 10 mm iPod nano (5th generation or earlier): Press the Center button and begin walking or running. mm iPod nano (6th generation): Tap Start Workout and begin walking or running.

mm iPhone 3GS, iPhone 4, and iPod touch: Tap Play and begin walking or running. Step 7: Monitor your progress. Nike + iPod automatically displays your workout status on the screen, similar to the following illustration. (Depending on your device type, the screen may appear slightly different.) iPod nano iPhone 3GS iPhone 4, iPod touch 11 Nike + iPod automatically gives you spoken feedback on your progress during your workout (see "Getting Spoken Feedback" on page 19).

You can also get feedback whenever you want it. To get spoken feedback manually: mm iPod nano (5th generation or earlier): Press the Center button at any time during your workout.



[You're reading an excerpt. Click here to read official APPLE NIKE PLUS IPOD SENSOR user guide](http://yourpdfguides.com/dref/3674014)
<http://yourpdfguides.com/dref/3674014>

mm iPod nano (6th generation): Press the Sleep/Wake button at any time during your workout. mm iPhone 3GS, iPhone 4, and iPod touch: Press the Home button at any time during your workout. Note: iPhone 3GS, iPhone 4, and iPod touch must be locked to get spoken feedback manually (see "Getting Spoken Feedback" on page 19). Step 8: End your workout. You can end your workout at any time. If you continue working out after you reach your time, distance, or calorie goal, your progress continues to be monitored. To end your workout: mm iPod nano (5th generation or earlier): Press the Play/Pause (') button to pause your workout. Then press the Menu button and choose End Workout.

mm iPod nano (6th generation): Tap the Pause button, then tap End Workout. If the screen is off, press the Sleep/Wake button. mm iPhone 3GS, iPhone 4, and iPod touch: Tap End Workout. If iPhone or iPod is locked, press the Home button and tap Pause. Then drag the slider and tap End Workout. 12 Step 9: Track your progress at nikeplus.com. At nikeplus.com you can track your progress over time, view a record of all of your past workouts, set and monitor goals, and compare your results with others. You can even compete with other Nike + iPod users in online workout challenges.

You can send your workout data from your computer to nikeplus.com, or if you have iPhone 3GS, iPhone 4, or iPod touch, you can send your workout data wirelessly to the Nike website. It's recommended that you first create a nikeplus.com account before you upload your workout data. Follow the instructions on the nikeplus.com website to sign up for a free account. To send your workout data from your computer to nikeplus.com: 1 Make sure your computer is connected to the Internet, and then connect iPod nano, iPhone 3GS, iPhone 4, or iPod touch to your computer. 2 Click Send in the dialog that asks if you want to send your workout data to nikeplus.com.

You can do it later if you don't want to do it now. 3 Click Visit in the dialog that asks if you want to go to nikeplus.com. The nikeplus.com website opens with a graph showing your most recent workout. 4 Click Save Your Runs, then click Sign Me Up and follow the onscreen instructions. 13 For more information, see "Sending Workouts to Nikeplus.com Automatically" on page 23. To send your workout data wirelessly to nikeplus.com from your iPhone 3GS, iPhone 4, or iPod touch: 1 Make sure your device is connected to the Internet, then choose Nike + iPod.

When you have a workout that hasn't been synced with your nikeplus.com account, a small red dot appears on the History button. 2 Tap the History button to view your workouts. 3 Tap the "Send to Nike+" button to send your workout data to nikeplus.com. You can do it later if you don't want to do it now. 4 Enter your email address and nikeplus.com account password and then tap "Login to Nike +." After you log in, your workouts are sent to your nikeplus.com account.

If you don't have a nikeplus.com account, tap "Join Nike+" and follow the instructions for creating an account. The nikeplus.com website opens with a graph exhibiting your most recent workout. 5 Follow the onscreen instructions for accessing your workouts. For more information, see "Sending Workouts to Nikeplus.com Automatically" on page 23. 14 Using Nike + iPod Follow these instructions to get the most out of Nike + iPod. Calibrating Nike + iPod The default calibration for Nike + iPod is accurate for many users. You can improve the accuracy by calibrating Nike + iPod to your natural running and walking style.

On iPod nano, you can perform a calibration workout over a known distance, or use your last completed workout and enter the distance travelled. On iPhone 3GS, iPhone 4, or iPod touch, you can calibrate using your latest completed workout for which you know the distance traveled. To calibrate Nike + iPod for running and walking using iPod nano (5th generation or earlier): 1 Choose Nike + iPod > Settings > Sensor > Calibrate. 2 Choose Run or Walk and enter a distance. For best results, use a distance of at least one mile. The shortest calibration distance you can enter is one quarter of a mile. 3 Press the Center button. 4 Run or walk the set distance at a steady, natural pace. 5 Press the Menu button and choose Done Calibrating. A message lets you know if the calibration was successful.

If you want to calibrate for both running and walking, repeat steps 15. Note: Even after calibrating, the accuracy of the distance measurements may vary depending on gait, running surface, incline, and temperature. 15 You can also calibrate iPod nano using the workout you just finished. This is useful if you've traveled a known distance that doesn't match the summary distance displayed on your device. To calibrate iPod nano (5th generation or earlier) using your latest completed workout: mm Choose End Workout, press and hold the Center button, then choose Calibrate. Set the correct distance you walked or ran, then press the Center button. The device senses whether the workout was a walk or run, and correctly uses the new calibration instead of the existing one. be connected to the Internet), iTunes prompts you to download feedback in that language. Â iPod nano (5th generation or earlier) can have only one non-English version of spoken feedback at a time. Â iPhone 3GS, iPhone 4, iPod touch, and iPod nano (6th generation) automatically support all spoken feedback languages.

19 Using a PowerSong Choose a song that motivates you and make it your PowerSong. You can switch quickly to your PowerSong at any time during your workout. To choose a PowerSong: mm iPod nano: Choose Nike + iPod > Settings > PowerSong, then choose a song. iPod nano (5th generation) can also use a playlist as a PowerSong. mm iPhone 3GS, iPhone 4, iPod touch, and iPod nano (6th generation): Choose Settings > Nike + iPod > PowerSong, then choose a song.

To play your PowerSong: mm iPod nano (5th generation or earlier): Hold down the Center button during a workout. After a short pause, your PowerSong plays. mm iPod nano (6th generation): Press the Sleep/Wake button to wake the screen, then swipe Now Running and tap PowerSong on the workout screen. When the screen is on, you can also place two fingers on the screen to start the PowerSong. mm iPhone 3GS, iPhone 4, and iPod touch: Tap PowerSong on the workout screen.

If iPhone or iPod touch is locked, press the Home button, drag the slider to unlock, then tap PowerSong. 20 Pausing a Workout You can pause your workout, temporarily stopping music and data collection, and resume the workout later without losing any data. To pause or resume a workout: mm iPod nano (5th generation or earlier): Press the Play/Pause (') button. mm iPhone 3GS, iPhone 4, iPod touch, and iPod nano (6th generation): Tap Pause. If the device is locked, first press the Home button once.



[You're reading an excerpt. Click here to read official APPLE NIKE PLUS IPOD SENSOR user guide](http://yourpdfguides.com/dref/3674014)
<http://yourpdfguides.com/dref/3674014>

Tap Play to resume your workout. If the iPod nano (6th generation) screen is off, press the Sleep/Wake button to wake it. Receiving Calls During a Workout You can use iPhone 3GS or iPhone 4 to answer calls during your workout. When you receive a call, your workout is automatically paused when you answer. To answer a call: mm Tap Answer, or press the mic button if you're wearing the stereo headset.

If iPhone 3GS or iPhone 4 is locked, drag the slider to unlock it. To silence a call: mm Press the Sleep/Wake button or either volume button. You can still answer the call after silencing it, until it goes to voicemail. To decline a call: mm Tap Decline, or hold down the mic button on the headset for about two seconds and then release it. Two low beeps confirm that the call was declined. 21 You can also press the Sleep/Wake button twice quickly to decline a call. This silences the ringer but the music doesn't resume until the call has gone to voicemail; the workout continues in the background. To resume your workout after a call: mm Tap Play. Changing Music During a Workout You can change your music during a workout without losing your workout data. Your workout is paused while the music changes.

To change music during a workout: 1 iPod nano (5th generation or earlier): Press the Menu button and choose Change Music. Your workout pauses. iPhone 3GS, iPhone 4, iPod touch, and iPod nano (6th generation): Tap Pause, then tap Change Music. If the device is locked, first press the Home button and drag the slider to unlock it. If the iPod nano screen is off, press the Sleep/Wake button to wake it.

2 iPod nano (5th generation or earlier): Choose new music. Your workout resumes automatically. iPhone 3GS, iPhone 4, iPod touch and iPod nano (6th generation): Choose new music. Tap the top of the music screen to return to your workout, then tap Play. 22 Sending Workouts to Nikeplus.com Automatically You can set iTunes to automatically send your workout data to nikeplus.com over the Internet whenever you connect your device to your computer. You can also send your workouts wirelessly to the nikeplus.com using iPhone 3GS, iPhone 4, or iPod touch. To send workouts to nikeplus.com automatically: 1 Make sure your computer is connected to the Internet, and then connect iPod nano, iPhone 3GS, iPhone 4, or iPod touch to your computer. 2 Open iTunes on your computer or device, click the Nike + iPod tab, then select "Automatically send workout data to nikeplus.com." 3 Click "Visit nikeplus.com" below the checkbox or, if you've already set your workout to be sent automatically, click Visit in the dialog that appears.

The nikeplus.com website opens with a graph showing your most recent workout. @@@@2 Choose a date and activity. @@@@Tap Edit, choose a workout session, then tap Delete. @@@@2 Tap Plus (+), then choose the type of workout and the workout goal. 3 Choose music, enter a name for the workout, then tap Save. @@@@Shortcuts are named according to the type of workout and music. @@Choose a shortcut. Shortcuts are named according to the type of workout and music. @@@@When you purchase a Nike+ Workout, you get a single workout track with music and voiceover, and you also get all the individual songs in the mix.

Choose mixes for your level and style of workout. To purchase a Nike+ Workout: 1 Open iTunes and click iTunes Store on the left side of the window, then type "Nike Sport Music" in the iTunes search field. 2 Click the Buy button next to the Nike+ Workout of your choice. 3 Follow the onscreen instructions to complete the purchase. The download begins automatically.

26 4 Connect the device to your computer and load the workout onto the device. Note: The iTunes Store is available only to people age 13 or older, in the U.S. and many other countries; for a list of countries, go to www.apple.com/itunes/download. Terms apply. You must have Internet access (fees may apply) to use the iTunes Store. Linking a Nike + iPod Compatible Remote or Heart Rate Monitor Nike + iPod compatible devices are sold separately from the Nike + iPod Sport Kit and the Nike + iPod Sensor. You can use a compatible remote to control Nike + iPod wirelessly while you work out. iPod nano (5th generation or later) also supports Nike + iPod compatible heart rate monitors.

Before using one of these devices for the first time, you must link it to your iPod nano receiver, iPhone 3GS, iPhone 4, or iPod touch. To link to a Nike + iPod compatible remote (sold separately): mm iPod nano (5th generation or earlier): Connect your Nike + iPod receiver to iPod nano, choose Nike + iPod > Settings > Sensor > Link, then follow the onscreen instructions. mm iPhone 3GS, iPhone 4, iPod touch, and iPod nano (6th generation): Choose Settings > Nike + iPod > Remote, then follow the onscreen instructions. 27 To link to a Nike + iPod compatible heart rate monitor (sold separately): mm iPod nano (5th generation or earlier): Connect your Nike + iPod receiver to iPod nano, choose Nike + iPod > Settings > Heart Rate Monitor > Link, then follow the onscreen instructions.

mm iPod nano (6th generation): Choose Settings > Nike + iPod > Heart Rate Monitor > Link, then follow the onscreen instructions. To unlink a device: mm iPod nano (5th generation or earlier): Choose Nike + iPod > Settings > Remote (or Heart Rate Monitor) > Unlink, then follow the onscreen instructions. mm iPod nano (6th generation): Choose Settings > Nike + iPod > Remote (or Heart Rate Monitor), then tap Unlink. mm iPhone 3GS, iPhone 4, and iPod touch:

Choose Settings > Nike + iPod > Remote (or Heart Rate Monitor), then tap Unlink. You can turn the functions of a Nike+ compatible remote on or off without unlinking the device. To turn remote functionality on or off: mm iPod nano (5th generation): Choose Nike + iPod > Settings > Remote, then set Remote to On or Off. mm iPod nano (6th generation): Choose Settings > Nike + iPod > Remote, then set Remote to On or Off. mm iPhone 3GS, iPhone 4, and iPod touch: Choose Settings > Nike + iPod > Remote, then link or unlink the remote. 28 Working Out with iPod Nano (6th Generation) and a Heart Rate Monitor If you have iPod nano (6th generation) and a heart rate monitor (purchased separately), iPod nano can record and display your heart rate as you work out. You can also specify a range or "zone" of the maximum and minimum heart rates that you want to maintain during a workout and track how well you maintain your heart rate within that zone as you exercise.

As you work out, iPod nano displays your current heart rate and an upward- or downward-pointing arrow appears when you need to increase or decrease your activity. You can use a heart rate monitor while doing any of the standard workouts. You can also monitor your heart rate as you participate in activities besides running or walking. For example, you can use iPod nano and a heart rate monitor as you participate in sports activities such as basketball, aerobics, circuit training, golf, hiking, soccer, and more.



[You're reading an excerpt. Click here to read official APPLE NIKE PLUS IPOD SENSOR user guide](http://yourpdfguides.com/dref/3674014)
<http://yourpdfguides.com/dref/3674014>

When your workout is done, you can transfer your heart rate information to your nikeplus.com account, where you can review it. As you set up a workout, you can set a zone of maximum and minimum heart rates that you want to maintain when you select a workout. You must first turn on the zone workout feature. 29 To turn zone workouts on or off: mm Tap Settings > Nike + iPod, then tap the On/Off button in Zone Workout. When you turn on zone workouts and select a workout, options appear for setting a heart rate zone.

As you work out, heart rate information is recorded and displayed during any of the workout types. iPod nano (6th generation) also provides a heart rate workout. To perform a heart rate workout, you specify the heart rate zone you want to maintain, choose the activity type that you'll be doing, and then enjoy a good workout. All your heart rate information is recorded automatically. When you do a heart rate workout, you don't need a sensor in your shoe to record motion. To start a heart rate workout: 1 Tap Fitness > Nike + iPod > Heart Rate. 2 Set the heart rate zone you want. 3 Choose an activity and tap Done. 4 Choose the workout music you want. 5 Tap Start Workout and begin your workout.

6 When done, press the Sleep/Wake button to wake the screen, tap Pause, then tap End Workout to finish your heart rate workout. Once you complete a heart rate workout, you can transfer the information to your nikeplus.com account just as you can with your other workouts. 30 Linking to Another Sensor Once your device links to a specific sensor, it's set to link with that sensor only. If you use a different sensor, you must set the device to link to the other sensor. You may want to do this, for example, if there's more than one person in your family with a sensor and Nike+ ready shoes. To link to another sensor: 1 iPod nano: Connect the receiver to iPod nano. 2 Put on the shoes with the new sensor, and make sure there's no other Nike + iPod Sensor nearby. Walk around to activate the sensor so that your receiver can detect it. 3 Link the sensor to your device: Â iPod nano (5th generation or earlier): Choose Nike + iPod > Settings > Sensor > Link, then follow the onscreen instructions.

A message indicates iPod is now linked to the new sensor. Â iPod nano (6th generation) : Choose Settings > Nike + iPod > Sensor, tap Link, then follow the onscreen instructions. Â iPhone 3GS, iPhone 4, and iPod touch: Choose Settings > Nike + iPod > Sensor, tap Link New, then follow the onscreen instructions. Note: If you link to a previously linked sensor, Nike + iPod detects your calibration settings. You don't need to recalibrate.

31 If you connect an iPod receiver to a different iPod and use it with the same sensor, you don't need to relink or recalibrate. The receiver stores your settings, your workout history, and your workout shortcuts. You don't need to relink or recalibrate. Putting the Nike + iPod Sensor to Sleep The sensor is awake and on by default. If you want to store the sensor for a long period of time or stop it from transmitting, you can put it to sleep.

Important: To comply with applicable government regulations, put the sensor to sleep before taking it on an aircraft. To put the sensor to sleep: mm Use a pen or a paper clip to hold down the Sleep/Wake button for three seconds. Sleep/Wake button To wake the sensor: mm Use a pen or a paper clip to press the Sleep/Wake button. 32 Important Safety Information WARNING: Failure to follow these safety instructions could result in injury or damage. Exercising Before starting any exercise program, you should have a complete physical examination by your physician. Do a warmup or stretching exercise before beginning any workout. Be careful and attentive while exercising. Slow down, if necessary, before adjusting your device while running. Stop exercising immediately if you feel pain, or feel faint, dizzy, exhausted, or short of breath. By exercising, you assume the risks inherent in physical exercise, including any injury that may result from such activity.

Do not use the receiver, iPhone, or iPod in or near water or wet locations. Choking hazard The receiver and sensor are potential choking hazards. Keep them away from children under three years of age. Avoid hearing damage Permanent hearing loss may occur if earphones are used at high volume. Set the volume to a safe level. You can adapt over time to a higher volume of sound that may sound normal but can be damaging to your hearing. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. Hearing experts suggest that to protect your hearing: Â Limit the amount of time you use the earphones at high volume. 33 Â Avoid turning up the volume to block out noisy surroundings.

Â Turn down the volume if you can't hear people speaking near you. Disassembling the sensor Do not attempt to open the sensor, disassemble it, or remove the battery. No userserviceable parts are inside. Learning More, Service, and Support Answers to frequently asked questions about Nike + iPod Go to www.apple.com/support/nikeplus.

Service and support for the Nike + iPod Sensor and Receiver Go to www.apple.com/support/nikeplus. Service and support for Nike+ ready shoes or the nikeplus.

com website Go to www.nikeplus.com. Information about using iTunes Open iTunes and choose Help > iTunes Help. Information about using iPod nano or iPod touch Go to www.apple.com/support/ipod. Information about using iPhone 3GS or iPhone 4 Go to www.apple.com/support/iphone.

34 Regulatory Compliance Information FCC Compliance Statement This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See instructions if interference to radio or television reception is suspected. Radio and Television Interference This computer equipment generates, uses, and can radiate radiofrequency energy. If it is not installed and used properly--that is, in strict accordance with Apple's instructions--it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in Part 15 of FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. You can determine whether your computer system is causing interference by turning it off. If the interference stops, it was probably caused by the computer or one of the peripheral devices.



[You're reading an excerpt. Click here to read official APPLE NIKE PLUS IPOD SENSOR user guide](http://yourpdfguides.com/dref/3674014)
<http://yourpdfguides.com/dref/3674014>

@@@· Move the computer farther away from the television or radio. @@@@See the service and support information that came with your Apple product. Or, consult an experienced radio/television technician for additional suggestions. Changes or modifications to this product not authorized by Apple Inc. could void the EMC compliance and negate your authority to operate the product.

36 This product was tested for EMC compliance under conditions that included the use of Apple peripheral devices and Apple shielded cables and connectors between system components. It is important that you use Apple peripheral devices and shielded cables and connectors between system components to reduce the possibility of causing interference to radios, television sets, and other electronic devices. You can obtain Apple peripheral devices and the proper shielded cables and connectors through an Apple Authorized Reseller. For non-Apple peripheral devices, contact the manufacturer or reseller for assistance.

Responsible party (contact for FCC matters only): Apple Inc.

Corporate Compliance 1 Infinite Loop, MS 26-A Cupertino, CA 95014 Wireless Information FCC Wireless Compliance for the Nike + iPod Sensor. The antenna used with this transmitter must not be colocated or operated in conjunction with any other antenna or transmitter subject to the conditions of the FCC Grant. Industry Canada Statement This Class B device meets all requirements of the Canadian interferencecausing equipment regulations. Cet appareil numérique de la Class B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada. European Wireless EU Declaration of Conformity This wireless device complies with the specifications EN 300 328, EN 301-489, EN 50371, and EN 60950 following the provisions of the R&TTE Directive. Industry Canada Statement Complies with the Canadian ICES-003 Class B, RSS 200 specifications. Cet appareil numérique de la classe B est conforme à la norme NMB-003 RSS 210 du Canada. European Community Complies with European Directives 72/23/EEC, 89/336/EEC, and 99/5/EEC. Exposure to Radio Frequency Energy The radiated output power of the included devices is far below the FCC radio frequency exposure limits. 37 Disposal and Recycling Information The Nike + iPod Sensor contains a battery.

Dispose of your Nike + iPod Sensor according to local environmental laws and guidelines. When discarding shoes, remove the Nike + iPod Sensor and dispose of it properly. For information about Apple's recycling program, go to www.apple.com/environment. 2010 38 Türkiye: EEE yönetmeliğine (Elektrikli ve Elektronik Eyalarda Bazı Zararlı Maddelerin Kullanımının Sınırlanmasına Dair Yönetmelik) uygundur. Brasil:Informaçõessobre descarte e reciclagem O símbolo indica que este produto e/ou sua bateria não devem ser descartadas no lixo doméstico. Quando decidir descartar este produto e/ou sua bateria, faça-o de acordo com as leis e diretrizes ambientais locais. Para informações sobre o programa de reciclagem da Apple, pontos de coleta e telefone de informações, visite www.apple.com/br/environment.

European Union--Disposal Information: The symbol above means that according to local laws and regulations your product should be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. Some collection points accept products for free. The separate collection and recycling of your product at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Deutschland: Dieses Gerät enthält Batterien. Bitte nicht in den Hausmüll werfen. Entsorgen Sie dieses Gerät am Ende seines Lebenszyklus entsprechend der maßgeblichen gesetzlichen Regelungen. Nederlands: Gebruikte batterijen kunnen worden ingeleverd bij de chemokar of in een speciale batterijcontainer voor klein chemisch afval (kca) worden gedeponeerd. Taiwan: Apple and the Environment At Apple, we recognize our responsibility to minimize the environmental impact of our operations and products.

For more information, go to www.apple.com/environment. 39 www.apple.com/ipod/nike www.apple.com/support/nikeplus 034-5596-A Printed in XXXX .



[You're reading an excerpt. Click here to read official APPLE NIKE PLUS IPOD SENSOR user guide](http://yourpdfguides.com/dref/3674014)
<http://yourpdfguides.com/dref/3674014>