



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSCH PSB 600 RE. You'll find the answers to all your questions on the BOSCH PSB 600 RE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BOSCH PSB 600 RE
User guide BOSCH PSB 600 RE
Operating instructions BOSCH PSB 600 RE
Instructions for use BOSCH PSB 600 RE
Instruction manual BOSCH PSB 600 RE



Robert Bosch GmbH
Power Tools Division
70745 Leinfelden-Echterdingen
www.bosch-pt.com
2 609 002 371 (2008.01) ○ / 125

PSB
530 RA | 600 RE | 650 RE | 650 RA

 **BOSCH**

de Originalbetriebsanleitung	el Πρωτότυπο οδηγίων χρήσης
en Original instructions	tr Orjinal işletme talimatı
fr Notice originale	
es Manual original	
pt Manual original	
it Istruzioni originali	
nl Oorspronkelijke gebruiksaanwijzing	
da Original brugsanvisning	
sv Bruksanvisning i original	
no Original driftsinstruks	
fi Alkuperäiset ohjeet	



[You're reading an excerpt. Click here to read official BOSCH PSB 600 RE user guide](http://yourpdfguides.com/dref/2287152)
<http://yourpdfguides.com/dref/2287152>

Manual abstract:

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool. 1) Work area safety a) Keep work area clean and well lit. cluttered or dark areas invite accidents. B) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes. C) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control. 2) Electrical safety a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. unmodified plugs and matching outlets will reduce risk of electric shock. B) Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded. C) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock. d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges and moving parts. E) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock. F) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock. @@@@ b) Use personal protective equipment. Always wear eye protection. @@ c) Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents. D) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury. This enables better control of the power tool in unexpected situations. f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts. G) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards. English | 17 4) Power tool use and care a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed. B) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired. C) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally. D) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users. e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools. f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control. g) Use the power tool, accessories and tool bits etc. In accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation. 5) Service a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained. Wear hearing protection when using impact drills. the influence of noise can lead to loss of hearing. Always use the auxiliary handle supplied with the machine. loss of control can cause personal injury. Use appropriate detectors to determine if utility lines are hidden in the work area or call the local utility company for assistance. Contact with electric lines can lead to fire and electric shock. damaging a gas line can lead to explosion. Penetrating a water line causes property damage or may cause an electric shock. Switch off the power tool immediately when the tool insert jams. Be prepared for high reaction torque that can cause kickback. The tool insert jams when: -- the power tool is subject to overload or -- it becomes wedged in the workpiece. Hold the power tool only by the insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will also make exposed metal parts of the power tool "live" and shock the operator. When working with the machine, always hold it firmly with both hands and provide for a secure stance. The power tool is guided more secure with both hands. secure the workpiece. A workpiece clamped with clamping devices or in a vice is held more secure than by hand. Dust from light alloys can burn or explode. Always wait until the machine has come to a complete stop before placing it down. The tool insert can jam and lead to loss of control over the power tool. 18 | English Never use the machine with a damaged cable. @@ Read all safety warnings and all instructions. @@@@ @@@@ It may be used for a preliminary assessment of exposure. @@@@ @@@@ Please observe the article number on the type plate of your machine. The trade names of the individual machines may vary. Wood or plastic chips can easily lead to clogging. wARNING Fire hazard! Do not work metallic materials with the extraction device mounted. Hot metal chips can ignite parts of the extraction device. @@ Before any work on the machine itself, pull the mains plug. @@ This also makes drilling at a right angle easier. @@@@ replace the dust protection ring when worn/damaged. Mounting the Extraction Device Guide the extraction device 9 from the front toward the bottom side of the impact drill. Pay attention that the extraction device 9 faces flush against the casing and that it is locked. Dusts from materials such as lead-containing coatings, some wood types, minerals and metal can be harmful to one's health. Touching or breathing-in the dusts can cause allergic reactions and/or lead to respiratory infections of the user or bystanders. Certain dusts, such as oak or beech dust, are considered as carcinogenic, especially in connection with wood-treatment additives (chromate, wood preservative).



[You're reading an excerpt. Click here to read official BOSCH PSB 600 RE user guide](http://yourpdfguides.com/dref/2287152)
<http://yourpdfguides.com/dref/2287152>

Materials containing asbestos may only be worked by specialists. Use dust extraction whenever possible. Provide for good ventilation of the working place.

English \ 21 Cleaning the Extraction Device (see figure A) Attach the locking latch 17 or empty the dust collector 15 before placing down the extraction device. When the extraction force diminishes or when the level indicator 20 is full, the dust collector 15 must be emptied. For this, press on the riffled surface of the release button 14 and take off the dust collector 15. Empty and clean the dust collector 15. Clean the filter element 19 by gently striking or tapping against it.

check the filter element 19 for damage and replace it as required. For this, as an example, pry off the holder of the filter element 19 () and change the filter element 19 including the holder (). When placing on the holder again, make sure that the rubber gasket is inserted. Reattach the dust collector 15 again and lock it by pressing against the smooth surface of the release button 14. Removing the Extraction Device For removal of the extraction device 9, push the release button 18 to the right or left and pull off the extraction device 9 toward the front.

insert a drill bit into the drill chuck and clamp the drill bit , see section "Changing the Tool" , page 21. Rotate the collar for the depth stop 13 upward until it can be moved on the telescopic guide 12. Place the machine, without switching it on, firmly against the surface to be drilled until the drill bit touches the surface. Slide the collar 13 to the calculated scale value and then rotate the collar 13 downward to lock the determined clearance. Adjusting the Drilling Depth (PSB 600 RE/PSB 650 RE) (ency (PSB 600 RE/PSB 650 RE/PSB 650 RA) With the thumbwheel for speed preselection 7, the required speed/impact frequency can be preselected even during operation.

The required speed/impact frequency depends on the material and the working conditions, and can be determined through practical testing. The wires in the cable are coloured according to the following code: Do not connect the blue or brown wire to the earth terminal of the plug. Important: If for any reason the moulded plug is removed from the cable of this power tool, it must be disposed of safely. Apply the power tool to the screw/nut only when it is switched off.

rotating tool inserts can slip off. After longer periods of working at low speed, allow the machine to cool down by running it for approx. Our after-sales service responds to your questions concerning maintenance and repair of your product as well as spare parts. Exploded views and information on spare parts can also be found under: www. bosch-pt. Com Our customer consultants answer your questions concerning best buy, application and adjustment of products and accessories.

Before any work on the machine itself, pull the mains plug. For safe and proper working, always keep the machine and ventilation slots clean. If the machine should fail despite the care taken in manufacturing and testing procedures, repair should be carried out by an after-sales service centre for Bosch power tools. @@@@ Subject to change without notice. @@Risk finns för att buller leder till hörselskada. Darbeli matkap Ürün kodu Giri gücü Ç k gücü Botaki devir say s Devir say s Darbe say s Anma torku Maksimum ç k gücündeki tork Devir say s ön seçimi Sa/sol dönü Mil kilitleme Toz emme Mil boynu çap Ø maks. Türkçe \ 123 Devir say s n n ve darbe say s n n ayarlanmas Açma/kapama alteri üzerine uygulad n z bast rma kuvvetini 6 azalt p çöaltarak alet çal r durumunda iken de devir say s n ve darbe say s n ayarlayabilirsiniz. Devir say s n n ve darbe say s n n ön seçimi (PSB 600 RE/PSB 650 RE/PSB 650 RA) Devir say s ön seçim dümesi 7 ile gerekli olan devir say s n ve darbe say s n iletim halinde de önceden seçerek ayarlayabilirsiniz. Gerekli devir say s ile darbe say s ilenen malzemeye çal ma koullar na bal olup, en doru biçimde deneyerek tespit edilebilir. Düşük devir say s ile uzun süre çal t n zda, soutma yapmak için elektrikli el aletini bota en yüksek devir say s ile yakla k 3 dakika kadar çal t r n.



[You're reading an excerpt. Click here to read official BOSCH PSB 600 RE user guide](http://yourpdfguides.com/dref/2287152)
<http://yourpdfguides.com/dref/2287152>