



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRIGGS & STRATTON 95900. You'll find the answers to all your questions on the BRIGGS & STRATTON 95900 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BRIGGS & STRATTON 95900  
User guide BRIGGS & STRATTON 95900  
Operating instructions BRIGGS & STRATTON 95900  
Instructions for use BRIGGS & STRATTON 95900  
Instruction manual BRIGGS & STRATTON 95900



- en** Operator's Manual
- bg** Инструкции за експлоатация
- cs** Návod k obsluze
- et** Kasutusjuhend
- hr** Priručnik za operatera
- hu** Kezelési útmutató
- it** Naudojimo instrukcija
- lv** Operatora rokasgrāmata
- pl** Instrukcja obsługi
- ro** Manual de utilizare
- ru** Руководство по эксплуатации
- sl** Priločnik za uporabo

#### Model 90000

300 Series™  
Classic™ 450 Series™  
Sprint™ 475 Series™  
Quattro™ 475 Series™

#### Model 100000

Sprint™ 500 Series™  
Quattro™ 500 Series™  
LX 500 Series™  
SQ 500 Series™  
Q 500/550 Series™



Briggs & Stratton is a registered trademark of Briggs & Stratton Corporation

© 2009 Briggs & Stratton Corporation, Milwaukee, WI, USA. All rights reserved.

Form No. 277038EST C

English	Български	Čeština	eesti keel	Hrvatski	Magyar	Lietuvių	Latviešu	Polski	Română	Русский	Slovenčina
en	bg	cs	et	hr	hu	lt	lv	pl	ro	ru	sl



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 95900 user guide](http://yourpdfguides.com/dref/3638687)  
<http://yourpdfguides.com/dref/3638687>

**Manual abstract:**

*NOTICE: This engine was shipped from Briggs & Stratton without oil. Before you start the engine, make sure you add oil according to the instructions in this manual. If you start the engine without oil, it will be damaged beyond repair and will not be covered under warranty. The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J1940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-05). Torque values are derived at 3060 RPM; horsepower values are derived at 3600 RPM. Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual "on-site" or net power). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc. ), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.*

*Gasoline and its vapors are extremely flammable and explosive. Turn engine off and let engine cool at least 2 minutes before removing the fuel cap. To allow for expansion of the gasoline, do not fill above the bottom of the fuel tank neck. Keep gasoline away from sparks, open flames, pilot lights, heat, and other ignition sources. If fuel spills, wait until it evaporates before starting engine.*

*Do not crank engine with spark plug removed. If engine floods, set choke (if equipped) to OPEN/RUN position, move throttle (if equipped) to FAST position and crank until engine starts. when Operating Equipment · Do not tip engine or equipment at angle which causes gasoline to spill. Never start or run the engine with the air cleaner assembly (if equipped) or the air filter (if equipped) removed. when Changing Oil · @@ when Transporting Equipment · Transport with fuel tank EMPTY or with fuel shut-off valve OFF.*

*when Storing Gasoline Or Equipment With Fuel In Tank · Store away from furnaces, stoves, water heaters or other appliances that have pilot light or other ignition source because they can ignite gasoline vapors. The safety alert symbol is used to identify safety information about hazards that can result in personal injury. a signal word (DANGER, WARNING, or CAUTION) is used with the alert symbol to indicate the likelihood and the potential severity of injury. In addition, a hazard symbol may be used to represent the type of hazard. DANGER indicates a hazard which, if not avoided, will result in death or WARNING indicates a hazard which, if not avoided, could result in death or CAUTION indicates a hazard which, if not avoided, could result in minor or NOTICE indicates a situation that could result in damage to the product. Certain components in this product and its related accessories contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Wash hands after handling. If there is natural or LP gas leakage in area, do not start engine. Do not use pressurized starting fluids because vapors are flammable. Breathing carbon monoxide can cause nausea, fainting or death.*

*start and run engine outdoors. Do not start or run engine in enclosed area, even if doors or windows are open. Rapid retraction of starter cord (kickback) will pull hand and arm toward engine faster than you can let go. Broken bones, fractures, bruises or sprains could result. @@Rotating parts can contact or entangle hands, feet, hair, clothing, or accessories. Keep hands and feet away from rotating parts. tie up long hair and remove jewelry. Do not wear loose-fitting clothing, dangling drawstrings or items that could become caught. Do not check for spark with spark plug removed. Engine parts, especially muffler, become extremely hot.*

*Allow muffler, engine cylinder and fins to cool before touching. Remove accumulated debris from muffler area and cylinder area. @@Other states or federal jurisdictions may have similar laws. Disconnect the spark plug wire and keep it away from the spark plug. Do not tamper with governor spring, links or other parts to increase engine speed.*

*Do not strike the flywheel with a hammer or hard object because the flywheel may later shatter during operation. Compare the illustration 1 with your engine to familiarize yourself with the location of various features and controls. Operation of the engine at altitudes below 2,500 feet (762 meters) with the high altitude kit is not recommended. Gasoline and its vapors are extremely flammable and explosive. Turn engine off and let engine cool at least 2 minutes before removing the fuel cap.*

*To allow for expansion of the gasoline, do not fill above the bottom of the fuel tank neck. Keep gasoline away from sparks, open flames, pilot lights, heat, and other ignition sources. If fuel spills, wait until it evaporates before starting engine. 1. Clean the fuel cap area of dirt and debris. Fill the fuel tank (B) with gasoline. To allow for expansion of the gasoline, do not fill above the bottom of the fuel tank neck (C). Other high-quality detergent oils are acceptable if classified for service SF, SG, SH, SJ or higher. Do not use special additives. Rapid retraction of starter cord (kickback) will pull hand and arm toward engine faster than you can let go.*

*Broken bones, fractures, bruises or sprains could result. @@Gasoline and its vapors are extremely flammable and explosive. Do not crank engine with spark plug removed. If engine floods, set choke (if equipped) to OPEN/RUN position, move throttle (if equipped) to FAST position and crank until engine starts. \*\* Above 80°F (27°C) the use of 10W-30 may cause increased oil consumption. Check oil level more frequently. Before adding or checking the oil · Clean the oil fill area of any debris. 1. Remove the dipstick (A) and wipe with a clean cloth (Figure 2). If low, add oil slowly into the engine oil fill (C). do not overfill. After adding oil, wait one minute and then recheck the oil level. Breathing carbon monoxide can cause nausea, fainting or death. start and run engine outdoors. Do not start or run engine in enclosed area, even if doors or windows are open.*

*Fuel must meet these requirements: · Clean, fresh, unleaded gasoline. Do not mix oil in gasoline or modify the engine to run on alternate fuels. This will damage the engine components and void the engine warranty. To protect the fuel system from gum formation, mix a fuel stabilizer into the fuel. If starting or performance problems occur, change fuel providers or change brands.*



**[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 95900 user guide](http://yourpdfguides.com/dref/3638687)**  
<http://yourpdfguides.com/dref/3638687>

*NOTICE: This engine was shipped from Briggs & Stratton without oil. Before you start the engine, make sure you add oil according to the instructions in this manual. If you start the engine without oil, it will be damaged beyond repair and will not be covered under warranty. Make sure equipment drive controls, if equipped, are disengaged. 3. Move the throttle control (A, Figure 4), if equipped, to the fast position. When starting a new engine for the first time, firmly push the red primer (B) five times. Then for all future starts, push the primer three times (Figure 4). Note: If engine runs out of fuel or has been stored for an extended period of time, it may be necessary to prime 5 times. Note: Priming is usually unnecessary when restarting a warm engine.*

*Note: If you push the primer too many times, excessive fuel will flood the engine and it will be difficult to start. 5. If the product is equipped with an engine stop lever (C), hold the engine stop lever against the handle (Figure 5). Pull the starter cord handle slowly until resistance is felt, then pull rapidly (Figure 4).*

*Note: If the engine does not start after repeated attempts, repeat Steps 4, 5, and 6. Check engine oil level Clean area around muffler and controls In dusty conditions or when airborne debris is present, clean more often. Release the engine stop lever (E). However, if adjustments are required, see any Briggs & Stratton Authorized Dealer for service. NOTICE: The manufacturer of the equipment on which this engine is installed specifies the top speed at which the engine will be operated. Do not exceed this speed.*

*We recommend that you see any Briggs & Stratton Authorized Dealer for all maintenance and service of the engine and engine parts. NOTICE: All the components used to build this engine must remain in place for proper operation. Other parts may not perform as well, may damage the unit, and may result in injury. In addition, use of other parts may void your warranty. Maintenance, replacement, or repair of the emissions control devices and systems may be performed by any non-road engine repair establishment or individual.*

*However, to obtain "no charge" emissions control service, the work must be performed by a factory authorized dealer. Disconnect the spark plug wire and keep it away from the spark plug. Do not tamper with governor spring, links or other parts to increase engine speed. Do not strike the flywheel with a hammer or hard object because the flywheel may later shatter during operation. Do not check for spark with spark plug removed.*

*Note: In some areas, local law requires using a resistor spark plug to suppress ignition signals. @@Engine parts, especially muffler, become extremely hot. Allow muffler, engine cylinder and fins to cool before touching. Remove accumulated debris from muffler area and cylinder area. @@Other states or federal jurisdictions may have similar laws. @@@@Gasoline and its vapors are extremely flammable and explosive. fire or explosion can cause severe burns or death. @@@@Broken bones, fractures, bruises or sprains could result. @@@@Do not discard with household waste. @@@@ 1.*

*With engine off but still warme Dealer in our dealer locator map at BRIGGSandSTRATTON. @@There is no other expressed warranty.*

*@@@@@Any Authorized Service Dealer may perform warranty repairs. @@If a customer differs with the decision of the*

*Service Dealer, an investigation will be made to determine whether the warranty applies. Ask the Service Dealer to submit all supporting facts to his Distributor or the Factory for review. If the Distributor or the Factory decides that the claim is justified, the customer will be fully reimbursed for those items that are defective. To avoid misunderstanding which might occur between the customer and the Dealer, listed below are some of the causes of engine failure that the warranty does not cover. Normal wear: Engines, like all mechanical devices, need periodic parts service and replacement to perform well. Warranty will not cover repair when normal use has exhausted the life of a part or an engine. Warranty would not apply if engine damage occurred because of misuse, lack of routine maintenance, shipping, handling, warehousing or improper installation.*

*Similarly, warranty is void if the serial number of the engine has been removed or the engine has been altered or modified. Improper maintenance: The life of an engine depends upon the conditions under which it operates, and the care it receives. Some applications, such as tillers, pumps and rotary mowers, are very often used in dusty or dirty conditions, which can cause what appears to be premature wear. Such wear, when caused by dirt, dust, spark plug cleaning grit, or other abrasive material that has entered the engine because of improper maintenance, is not covered by warranty. This warranty covers engine related defective material and/or workmanship only, and not replacement or refund of the equipment to which the engine may be mounted.*

*Nor does the warranty extend to repairs required because of: 1 2 3 Problems caused by parts that are not original Briggs & Stratton parts. Equipment controls or installations that prevent starting, cause unsatisfactory engine performance, or shorten engine life. (Contact equipment manufacturer. ) Leaking carburetors, clogged fuel pipes, sticking valves, or other damage, caused by using contaminated or stale fuel. The warranty period begins on the date of purchase by the first retail consumer or commercial end user, and continues for the period of time stated in the table above.*

*"Consumer use" means personal residential household use by a retail consumer. "Commercial use" means all other uses, including use for commercial, income producing or rental purposes. Once an engine has experienced commercial use, it shall thereafter be considered as a commercial use engine for purposes of this warranty. Parts which are scored or broken because an engine was operated with insufficient or contaminated lubricating oil, or an incorrect grade of lubricating oil (check and refill when necessary, and change at recommended intervals). OIL GARD may not shut down running engine. Engine damage may occur if oil level is not properly maintained. Damage or wear to parts caused by dirt, which entered the engine because of improper air cleaner maintenance, re-assembly, or use of a non-original air cleaner element or cartridge. at recommended intervals , clean and/or replace the filter as stated in the Operator's Manual. Parts damaged by over-speeding, or overheating caused by grass, debris, or dirt, which plugs or clogs the cooling fins, or flywheel area, or damage caused by operating the engine in a confined area without sufficient ventilation. clean engine debris at recommended intervals as stated in the Operator's Manual.*

*Engine or equipment parts broken by excessive vibration caused by a loose engine mounting, loose cutter blades, unbalanced blades or loose or unbalanced impellers, improper attachment of equipment to engine crankshaft, over-speeding or other abuse in operation.*



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 95900 user guide](http://yourpdfguides.com/dref/3638687)  
<http://yourpdfguides.com/dref/3638687>

A bent or broken crankshaft, caused by striking a solid object with the cutter blade of a rotary lawn mower, or excessive v-belt tightness. Engine or engine component failure, i. Locate your nearest Authorized Service Dealer in our dealer locator map on BRIGGSandSTRATTON. Commercial Use 2 years 1 year 90 days EPA, and Briggs & Stratton (B&S) are pleased to explain the emissions control system warranty on your Model Year 2008 and later engine/equipment. In California, new small off-road engines must be designed, built, and equipped to meet the State's stringent anti-smog standards. B&S must warrant the emissions control system on your engine/equipment for the periods of time listed below provided there has been no abuse, neglect, or improper maintenance of your small off-road engine. Your emissions control system may include parts such as the carburetor or fuel injection system, fuel tank, ignition system, and catalytic converter. Also included may be hoses, belts, connectors, sensors, and other emissions-related assemblies. Where a warrantable condition exists, B&S will repair your engine/equipment at no cost to you including diagnosis, parts, and labor.

As the small engine/equipment owner, you are responsible for the performance of the required maintenance listed in your owner's manual. B&S recommends that you retain all receipts covering maintenance on your engine/equipment, but B&S cannot deny warranty solely for the lack of receipts or your failure to ensure the performance of all scheduled maintenance. As the engine/equipment owner, you should however be aware that B&S may deny you warranty coverage if your engine/equipment or a part has failed due to abuse, neglect, improper maintenance, or unapproved modifications. You are responsible for presenting your engine/equipment to a B&S distribution center, servicing dealer, or other equivalent entity, as applicable, as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact B&S at (414) 259-5262. Small off-road engines are warranted for two years. If any emissions-related part on your engine/equipment is defective, the part will be repaired or replaced by B&S. Warranted Emissions Parts Coverage under this warranty extends only to the parts listed below (the emissions control systems parts) to the extent these parts were present on the engine purchased. Fuel line, fuel line fittings, clamps · Connectors and assemblies Length of Coverage For a period of two years from date of original purchase, B&S warrants to the original purchaser and each subsequent purchaser that the engine is designed, built, and equipped so as to conform with all applicable regulations adopted by the Air Resources Board; that it is free from defects in material and workmanship that could cause the failure of a warranted part; and that it is identical in all material respects to the engine described in the manufacturer's application for certification.

The warranty period begins on the date the engine is originally purchased. Any warranted part that is not scheduled for replacement as required maintenance in the owner's manual supplied, is warranted for the warranty period stated above. If any such part fails during the period of warranty coverage, the part will be repaired or replaced by B&S at no charge to the owner. any such part repaired or replaced under the warranty will be warranted for the remaining warranty period. Any warranted part that is scheduled only for regular inspection in the owner's manual supplied, is warranted for the warranty period stated above. any such part repaired or replaced under warranty will be warranted for the remaining warranty period. Any warranted part that is scheduled for replacement as required maintenance in the owner's manual supplied, is warranted for the period of time prior to the first scheduled replacement point for that part. if the part fails prior to the first scheduled replacement , the part will be repaired or replaced by B&S at no charge to the owner.

@@@Engines that are certified to meet the California Air Resources Board (CARB) Emissions Standard must display information regarding the Emissions Durability Period and the Air Index. Briggs & Stratton makes this information available to the consumer on our emissions labels.

the engine emissions label will indicate certification information. The Emissions Durability Period describes the number of hours of actual running time for which the engine is certified to be emissions compliant, assuming proper maintenance in accordance with the Operating & Maintenance Instructions. The following categories are used: Moderate: Engine is certified to be emissions compliant for 125 hours of actual engine running time. Intermediate: Engine is certified to be emissions compliant for 250 hours of actual engine running time. Extended: Engine is certified to be emissions compliant for 500 hours of actual engine running time. For example, a typical walk-behind lawn mower is used 20 to 25 hours per year. Therefore, the Emissions Durability Period of an engine with an intermediate rating would equate to 10 to 12 years. Briggs & Stratton engines are certified to meet the United States Environmental Protection Agency (USEPA) Phase 2 emissions standards. For Phase 2 certified engines, the Emissions Compliance Period referred to on the Emissions Compliance label indicates the number of operating hours for which the engine has been shown to meet Federal emissions requirements. for engines less than 225 cc displacement.

Category C = 125 hours , Category B = 250 hours , Category A = 500 hours For engines of 225 cc or more displacement. Category C = 250 hours , Category B = 500 hours , Category A = 1000 hours Coverage shall extend to the failure of any engine components caused by the failure of any warranted emissions parts. Claims and Coverage Exclusions Warranty claims shall be filed according to the provisions of the B&S engine warranty policy. Warranty coverage does not apply to failures of emissions parts that are not original equipment B&S parts or to parts that fail due to abuse, neglect, or improper maintenance as set forth in the B&S engine warranty policy. B&S is not liable for warranty coverage of failures of emissions parts caused by the use of add-on or modified parts.

The following are specific provisions relative to your Emissions Control Warranty Coverage. It is in addition to the B&S engine warranty for non-regulated engines found in the Operator's Manual. Nu purtați haine largi, ˆnururi care atˆrnˆ sau articole care ar putea fi agˆpate. NOTIFICARE: Producˆtorul echipamentului pe care e instalat motorul a precizat turˆpia maximˆ la care poate fi utilizat acest motor.



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 95900 user guide](http://yourpdfguides.com/dref/3638687)  
<http://yourpdfguides.com/dref/3638687>

*Pentru a evita eventualele neînțelegeri care pot interveni între clienții și distribuitori, vă prezentăm enumerate mai jos câteva din cauzele defectării motorului pentru care nu se aplică garanția.*



[You're reading an excerpt. Click here to read official BRIGGS & STRATTON 95900 user guide](http://yourpdfguides.com/dref/3638687)  
<http://yourpdfguides.com/dref/3638687>