

Manual abstract:

Each section of this manual provides you with the information you need to perform operations in each mode. Further details and technical information can be found in the "Reference" section. General Guide Press C to change from mode to mode. After you perform an operation (except for B) in any mode, pressing C returns to the Timekeeping Mode. In any mode, press B to illuminate the display. Timekeeping Mode Telememo Mode World Time Mode Alarm Mode Countdown Timer Mode Stopwatch Mode Hand Setting Mode Press C. Timekeeping This watch features separate digital and analog timekeeping. The procedures for setting the digital time and analog time are different. In the Timekeeping Mode, press A to toggle the display between the date screen and the time screen. Date Screen Time Screen Seconds Hour hand Minute hand To toggle between 12-hour and 24-hour timekeeping In the Timekeeping Mode, press D to toggle between 12-hour timekeeping (indicated by A or P on the display), or 24-hour timekeeping.

With the 12-hour format, the P (PM) indicator appears on the display for times in the range of noon to 11:59 p.m. and the A (AM) indicator appears for times in the range of midnight to 11:59 a.m. @@@@ In the Timekeeping Mode, hold down A until the seconds start to flash, which indicates the setting screen.

2. Press C to move the flashing in the sequence shown below to select the other settings. Seconds Day DST Month Hour Minutes Year To toggle the Timekeeping Mode digital time between DST and Standard Time 1. In the Timekeeping Mode, hold down A until the seconds start to flash, which indicates the setting screen. 2.

Press C once to display the DST setting screen. 3. @4. Press A to exit the setting screen. The DST indicator appears on the Timekeeping, Alarm, and Hand Setting Mode to indicate that Daylight Saving Time is turned on. Setting the Analog Time Perform the procedure below when the time indicated by the analog hands does not match the time of the digital display. To adjust the analog time 1. In the Timekeeping Mode, press C six times to enter the Hand Setting Mode. 2. Hold down A until the current digital time starts to flash, which indicates the analog setting screen.

3. Press D to advance the analog time setting by 20 seconds. Holding down D advances the analog time setting at high speed. 3. When the setting you want to change is flashing, use B and D to change it as described below. Screen FA OFF P 10:08 CAAD 6-30 To do this: Reset the seconds to AA. Toggle between Daylight Saving Time (ON) and Standard Time (OFF). Change the hour or minutes. Change the year. Change the month or day. Do this: Press D. Press D. Use D (+) and B (-). 4. Press A to exit the setting screen.

Resetting the seconds only (without changing the hour, minute, or DST setting) causes the analog minute hand setting to be adjusted automatically. If you change the hour, minute, or DST setting, you should also use the procedure under "To adjust the analog time" to adjust the analog hands accordingly. See "Digital Time Daylight Saving Time (DST) Setting" for details about the DST setting. Resetting the seconds to AA while the current count is in the range of 30 to 59 causes the minutes to be increased by 1. In the range of 00 to 29, the seconds are reset to AA without changing the minutes.

The day of the week is automatically displayed in accordance with the date (year, month, and day) settings. The year can be set in the range of 2000 to 2099. The watch's built-in full automatic calendar makes allowances for different month lengths and leap years. Once you set the date, there should be no reason to change it except after you have the watch's battery replaced. If you need to advance the analog time a long way, press D and B at the same time. This locks the high speed hand movement, so you can release the two buttons. High-speed hand movement continues until you press any button. It will also stop automatically after the time advances 12 hours or if an alarm (daily alarm, Hourly Time Signal, or countdown alarm) starts to sound. 4. Press A to exit the setting screen.

To return to the Timekeeping Mode, press C. 1 USER'S GUIDE 2747 Telememo Remaining memory World Time Telememo lets you store up to 30 records, each containing name and telephone number data. Records are automatically sorted based on the characters of the name. You can recall records by scrolling through them on the display. A Telememo Mode record has a name field and a number field. See "Character List" for details on how the watch sorts records. All of the operations in this section are performed in the Telememo Mode, which you enter by pressing C. City code World Time digitally displays the current time in 30 cities (29 time zones) around the world. All of the operations in this section are performed in the World Time Mode, which you enter by pressing C.

Name World Time Current time for the selected city code Record number The time settings of the Timekeeping Mode and the World Time Mode are independent of each other, so you must make separate settings for each.

This watch is preset with a number of city codes, each of which represents the time zone where that city is located. Number Whenever you change the time setting for any city in the World Time Mode, the settings of all other cities are changed accordingly. If your location is not included in the preset city codes, select the preset city code that is in the same time zone as your location. For full information on city codes, see the "City Code Table". To create a new Telememo record 1.

In the Telememo Mode, press B and D at the same time to display the new data screen. The new data screen shows ____, which indicates that there is no text in the name field. If the new data screen does not appear, it means that memory is full. To store another record, you will first have to delete some of the records stored in memory. New Data Screen 2.

@3. @@The character changes in the following sequence. Press Press . (space) to to to To set the World Time 1. In the World Time Mode, press D to scroll through city codes. 2. @3. @@While a setting is flashing, use D and B to change it. @@@@5.

@@For details, see the "Character List". 4. @5. Repeat steps 3 and 4 until the name is complete. You can input up to eight characters for the name. 6. @@@The number field has a short cursor (_). @@ The number field has spaces for 16 digits. @7. @@The character changes in the following sequence.

Press Press . @@@@2. @3. @4.

@@@@@9. Repeat steps 7 and 8 until you complete number input. You can input up to 16 digits for the number. 10. Press A to store your data and return to the Telememo record screen (without the cursor).

After you press A to store data, the name flashes for about one second to indicate that records are being sorted. Note that a record must have something input in the name field, otherwise you will not be able to store it.



You're reading an excerpt. Click here to read official CASIO 2747 user guide
<http://yourpdfguides.com/dref/529289>

Alarm time (Hour : Minutes) You can set three independent Daily Alarms. When an alarm is turned on, the alarm tone sounds when the alarm time is reached. One of the alarms is a snooze alarm, while the other two are one-time alarms. You can turn on an Hourly Time Signal that causes the watch to beep twice every hour on the hour. There are four screens in the Alarm Mode. Two are for one-time alarms (indicated by numbers AL1 and AL2), one is for a snooze alarm (indicated by SNZ), and one is for the Hourly Time Signal (indicated by SIG). To recall Telememo records In the Telememo Mode, press D (+) to scroll through Telememo records on the display. Only name data appears when you scroll through Telememo records.

Press A to toggle the screen between the name and number fields. Name Press A. Number All of the operations in this section are performed in the Alarm Mode, which you enter by pressing C. To set an alarm time 1. In the Alarm Mode, use D to scroll through the alarm screens until the one whose time you want to set is displayed. The name and number scroll from right to left on the display. A separator (<) is inserted between the last character and first character of the data. Pressing D while the last Telememo record is on the display causes the new data screen to appear. To edit a Telememo record 1. In the Telememo Mode, use D to scroll through the records and display the one you want to edit.

2. Hold down A until the flashing cursor appears on the display. 3. Use C to move the flashing to the character you want to change. 4. Use B and D to change the character. For details on inputting characters, see "To create a new Telememo record" (step 3 for name input and 7 for number input). 5. After making the changes that you want, press A to store them and return to the Telememo record screen. To delete a Telememo record 1. In the Telememo Mode, use D to scroll through the records and display the one you want to delete. 2. Hold down A until the flashing cursor appears on the display. 3. Press B and D at the same time to delete the record. CLR appears to indicate that the record is being deleted. After the record is deleted, the cursor appears on the display, ready for input. 4. Input data or press A to return to the Telememo record screen. To set a one-time alarm, display one of the screens indicated by an alarm number AL1 or AL2.

To ss The countdown timer can be set within a range of one minute to 24 hours. An alarm sounds when the countdown reaches zero. · All of the operations in this section are performed in the Countdown Timer Mode, which you enter by pressing C. Display Illumination Precautions The light that illuminates the face uses two LEDs (light-emitting diode) and a light guide panel that cause the display to glow for easy reading in the dark. In any mode (except when a setting screen is on the display), press B to illuminate the display for about one second. · The illumination provided by the light may be hard to see when viewed under direct sunlight. · The light automatically stops illuminating whenever an alarm sounds. · Frequent use of the light shortens the battery life. Hours Minutes To set the countdown start time 1. In the Countdown Timer Mode, hold down A until the hour setting of the countdown start time starts to flash, which indicates the setting screen.

Character List 2. Press C to move the flashing between the hour and minute settings. 3. While a setting is flashing, use D (+) and B () to change it. · To set the starting value of the countdown time to 24 hours, set 0:00.

4. Press A to exit the setting screen. To use the countdown timer Press D while in the Countdown Timer Mode to start the countdown timer. · When the end of the countdown is reached, the alarm sounds for 10 seconds or until you stop it by pressing any button. @@ Press D again to resume the countdown.

@@ This returns the countdown time to its starting value. @@@@ · The stopwatch continues to run, restarting from zero after it reaches its limit, until you stop it. · The stopwatch measurement operation continues even if you exit the Stopwatch Mode. · Exiting the Stopwatch Mode while a split time is frozen on the display clears the split time and returns to elapsed time measurement. · All of the operations in this section are performed in the Stopwatch Mode, which you enter by pressing C. City City Code PPG PAGO PAGO HNL HONOLULU ANC ANCHORAGE LAX LOS ANGELES DEN CHI NYC DENVER CHICAGO

NEW YORK UTC Differential 11.0 10.0 09.0 08.0 07.

0 06.0 05.0 04.0 03.0 02.0 01.0 +00.0 +01.0 +02.0 +03.

0 +03.5 +04.0 +04.5 +05.0 +05.

5 +06.0 +06.5 +07.0 +08.0 Other major cities in same time zone PAPEETE NOME SAN FRANCISCO, LAS VEGAS, VANCOUVER, SEATTLE, DAWSON CITY EL PASO, EDMONTON HOUSTON, DALLAS/FORT WORTH, NEW ORLEANS, MEXICO CITY, WINNIPEG MONTREAL, DETROIT, MIAMI, BOSTON, PANAMA CITY, HAVANA, LIMA, BOGOTA LA PAZ, SANTIAGO, PORT OF SPAIN SAO PAULO, BUENOS AIRES, BRASILIA, MONTEVIDEO PRAIA DUBLIN, LISBON, CASABLANCA, DAKAR, ABIDJAN MILAN, ROME, MADRID, AMSTERDAM, ALGIERS, HAMBURG, FRANKFURT, VIENNA, STOCKHOLM ATHENS, HELSINKI, ISTANBUL, BEIRUT, DAMASCUS, CAPE TOWN KUWAIT, RIYADH, ADEN, ADDIS ABABA, NAIROBI SHIRAZ ABU DHABI, MUSCAT MALE MUMBAI, KOLKATA COLOMBO JAKARTA, PHNOM PENH, HANOI, VIENTIANE SINGAPORE, KUALA LUMPUR, BEIJING, TAIPEI, MANILA, PERTH, ULAANBAATAR SEOUL, PYONGYANG DARWIN MELBOURNE, GUAM, RABAU PORT VILA CHRISTCHURCH, NADI, NAURU ISLAND Hours Minutes To measure times with the stopwatch Elapsed Time Start Split Time Start Two Finishes Start Split First runner finishes.

*Display time of first runner. Stop Re-start Stop Clear Split Split release Stop Clear CCS CARACAS RIO RIO DE JANEIRO LON LONDON PAR PARIS BER BERLIN CAI CAIRO JRS JERUSALEM JED JEDDAH MOW MOSCOW THR TEHRAN DXB DUBAI KBL KABUL KHI KARACHI DEL DELHI DAC DHAKA RGN YANGON BKK BANGKOK HKG HONG KONG Stop Second runner finishes. Split release Display time of second runner. Clear TYO TOKYO +09.0 ADL ADELAIDE +09.5 SYD SYDNEY +10.0 NOU NOUMEA +11.0 WLG WELLINGTON +12.0 *Based on data as of December 2002. 3 .*



[You're reading an excerpt. Click here to read official CASIO 2747 user guide](http://yourpdfguides.com/dref/529289)
<http://yourpdfguides.com/dref/529289>