




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for CASIO 5069. You'll find the answers to all your questions on the CASIO 5069 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual CASIO 5069 User guide CASIO 5069 Operating instructions CASIO 5069 Instructions for use CASIO 5069 Instruction manual CASIO 5069



You're reading an excerpt. Click here to read official CASIO 5069 user guide <http://yourpdfguides.com/dref/2425452>

Manual abstract:

To get the most out of your purchase, be sure to read this manual carefully. About This Manual Indicator hand What to do if the bottom dial hand is stopped The watch is shipped from the factory with the bottom dial hand stopped in order to conserve battery power. Even though the bottom dial hand is stopped, the watch continues to maintain the current time internally. If the bottom dial hand is stopped when you purchase the watch, press any one of the watch's buttons to start hand movement. Hour hand Minute hand · Each section of this manual provides you with the · Button operations are indicated using the letters shown in the illustration. 30 Bottom dial hand information you need in order to perform operations in each mode. Further details and technical information can be found in the "Reference" section. · The bottom dial is a disk that rotates to indicate various types of information, depending on the mode. - During regular timekeeping, the thick line of the disk 30 indicates the current second. In other modes, the thick line on the disk will indicate the day of the week, the alarm ON/OFF setting, and the DST ON/OFF setting.

- When setting the date, the disk rotates so the arrow Left dial Day mark at the top of the dial points to the value that hand represents the ones digit of the current year setting. Bottom dial hand During a stopwatch operation, the dial rotates at one revolution per second. @@Stopwatch Mode General Guide Press D. @@@@. The indicator hand will move to the city code that is currently selected as the Home City. This is the city code setting mode. · The bottom dial hand also will indicate the current 30 DST on/off setting at this time. 2. Press D to move the indicator hand clockwise, until it points at the city code you want to select as your Home City. @@3. @@@@4.

After the Home City and DST settings are the way you want, press C. · This will cause the watch to beep and the indicator 30 hand to move to the 12 o'clock position. This is the time setting mode. · All hands (except for the indicator hand and the bottom dial hand) and the day display will change Minute hand automatically to the current time and date settings for Hour hand the selected city code. · All button operations are disabled while the hands and Left dial hand day display are changing. 5. Use D (+) and B () to change the time (hour and minute) setting. Indicator 00 · As you set the time, take care to ensure that the 10 hand left dial hand also indicates the correct 24-hour 20 timekeeping hour. 6. After the time setting is the way you want, press C.

30 90 · This will cause the watch to beep and change to the 30 40 year setting mode. 80 7. Use D and B to change the year setting. 70 60 50 · You can set the year within the range of 2001 to 2099. Setting the year (10s digit) · Use B to move the indicator hand clockwise to the value of the tens digit that you want to specify. To set Bottom dial 2012, for example, move the hand to 10. 2 1 hand 3 · Use D to rotate the bottom dial so the ones digit you 0 4 want to specify is at the top (under the mark). To set 2012, for example, rotate the dial until 2 is at the 9 5 top as shown in the illustration. 8 6 7 8. After the year setting is the way you want, press C.

@@@ Press A. Press A to return to regular timekeeping. @@@@ To set June, for example, move the hand to 6 (Jun). 10. After the month setting is the way you want, press C. · This will cause the watch to beep and change to the day setting mode. 11. Use D (+) and B () to change the day setting. · When setting the day, the watch automatically will skip days (30 and 31) that are not included in the currently selected month. If you can't select 30 or 31 when you want to, check to make sure that the proper month is selected.

· You can return to the time setting mode after configuring the day setting by pressing C. Pressing C will cause the watch to beep twice. 3 30 0 Month Day 12. After all of the settings are the way you want and the day display is no longer changing, press A. @@@@ In the Timekeeping Mode, press D to enter the Stopwatch Mode. 2. In the Stopwatch Mode, press B to start elapsed time measurement. 3. Press B to stop elapsed time measurement. @@@@4.

Check the elapsed time. @@@@ In the Timekeeping Mode, press B to start elapsed time measurement. @@@@ Press B to stop elapsed time measurement. @@@@3. Check the elapsed time. @@@@ · To return to regular timekeeping, press D while the stopwatch is reset. 2. Use D (+) and B () to change the alarm time setting in the right dial. · Each press of either button changes the setting by one minute. 3.

After setting the alarm time, press A to exit the setting mode. · Setting the alarm time causes the alarm to turn on automatically. Alarm Operation The alarm tone sounds at the alarm time for 10 seconds, regardless of the mode the watch is in. · Alarm operations are performed in accordance with the Timekeeping Mode time. · Pressing any button stops the alarm tone operation.

To toggle an alarm on and off In the Alarm Mode, press A to toggle the alarm setting indicated by the bottom dial hand ON or OFF. Adjusting the Home Positions If you notice that the watch hands are not indicating 12 o'clock, ON/OFF settings, or other indicator settings correctly, you can adjust the "home positions" of the hands manually to correct them. World Time Indicator hand City code 30 Bottom dial World Time (24-hour format) The World Time Mode shows you the current time in 29 cities (29 time zones) around the world. @@@@ · If the bottom dial hand moves to 12 o'clock, it is in the correct home position. If it doesn't, use D to move the bottom dial hand to 12 o'clock.

30 · The indicator hand is also in the proper home position if it moves to 12 o'clock. If it doesn't, press B to move it to 12 o'clock. Bottom dial hand Correct bottom dial hand and indicator hand home positions To view the time in another city In the World Time Mode, use D to move the indicator hand clockwise to the city code of the city you want to select as the World Time City. · The right dial hands will move to indicate the current time in the selected city code. The day display will continue to indicate the day in your Home City. · For full information on city codes, see the "City Code Table". To check whether the time for the selected city code is Standard Time or Daylight Saving Time 1. In the World Time Mode, use D to select the city code that you want to check. 2. Press A.

@@@@ In the World Time Mode, use D to move the indicator hand to the city code whose Standard Time/Daylight Saving Time setting you want to change. 2. Hold down A for about three seconds until the watch beeps. This will cause the bottom dial to toggle between ON the alarm sounds when the alarm time is reached.



[You're reading an excerpt. Click here to read official CASIO 5069 user guide](http://yourpdfguides.com/dref/2425452)
<http://yourpdfguides.com/dref/2425452>

· Whenever you enter the Alarm Mode, the indicator hand will move to the ALM position. The bottom dial will move to the alarm's current ON/OFF status. @@@@ Leap seconds are added or subtracted as necessary to keep UTC in sync with the Earth's rotation. The reference point for UTC is Greenwich, England. 30 To set an alarm time 1. In the Alarm Mode, hold down A for about three seconds until the watch beeps. This indicates it is in the setting mode. · The bottom dial will move to ON (alarm on) at this time. 2 Operation Guide 5069 Specifications Accuracy at normal temperature: ± 20 seconds a month Timekeeping: Hour, minutes (hand moves every 10 seconds), seconds, 24-hour, day, day of the week Calendar system: Full Auto-calendar pre-programmed from the year 2001 to 2099 Other: Home City code (can be assigned one of 29 city codes); Daylight Saving Time (summer time) / Standard Time Stopwatch: Measuring capacity: 23:59'59.95" Measuring unit: 1/20 second World Time: 29 cities (29 time zones) Other: Standard Time/Daylight Saving Time (summer time); Home City/World Time City swapping Alarm: Daily alarm Battery: One silver oxide battery (Type: SR927W) Approximately 2 years on type SR927W (10 seconds of alarm operation per day) City Code Table City Code PPG HNL ANC LAX DEN CHI NYC SCL RIO FEN RAI UTC LON PAR ATH City Pago Pago Honolulu Anchorage Los Angeles Denver Chicago New York Santiago Rio De Janeiro Fernando De Noronha Praia London Paris Athens UTC Offset 11 10 9 8 7 6 5 4 3 2 1 +0 +1 +2 City Code JED THR DXB KBL KHI DEL DAC RGN BKK HKG TYO ADL SYD NOU WLG City Jeddah Tehran Dubai Kabul Karachi Delhi Dhaka Yangon Bangkok Hong Kong Tokyo Adelaide Sydney Noumea Wellington UTC Offset +3 +3.5 +4 +4.5 +5 +5.5 +6 +6.5 +7 +8 +9 +9.5 +10 +11 +12 · Based on data as of June 2008. · The rules governing global times (UTC offset and GMT differential) and summer time are determined by each individual country.

3.



[You're reading an excerpt. Click here to read official CASIO 5069 user guide](http://yourpdfguides.com/dref/2425452)
<http://yourpdfguides.com/dref/2425452>