



**Manual abstract:**

2329 GENERAL GUIDE · Press B to change from mode to mode. · If you do not perform any operation for a few minutes while a setting screen (with flashing digits) is on the display, the watch automatically exits the setting screen. Timekeeping Mode Stopwatch Mode Press B. Recall Mode Alarm Mode 2329-1 TIMEKEEPING MODE · Pressing C in the Timekeeping Mode illuminates the display for about two seconds. The backlight is disabled while a setting screen is on the display. · When using 12-hour timekeeping, a P appears on the display for "pm" times (noon to 11:59 pm). An "am" time (midnight to 11:59 am) is indicated when there is no P indicator on the display. 24-hour timekeeping is being used when the 24 indicator is on the display. Hour hand Minute hand Month Day Second hand ABOUT THE BACKLIGHT About the Auto Light Switch Function When the auto light switch function is turned on, the backlight automatically turns on for two seconds under the conditions described below. Avoid wearing the watch on the inside of your wrist.

Doing so causes the auto light switch to operate when not needed, which shortens battery life. Moving the watch to a position that is parallel to the ground and then tilting it towards you approximately 40 degrees causes the backlight to illuminate. Parallel to ground 40° PM indicator Hour Seconds Day of week ·

The backlight may not illuminate if the face of the watch is more than 15 degrees off parallel to the left or right. Make sure that the back of your hand is parallel to the ground. Parallel to ground More than 15 degrees too high More than 15 degrees too low Minutes To set the time and date 1.

While in the Timekeeping Mode, hold down A until the seconds digits flash on the display, indicating the setting screen. 2. Press B to move the flashing in the sequence shown below. Seconds Day DST Month Hour Year Minutes 12/24 3. @@@@ Daylight Saving Time (DST), which is also sometimes called "summer time" advances the time for one hour, as is the custom in some areas during the summer.

Remember that not all countries or even local areas use Daylight Saving Time. DST indicator 2 DST indicator 1 DST indicator 2 DST indicator 1 · Static electricity or magnetic force can interfere with proper operation of the auto light switch function. If the backlight does not illuminate, try moving the watch back to the starting position (parallel with the ground) and then tilt it back toward you again. If this does not work, drop your arm all the way down so it hangs at your side, and then bring it back up again. · Under certain conditions the backlight may not light until about one second or less after turn the face of the watch towards you. This does not necessarily indicate malfunction of the backlight. To switch the auto light switch function on and off In the Timekeeping Mode (except when making any settings), hold down C for two seconds to turn the auto light switch function on and off. Auto light switch indicator Hold down C. Press C. ON OFF DST OFF DST ON · DST indicator 1 flashes on the display only while the DST setting is selected on the setting screen.

It shows 0 when DST is turned off, and 1 when DST is turned on. · DST indicator 2 also flashes on the display while the DST setting is selected on the setting screen. In addition, it appears in the Timekeeping Mode and Alarm Mode while DST is turned on. DST indicator 1 is not displayed in these modes while DST is turned off. · While the 12/24 setting is selected, press C to toggle it between 12-hour and 24hour timekeeping. 4. While any other digits are selected (flashing), press C to increase them. Holding down C changes the digits at high speed. 5. After you make the settings you want, press A to exit the setting screen.

· The day of the week is set automatically in accordance with the date. · The date can be set within the range of January 1, 2000 to December 31, 2039. · The auto light switch indicator is shown on the display in all modes while the auto light switch function is on. @@@@ · Frequent use of the backlignht shortens the battery life. @@This is because the EL light vibrates slightly when lit.

It does not indicate malfunction of the watch. Warning! @@Doing so is dangerous and can result in serious personal injury. @@Doing so is dangerous and can result in serious personal injury. @@@@1. @@2.

Rotate the crown to set the hour and minutes. 3. @@@@ · Press C to scroll through Recall Mode records. @@@@1. Press A to start the stopwatch. 2. Press A to stop the stopwatch. @@3. Press C to clear the stopwatch to all zeros (00' 00" 00). Current time When a Daily Alarm is turned on, the alarm sounds for about 20 seconds at the preset time each day.

Press any button to stop the alarm after it starts to sound. When the Hourly Time Signal is turned on, the watch beeps every hour on the hour. To set the alarm time 1. Hold down A while in the alarm Mode, until the hour digits starts to flash on the display, indicating the setting screen. The alarm is automatically turned on at this time. 2. Press B to change the selection in the sequence shown below. Hour Minutes To record a lap time 1. In the Recall Mode, use A to select lap time as the timing operation. @@2.

Enter the Stopwatch Mode, and then press A to start the stopwatch. 3. Press C to freeze the lap time and display the lap number for about six seconds. Stopwatch timing continues internally. · The first nine lap times you record are stored in memory.

@@ · If you continue to perform the lap time operation after 1/100 second there are already nine times in memory, the lap times Seconds are shown on the display but are not stored into memory. · You can perform up to 99 lap time operations (9 stored Minutes + 90 unstored) during each elapsed time operation.

You can recall lap times using the Recall Mode. 4. Press A to stop the time measurement.

5. Press C to clear the stopwatch to all zeros. Daily Alarm indicator Hourly Time Signal indicator 3. Press C to increase the selected digits. Holding down C changes them at high speed. 4. After you make the settings you want, press A to exit the input screen. · The format (12-hour and 24-hour) of the alarm time matches the format you select for normal timekeeping. · When setting the alarm time using the 12-hour format, take care to set the time correctly as morning or afternoon. To stop the alarm · Press any button to stop the alarm after it starts to sound.

To turn a daily Alarm and the Hourly Time Signal on and off Press C while in the Alarm Mode to change the status of the Daily Alarm and Hourly Time Signal in the following sequence. To record a split time 1. In the Recall Mode, use A to select split time as the timing operation. @@2. Enter the Stopwatch Mode, and then press A to start the stopwatch. 3.



**You're reading an excerpt. Click here to read official CASIO WS 300 user guide**  
<http://yourpdfguides.com/dref/2168056>

*@@ Stopwatch timing continues internally. · The first nine split times you record are stored in memory. @@ · If you continue to perform the split time operation after Lap number LAP indicator Both OFF Daily Alarm Only Hourly Time Signal Only Both ON To test the alarm Hold down B in any mode (except when making any settings) to sound the alarm. @@ In the Recall Mode, use A to select split time as the timing operation.*

*@@ 2. Enter the Stopwatch Mode, and then press A to start the stopwatch. 3. Press C as each runner finishes. The finish time and sequence number remains on the display for about six seconds.*

*Stopwatch timing continues internally. · The first nine split times (finish time) you record are stored in memory. @@ · If you continue to perform the split time operation after .*



[You're reading an excerpt. Click here to read official CASIO WS 300 user guide](http://yourpdfguides.com/dref/2168056)

<http://yourpdfguides.com/dref/2168056>