




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for D-LINK DWL-G700AP. You'll find the answers to all your questions on the D-LINK DWL-G700AP in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual D-LINK DWL-G700AP
User guide D-LINK DWL-G700AP
Operating instructions D-LINK DWL-G700AP
Instructions for use D-LINK DWL-G700AP
Instruction manual D-LINK DWL-G700AP



[You're reading an excerpt. Click here to read official D-LINK DWL-G700AP user guide](http://yourpdfguides.com/dref/5129725)

<http://yourpdfguides.com/dref/5129725>

Manual abstract:

.....
.....
.....
.....
.....
.....
.....
.....

. 9 Networking Basics

.....
.....
.....
.....
.....
.....

.... 21 Troubleshooting .

.....
.....
.....
.....
.....
.....
.....

. 34 Technical Specifications

.....
.....
.....
.....
.....

39 Contacting Technical Support

.....
.....
.....
.....
.....
.....

. 41 Warranty

.....
.....
.....
.....

deployed. Inexpensive Solution - Wireless network devices are as competitively priced as conventional Ethernet network devices.

D-Link Systems, Inc. 6 DWL-700AP User's Manual Wireless Basics Wireless Basics (continued) Installation Considerations The number, thickness and location of walls, ceilings, or other objects that the wireless signals must pass through, may limit the range. Typical ranges vary depending on the types of materials and background RF (radio frequency) noise in your home or business. The key to maximizing wireless range is to follow these basic guidelines: 1 Keep the number of walls and ceilings between the DWL-700AP and other network devices to a minimum - each wall or ceiling can reduce your D-Link Air Wireless product's range from 3-90 feet (1-30 meters). Position your devices so that the number of walls or ceilings is minimized.

2 Be aware of the direct line between network devices.



[You're reading an excerpt. Click here to read official D-LINK DWL-G700AP user guide](http://yourpdfguides.com/dref/5129725)

<http://yourpdfguides.com/dref/5129725>

A wall that is 1.5 feet thick (.5 meters), at a 45-degree angle appears to be almost 3 feet (1 meter) thick. At a 2-degree angle it looks over 42 feet (14 meters) thick! Position devices so that the signal will travel straight through a wall or ceiling (instead of at an angle) for better reception. Building Materials can impede the wireless signal - a solid metal door or aluminum studs may have a negative effect on range. Try to position wireless devices and computers with wireless adapters so that the signal passes through drywall or open doorways and not other materials. Keep your product away (at least 3-6 feet or 1-2 meters) from electrical devices or appliances that generate RF noise. 3 4 D-Link Systems, Inc. 7 DWL-700AP User's Manual Getting Started Getting Started Setting up a Wireless Infrastructure Network 2 1 3 4 5 6 Please remember that D-Link Air wireless devices are pre-configured to connect together, right out of the box, with their default settings.

For a typical wireless setup at home (as shown above), please do the following: You will need broadband Internet access (a Cable or DSL-subscriber line into your home or office). Consult with your Cable or DSL provider for proper installation of the modem. Connect the Cable or DSL modem to your broadband router (see the Quick Installation Guide included with your router.) Connect the router to the D-Link Air DWL-700AP. (See the Quick Installation Guide included with the DWL-700). If you are connecting a desktop computer in your network, you can install the D-Link Air DWL-520 Wireless PCI Adapter into an available PCI slot on your desktop computer. (See the Quick Installation Guide included with the DWL-520). Install the D-Link Air DWL-650 Wireless Cardbus Adapter into a laptop computer. (See the Quick Installation Guide included with the DWL-650). D-Link Systems, Inc.

8 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility If you wish to change the default settings or optimize the performance of the DWL-700AP, D-Link has included a configuration utility for this purpose. Whenever you want to configure your network or the DWL-700AP, you can access the Configuration Utility by opening the web-browser and typing in the IP address of the DWL-700AP. The DWL-700AP's default IP address is shown below: Open the web browser Type in the IP address of the access point (The IP address shown in the example above is the default setting. Use this IP address when connecting to a network consisting of other D-Link devices set to their default settings. If you have changed the IP address of the DWL-700AP to conform to a network other than one with D-Link devices, then input that IP address in the web browser, instead of the default IP address shown.

) Type admin in the User name field Leave the Password blank Click OK D-Link Systems, Inc. 9 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility (continued) After logging in, the screen below will appear. Click on the tabs in the screen to access different segments of the Configuration Utility. If you choose to use the web-based configuration menu, please configure the DWL-700AP from a computer with an ethernet connection to the DWL-700AP. Home > Wizard Clicking Apply will save changes made to the page.

Apply Clicking Cancel will clear changes made to the page. Cancel Clicking Help will bring up helpful information regarding the page. Help Clicking Restart will restart the router. (Necessary for some changes.) Restart D-Link Systems, Inc. 10 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility (continued) Home > Wireless AP Name: You may choose to rename your access point, especially if you have more than one access point on your network. SSID: The SSID is a unique name that identifies a network. All devices on a network must share the same SSID name in order to communicate on the network. If you choose to change the SSID from the default setting, input your new SSID name in this field.

The SSID can be up to 32 characters in length. Channel: Channel 6 is the default channel. Input a new number if you want to change the default setting. All devices on the network must be set to the same channel to communicate on the network. WEP Encryption: Select Enable Encryption to use WEP (Wired Equivalent Privacy) on the network. All devices on the network, and the access point, must share the same WEP selection - either Enable or Disable, and they must share the same WEP key. The WEP key is generated from ASCII or Hexadecimal entries that are either 64-, 128-or 256- bit in length. When enabling encryption, select the Key Type (ASCII or Hexadecimal) and then input the appropriate digits or letters. You cf you encounter inconsistent data flow, only minor modifications to the value range between 256 and 2,437 are recommended. Fragmentation: This value should remain at its default setting of 2,347.

If you experience a high packet error rate, you may slightly increase your fragmentation threshold within the value range of 256 to 2,346. Setting the fragmentation threshold too low may result in poor performance. DTIM Interval (Beacon Rate): (Delivery Traffic Indication Message) Enter a value between 1 and 255 (default is 3) for the Delivery Traffic Indication Message. A DTIM is a countdown informing clients of the next window for listening to broadcast and multicast messages. Basic Rates: Default is 2Mbps.

We recommend that you keep the setting at default. If you lose connection at the TX rate, you will regain connection at the basic rate. A lower basic rate will make reconnection easier. TX Rates: Select the transmission rate for the network. The default rate is 11Mbps.

Preamble: Long Preamble is the default setting. (High traffic networks should use the shorter preamble type.) The preamble defines the length of the CRC block (Cyclic Redundancy Check is a common technique for detecting data transmission errors) used in communication between the access point and the roaming wireless network adapters. Authentication: Open System - communicates the key across the network. Shared Key - devices must have identical WEP settings to communicate. Auto - automatically adjusts to the Authentication mode of the wireless client. SSID Broadcast: (Service Set Identifier) Enable or Disable (default) the broadcast of the SSID name across the network. SSID is a name that identifies a wireless network. All devices on a network must use the same SSID to establish communication. D-Link Systems, Inc.

15 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility (continued) Advanced > Filters Use MAC Filters to allow or deny computers by their MAC Addresses from accessing the DWL-700AP. You can either manually add a MAC Address or select the MAC Address from the list of clients that are currently connected to the broadband router (Connected PCs).



[You're reading an excerpt. Click here to read official D-LINK DWL-700AP user guide](http://yourpdfguides.com/dref/5129725)

<http://yourpdfguides.com/dref/5129725>

The default setting is Disabled MAC Filters. MAC Filter List: This list will display the MAC Addresses that are in the selected filter. D-Link Systems, Inc. 16 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility (continued) Tools > Admin New Password: Enter the new password. Confirm Password: Re-enter the password to confirm it. Tools > System Restore: You may also restore the factory settings by clicking on Restore. Make sure to save the unit's settings before clicking on Restore. drive.

Save Settings: The current system settings can be saved as a file onto the local hard Load Settings: The saved file or any other saved setting file can be loaded back on the access point. To reload a system settings file, click on Browse to browse the local hard drive and locate the system file to be used. Click Load when you have selected the file to be loaded back onto the access point. Reset: To complete the reset, click Reset. D-Link Systems, Inc.

17 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility (continued) Tools > Firmware Click on Click here to check for the latest firmware.... Download the latest firmware to your hard drive.

Then click Browse on this page to find the firmware upgrade on your hard drive. Click Apply to start the firmware upgrade. Status > Device Info This screen displays the current wireless and Ethernet settings of the DWL-700AP. D-Link Systems, Inc. 18 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility (continued) Status > Log View Log The access point keeps a running log of events and activities occurring on the AP. If the device is rebooted, the logs are automatically cleared. First Page - The first page of the log. Last Page - The last page of the log. Previous - Moves back one log page. Next - Moves forward one log page.

Clear - Clears the logs completely. D-Link Systems, Inc. 19 DWL-700AP User's Manual Using the Configuration Utility Using the Configuration Utility (continued) Status> Stats Traffic Statistics The access point keeps traffic statistics. You are able to view the statistics of the router on both the Ethernet portion of the network and the wireless portion of the network. The traffic counter will reset if the device is rebooted. Status > Wireless Connected Wireless PCs List This list displays the MAC Addresses of connected PC's and the length of time that they have been connected. Help Menu Select from this menu for extra help. D-Link Systems, Inc. 20 DWL-700AP User's Manual Networking Basics Networking Basics Using the Network Setup Wizard in Windows XP In this section you will learn how to establish a network at home or work, using Microsoft Windows XP. Note: Please refer to websites such as <http://www.homenethelp.com> and <http://www.@@@.@@@.@@@.@@@> Enter a Workgroup name. @@ Please wait while the Network Setup Wizard configures the computer. @@ In this example, Create a Network Setup Disk has been selected.

You will run this disk on each of the computers on your network. @@@@ Right-click on My Computer. @@@@ Input your IP address and subnet mask. (The IP addresses on your network must be within the same range. @@@@ Enter the LAN IP address of the wireless router. @@@@ A window similar to this one will appear. Type ping xxx.xxx.xxx. @@@@ A window similar to this will appear. Type ping xxx.xxx.xxx.xxx where xxx is the IP address of the wireless router or access point. A good wireless connection will show four replies from the wireless router or access point, as shown.

D-Link Systems, Inc. 33 DWL-700AP User's Manual Troubleshooting Troubleshooting This chapter provides solutions to problems that can occur during the installation and operation of the DWL-700AP. We cover various aspects of the network including network adapters. (The examples below are illustrated in Windows XP. If you have another operating system, these solutions will still apply although the appearance on your computer screen may differ.) Note: It is recommended that you use an Ethernet connection to configure the DWL-700AP Access Point. 1. The computer used to configure the DWL-700AP cannot access the configuration menu. Check that the Ethernet LED on the DWL-700AP is ON. If the LED is not ON, check that the cable for the Ethernet connection is securely inserted.

Check that the Ethernet Adapter is working properly. Please see item 3 (Check that the drivers for the network adapters are installed properly) in this Troubleshooting section to check that the drivers are loaded properly. Check that the IP address is in the same range and subnet as the DWL-700AP. Please see Checking the IP Address in Windows XP in the Networking Basics section of this manual. Note: The IP address of the DWL-700AP is 192.

168.0.50. All the computers on the network must have a unique IP address in the same range, e.g.

, 192.168.0.x. Any computers that have identical IP addresses will not be visible on the network. They must all have the same subnet mask, e.g., 255.255.255.

0 Do a Ping test to make sure that the DWL-700AP is responding. Go to Start>Run>Type Command>Type ping 192.168.0.50. A successful ping will show

four replies. D-Link Systems, Inc. 34 DWL-700AP User's Manual Troubleshooting Troubleshooting (continued) 2. The wireless client cannot access the Internet in the Infrastructure mode. Make sure the wireless client is associated and joined with the correct access point.

To check this connection: Right-click on the Local Area Connection icon in the taskbar> select View Available Wireless Networks. The Connect to Wireless Network screen will appear. Please make sure you have selected the correct available network, as shown in the illustrations below. Note: Screen shots were taken using Windows XP. Your screens may look similar.

default default Check that the IP address assigned to the wireless adapter is within the same IP address range as the access point and gateway. Since the DWL-700AP has an IP address of 192.168.0.50, wireless adapters must have an IP address in the same range, e.g., 192.168.0.x. Each device must have a unique IP address; no two devices may have the same IP address. The subnet mask must be the same for all the computers on the network. To check the IP address assigned to the wireless adapter, double-click on the Local Area Connection icon in the taskbar > select the Support tab and the IP address will be displayed. (Please refer to Checking the IP Address in the Networking Basics section of this manual.) If it is necessary to assign a static IP address to the wireless adapter, please refer to the appropriate section in Networking Basics.

If you are entering a DNS server address you must also enter the default gateway address. (Remember that if you have a DHCP-capable router, you will not need to assign a static IP address. See Networking Basics: Assigning a Static IP Address.) D-Link Systems, Inc. 35 DWL-700AP User's Manual Troubleshooting Troubleshooting (continued) 3.



[You're reading an excerpt. Click here to read official D-LINK DWL-G700AP user guide](http://yourpdfguides.com/dref/5129725)
<http://yourpdfguides.com/dref/5129725>

Check that the drivers for the network adapters are installed properly. You may be using different network adapters than those illustrated here, but this procedure will remain the same, regardless of the type of network adapters you are using. Go to Start. Right-click on My Computer. Click Properties. Select the Hardware Tab. Click Device Manager. D-Link Systems, Inc. 36 DWL-700AP User's Manual Troubleshooting Troubleshooting (continued) Double-click on Network adapters. Right-click on D-Link Air DWL-650 Wireless Cardbus Adapter (or whatever network adapter you are using).

Select Properties to check that the drivers are installed properly. D-Link Air DWL-650 Wireless Cardbus Adapter D-Link Air DWL-650 Wireless Cardbus Adapter D-Link Air DWL-650 Wireless Cardbus Adapter Look under Device Status to check that the device is working properly. Cardbus Click OK. D-Link Systems, Inc. 37 DWL-700AP User's Manual Troubleshooting Troubleshooting (continued) 4.

Resetting the DWL-700AP to Factory Default Settings After you have tried other methods for troubleshooting your network, you may choose to reset the DWL-700AP to the factory default settings. Remember that D-Link Air products network together, out of the box, at the factory default settings. To hard-reset the D-Link Air DWL-700AP to the factory default settings, please do the following: Locate the reset button on the back of the DWL-700AP Use a paper clip to press the reset button Hold for about 5 seconds and then release After the DWL-700AP reboots (this may take a few minutes) it will be reset to the factory default settings. D-Link Systems, Inc. 38 DWL-700AP User's Manual Technical Specifications Technical Specifications Standards IEEE 802.11 IEEE 802.11b IEEE 802.3 IEEE 802.3u Port: 10/100 Mbps Fast Ethernet Data Rates*: 1, 2, 5.5, 11Mbps (with Automatic Fallback) Encryption: Supports 64 and 128-bit WEP Media Access Control: CSMA/CA with ACK Frequency Range: 2.

4 - 2.462GHz Operating Range: Indoors - up to 328 feet (100 meters) Modulation Technology: DSSS - Direct Sequence Spread Spectrum 11-chip Barker sequence * Maximum wireless signal rate based on IEEE Standard 802.11b specifications. Actual data throughput will vary. Network conditions and environmental factors, including volume of network traffic, building materials and construction, and network overhead lower actual data throughput rate. D-Link Systems, Inc. 39 DWL-700AP User's Manual Technical Specifications Technical Specifications (continued) Modulation Techniques Barker (1Mbps/0db) Barker (2Mbps/3db) Physical Dimensions: LEDs: CCK (5.5Mbps/5.5db) CCK (11Mbps/8.5db) Transmitter Output Power: L = 5.5 inches (140mm) W = 4.5 inches (114mm) H = 1 inches (25.4mm) 15dBm +/- 2dB External Antenna Type: 2.5dB gain with reverse SMA connector Over-Driving Levels: Power (Green) Link (Green) TX/RX (Green) Power Input: External Power Supply: DC 5V, 2.4A Weight: Tolerates up to +17dBm at the Antenna Device Management Web-Based - Internet Explorer v5 or later; Netscape Navigator v4 or later; or other Java-enabled browsers.

.44 lbs. (200g) Warranty: 1 Year Operating Temperature: 32°F to 131°F (0°C to 55°C) Humidity: 5% - 95%, non-condensing Safety & Emissions FCC UL D-Link Systems, Inc. 40 DWL-700AP User's Manual Technical Support Technical Support Technical Support You can find software updates and user documentation on the D-Link website. D-Link provides free technical support for customers within the United States and within Canada for the duration of the warranty period on this product.

U.S. and Canadian customers can contact D-Link technical support through our website, or by phone. Tech Support for customers within the United States: D-Link Technical Support over the Telephone: (877) 453-5465 24 hours a day, seven days a week. D-Link Technical Support over the Internet: <http://support.dlink.com> email:support@dlink.com Tech Support for customers within Canada: D-Link Technical Support over the Telephone: (800) 361-5265 Monday to Friday 8:30am to 9:00pm EST D-Link Technical Support over the Internet: <http://support.dlink.ca> email:support@dlink.

ca D-Link Systems, Inc. 41 DWL-700AP User's Manual Warranty Warranty (USA only) Subject to the terms and conditions set forth herein, D-Link Systems, Inc. ("D-Link") provides this Limited warranty for its product only to the person or entity that originally purchased the product from: •• D-Link or its authorized reseller or distributor and Products purchased and delivered within the fifty states of the United States, the District of Columbia, U.S. Possessions or Protectorates, U.S. Military Installations, addresses with an APO or FPO. Limited Warranty: D-Link warrants that the hardware portion of the D-Link products described below will be free from material defects in workmanship and materials from the date of original retail purchase of the product, for the period set forth below applicable to the product type ("Warranty Period"), except as otherwise stated herein. 1-Year Limited Warranty for the Product(s) is defined as follows: ••• Hardware (excluding power supplies and fans) One (1) Year Power Supplies and Fans One (1) Year Spare parts and spare kits Ninety (90) days D-Link's sole obligation shall be to repair or replace the defective Hardware during the Warranty Period at no charge to the original owner or to refund at D-Link's sole discretion. Such repair or replacement will be rendered by D-Link at an Authorized D-Link Service Office.

The replacement Hardware need not be new or have an identical make, model or part. D-Link may in its sole discretion replace the defective Hardware (or any part thereof) with any reconditioned product that D-Link reasonably determines is substantially equivalent (or superior) in all material respects to the defective Hardware. Repaired or replacement Hardware will be warranted for the remainder of the original Warranty Period from the date of original retail purchase. If a material defect is incapable of correction, or if D-Link determines in its sole discretion that it is not practical to repair or replace the defective Hardware, the price paid by the original purchaser for the defective Hardware will be refunded by D-Link upon return to D-Link of the defective Hardware. All Hardware (or part thereof) that is replaced by D-Link, or for which the purchase price is refunded, shall become the property of D-Link upon replacement or refund.

Limited Software Warranty: D-Link warrants that the software portion of the product ("Software") will substantially conform to D-Link's then current functional specifications for the Software, as set forth in the applicable documentation, from the date of original retail purchase of the Software for a period of ninety (90) days ("Warranty Period"), provided that the Software is properly installed on approved hardware and operated as contemplated in its documentation.



[You're reading an excerpt. Click here to read official D-LINK DWL-G700AP user guide](http://yourpdfguides.com/dref/5129725)
<http://yourpdfguides.com/dref/5129725>

D-Link further warrants that, during the Warranty Period, the magnetic media on which D-Link delivers the Software will be free of physical defects. D-Link's sole obligation shall be to replace the non-conforming Software (or defective media) with software that substantially conforms to D-Link's functional specifications for the Software or to refund at D-Link's sole discretion. Except as otherwise agreed by D-Link in writing, the replacement Software is provided only to the original licensee, and is subject to the terms and conditions of the license granted by D-Link for the Software. Software will be warranted for the remainder of the original Warranty Period from the date or original retail purchase.

If a material non-conformance is incapable of correction, or if D-Link determines in its sole discretion that it is not practical to replace the non-conforming Software, the price paid by the original licensee for the non-conforming Software will be refunded by D-Link; provided that the non-conforming Software (and all copies thereof) is first returned to D-Link. The license granted respecting any Software for which a refund is given automatically terminates. Non-Applicability of Warranty: The Limited Warranty provided hereunder for hardware and software of DLink's products will not be applied to and does not cover any refurbished product and any product purchased through the inventory clearance or liquidation sale or other sales in which D-Link, the sellers, or the liquidators expressly disclaim their warranty obligation pertaining to the product and in that case, the product is being sold "As-Is" without any warranty whatsoever including, without limitation, the Limited Warranty as described herein, notwithstanding anything stated herein to the contrary. D-Link Systems, Inc. 42 DWL-700AP User's Manual Warranty Warranty (Continued) Submitting A Claim: The customer shall return the product to the original purchase point based on its return policy. In case the return policy period has expired and the product is within warranty, the customer shall submit a claim to D-Link as outlined below: ••The customer must submit with the product as part of the claim a written description of the Hardware defect or Software nonconformance in sufficient detail to allow D-Link to confirm the same. The original product owner must obtain a Return Material Authorization ("RMA") number from the Authorized D-Link Service Office and, if requested, provide written proof of purchase of the product (such as a copy of the dated purchase invoice for the product) before the warranty service is provided. After an RMA number is issued, the defective product must be packaged securely in the original or other suitable shipping package to ensure that it will not be damaged in transit, and the RMA number must be prominently marked on the outside of the package. Do not include any manuals or accessories in the shipping package. D-Link will only replace the defective portion of the Product and will not ship back any accessories.

The customer is responsible for all in-bound shipping charges to D-Link. No Cash on Delivery ("COD") is allowed. Products sent COD will either be rejected by D-Link or become the property of D-Link. Products shall be fully insured by the customer. D-Link will not be held responsible for any packages that are lost in transit to D-Link. The repaired or replaced packages will be shipped to the customer via UPS Ground or any common carrier selected by D-Link, with shipping charges prepaid. Expedited shipping is available if shipping charges are prepaid by the customer and upon request. •••Return Merchandise Ship-To Address USA: 17595 Mt. Herrmann St. Fountain Valley, CA 92708 D-Link may reject or return any product that is not packaged and shipped in strict compliance with the foregoing requirements, or for which an RMA number is not visible from the outside of the package.

The product owner agrees to pay D-Link's reasonable handling and return shipping charges for any product that is not packaged and shipped in accordance with the foregoing requirements, or that is determined by D-Link not to be defective or non-conforming. What Is Not Covered: This limited warranty provided by D-Link does not cover: Products, if in D-Link's judgment, have been subjected to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, repair or service in any way that is not contemplated in the documentation for the product, or if the model or serial number has been altered, tampered with, defaced or removed; Initial installation, installation and removal of the product for repair, and shipping costs; Operational adjustments covered in the operating manual for the product, and normal maintenance; Damage that occurs in shipment, due to act of God, failures due to power surge, and cosmetic damage; Any hardware, software, firmware or other products or services provided by anyone other than D-Link; Products that have been purchased from inventory clearance or liquidation sales or other sales in which D-Link, the sellers, or the liquidators expressly disclaim their warranty obligation pertaining to the product. Repair by anyone other than D-Link or an Authorized D-Link Service Office will void this Warranty. Disclaimer of Other Warranties: EXCEPT FOR THE LIMITED WARRANTY SPECIFIED HEREIN, THE PRODUCT IS PROVIDED "AS-IS" WITHOUT ANY WARRANTY OF ANY KIND WHATSOEVER INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT. @@@@THE FOREGOING EXPRESS WRITTEN WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ANY OTHER WARRANTIES OR REMEDIES, EXPRESS, IMPLIED OR STATUTORY.

Governing Law: This Limited Warranty shall be governed by the laws of the State of California. Some states do not allow exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the foregoing limitations and exclusions may not apply. This limited warranty provides specific legal rights and the product owner may also have other rights which vary from state to state. Trademarks: D-Link is a registered trademark of D-Link Systems, Inc. Other trademarks or registered trademarks are the property of their respective manufacturers or owners.

Copyright Statement: No part of this publication or documentation accompanying this Product may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from D-Link Corporation/D-Link Systems, Inc., as stipulated by the United States Copyright Act of 1976. Contents are subject to change without prior notice. Copyright© 2002 by DLink Corporation/D-Link Systems, Inc. All rights reserved. CE Mark Warning: This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.



[You're reading an excerpt. Click here to read official D-LINK DWL-G700AP user guide](http://yourpdfguides.com/dref/5129725)
<http://yourpdfguides.com/dref/5129725>

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: •••• Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

For detailed warranty outside the United States, please contact corresponding local D-Link office. D-Link Systems, Inc. 44 DWL-700AP User's Manual Warranty Warranty (Continued) FCC Caution: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment; such modifications could void the user's authority to operate the equipment. (1) The devices are restricted to indoor operations within the 5.15 to 5.

25GHz range. (2) For this device to operate in the 5.15 to 5.25GHz range, the devices must use integral antennas. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. IMPORTANT NOTE: FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The antenna(s) used for this equipment must be installed to provide a separation distance of at least eight inches (20 cm) from all persons. This equipment must not be operated in conjunction with any other antenna. D-Link Systems, Inc.

45 DWL-700AP User's Manual Registration Product registration is entirely voluntary and failure to complete or return this form will not diminish your warranty rights. Version 1.3 06/02/05 D-Link Systems, Inc. 46 .



[You're reading an excerpt. Click here to read official D-LINK DWL-G700AP user guide](http://yourpdfguides.com/dref/5129725)

<http://yourpdfguides.com/dref/5129725>