



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ESTATE EED4100SQ. You'll find the answers to all your questions on the ESTATE EED4100SQ in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ESTATE EED4100SQ
User guide ESTATE EED4100SQ
Operating instructions ESTATE EED4100SQ
Instructions for use ESTATE EED4100SQ
Instruction manual ESTATE EED4100SQ

29" (73.7 CM) ELECTRIC DRYER INSTALLATION INSTRUCTIONS

Table of Contents

DRYER SAFETY.....	1	Plan Vent System.....	10
INSTALLATION INSTRUCTIONS.....	1	Install Vent System.....	11
Table of Contents.....	1	Install Leveling Legs.....	11
Tools and Parts.....	1	Connect Vent.....	11
Location Requirements.....	2	Level Dryer.....	11
Electrical Requirements.....	3	Reverse Door Swing (Optional).....	11
Electrical Connection.....	4	Complete Installation.....	12
Venting Requirements.....	9		

DRYER SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER" or "WARNING."

These words mean:

DANGER

You can be killed or seriously injured if you don't immediately follow instructions.

WARNING

You can be killed or seriously injured if you don't follow instructions.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

INSTALLATION INSTRUCTIONS

Tools and Parts

Gather the required tools and parts before starting installation. Read and follow the instructions provided with any tools listed here.

- Flat-blade screwdriver
- #2 Phillips screwdriver
- Adjustable wrench that opens to 1" (2.5 cm) or hex-head socket wrench (for adjusting dryer feet)
- Vent clamps
- Tin snips (new vent installations)
- Caulking gun and compound (for installing new exhaust vent)
- Wire stripper (direct wire installations)
- Level

Parts supplied:

Remove parts package from dryer drum. Check that all parts were included.



4 leveling legs

Parts needed:

Check local codes. Check existing electrical supply and venting and see "Electrical Requirements" and "Venting Requirements" before purchasing parts.

Mobile home installations require metal exhaust system hardware available for purchase from the dealer from whom you purchased your dryer. For further information, please reference the "Assistance or Service" section of the Dryer User Instructions.

8577187



[You're reading an excerpt. Click here to read official ESTATE EED4100SQ user guide](http://yourpdfguides.com/dref/208989)
<http://yourpdfguides.com/dref/208989>

Manual abstract:

This is the safety alert symbol. @@@@Read and follow the instructions provided with any tools listed here. s s Remove parts package from dryer drum. Check that all parts were included. Flat-blade screwdriver #2 Phillips screwdriver Adjustable wrench that opens to 1" (2.5 cm) or hex-head socket wrench (for adjusting dryer feet) Vent clamps s s Tin snips (new vent installations) Caulking gun and compound (for installing new exhaust vent) Wire stripper (direct wire installations) Level 4 leveling legs Parts needed: Check local codes. Check existing electrical supply and venting and see "Electrical Requirements" and "Venting Requirements" before purchasing parts. Mobile home installations require metal exhaust system hardware available for purchase from the dealer from whom you purchased your dryer. For further information, please reference the "Assistance or Service" section of the Dryer User Instructions. s s 8577187 Location Requirements WARNING Dryer Dimensions 43 3/4" (110cm) 15 1/4" (38.

74cm) 43 3/4" (110cm) 22 3/4" (57.8cm) Explosion Hazard Keep flammable materials and vapors, such as gasoline, away from dryer. Place dryer at least 18 inches (46 cm) above the floor for a garage installation. Failure to do so can result in death, explosion, or fire. *26" (66cm) 29" (73.

66cm) *27 3/4" (70.5cm) 29" (73.66cm) A B 43 3/4" (110cm) 22 3/4" (57.8cm) 43 3/4" (110cm) You will need s s A location that allows for proper exhaust installation. See "Venting Requirements.

" A separate 30-amp circuit. If using a power supply cord, a grounded electrical outlet located within 2 ft (61 cm) of either side of the dryer. See "Electrical Requirements." A sturdy floor to support the total weight (dryer and load) of 200 lbs (90.7 kg). The combined weight of a companion appliance should also be considered. A level floor with a maximum slope of 1" (2.5 cm) under entire dryer. (If slope is greater than 1" [2.5 cm], install Extended Dryer Feet Kit, Part Number 279810.

) Clothes may not tumble properly and models with automatic sensor cycles may not operate correctly if dryer is not level. 13 3/4" (34.9cm) *27 3/4" (70.5cm) 29" (73.66cm) *27 3/4" (70.5cm) 29" (73.66cm) C A. Small opening side-swing door B. Large opening side-swing door C. Wide opening side-swing door D.

Wide opening hamper door D s s *Most installations require a minimum 5 1/2" (14 cm) clearance behind the dryer for the exhaust vent with elbow. See "Venting Requirements." Do not operate your dryer at temperatures below 45°F (7°C). At lower temperatures, the dryer might not shut off at the end of an automatic cycle. Drying times can be extended.

The dryer must not be installed or stored in an area where it will be exposed to water and/or weather. Check code requirements. Some codes limit, or do not permit, installation of the dryer in garages, closets, mobile homes or sleeping quarters. Contact your local building inspector. Minimum installation spacing for recessed area or closet installation The dimensions shown following are for the minimum spacing allowed.

s Additional spacing should be considered for ease of installation and servicing. s s Additional clearances might be required for wall, door and floor moldings. For closet installation, with a door, minimum ventilation openings in the top and bottom of the door are required. Louvered doors with equivalent ventilation openings are acceptable. Companion appliance spacing should also be considered. 14" max. (35.6cm) 3" (7.6 cm) 48 in. 2 (310 cm²) Installation Clearances The location must be large enough to allow the dryer door to open fully.

s 18" (45.7 cm) 24 in. 2 (155 cm) 0"* (0 cm) 29" (73.66 cm) 0"* (0 cm) 27 3/4" 5 1/2" 0"* (0 cm) (70.5 cm) (14 cm) 2 3" (7.6 cm) A B C A. Recessed area B. Side view - closet or confined area C. Closet door with vents *Additional spacing recommended 2 Mobile Home - Additional Installation Requirements This dryer is suitable for mobile home installations. The installation must conform to the Manufactured Home Construction and Safety Standard, Title 24 CFR, Part 3280 (formerly the Federal Standard for Mobile Home Construction and Safety, Title 24, HUD Part 280).

Mobile home installations require: s Metal exhaust system hardware, which is available for purchase from your dealer. s s A UL listed 30-amp power supply cord, rated 120/240 volt minimum. The cord should be type SRD or SRDT and be at least 4 ft (1.22 m) long. The wires that connect to the dryer must end in ring terminals or spade terminals with upturned ends.

A UL listed strain relief. s If your outlet looks like this: Special provisions must be made in mobile homes to introduce outside air into the dryer. The opening (such as a nearby window) should be at least twice as large as the dryer exhaust opening. 4-wire receptacle (14-30R) Electrical Requirements It is your responsibility s s To contact a qualified electrical installer. To be sure that the electrical connection is adequate and in conformance with the National Electrical Code, ANSI/NFPA 70-latest edition and all local codes and ordinances.

The National Electric Code requires a 4-wire supply connection for homes built after 1996, dryer circuits involved in remodeling after 1996, and all mobile home installations. A copy of the above code standards can be obtained from: National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269. Then choose a 4-wire power supply cord with ring or spade terminals and UL listed strain relief. The 4-wire power supply cord, at least 4 ft (1.22 m) long, must have four 10-gauge copper wires and match a 4-wire receptacle of NEMA Type 14-30R. The ground wire (ground conductor) may be either green or bare. The neutral conductor must be identified by a white cover. If your outlet looks like this: 3-wire receptacle (10-30R) s To supply the required 3 or 4 wire, single phase, 120/240 volt, 60 Hz., AC only electrical supply (or 3 or 4 wire, 120/208 volt electrical supply, if specified on the serial/rating plate) on a separate 30-amp circuit, fused on both sides of the line. A time-delay fuse or circuit breaker is recommended.

Connect to an individual branch circuit. Do not have a fuse in the neutral or grounding circuit. Do not use an extension cord. If codes permit and a separate ground wire is used, it is recommended that a qualified electrician determine that the ground path is adequate. s s Then choose a 3-wire power supply cord with ring or spade terminals and UL listed strain relief. The 3-wire power supply cord, at least 4 ft (1.22 m) long, must have three 10-gauge copper wires and match a 3-wire receptacle of NEMA Type 10-30R.



[You're reading an excerpt. Click here to read official ESTATE](http://yourpdfguides.com/dref/208989)

[EED4100SQ user guide](http://yourpdfguides.com/dref/208989)

<http://yourpdfguides.com/dref/208989>

If connecting by direct wire: Power supply cable must match power supply (4-wire or 3-wire) and be: s Flexible armored cable or nonmetallic sheathed copper cable (with ground wire), protected with flexible metallic conduit. All current-carrying wires must be insulated. s s 10-gauge solid copper wire (do not use aluminum).

At least 5 ft (1.52 m) long. Electrical Connection To properly install your dryer, you must determine the type of electrical connection you will be using and follow the instructions provided for it here. s If local codes do not permit the connection of a neutral ground wire to the neutral wire, see "Optional 3-wire connection" section. s GROUNDING INSTRUCTIONS s This dryer is manufactured ready to install with a 3-wire electrical supply connection.

The neutral ground wire is permanently connected to the neutral conductor (white wire) within the dryer. If the dryer is installed with a 4-wire electrical supply connection, the neutral ground wire must be removed from the external ground conductor screw (green screw), and secured under the neutral terminal (center or white wire) of the terminal block. When the neutral ground wire is secured under the neutral terminal (center or white wire) of the terminal block, the dryer cabinet is isolated from the neutral conductor. A 4-wire power supply connection must be used when the appliance is installed in a location where grounding through the neutral conductor is prohibited. Grounding through the neutral is prohibited for (1) new branch-circuit installations, (2) mobile homes, (3) recreational vehicles, and (4) areas where local codes prohibit grounding through the neutral conductors.

For a grounded, cord-connected dryer: This dryer must be grounded. In the event of malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This dryer uses a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances. For a permanently connected dryer: This dryer must be connected to a grounded metal, permanent wiring system, or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment-grounding terminal or lead on the dryer. s s If using a power supply cord: Use a UL listed power supply cord kit marked for use with clothes dryers. The kit should contain: WARNING: Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service representative or personnel if you are in doubt as to whether the dryer is properly grounded. Do not modify the plug on the power supply cord: if it will not fit the outlet, have a proper outlet installed by a qualified electrician. SAVE THESE INSTRUCTIONS 3 Electrical Connection Power Supply Cord Direct Wire WARNING Fire Hazard Use a new UL listed 30 amp power supply cord.

Use a UL listed strain relief. Disconnect power before making electrical connections. Connect neutral wire (white or center wire) to center terminal (silver). Ground wire (green or bare wire) must be connected to green ground connector. Connect remaining 2 supply wires to remaining 2 terminals (gold). Securely tighten all electrical connections. Failure to do so can result in death, fire, or electrical shock. Fire Hazard Use 10 gauge solid copper wire. Use a UL listed strain relief. Disconnect power before making electrical connections.

Connect neutral wire (white or center wire) to center terminal (silver). Ground wire (green or bare wire) must be connected to green ground connector. Connect remaining 2 supply wires to remaining 2 terminals (gold). Securely tighten all electrical connections. Failure to do so cands of wires into a hook shape.

A B C E D A. @@Center silver-colored terminal block screw C. Neutral wire (white or center wire) D. 3/4" (1.9 cm) UL listed strain relief E. @@@@Tighten screw. A B C I. Remove center silver-colored terminal block screw. 2. Remove neutral ground wire from external ground conductor screw. @@Squeeze hooked ends together. Tighten screw. A B C F E D A. External ground conductor screw B. Center silver-colored terminal block screw C.

Neutral wire (white or center wire) D. 3/4" (1.9 cm) UL listed strain relief E. Neutral ground wire F. Ground wire (green or bare) of power supply cord E D 4. Connect the other wires to outer terminal block screws. Tighten screws. 5. Tighten strain relief screws. 6.

Insert tab of terminal block cover into slot of dryer rear panel. Secure cover with hold-down screw. 7. You have completed your electrical connections. Now go to "Venting Requirements.

" A. @@Center silver-colored terminal block screw C. Neutral wire (white or center wire) D. 3/4" (1.9 cm) UL listed strain relief E.

Neutral ground wire 6 3. @@Tighten screw. A B C I. Loosen or remove center silver-colored terminal block screw. 2. @@Tighten screw. B C D F E D A A. External ground conductor screw B. Center silver-colored terminal block screw C. Neutral wire (white or center wire) D.

3/4" (1.9 cm) UL listed strain relief E. Neutral ground wire F. Ground wire (green or bare) of power supply cord E A. Neutral ground wire B. External ground conductor screw C. Center silver-colored terminal block screw D. Neutral wire (white or center wire) E. 3/4" (1.9 cm) UL listed strain relief 4.

@@Squeeze hooked ends together. Tighten screws. 3. Connect the other wires to outer terminal block screws. Tighten screws.

4. Tighten strain relief screws. 5. Insert tab of terminal block cover into slot of dryer rear panel. Secure cover with hold-down screw.

6. You have completed your electrical connections. @@Tighten strain relief screws. 6. Insert tab of terminal block cover into slot of dryer rear panel. Secure cover with hold-down screw. 7. You have completed your electrical connections. @@@@Strip 3/4" (8.9 cm) of outer covering from end of cable.

Strip insulation back 1" (2.5 cm). @@@@3-wire receptacle (NEMA type 10-30R) B. 3-wire plug C. Neutral prong D. Spade terminals with up turned ends E. 3/4" (1.9 cm) UL listed strain relief F. Ring terminals G. @@Loosen or remove center silver-colored terminal block screw.

2. @@Squeeze hooked end together. @@1. Remove center silver-colored terminal block screw. 2.

Remove neutral ground wire from external ground conductor screw. @@Tighten screw. B C D A B C A E D A. Neutral ground wire B. External ground conductor screw C.

Center silver-colored terminal block screw D. Neutral wire (white or center wire) E. 3/4" (1.9 cm) UL listed strain relief E F 3. @@Squeeze hooked ends together. Tighten screws. A. External ground conductor screw B. Neutral ground wire C. Center silver-colored terminal block screw D.

Neutral wire (white or center wire) E.



[You're reading an excerpt. Click here to read official ESTATE EED4100SQ user guide](http://yourpdfguides.com/dref/208989)
<http://yourpdfguides.com/dref/208989>

3/4" (1.9 cm) UL listed strain relief F. Grounding path determined by a qualified electrician 4. Tighten strain relief screw. 5. Insert tab of terminal block cover into slot of dryer rear panel. Secure cover with hold-down screw. 6. You have completed your electrical connections. Now go to "Venting Requirements." 3. Connect the other wires to outer terminal block screws. Tighten screws. 4. Tighten strain relief screws. 5. Insert tab of terminal block cover into slot of dryer rear panel. Secure cover with hold-down screw. 6. @@@@Do not use a plastic vent. Do not use a metal foil vent. @@@@IMPORTANT: Observe all governing codes and ordinances. @@Exhaust vent must not be connected or secured with screws or other fastening devices that extend into the interior of the duct. Do not use duct tape. If using an existing vent system s s Clean lint from the entire length of the system and make sure exhaust hood is not plugged with lint. Replace any plastic or metal foil vent with rigid or flexible heavy metal vent. Review Vent system chart. Modify existing vent system if necessary to achieve the best drying performance. Clamp Exhaust Recommended hood styles are shown here.

B If this is a new vent system Vent material s s A 4" (10.2 cm) 4" (10.2 cm) Use a heavy metal vent. Do not use plastic or metal foil vent. 4" (10.2 cm) heavy metal exhaust vent and clamps must be used. DURASAFETM venting products are recommended. A. Louvered hood style B. Box hood style The angled hood style (shown here) is acceptable.

4" 10.2 cm 4" (10.2 cm) 4" (10.2 cm) heavy metal exhaust vent DURASAFETM vent products can be purchased from your dealer or by calling Whirlpool Parts and Accessories. For more information, see the "Assistance or Service" section of this manual.

Rigid metal vent s For best drying performance, rigid metal vents are recommended. s 2 1/2" (6.4 cm) s s An exhaust hood should cap the vent to prevent rodents and insects from entering the home. Exhaust hood must be at least 12" (30.5 cm) from the ground or any object that may be in the path of the exhaust (such as flowers, rocks or bushes, snow line, etc.

). Do not use an exhaust hood with a magnetic latch. Rigid metal vent is recommended to prevent crushing and kinking. s Flexible metal vent s Flexible metal vents are acceptable only if accessible for cleaning. s Improper venting can cause moisture and lint to collect indoors, which may result in: Moisture damage to woodwork, furniture, paint, wallpaper, carpets, etc. Housecleaning problems and health problems. Flexible metal vent must be fully extended and supported when the dryer is in its final position. 9 Plan Vent System Choose your exhaust installation type Recommended exhaust installations Typical installations vent the dryer from the rear of the dryer. Other installations are possible. NOTE: The following kits for close clearance alternate installations are available for purchase.

Please see the service number located on the back page of this manual to order. s Over-the-Top Installation: Part Number 4396028 s B C D A E F G B H A. Dryer B. Elbow C. Wall D. Exhaust hood E. Clamps F. Rigid metal or flexible metal vent G. Vent length necessary to connect elbows H. Exhaust outlet Periscope Installation (For use with dryer vent to wall vent mismatch): Part Number 4396037 - 0" (0 cm) to 18" (45.

72 cm) mismatch Part Number 4396011 - 18" (45.72 cm) to 29" (73.66 cm) mismatch Part Number 4396014 - 29" (73.66 cm) to 50" (127 cm) mismatch Special provisions for mobile home installations The exhaust vent must be securely fastened to a noncombustible portion of the mobile home structure and must not terminate beneath the mobile home. Terminate the exhaust vent outside.

Standard exhaust installation with rigid metal or flexible metal vent Determine vent path s s s Select the route that will provide the straightest and most direct path outdoors. Plan the installation to use the fewest number of elbows and turns. When using elbows or making turns, allow as much room as possible. Bend vent gradually to avoid kinking. Use the fewest 90° turns possible.

Alternate installations for close clearances Venting systems come in many varieties. Select the type best for your installation. Two close-clearance installations are shown. Refer to the manufacturer's instructions. s s Determine vent length and elbows needed for best drying performance s Use the Vent system chart below to determine type of vent material and hood combinations acceptable to use. NOTE: Do not use vent runs longer than those specified in the Vent system chart. Exhaust systems longer than those specified will: s s A B Shorten the life of the dryer. Reduce performance, resulting in longer drying times and increased energy usage. A. Over-the-top installation (also available with one offset elbow) B.

Periscope installation The Vent system chart provides venting requirements that will help to achieve the best drying performance. 10 Vent system chart NOTE: Side and bottom exhaust installations have a 90° turn inside the dryer. To determine maximum exhaust length, add one 90° turn to the chart. Number of 90° turns or elbows 0 1 2 3 4 Type of vent Rigid metal Flexible metal Rigid metal Flexible metal Rigid metal Flexible metal Rigid metal Flexible metal Rigid metal Flexible metal Box or louvered hoods 64 ft (20 m) 36 ft (11 m) 54 ft (16.5 m) 31 ft (9.4 m) 44 ft (13.4 m) 27 ft (8.2 m) 35 ft (10.7 m) 25 ft (7.6 m) 27 ft (8.2 m)

2 m) 23 ft (7 m) Angled hoods 58 ft (17.7 m) 28 ft (8.5 m) 48 ft (14.6 m) 23 ft (7 m) 38 ft (11.6 m) 19 ft (5.8 m) 29 ft (8.8 m) 17 ft (5.2 m) 21 ft (6.4 m) 15 ft (4.6 m) 5.

Place a carton corner post from dryer packaging under each of the 2 dryer back corners. Stand the dryer up. Slide the dryer on the corner posts until it is close to its final location. Leave enough room to connect the exhaust vent. Connect Vent 1. Using a 4" (10.2 cm) clamp, connect vent to exhaust outlet in dryer. If connecting to existing vent, make sure the vent is clean. The dryer vent must fit over the dryer exhaust outlet and inside the exhaust hood. Make sure the vent is secured to exhaust hood with a 4" (10.

2 cm) clamp. 2. Move dryer into its final position. Do not crush or kink vent. 3. (On gas models) Check to be sure there are no kinks in the flexible gas line. 4. Once the exhaust vent connection is made, remove the corner posts and cardboard. Level Dryer Check the levelness of the dryer. Check levelness first side to side, then front to back.

Install Vent System 1. Install exhaust hood. Use caulking compound to seal exterior wall opening around exhaust hood. 2. Connect vent to exhaust hood. Vent must fit inside exhaust hood. Secure vent to exhaust hood with 4" (10.2 cm) clamp. 3. Run vent to dryer location. Use the straightest path possible. See "Determine vent path" in "Plan Vent System.



[You're reading an excerpt. Click here to read official ESTATE EED4100SQ user guide](http://yourpdfguides.com/dref/208989)
<http://yourpdfguides.com/dref/208989>

" Avoid 90° turns. Use clamps to seal all joints. Do not use duct tape, screws or other fastening devices that extend into the interior of the vent to secure vent. If the dryer is not level, prop up the dryer using a wood block. Use a wrench to adjust the legs up or down and check again for levelness. Reverse Door Swing (Optional) You can change your door swing from a right-side opening to a left-side opening, if desired. Install Leveling Legs **WARNING Excessive Weight Hazard** Use two or more people to move and install dryer. Failure to do so can result in back or other injury.

1. @@Place cardboard under the entire back side of the dryer. 2. Firmly grasp the body of the dryer (not the top or console panel). Gently lay the dryer on the cardboard. @@Examine the leveling legs. Find the diamond marking. 4. Screw the legs into the leg holes by hand. @@Place towel (A) on top of dryer to protect surface.

2. Open dryer door. Remove bottom screws from cabinet side of hinges (C). Loosen (do not remove) top screws from cabinet side of hinges. 3. @@Pull door forward off screws. Set door on top of dryer. Remove top screws from cabinet. 4. Use a small, flat-blade screwdriver to gently remove 4 hinge hole plugs (D) on left side of cabinet.

Insert plugs into hinge holes on right side of cabinet. 11 5. Insert screws into bottom holes on left side of cabinet. Tighten screws halfway. Position door so large end of door hinge slot is over screws. Slide door up so screws are in bottom of slots. Tighten screws. Insert and tighten top screws in hinges. 8. Remove door strike (E) from cabinet.

Use a small, flat-blade screwdriver to gently remove 4 hinge hole plugs (F) on left side of cabinet. Insert plugs into hinge holes on right side of cabinet. 9. Insert screws into bottom holes on left side of cabinet. Tighten screws halfway. Position door so large end of door hinge slot is over screws. Slide door up so screws are in bottom of slots. Tighten screws. Insert and tighten top screws in hinges. 6.

Close door and check that door strike aligns with door catch (B). If needed, slide door catch left or right within slot to adjust alignment. Reversible Super Wide Side-Swing Door A B C E F D 10. Remove door strike plug (B). Insert the door strike you removed in Step 8 into hole and secure with screw. Insert door strike plug into original door strike hole and secure with screw. 11. Close door and check that door strike aligns with door catch (C). If needed, slide door catch left or right within slot to adjust alignment. Complete Installation I.

Check that all parts are now installed. If there is an extra part, go back through the steps to see which step was skipped. 2. Check that you have all of your tools. 3. Dispose of/recycle all packaging materials. 4. Check the dryer's final location. Be sure the vent is not crushed or kinked. 5.

Check that the dryer is level. See "Level Dryer." 6. For power supply cord installation, plug into an outlet. For direct wire installation, turn on power. 7. Remove the blue protective film on the console and any tape remaining on the dryer. 8. Read "Dryer Use" in the Dryer User Instructions. 9. Wipe the dryer drum interior thoroughly with a damp cloth to remove any dust. 10. Set the dryer on a full heat cycle (not an air cycle) for 20 minutes and start the dryer. If the dryer will not start, check the following: s s s s 1. Place towel (A) on top of dryer to protect surface.

2. Open dryer door. Remove bottom screws from cabinet side of hinges (D). Loosen (do not remove) top screws from cabinet side of hinges. 3. @@Pull door forward off screws. Set door (handle side up) on top of dryer. Remove top screws from cabinet. 4. Remove screws attaching hinges to door. 5. Remove screws at top, bottom and side of door (4 screws). Holding door over towel on dryer, grasp sides of outer door and gently lift to separate it from inner door. Do not pry apart with putty knife. Do not pull on door seal or plastic door catches.

6. Be certain to keep cardboard spacer centered between doors. Reattach outer door panel to inner door panel so handle is on the side where hinges were just removed. Controls are set in a running or "On" position. Start button has been pushed firmly. Dryer is plugged into an outlet and/or electrical supply is on. Household fuse is intact and tight, or circuit breaker has not tripped. Dryer door is closed. 7. Attach door hinges to dryer door so that the larger hole is at the bottom of the hinge.

11. When the dryer has been running for 5 minutes, open the dryer door and feel for heat. If you feel heat, cancel cycle and close the door. If you do not feel heat, turn off the dryer and check the following: s There may be 2 household fuses or circuit breakers for the dryer. Check to make sure both fuses are intact and tight, or that both circuit breakers have not tripped.

If there is still no heat, contact a qualified technician. NOTE: You may notice a burning odor when the dryer is first heated. This odor is common when the heating element is first used. The odor will go away. 8577187 © 2005.

All rights reserved. Benton Harbor, Michigan 49022 TM DURASAFE is a trademark of Whirlpool, U.S.A. 7/05 Printed in U.S.A. .



[You're reading an excerpt. Click here to read official ESTATE EED4100SQ user guide](http://yourpdfguides.com/dref/208989)
<http://yourpdfguides.com/dref/208989>