



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for FRIGIDAIRE FFHS2622MH. You'll find the answers to all your questions on the FRIGIDAIRE FFHS2622MH in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual FRIGIDAIRE FFHS2622MH
User guide FRIGIDAIRE FFHS2622MH
Operating instructions FRIGIDAIRE FFHS2622MH
Instructions for use FRIGIDAIRE FFHS2622MH
Instruction manual FRIGIDAIRE FFHS2622MH

FRIGIDAIRE

All about the

Use & Care

of your Refrigerator



TABLE OF CONTENTS

Important Safety Instructions.....	2	Automatic Ice & Water Dispenser	14
Features at a Glance.....	4	Changing the Filter	18
Installation	5	Normal Operating Sounds and Sights.....	19
Door Removal Instructions.....	7	Care and Cleaning	20
Connecting Water Supply.....	8	Before you Call	21
Controls.....	9	Major Appliance Warranty	23
Storage Features.....	13		

www.frigidaire.com USA 1-800-944-9044

www.frigidaire.ca Canada 1-800-265-8352

©2012 APO 10150002



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFHS2622MH user guide](http://yourpdfguides.com/dref/3950175)
<http://yourpdfguides.com/dref/3950175>

Manual abstract:

· Avoid contact with any moving parts of automatic ice maker. @ @ It is used to alert you to potential personal injury hazards. @ @ Children should NEVER use these items to play. Cartons covered with rugs, bedspreads, plastic sheets or stretch wrap may become airtight chambers, and can quickly cause suffocation. Fault Interrupter (GFI) circuit. Do not use an extension cord or adapter plug. · If the power cord is damaged, it should be replaced by an authorized service technician to prevent any risk. · Never unplug the refrigerator by pulling on the power cord. Always grip the plug firmly, and pull straight out from the receptacle to prevent damaging the power cord. · Unplug the refrigerator before cleaning and before replacing a light bulb to avoid electrical shock.

· Performance may be affected if the voltage varies by 10% or more. Operating the refrigerator with insufficient power can damage the compressor. Such damage is not covered under your warranty. · Do not plug the unit into an electrical outlet controlled by a wall switch or pull cord to prevent the refrigerator from being turned off accidentally. Proper Disposal of your refrigerator or Freezer risk of child entrapment Child entrapment and suffocation are not problems of the past.

Junked or abandoned refrigerators or freezers are still dangerous even if they will sit for "just a few days". If you are getting rid of your old refrigerator or freezer, please follow the instructions below to help prevent accidents. Proper Disposal of refrigerators/Freezers We strongly encourage responsible appliance recycling/ disposal methods. Check with your utility company or visit www.recyclemyoldfridge.com for more information on recycling your old refrigerator. Before you throw away your old refrigerator/freezer: · Removed doors. · Leave shelves in place so children may not easily climb inside. · Have refrigerant removed by a qualified service technician. IMPORTANT Pressing and holding the On/Off button for 3 seconds, located on the left side of the temperature control panel (Electronic controls), or turning the Freezer and Fresh Food controls to "0" (Mechanical controls) will disable your refrigerator's cooling system, but does not disconnect the power to the light bulb and other electrical components. To turn off power to your refrigerator you must unplug the power cord from the electrical outlet. WARNING These guidelines must be followed to ensure that safety mechanisms in this refrigerator will operate properly. Electrical information · The refrigerator must be plugged into its own dedicated 115 Volt, 60 Hz., 15 Amp, AC only electrical outlet. The power cord of the appliance is equipped with a three-prong grounding plug for your protection against electrical shock hazards.

It must be plugged directly into a properly grounded three prong receptacle. The receptacle must be installed in accordance with local codes and ordinances. Consult a qualified electrician. Avoid connecting refrigerator to a Ground CAUTION To avoid personal injury or property damage, handle tempered glass shelves carefully. Shelves may break suddenly if nicked, scratched, or exposed to sudden temperature change. 3 FEATURES AT A GLANCE Features may vary according to model SpillSafe Adjustable Shelf® SpillSafe Adjustable Shelf® IMPORTANT Features not included with your refrigerator can be purchased at www.frigidaire.com or by calling 1-800-944-9044. 4 INSTALLATION This Use & Care Guide provides general operating instructions for your model. Use the refrigerator only as instructed in this Use & Care Guide.

Before starting the refrigerator, follow these important first steps. Toe Grille Installation and removal To install toe grille 1 Open both doors. Slide left and right sides of toe grille over lower hinges of refrigerator. 2 While pushing toe grille firmly against cabinet, fasten bottom clips of toe grille to cabinet. 3 Fasten top clips to cabinet. 4 Close the doors. Fasten right and left side clips into groove of bottom hinge. Location · Choose a place that is near a grounded electrical outlet. Do Not use an extension cord or an adapter plug. · If possible, place the refrigerator out of direct sunlight and away from the range, dishwasher or other heat sources. · The refrigerator must be installed on a floor that is level and strong enough to support a fully loaded refrigerator. · Consider water supply availability for models equipped with an automatic ice maker. If you do not hook up water to the refrigerator, remember to turn the ice maker off. CAUTION Do Not install the refrigerator where the temperature will drop below 55°F (13°C) or rise above 110°F (43°C). The compressor will not be able to maintain proper temperatures inside the refrigerator. Do Not block the toe grille on the lower front of your refrigerator. Sufficient air circulation is essential for the proper operation of your refrigerator. To remove toe grille 1 With both doors closed, unfasten right and left side clips of toe grille from bottom hinge groove. 2 Open both doors. Press firmly on top of toe grille until top of toe grille pops off.

3 Pull toe grille outward toward your body and off of lower hinges. Installation Installation clearances · Allow the following clearances for ease of installation, proper air circulation, and plumbing and electrical connections: Sides & Top Back /8 inch 1 inch 3 NOTE If your refrigerator is placed with the door hinge side against a wall, you may have to allow additional space so the door can be opened wider. 5 INSTALLATION Door Opening To level the doors using the adjustable lower hinge: NOTE The refrigerator doors are designed to shut by themselves within a 20 degree opening. Your refrigerator should be positioned to allow easy access to a counter or table when removing food. For best use of drawers and freezer baskets, the refrigerator should be in a position where both the refrigerator and freezer doors can be fully opened. NOTE Some models will not have a set screw. For those models follow steps 2 through 4. 1 Before leveling either door, remove set screw that locks door height into position. (The door cannot be adjusted without set screw removed). 2 If the refrigerator door is lower than the freezer door, raise the refrigerator door by turning the adjustment screw clockwise using a 7/16 inch wrench. (See illustration.) 3 If the freezer door is lower than the refrigerator door, raise the freezer door by turning the adjustment screw clockwise using a 7/16 inch wrench. (See illustration.) Guidelines for final positioning of your refrigerator: · All four corners of the cabinet must rest firmly on the floor. · The cabinet should be level at the front and rear.

· The sides should tilt 1/4 inch (6mm) from front to back (to ensure that doors close and seal properly). · Doors should align with each other and be level. All of these conditions can be met by raising or lowering the adjustable front rollers.

3 Pull toe grille outward toward your body and off of lower hinges. Installation Installation clearances · Allow the following clearances for ease of installation, proper air circulation, and plumbing and electrical connections: Sides & Top Back /8 inch 1 inch 3 NOTE If your refrigerator is placed with the door hinge side against a wall, you may have to allow additional space so the door can be opened wider. 5 INSTALLATION Door Opening To level the doors using the adjustable lower hinge: NOTE The refrigerator doors are designed to shut by themselves within a 20 degree opening. Your refrigerator should be in a position where both the refrigerator and freezer doors can be fully opened. NOTE Some models will not have a set screw. For those models follow steps 2 through 4. 1 Before leveling either door, remove set screw that locks door height into position. (The door cannot be adjusted without set screw removed). 2 If the refrigerator door is lower than the freezer door, raise the refrigerator door by turning the adjustment screw clockwise using a 7/16 inch wrench. (See illustration.) 3 If the freezer door is lower than the refrigerator door, raise the freezer door by turning the adjustment screw clockwise using a 7/16 inch wrench. (See illustration.) Guidelines for final positioning of your refrigerator: · All four corners of the cabinet must rest firmly on the floor. · The cabinet should be level at the front and rear.

· The sides should tilt 1/4 inch (6mm) from front to back (to ensure that doors close and seal properly). · Doors should align with each other and be level. All of these conditions can be met by raising or lowering the adjustable front rollers.

· The sides should tilt 1/4 inch (6mm) from front to back (to ensure that doors close and seal properly). · Doors should align with each other and be level. All of these conditions can be met by raising or lowering the adjustable front rollers.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](http://yourpdfguides.com/dref/3950175)

[FFHS2622MH user guide](http://yourpdfguides.com/dref/3950175)

<http://yourpdfguides.com/dref/3950175>

To level the cabinet using the front rollers: 1 Open both doors and remove the toe grille (see "Toe Grille Installation and removal" in the "Installation" section). 2 Close the doors and use a flat-blade screwdriver or 3/8 inch socket wrench to raise or lower the front rollers.

3 Ensure both doors are bind-free with their seals touching the cabinet on all four sides. 4 After leveling, verify door stop contacts lower hinge and top of door does not contact upper hinge through full movement of door (from fully closed to fully open). 5 Reinstall set screw, locking the door height. Open Door 7/16" Wrench and 3/32" Hex Key (some models) Door Stop Flange Hinge Flange Set Screw (some models) Hinge 6 Replace the toe grille by fitting it into place (see "Toe Grille Installation and Removal" in the "Installation" section). 6 DOOR REMOVAL INSTRUCTIONS Getting through narrow spaces If your refrigerator will not fit through an entrance area, you can reduce its size by removing the doors. Check first by measuring the entrance. required Tools You will need the following tools: Top Hinge Cover Front Screw Top Hinge Cover Rear Screw Tools Necessary: Top Hinge Screw Bottom Hinge Screw AND Phillips Head TM OR Socket Wrench Set OR Adjustable Wrench 3/8" Fixed Wrench To prepare for removing the doors: 1 Make sure the electrical power cord is unplugged from the wall outlet. 2 Open both doors and remove the toe grille (as explained in the Installation Instructions that came with your appliance). 3 Remove any food from the door shelves. 4 Close the doors.

To remove the refrigerator top hinge cover: 1 Remove the three screws from each cover over the top door hinges. 2 Lift hinge cover straight up and off. To remove the refrigerator door: 1 Trace lightly around the door's top hinge with a pencil. This makes reinstallation easier. 2 Remove the two screws from the top hinge. Lift the door off of the bottom hinge and set it aside. 3 Remove the two bottom hinge screws and hinge if necessary. CAUTION Be sure doors are set aside in a secure position where they cannot fall and cause personal injury. Adjustable Hinge (some models) Non-Adjusting Hinge (some models) To reinstall the refrigerator door, reverse the above steps. 7 DOOR REMOVAL INSTRUCTIONS To remove the freezer top hinge cover: 1 Remove the two screws from each cover over the top door hinges.

2 Lift hinge cover straight up and off. 3 Detach the water tube from the connector located below the freezer door. The connector releases when you press its outer sleeve inward. To remove the freezer door: Adjustable Hit the ice maker inlet valve at the back of the refrigerator to your cold water pipe. Then add

approximately 7 feet (2.1 meters), so the refrigerator can be moved out for cleaning (as shown). · Shut off valve to connect the water supply line to your household water system. DO NOT use a self-piercing type shutoff valve. · A compression nut and ferrule (sleeve) for connecting a copper water supply line to the ice maker inlet valve. Copper water line from household water supply (Include enough tubing in loop to allow moving refrigerator out for cleaning.

) NOTE Check with your local building authority for recommendations on water lines and associated materials prior to installing your new refrigerator. Depending on your local/state building codes, Frigidaire recommends for homes with existing valves its Smart Choice® water line kit 5305513409 (with a 6 ft. Stainless Steel Water Line) and for homes without an existing valve, Frigidaire recommends its Smart Choice water® line kit 5305510264 (with a 20 ft. Copper Water Line with self-tapping saddle valve). Please refer to www.frigidaire.com/store for more information. Figure 1 Figure 2 IMPORTANT After connecting the water supply, refer to "How to Prime the Water Supply System" for important information about priming an empty water supply system. Your refrigerator's water supply system includes several tubing lines, a water filter, a water valve, and a water tank. To ensure that your water dispenser works properly, this system must be completely filled with water when your refrigerator is first connected to the household water supply line.

9 CONTROLS Cool Down Period To ensure safe food storage, allow the refrigerator to operate with the doors closed for at least 8 to 12 hours before loading it with food. refrigerator & freezer controls NOTE When changing control settings, wait 24 hours for the temperature to stabilize before making additional changes. Temperature adjustment · After 24 hours, adjust the controls as needed. Adjust temperatures gradually; move the knob in small increments, allowing the temperature to stabilize. · For colder temperatures, turn the knob towards Colder. · For warmer temperatures, turn the knob towards Cold. To maintain temperatures, a fan circulates air in the refrigerator and freezer compartments. For good circulation, do not block cold air vents with food items. Refrigerator & Freezer Controls (Features may vary according to model.) IMPORTANT Turning the Freezer and Fresh Food Controls to "0" turns off the compressor and prevents your refrigerator from cooling, but does not disconnect the power to the light bulb and other electrical components.

To turn off power to your refrigerator you must unplug the power cord from the electrical outlet. Temperature Adjustment If Fresh Food compartment is too warm If Fresh Food compartment is too cold If Freezer compartment is too warm If Freezer compartment is too cold *To Turn Refrigerator Off Turn Fresh Food Control Slightly Towards Colder. Turn Fresh Food Control Slightly Towards Cold. Turn Freezer Control Slightly Towards Colder. Turn Freezer Control Slightly Towards Cold.

Turn Freezer and Fresh Food Controls to 0. 10 CONTROLS Allowing Cooling Time Before Use To ensure safe food storage, allow your refrigerator to operate with the doors closed for at least 8 to 12 hours before placing food inside. During this cooling period, you do not need to adjust the controls, which are preset at the factory. Setting Cooling Temperatures Your refrigerator comes with a state-of-the-art electronic digital control system. The system's control panel is located at the top of the fresh food compartment.

The two digital displays on the left half of the control panel indicate the current settings or temperatures of your freezer and fresh food compartments. The models with a 2-digit temperature display are for reference only, and do not display the current accurate compartment temperature. Should you desire to see what the current accurate temperature is, place a separate thermometer inside the freezer or fresh food compartment in the desired location. NOTE The advanced electronic control system in your refrigerator includes additional display modes that service professionals can use to rapidly diagnose performance issues.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFHS2622MH user guide](http://yourpdfguides.com/dref/3950175)
<http://yourpdfguides.com/dref/3950175>

TEMPERATURE ADJUSTMENT To adjust the temperature to a higher or lower setting, press the Up (Cold) or Down (Colder) button closest to the display. The first time you press the button, the display shows current setting you entered. Each press of the button after that changes the setting by one. (Single Digit Display - Features may vary.) The display shows your new setting momentarily, then changes back to the current temperature. IF TEMPERATURE DISPLAYS FLASH.

.. If every you see both temperature displays continuously flashing, it may indicate that the control system has detected a performance problem.

Call your service representative, who can interpret the flashing message. To maintain temperatures, a fan circulates air in the refrigerator and freezer compartments. For good circulation, do not block cold air vents with food items. Numeric Display Freezer Fresh Food 1 6 9 Temperature Control Range Freezer Fahrenheit Warmest Warmer Factory Setting Colder Coldest -6° -21° 33° 1° Midpoint 0° -18° 37° 3° 6° Centigrade -14° Warmest 1 6 9 Fresh Food Fahrenheit 47° Centigrade 8° Factory Setting Coldest Temperature Adjustment If Fresh Food compartment is too warm Adjust Fresh Food control one degree colder by pressing Down (Colder) button. Adjust Fresh Food control one degree warmer by pressing the Up (Cold) button. Adjust Freezer control one degree colder by pressing Down (Colder) button. Adjust Freezer control one degree warmer by pressing the Up (Cold) button. If Fresh Food compartment is too cold If Freezer compartment is too warm If Freezer compartment is too cold 11 CONTROLS Cooling System On/Off Button Indicator NOTE Pressing the On/Off button on the control panel disables your refrigerator's cooling system but does not disconnect power to lights and other electrical components. To turn off power to your refrigerator you must unplug the power cord from the wall outlet. Each time you make settings on the control panel, a single audible tone acknowledges your input. Turning the Cooling system on and off You can disable the cooling system in your refrigerator by pressing the On/Off button located on the left side of the temperature control panel. To ensure that you do not accidentally turn off the cooling system, the button does not work unless you press and hold it for three seconds.

Once you disable the cooling system, all refrigeration to the freezer and fresh food compartments stops. To turn the cooling system back on, you must again press and hold the On/Off button for three more seconds. 12 STORAGE FEATURES CAUTION To avoid personal injury or property damage, handle tempered glass shelves carefully. Shelves may break suddenly if nicked, scratched, or exposed to sudden temperature change. See "Glass Shelves" in Care & Cleaning Chart.

fresh produce. The fresh drawers feature humidity control which allows you to adjust the humidity within the drawer. This can extend the life of fresh vegetables that keep best in high humidity. Wash items in clear water and remove excess water before placing them in the crispers. Items with strong odors or high moisture content should be wrapped before storing. Cantilever Shelf Adjustment Refrigerator shelves are easily adjusted to suit individual needs. Before adjusting the shelves, remove all food. Cantilever shelves are supported at the back of the refrigerator. To adjust cantilever shelves: 1 2 Crisper Humidity Control Lift front edge up. Pull shelf out.

NOTE Leafy vegetables keep best when stored with the humidity control set on Higher Humidity, or in a drawer without a Humidity Control. This keeps incoming air to a minimum and maintains maximum moisture content. Replace the shelf by inserting the hooks at rear of the shelf into the wall bracket. Lower the shelf into the desired slots and lock into position. SpillSafe™ glass shelves (some models) catch and hold accidental spills. In some models, the SpillSafe™ shelves slide out for easy access to food and for fast cleaning. The shelves slide out independently of their mounting brackets. Just pull the front of the shelf forward. Shelves can be extended as far as the stopper will allow but are not removable from their mounting brackets. 1 Crispers Crispers allow you the flexibility to store any manner of items including fruits, vegetables, nuts, etc.

Crispers do not feature humidity controls. 1 Cool Drawer (some models) 2 Crisper Drawer 2 Some models are equipped with a Cool Drawer for storage of luncheon meats, spreads, cheeses, and other deli items. This drawer does not have a separate temperature control Cantilever Glass Shelf Cantilever Sliding Glass Shelf Door storage Door bins and shelves are provided for convenient storage of jars, bottles, and cans. Frequently used items can be quickly selected.

Some models have door bins that can accommodate gallon-sized plastic drink containers and economy-sized jars and containers.

Some bins are adjustable for maximum storage capacity. The dairy compartment, which is warmer than the general food storage section, is intended for short term storage of cheese, spreads, or butter. Chill Drawer (some models) Some models are equipped with a Chill Drawer. Chill Drawer temperatures can be adjusted by sliding the Chill Drawer Temperature Control in either direction. Use this pan for short term storage of bulk meat items.

If meats are to be kept longer than one or two days, they should be frozen. The Chill Drawer is fixed and cannot be moved up or down. If fruits or vegetables are to be stored in the Chill Drawer, set the Chill Drawer Temperature Control to a warmer setting to prevent freezing. Fresh Drawers with Humidity Control (some models) The fresh drawers, located under the bottom refrigerator shelf, are designed for storing fruits, vegetables, and other Chill Drawer with Temperature Control 13 AUTOMATIC ICE & WATER DISPENSER Features may vary according to model. EXTREME FREEZE EXTRA ICE To freeze food at a faster rate to preserve freshness, push the Touch Pad for 3-5 seconds to activate this feature. A green light will appear above the Touch Pad. Push the Touch Pad again for 3-5 seconds to deactivate. To increase ice production for special occasions, such as parties, push the Touch Pad for 3-5 seconds to activate this feature. A green light will appear above the Touch Pad. Push the Touch Pad again for 3-5 seconds to deactivate.

EXTRA ICE should produce 25 percent to 50 percent more ice every 24 hours. Press the CUBE Touch Pad to get cubed ice. A green light will appear above the Touch Pad. Press glass against ICE dispensing paddle as far up as possible to catch all ice. Press the CRUSH Touch Pad to get crushed ice. A green light will appear above the Touch Pad. Press glass against ICE dispensing paddle as far up as possible to catch all ice. Press the LIGHT Touch Pad to turn on dispenser light. Press again to turn the light off. The light also turns on automatically when ice and/or water is dispensed.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](http://yourpdfguides.com/dref/3950175)

[FFHS2622MH user guide](http://yourpdfguides.com/dref/3950175)

<http://yourpdfguides.com/dref/3950175>

3 Slide the old water filter cartridge straight out of the housing and discard it. Ordering replacement Filters To order your replacement filters, please visit our online store at www.frigidaire.com/store, by calling toll-free at 877-808-4195, or by visiting the dealer where you purchased your refrigerator. Electrolux recommends that you order extra filters when you first install your refrigerator, and that you replace your filters at least once every six months.

Here are the product numbers to request when ordering: PureSource 3™ Water Filter Part #WF3CB 4 Unpack the new filter cartridge. Using the alignment guide, slide it gently into the filter housing until it stops against the snap-in connector at the back of the housing. 5 Push firmly until the cartridge snaps into place (you should hear a click as the cartridge engages the snap-in connector). 6 Press a drinking glass against the water dispenser while checking for any leaks at the filter housing. Any spurts and sputters that occur as the system purges air out of the dispenser system are normal.

7 After filling one glass of water, continue flushing the system for about four (4) minutes. 8 Turn On the ice maker. 9 Press and hold the Water Filter button on the Ice & Water Dispenser control panel for three seconds. When the display changes from "red" to "Green," the status has been reset. 18 **NORMAL OPERATING SOUNDS AND SIGHTS** Understanding the Sounds you may Hear Your new, high-efficiency refrigerator may introduce unfamiliar sounds.

These sounds normally indicate your refrigerator is operating correctly. Some surfaces on floors, walls, and kitchen cabinets may make these sounds more noticeable. Following is a list of major components in your refrigerator and the sounds they can cause: A Evaporator Refrigerant through the evaporator may create a boiling or gurgling sound. B Evaporator fan You may hear air being forced through the refrigerator by the evaporator fan. C Defrost heater During defrost cycles, water dripping onto the defrost heater may cause a hissing or sizzling sound. After defrosting, a popping sound may occur. D Automatic ice maker When ice has been produced, you will hear ice cubes falling into the ice bin. E Electronic control & automatic defrost control These parts can produce a snapping or clicking sound when turning the cooling system on and off. F Condenser fan You may hear air being forced through the condenser. G Compressor Modern, high-efficiency compressors run much faster than in the past.

The compressor may have a high-pitched hum or pulsating sound. H Water valve Makes a buzzing sound each time it opens to fill the icemaker. I Drain pan (not removable) You may hear water dripping into the drain pan during the defrost cycle. J Condenser May create minimal sounds from forced air. K Motorized damper May produce a light humming during operation. L Ice chute When dispensing ice, you will hear a snapping or clicking sound when the solenoid opens and closes the ice chute. **NOTE** Energy efficient foam in your refrigerator is not a sound insulator. **NOTE** During automatic defrost cycle, a red glow in the back wall vents of your freezer compartment is normal. **DOR 19 CARE & CLEANING** Protecting your investment Keeping your refrigerator clean maintains appearance and prevents odor build-up. Wipe up any spills immediately and clean the freezer and fresh food compartments at least twice a year.

When cleaning, take the following precautions: · Never use **CHLORIDE** or cleaners with bleach to clean stainless steel. ·

Do not wash any removable parts in a dishwasher. · Always unplug the electrical power cord from the wall outlet before cleaning. ·

Remove adhesive labels by hand. Do not use a razor blade or other sharp instruments which can scratch the appliance surface.

· Do not remove the serial plate. Do not use abrasive cleaners such as window sprays, scouring cleansers, brushes, flammable fluids, cleaning waxes, concentrated detergents, bleaches or cleansers containing petroleum products on plastic parts, interior doors, gaskets or cabinet liners. Do not use paper towels, metallic scouring pads, or other abrasive cleaning materials or strong alkaline solutions. **NOTE** If you set your temperature controls to turn off cooling, power to lights and other electrical components will continue until you unplug the power cord from the wall outlet. **CAUTION** · Pull the refrigerator straight out to move it. Shifting it from side to side may damage flooring. Be careful not to move the refrigerator beyond the plumbing connections. ·

Damp objects stick to cold metal surfaces. Do not touch refrigerated surfaces with wet or damp hands. **IMPORTANT** If you store or move your refrigerator in freezing temperatures, be sure to completely drain the water supply system. Failure to do so could result in water leaks when the refrigerator is put back into service. Contact a service representative to perform this operation. **Care & Cleaning Tips Part Interior & Door Liners Door Gaskets Drawers & Bins Glass Shelves Toe Grille Exterior & Handles Exterior & Handles (Stainless Steel Models Only)** · · · · · **What To Use Soap and water Baking soda and water Soap and water Soap and water Soap and water Glass cleaner Mild liquid sprays Soap and water Mild liquid sprays Vacuum attachment Soap and water Non Abrasive Glass Cleaner Soap and water Stainless Steel Cleaners Tips and Precautions Use 2 tablespoons of baking soda in 1 quart of warm water. Be sure to wring excess water out of sponge or cloth before cleaning around controls, light bulb or any electrical part. Wipe gaskets with a clean soft cloth.**

Use a soft cloth to clean drawer runners and tracks. Allow glass to warm to room temperature before immersing in warm water. Vacuum dust from front of toe grille. Remove toe grille (see Installation Instructions). Vacuum backside, wipe with sudsy cloth or sponge. Rinse and dry. Do not use commercial household cleaners containing ammonia, bleach or alcohol to clean handles. Use a soft cloth to clean smooth handles. **DO NOT** use a dry cloth to clean smooth doors. Never use **CHLORIDE** or cleaners with bleach to clean stainless steel.

Clean stainless steel front and handles with non-abrasive soapy water and a dishcloth. Rinse with clean water and a soft cloth. Use a non-abrasive stainless steel cleaner. These cleaners can be purchased at most home improvement or major department stores. Always follow manufacturer's instructions.

Do not use household cleaners containing ammonia or bleach. **NOTE:** Always clean, wipe and dry with the grain to prevent scratching. Wash the rest of the cabinet with warm water and mild liquid detergent. Rinse well, and wipe dry with a clean soft cloth. **replacing Light Bulbs** · · · · · **Unplug refrigerator Wear gloves Remove light cover Replace old bulb Replace light cover Plug in the refrigerator CAUTION: Wear gloves when replacing light bulbs to avoid getting cut.**

Use same wattage when replacing bulb 20 **BEFORE YOU CALL** 1-800-944-9044 (United States) 1-800-265-8352 (Canada) Visit our web site at www.frigidaire.com.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFHS2622MH user guide](#)
<http://yourpdfguides.com/dref/3950175>

frigidaire.com. **PROBLEM AUTOMATIC ICE MAKER** Ice maker is not making any ice. . . . Ice maker is not making enough ice. · CAUSE Ice maker wire signal arm is in the "up" or OFF position. Ice maker power switch is Off. Ice maker has small cube caught in mechanism. Saddle valve on cold water pipe is clogged or restricted by foreign material. Ice maker is producing less ice than you expect.

. . . . **CORRECTION** Move wire signal arm to the "down" or ON position. (side mounted) Turn power switch to On ("I") position. (rear mounted) Remove small cube from ice maker. The ice and water filter cartridge may be clogged. Replace filter cartridge. Turn off household water line valve. Remove valve. Ensure that valve is not a self-piercing saddle valve. Clean valve. Replace valve if necessary.

Side mounted ice maker should produce 4 to 4.5 pounds (approximately 4 quarts) of ice every 24 hours. A rear mounted ice maker should produce 3 to 4 pounds (approximately 3½ quarts) of ice every 24 hours. Quick Ice option should produce up to 50% more ice every 24 hours.

If it is, replace the ice and water filter cartridge.

Move item and release wire signal arm. Remove any ice cubes that are frozen together over the wire signal arm. Remove ice container and discard ice from container. Ice maker will produce fresh supply. The ice and water filter cartridge may be clogged.

Replace filter cartridge. Set freezer control to colder setting. Allow 24 hours for temperature to stabilize. When the first supply of ice is dropped into the container, the dispenser should operate. Turn freezer control to a higher setting so that ice cubes will be made. When first supply of ice is made, dispenser should operate.

Open household water line valve. Allow sufficient time for the ice to be made. When ice is made, the dispenser should operate. Motor is overloaded.

Motor over load protector will reset in approximately 3 minutes. Ice can then be dispensed. Remove ice container, thaw, and empty the contents. Clean container, wipe dry, and replace in proper position. When new ice is made, dispenser should operate. Remove ice cubes that are jamming the dispenser. · Ice maker will not stop · making ice. Ice cubes are freezing together. · · ICE DISPENSER Dispenser will not dispense ice. · · · Ice dispenser is jammed.

· Check to see if water dispenser · is dispensing slower than normal. Ice maker wire signal arm is being held down by some item in the freezer. · Ice cubes are not being used · frequently enough. Ice cubes are hollow (partially · frozen cubes with water inside). Freezer control is set too warm.

· Ice storage container is empty. Freezer temperature is set too warm. Household water line valve is not open. Ice dispensing arm has been held in for more than 4-5 minutes. Ice has melted and frozen around auger due to infrequent use, temperature fluctuations, and/or power outages.

Ice cubes are jammed between ice maker and back of ice container. **OPENING/CLOSING OF DOOR/DRAWERS** Door(s) will not close. · · Drawers are difficult to · move. · Door was closed too hard, caus- · ing other door to open slightly. Refrigerator is not level. It · rocks on the floor when moved slightly.

Refrigerator is touching a wall · or cabinet. Food is touching shelf on top of drawer. Track that drawers slide on is dirty. · · Close both doors gently.

Ensure floor is level and solid, and can adequately support the refrigerator. Contact a carpenter to correct a sagging or sloping floor.

Ensure floor is level and solid, and can adequately support the refrigerator. Contact a carpenter to correct a sagging or sloping floor. Remove top layer of items in drawer. Ensure drawer is properly installed on track. Clean drawer, rollers, and track. See Care & Cleaning, 21 **BEFORE YOU CALL (CONTINUED)**

PROBLEM RUNNING OF REFRIGERATOR Compressor does not run. · · · · refrigerator runs too much or too long.

· · · · · Compressor goes off and on frequently. Digital temperature displays are flashing. **WATER DISPENSER** Dispenser will not dispense water. · · Water has an odd taste · and/or odor. · Water pressure is extremely low.

· Household water line valve is not open. Ice and water filter cartridge is clogged. Filter not fully installed. Water has been in the tank for a period of time. Unit not properly connected to cold water line.

· · · · Open household water line valve. See **PROBLEM** column **AUTOMATIC ICE MAKER**. Replace filter cartridge. Push filter in until you hear a "click". Draw and discard 10-12 glasses of water to freshen the supply and completely rinse out the tank. Connect unit to cold water line that supplies water to the kitchen faucet. Have someone turn up the cut-off and cut-on pressure on the water pump system (well systems only). It is normal for a reverse osmosis system to be below 20 psi during the regenerative phase. The rate of frost buildup and internal sweating increases. See **PROBLEM** column **OPENING/CLOSING OF DOOR/DRAWERS**.

It is not unusual to have moisture on the bottom side of the cover. Move humidity control (some models) to lower setting. Dry items before putting them in the drawer. Water collecting in bottom of drawer is normal. This is normal in humid weather. When humidity is lower, the moisture should disappear. See **PROBLEM** column **OPENING/CLOSING OF DOOR/DRAWERS**. · Freezer control is set to "OF" or "0". Refrigerator is in defrost cycle. Plug at electrical outlet is disconnected.

House fuse blown or tripped circuit breaker. Power outage. · · · · Set freezer control. This is normal for a fully automatic defrost refrigerator. The defrost cycle occurs periodically, lasting about 30 minutes.

Ensure plug is tightly pushed into outlet. Check/replace fuse with a 15 amp time-delay fuse. Reset circuit breaker. Check house lights. Call local electric company.

It's normal for the refrigerator to work longer under these conditions. Warm air entering the refrigerator causes it to run more. Open doors less often. Ensure refrigerator is level. Keep food and contents from blocking door. See **PROBLEM** column **OPENING/CLOSING OF DOORS/DRAWERS**. Set Fresh Food control to warmer setting until refrigerator temperature is satisfactory. Allow 24 hours for temperature to stabilize. Clean or change gasket. Leaks in door seal will cause refrigerator to run longer in order to maintain desired temperatures.

Clean condenser. See Care & Cleaning. This is normal. Refrigerator goes on and off to keep temperature constant. Call your Frigidaire service representative, who can interpret any messages or number codes flashing on the digital displays. **CAUSE CORRECTION** Room or outside weather is · hot.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFHS2622MH user guide](http://yourpdfguides.com/dref/3950175)
<http://yourpdfguides.com/dref/3950175>

Doors are opened too frequently or too long. Fresh Food/freezer door may be slightly open. Freezer control is set too cold. Fresh Food/freezer gasket is dirty, worn, cracked, or poorly fitted.

Condenser is dirty. Thermostat keeps the refrigerator at a constant temperature. Electronic control system has detected a performance problem.

DIGITAL TEMPERATURE DISPLAY Cut-off and cut-on pressures are too low (well systems only). Reverse osmosis system is in regenerative phase.

Weather is hot and humid. Door is slightly open. Vegetables contain and give off moisture. Washed vegetables and fruit drain while in the drawer. Weather is humid.

Water collects on bottom side of drawer cover. Water collects in bottom of drawer. Moisture collects on outside of refrigerator or between doors.

Products with original serial numbers that have been removed, altered or cannot be readily determined. 2. Product that has been transferred from its original owner to another party or removed outside the USA or Canada. 3. Rust on the interior or exterior of the unit. 4. Products purchased "as-is" are not covered by this warranty.

5. Food loss due to any refrigerator or freezer failures. 6. Products used in a commercial setting. 7. Service calls which do not involve malfunction or defects in materials or workmanship, or for appliances not in ordinary household use or used other than in accordance with the provided instructions. 8. Service calls to correct the installation of your appliance or to instruct you how to use your appliance. 9. Expenses for making the appliance accessible for servicing, such as removal of trim, cupboards, shelves, etc.

, which are not a part of the appliance when it is shipped from the factory. 10.

Service call to repair or replace appliance light bulbs, air filters, water filters, other consumables, or knobs, handles, or other cosmetic parts. 11. Surcharges including, but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas, including the state of Alaska.

12. Damage to the finish of appliance or home incurred during installation, including but not limited to floors, cabinets, walls, etc. 13. Damages caused by: services performed by unauthorized service companies; use of parts other than genuine Electrolux parts or parts obtained from persons other than authorized service companies; or external causes such as abuse, misuse, inadequate power supply, accidents, fires, or acts of God. **DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR OR REPLACEMENT AS PROVIDED HEREIN.**

CLAIMS BASED ON IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW, BUT NOT LESS THAN ONE YEAR. ELECTROLUX SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN LIMITED WARRANTY OR ANY IMPLIED WARRANTY. SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THESE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WRITTEN WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE. If you Need Service Keep your receipt, delivery slip, or some other appropriate payment record to establish the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts. Service under this warranty must be obtained by contacting Electrolux at the addresses or phone numbers below. This warranty only applies in the USA and Canada. In the USA, your appliance is warranted by Electrolux Major Appliances North America, a division of Electrolux Home Products, Inc.

In Canada, your appliance is warranted by Electrolux Canada Corp. Electrolux authorizes no person to change or add to any obligations under this warranty. Obligations for service and parts under

this warranty must be performed by Electrolux or an authorized service company. Product features or specifications as described or illustrated are subject to change without notice. USA 1.800.944.9044 Electrolux Major Appliances North America 10200 David Taylor Drive Charlotte, NC 28262 Canada 1.800.265.

8352 Electrolux Canada Corp. 5855 Terry Fox Way Mississauga, Ontario, Canada L5V 3E4 23.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](http://yourpdfguides.com/dref/3950175)

[FFHS2622MH user guide](http://yourpdfguides.com/dref/3950175)

<http://yourpdfguides.com/dref/3950175>