



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for FRIGIDAIRE FRQE7000LW. You'll find the answers to all your questions on the FRIGIDAIRE FRQE7000LW in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual FRIGIDAIRE FRQE7000LW
User guide FRIGIDAIRE FRQE7000LW
Operating instructions FRIGIDAIRE FRQE7000LW
Instructions for use FRIGIDAIRE FRQE7000LW
Instruction manual FRIGIDAIRE FRQE7000LW

All about the

Installation

of your Dryer




TABLE OF CONTENTS

Important Safety Instructions.....	2-3	Reversing Door	18-19
Installation Requirements	4-10	Accessories.....	20
Installed Dryer Dimensions	11	Español	21
Installation Instructions	12-17		

(6002) 1/0001/01/01/01



[You're reading an excerpt. Click here to read official FRIGIDAIRE FRQE7000LW user guide](http://yourpdfguides.com/dref/3671165)
<http://yourpdfguides.com/dref/3671165>

Manual abstract:

.....
.....
.....
.....

... 11 Installation Instructions

.....
.....
.....

..... @@@@Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. **WARNING - RISK OF FIRE** Read all of the following instructions before installing and using this appliance: · Destroy the carton and plastic bags after the dryer is unpacked. Children might use them for play.

Cartons covered with rugs, bedspreads, or plastic sheets can become airtight chambers causing suffocation. Place all materials in a garbage container or make materials inaccessible to children. · Clothes dryer installation and service must be performed by a qualified installer, service agency or the gas supplier. · Install the clothes dryer according to the manufacturer's instructions and local codes. · The electrical service to the dryer must conform with local codes and ordinances and the latest edition of the National Electrical Code, ANSI/NFPA 70, or in Canada, the Canadian electrical code C22.

I part 1. · The gas service to the dryer must conform with local codes and ordinances and the latest edition of the National Fuel Gas Code ANSI Z223.1, or in Canada, CAN/ACG B149.1-2000. · The dryer is designed under ANSI Z 21.

5.1 or ANSI/UL 2158 - CAN/CSA C22.2 No. 112 (latest editions) for HOME USE only. This dryer is not recommended for commercial applications such as restaurants, beauty salons, etc. · Do not install a clothes dryer with flexible plastic venting material. Flexible venting materials are known to collapse, be easily crushed and trap lint. These conditions will obstruct clothes dryer airflow and increase the risk of fire. · Do not stack a dryer on top of washer already installed on pedestal. Do not stack washer on top of dryer.

Do not stack washer on top of another washer. · The instructions in this manual and all other literature included with this dryer are not meant to cover every possible condition and situation that may occur. Good safe practice and caution **MUST** be applied when installing, operating and maintaining any appliance. **WHAT TO DO IF YOU SMELL GAS:** · · · Do not try to light any appliance. Do not touch any electrical switch; do not use any phone in your building. Clear the room, building or area of all occupants. Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. · If you cannot reach your gas supplier, call the fire department. Save these instructions for future reference.

Pre-Installation Requirements Tools and materials needed for installation: · Adjustable pliers · Phillips, straight, & square bit screwdrivers · Adjustable wrench · Pipe wrench for gas supply (gas dryer) · LP-resistant thread tape (for natural gas or LP supply, gas dryer) · Carpenter's level · External vent hood · 4-inch (102 mm), rigid metal or semi-rigid metal exhaust duct work · 3-wire or 4-wire 240 volt cord kit (electric dryer) · 4 in. (102 mm) clamp · Gas line shutoff valve (gas dryer) · ½ NPT union flare adapters (x2) and flexible gas supply line (gas dryer) · Metal foil tape (not duct tape) 2 **IMPORTANT SAFETY INSTRUCTIONS WARNING** Please read all instructions before using this dryer. **Installation Checklist** Exhaust Venting Free-flowing, clear of lint buildup 4 inch (102 mm) rigid or semi-rigid ducting of minimal length and turns NO foil or plastic venting material Approved vent hood exhausted to outdoors Recognize safety symbols, words and labels Safety items throughout this manual are labeled with a **WARNING** or **CAUTION** based on the risk type as described below: Leveling Dryer is level, side-to-side and front-to-back Cabinet is setting solid on all corners Definitions This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

Gas Supply (Gas Dryer) Manual shutoff valve present in supply All connections sealed with approved sealer and wrench tight Conversion kit for LP system Gas supply turned on No leaks present at all connections check with soapy water, NEVER check with flame **DANGER DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. **WARNING WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. 240v Electric Supply (Electric Dryer) Approved NEMA 10-30R or 14-30R service cord with all screws tight on terminal block Approved strain relief installed Terminal access cover installed before initial operation **CAUTION CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. Door Reversal Follow detailed instructions in this guide Test hinge and latch for function Electrical Power House power turned on Dryer plugged in **IMPORTANT IMPORTANT** indicates installation, operation or maintenance information which is important but not hazard-related. Final Checks Installation Instructions and Use and Care Guide read thoroughly Door latches and drum tumbles when cycle starts Registration card sent in 3 **INSTALLATION REQUIREMENTS NOTE** Because of potentially inconsistent voltage capabilities, the use of this dryer with power created by gas powered generators, solar powered generators, wind powered generators or any other generator other than the local utility company is not recommended.

Electrical requirements for electric dryer **CIRCUIT** - Individual 30 amp. branch circuit fused with 30 amp. time delay fuses or circuit breakers. Use separately fused circuits for washer and dryer. **DO NOT** operate a washer and a dryer on the same circuit. **POWER SUPPLY** - 3-wire or 4-wire, 240 volt, single phase, 60 Hz, Alternating Current. **IMPORTANT** This dryer is internally grounded to neutral unless it was manufactured for sale in Canada. Only a 4-conductor cord shall be used when the appliance is installed in a location where grounding through the neutral conductor is prohibited. Grounding through the neutral link is prohibited for: (1) new branch circuit installations, (2) mobile homes, (3) recreational vehicles, and (4) areas where local codes do not permit grounding through the neutral. **OUTLET RECEPTACLE** - NEMA 10-30R or NEMA 14-30R receptacle to be located so the power supply cord is accessible when the dryer is in the installed position.

GROUNDING CONNECTION - See "Grounding requirements" in Electrical Installation section. **3-WIRE POWER SUPPLY CORD KIT** (not supplied) **4-WIRE POWER SUPPLY CORD KIT** (not supplied) 3-wire receptacle (NEMA type 10-30R) The dryer **MUST** employ a 3-conductor power supply cord NEMA 10-30 type SRDT rated at 240 volt AC minimum, 30 amp, with 3 open end spade lug connectors with upturned ends or closed loop connectors and marked for use with clothes dryers.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FRQE7000LW user guide](#)

For 3-wire cord connection instructions see **ELECTRICAL CONNECTIONS FOR A 3-WIRE SYSTEM**. 4-wire receptacle (NEMA type 14-30R) The dryer MUST employ a 4-conductor power supply cord NEMA 14-30 type SRDT or ST (as required) rated at 240 volt AC minimum, 30 amp, with 4 open end spade lug connectors with upturned ends or closed loop connectors and marked for use with clothes dryers. For 4-wire cord connection instructions see **ELECTRICAL CONNECTIONS FOR A 4-WIRE SYSTEM**. NOTE Dryers manufactured for sale in Canada have factory installed, 4-wire power supply cord (NEMA 14-30R). 4 **INSTALLATION REQUIREMENTS** Electrical requirements for gas dryer **CIRCUIT** - Individual, properly polarized and grounded 15 amp. branch circuit fused with 15 amp. time delay fuse or circuit breaker. **POWER SUPPLY** - 2-wire, with ground, 120 volt, single phase, 60 Hz, Alternating Current.

POWER SUPPLY CORD - The dryer is equipped with a 120 volt 3-wire power cord. **GROUNDING CONNECTION** - See "Grounding requirements" in Electrical Installation section. Grounding type wall receptacle wall receptacle Do not, under any circumstances, any circumstances, cut, remove, remove or bypass the grounding prong. Power cord with 3-prong grounded plug grounded Gas supply requirements **WARNING EXPLOSION HAZARD** Uncoated copper tubing will corrode when subjected to natural gas, causing gas leaks.

Use **ONLY** black iron, stainless steel, or plastic-coated brass piping for gas supply. 1 Installation **MUST** conform with local codes, or in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1 (latest edition). 2 The gas supply line should be 1/2 inch (1.27 cm) pipe.

3 If codes allow, flexible metal tubing may be used to connect your dryer to the gas supply line. The tubing **MUST** be constructed of stainless steel or plastic-coated brass. 4 The gas supply line **MUST** have an individual shutoff valve. 5 A 1/8 inch (0.32 cm) N.P.T. plugged tapping, accessible for test gauge connection, **MUST** be installed immediately upstream of the gas supply connection to the dryer. 6 The dryer **MUST** be disconnected from the gas supply piping system during any pressure testing of the gas supply piping system at test pressures in excess of 1/2 psig (3.45 kPa).

7 The dryer **MUST** be isolated from the gas supply piping system during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.45 kPa). 8 Connections for the gas supply must comply with the Standard for Connectors for Gas Appliances, ANSI Z21.24. 5 **INSTALLATION REQUIREMENTS** Exhaust system requirements Use only 4 inch (102 mm) diameter (minimum) rigid or flexible metal duct and approved vent hood which has a swing-out damper(s) that open when the dryer is in operation. When the dryer stops, the dampers automatically close to prevent drafts and the entrance of insects and rodents. To avoid restricting the outlet, maintain a minimum of 12 inches (30.5 cm) clearance between the vent hood and the ground or any other obstruction. **WARNING FIRE HAZARD** Failure to follow these instructions can create excessive drying times and fire hazards. Correct Incorrect The following are specific requirements for proper and safe operation of your dryer.

WARNING FIRE HAZARD Do not install a clothes dryer with flexible plastic or metal foil venting materials. Flexible venting materials are known to collapse, be easily crushed and trap lint. These conditions will obstruct clothes dryer airflow and increase the risk of fire. If your present system is made up of plastic duct or metal foil duct, replace it with a rigid or semi-rigid metal duct. Also, ensure the present duct is free of any lint prior to installing dryer duct.

Correct Incorrect 6 **INSTALLATION REQUIREMENTS** Exhaust system requirements, continued **WARNING FIRE HAZARD** A clothes dryer must be exhausted outdoors. Do not exhaust dryer into a chimney, a wall, a ceiling, an attic, a crawl space or any concealed space of a building. A clothes dryer produces combustible lint. If the dryer is not exhausted outdoors, some fine lint will be expelled into the laundry area. An accumulation of lint in any area of the home can create a health and fire hazard.

The dryer must be connected to an exhaust outdoors. Regularly inspect the outdoor exhaust opening and remove any accumulation of lint around the outdoor exhaust opening and in the surrounding area. **WARNING FIRE HAZARD** Exceeding the length of duct pipe or number of elbows allowed in the "MAXIMUM LENGTH" charts can cause an accumulation of lint in the exhaust system. Plugging the system could create a fire hazard, as well as increase drying times.

MAXIMUM LENGTH of 4" (102mm) Rigid Metal Duct **VENT HOOD TYPE** (Preferred) Number of 90° turns **WARNING FIRE HAZARD** · Do not allow combustible materials (for example: clothing, draperies/curtains, paper) to come in contact with exhaust system. The dryer **MUST NOT** be exhausted into a chimney, a wall, a ceiling, or any concealed space of a building which can accumulate lint. If the dryer is exhausted through the floor and area beneath the mobile home is enclosed, the exhaust system **MUST** terminate outside the enclosure with the termination securely fastened to the mobile home structure. 4 Refer to previous sections in this guide for other important exhaust venting system requirements. 5 When installing a gas dryer into a mobile home, a provision must be made for outside make up air. This provision is to be not less than twice the area of the dryer exhaust outlet. 6 Installer **MUST** anchor this (1) dryer or (2) dryer mounted on pedestal to the floor with approved Mobile Home Installation Kit - P/N 137067200.

Clearance requirements **WARNING EXPLOSION HAZARD** Do not install the dryer where gasoline or other flammables are kept or stored. If the dryer is installed in a garage, it must be a minimum of 18 inches (45.7 cm) above the floor. Failure to do so can result in death, explosion, fire or burns. **IMPORTANT DO NOT INSTALL YOUR DRYER:** 1 In an area exposed to dripping water or outside weather conditions. 2 In an area where it will come in contact with curtains, drapes, or anything that will obstruct the flow of combustion and ventilation air. 3 On carpet. Floor **MUST** be solid with a maximum slope of 1 inch (2.54 cm). 9 **INSTALLATION REQUIREMENTS** Clearance requirements, continued Installation in a Recess or Closet 1 A dryer installed in a bedroom, bathroom, recess or closet, **MUST** be exhausted outdoors.

2 No other fuel burning appliance shall be installed in the same closet as the gas dryer. 3 Your dryer needs the space around it for proper ventilation. **DO NOT** install your dryer in a closet with a solid door. 4 Closet door ventilation required: A minimum of 120 square inches (774.2 cm²) of opening, equally divided at the top and bottom of the door, is required.

Openings should be located 3 inches (7.6 cm) from bottom and top of door. Openings are required to be unobstructed when a door is installed.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](http://yourpdfguides.com/dref/3671165)

[FRQE7000LW user guide](http://yourpdfguides.com/dref/3671165)

<http://yourpdfguides.com/dref/3671165>

A louvered door with equivalent air openings for the full length of the door is acceptable. 3" (7.

6cm) MINIMUM INSTALLATION CLEARANCES - Inches (cm) SIDES Alcove REAR TOP FRONT n/a n/a 1" (2.5 cm) 0" (0 cm) 0" (0 cm)* 0" (0 cm) Under 0" (0 cm) 0" (0 cm)* 0" (0 cm) Counter Closet 0" (0 cm) 0" (0 cm)* 0" (0 cm) * Dryer must be vented straight back to achieve 0" (0 cm) rear installation. 0" (0cm) 0" (0cm) 60 sq. in. (387.1cm²) 1" (2.54cm) 0" (0cm) 60 sq. in. (387.1cm²) 3" (7.

6cm) closet door 10 INSTALLED DIMENSIONS 48.25" (122.5cm)* to clear open door 30.5" (77.5cm)* to front of closed door 27.0" (68.5cm) 36.0" (91.5cm) electrical supply on rear of unit centerline height for rear vent 3.7" (9.

5cm) 51.25" (130cm) freestanding dryer on floor gas supply pipe on rear of gas unit 1.6" (4cm) floor line dryer mounted on optional pedestal 16.9" (43cm) 19.0" (48cm) floor line * To obtain these minimal depth dimensions, dryer must be vented straight back.

Using a quick-turn 90° elbow (right or down on freestanding dryer) adds approximately 0.75 in. (2.0 cm) to installation depth. Upward venting of exhaust on pedestal-mounted or freestanding dryer adds approximately 4 in.

(10.2 cm) to installation depth. Leftward venting on pedestal-mounted or freestanding dryer adds approximately 3.75 in. (9.5 cm) to installation depth. Downward venting of exhaust on pedestal-mounted dryer adds approximately 2.25 in. (5.7 cm) to installation depth.

3.75" (9.5cm) 13.50" (34.5cm) to center of rear vent 48.25" (122.5cm)* to clear open door 30.5" (77.5cm)* to front of closed door 27.0" (68.

5cm) 71.5" (182cm) electrical supply on rear of unit gas supply pipe on rear of gas unit centerline height for rear vent 37" (94cm) 39" (99cm) * To obtain these minimal depth dimensions, dryer must be vented straight back. Using a quick-turn 90° elbow (right) adds approximately 0.75 in. (2 cm) to installation depth.

Upward venting of exhaust on stacked dryer adds approximately 4 in. (10.2 cm) to installation depth. Downward venting of exhaust on stacked dryer adds approximately 2.25 in.

(6.5 cm) to installation depth. Leftward venting of exhaust on stacked dryer adds approximately 3.75 in. (9.5 cm) to installation depth. 11 INSTALLATION INSTRUCTIONS Electrical installation The following are specific requirements for proper and safe electrical installation of your dryer. Failure to follow these instructions can create electrical shock and/or a fire hazard. WARNING ELECTRICAL SHOCK HAZARD · A U.L.

-approved strain relief must be installed onto power cord. If the strain relief is not attached, the cord can be pulled out of the dryer and can be cut by any movement of the cord, resulting in electrical shock. · Do not use an aluminum wired receptacle with a copper wired power cord and plug (or vice versa). A chemical reaction occurs between copper and aluminum and can cause electrical shorts. The proper wiring and receptacle is a copper wired power cord with a copper wired receptacle. WARNING ELECTRICAL SHOCK HAZARD · This appliance MUST be properly grounded. Electrical shock can result if the dryer is not properly grounded. Follow the instructions in this manual for proper grounding. · Do not use an extension cord with this dryer. Some extension cords are not designed to withstand the amounts of electrical current this dryer utilizes and can melt, creating electrical shock and/or fire hazard.

Locate the dryer within reach of the receptacle for the length power cord to be purchased, allowing some slack in the cord. Refer to the pre-installation requirements in this manual for the proper power cord to be purchased. NOTE Dryers operating on 208 volt power supply will have longer drying times than dryers operating on 240 volt power supply. Grounding requirements - Electric dryer (USA) WARNING ELECTRICAL SHOCK HAZARD Improper connection of the equipment grounding conductor can result in a risk of electrical shock. Check with a licensed electrician if you are in doubt as to whether the appliance is properly grounded.

For a grounded, cord-connected dryer: 1 The dryer MUST be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electrical shock by a path of least resistance for electrical current. 2 After you purchase and install a 3 wire or 4 wire power supply cord having an equipment-grounding conductor and a grounding plug that matches your wiring system, the plug MUST be plugged into an appropriate, copper wired receptacle that is properly installed and grounded in accordance with all local codes and ordinances. If in doubt, call a licensed electrician. 3 DO NOT modify the plug you've installed on this appliance.

If it will not fit the outlet, have a proper outlet installed by a qualified electrician. For a permanently connected dryer: 1 The dryer MUST be connected to a grounded metal, permanent wiring system; or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment-grounding terminal or lead on the appliance. 12 INSTALLATION INSTRUCTIONS Grounding requirements - Electric dryer (Canada) WARNING ELECTRICAL SHOCK HAZARD Improper connection of the equipment grounding conductor can result in a risk of electrical shock. Check with a licensed electrician if you are in doubt as to whether the appliance is properly grounded. For a grounded, cord-connected dryer: 1 The dryer MUST be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electrical shock by a path of least resistance for electrical current. 2 Since your dryer is equipped with a power supply cord having an equipment-grounding conductor and a grounding plug, the plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances. If in doubt, call a licensed electrician. 3 DO NOT modify the plug provided with this appliance. If it will not fit the outlet, have a proper outlet installed by a qualified electrician.

Grounding requirements - Gas dryer (USA and Canada) 1 The dryer is equipped with a three-prong (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. 2 The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances. If in doubt, call a licensed electrician. 3 DO NOT modify the plug provided with this appliance. If it will not fit the outlet, have a proper outlet installed by a qualified electrician. Grounding type wall receptacle wall receptacle

Do not, under any circumstances, any circumstances, cut, remove, remove or bypass the bypass th grounding prong. grounding prong. Power Power cord with 3-prong grounded plug grounded 13 INSTALLATION INSTRUCTIONS Gas connection 1 Remove the shipping cap from gas pipe at the rear of the dryer.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FRQE7000LW user guide](http://yourpdfguides.com/dref/3671165)
<http://yourpdfguides.com/dref/3671165>

3 Open the shutoff valve in the gas supply line to allow gas to flow through the pipe. Wait a few minutes for gas to move through the gas line. **to d IMPORTANT DO NOT connect the dryer to L.P. gas service without converting the gas valve. An L.P. conversion kit must be installed by a qualified gas technician.** 2 Connect a 1/2 inch (1.27 cm) I.D. semi-rigid or approved pipe from gas supply line to the 3/8 inch (0.96 cm) pipe located on the back of the dryer. Use a 1/2 inch to 3/8 inch (1.27 cm to 0.96 cm) reducer for the connection. Apply an approved thread sealer that is resistant to the corrosive action of liquefied gases on all pipe connections. **GAS FLOW** rye r fro m ga ss up ply Shutoff Valve Open position 4 Check for gas system leaks with a manometer. If a manometer is not available, test all connections by brushing on a soapy water solution. Manual Shutoff Flare Valve Union Flare Union Closed Nipple Open Flexible Connector Inlet Pipe on Back of Dryer **WARNING EXPLOSION HAZARD NEVER test for gas leaks with an open flame. All connections must be wrench-tightened IMPORTANT The supply line must be equipped with an approved manual shutoff valve. This valve should be located in the same room as the dryer and should be in a location that allows ease of opening and closing.**

Do not block access to the gas shutoff valve. 14 **INSTALLATION INSTRUCTIONS Electrical connection (non-Canada) - 3 wire cord 3-wire receptacle (NEMA type 10-30R) WARNING ELECTRICAL SHOCK HAZARD Failure to disconnect power source before servicing could result in personal injury or even death.** 1 Turn off power supply to outlet. 2 Remove the screw securing the terminal block access cover in the lower corner on the back of the dryer. 3 Install a UL-approved strain relief according to the power cord/strain relief manufacturer's instructions in the power cord entry hole below the access panel. At this time, the strain relief should be loosely in place. 4 Thread an UNPLUGGED, UL-approved, 30 amp. power cord, NEMA 10-30 type SRDT, through the strain relief. 5 Attach the power cord neutral (center wire) conductor to the SILVER colored center terminal on the terminal block. Tighten the screw securely.

6 Attach the remaining two power cord outer conductors to the outer, BRASS colored terminals on the terminal block. Tighten both screws securely. 30 AMP NEMA 10-30 Neutral (center wire) Access cover screw Terminal block Line 2 (BRASS terminal) Neutral (SILVER terminal) Line 1 (BRASS terminal) Internal ground (GREEN screw) Install UL-approved strain relief here Terminal screw recovery slot **NOTE If a terminal screw falls during cord installation, it can be retrieved in the terminal screw recovery slot below the access panel. DO NOT remove internal ground in a 3-wire system!! WARNING ELECTRICAL SHOCK HAZARD Do not make a sharp bend or crimp wiring/conductor at connections.** 7 Follow manufacturer's guidelines for firmly securing the strain relief and power cord.

8 Reinstall the terminal block cover. Neutral terminal **IMPORTANT If moving dryer from a 4-wire system and installing it in a 3-wire system, move the internal ground from the center terminal back to the GREEN screw next to the terminal block.** 15 **INSTALLATION INSTRUCTIONS Electrical connection (non-Canada) - 4 wire cord 4-wire receptacle (NEMA type 14-30R) WARNING ELECTRICAL SHOCK HAZARD Failure to disconnect power source before servicing could result in personal injury or even death.** 1 Turn off power supply to outlet. 2 Remove the screw securing the terminal block access cover in the lower corner on the back of the dryer.

3 Install a UL-approved strain relief according to the power cord/strain relief manufacturer's instructions in the power cord entry hole below the access panel. At this time, the strain relief should be loosely in place. 4 Thread an UNPLUGGED, UL-approved, 30 amp. power cord, NEMA 14-30 type ST or SRDT, through the strain relief. 5 Disconnect the internal (WHITE) dryer harness ground wire from the (GREEN) ground screw next to the terminal block. 6 Attach the ground (GREEN) power cord wire to the cabinet with the ground (GREEN) screw. Tighten the screw securely. 7 Move the internal dryer harness ground (WHITE) wire to the terminal block and attach it along with the neutral (WHITE) power cord wire conductor to the center, SILVER colored terminal on the terminal block. Tighten the screw securely. 8 Attach the RED and BLACK power cord conductors to the outer, BRASS colored terminals on the terminal block.

Tighten both screws securely. 30 AMP NEMA 14-30 Neutral (WHITE wire) Ground (GREEN wire) Access cover screw Terminal block Line 2 (BRASS terminal) Neutral (SILVER terminal) Line 1 (BRASS terminal) Internal ground (GREEN screw) Install UL-approved strain relief here Terminal screw recovery slot **NOTE If a terminal screw falls during cord installation, it can be retrieved in the terminal screw recovery slot below the access panel. Move internal ground (WHITE) wire to neutral (SILVER) terminal for 4-wire system. Neutral terminal WARNING ELECTRICAL SHOCK HAZARD Do not make a sharp bend or crimp wiring/conductor at connections.** 9 Follow manufacturer's guidelines for firmly securing the strain relief and power cord. 10 Reinstall the terminal block cover. GREEN ground screw WHITE neutral wire GREEN ground wire BLACK or RED power wire BLACK or RED power wire 16 **INSTALLATION INSTRUCTIONS General installation** 1 Connect the exhaust duct to the outside exhaust system (see pages 6 through 8). Use of a 4" (102 mm) clamp (item A) is recommended to connect the dryer to the exhaust vent system. Use metal foil tape to seal all other joints. 2 Carefully slide the dryer to its final position.

Adjust one or more of the legs until the dryer is resting solidly on all four legs. Place a level on top of the dryer. The dryer **MUST** be level and resting solidly on all four legs. Rock alternating corners to check for stability. Remove and discard door tape.

A IMPORTANT Be sure the power is off at a circuit breaker/fuse box before plugging the power cord into an outlet. 3 Plug the power cord into a grounded outlet. 4 Turn on the power at the circuit breaker/fuse box. 5 Read the Use & Care Guide provided with the dryer. It contains valuable and helpful information that will save you time and money.

6 If you have any questions during initial operation, please review the "Avoid Service Checklist" in your Use & Care Guide before calling for service. 7 Place these instructions in a location near the dryer for future reference. **NOTE A wiring diagram and technical data sheet are located inside the dryer console.** Grounding type wall receptacle wall receptacle Do not, under any circumstances, any circumstances, cut, remove, remove or bypass the bypass th grounding prong. grounding prong. Power Power cord with 3-prong grounded plug grounded 17 **REVERSING DOOR** Figure 1 Figure 4 1 Open door and remove four plugs in the door opening opposite the hinges.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FRQE7000LW user guide](http://yourpdfguides.com/dref/3671165)
<http://yourpdfguides.com/dref/3671165>

Retain all parts for use later, unless otherwise noted. (Figure 1). 5 Remove two door handle screws and two hole plugs from door. (Figure 4) Figure 2 2 Begin removing the four screws that attach the hinge to the front panel.

(Figure 2) Start by only removing one screw per hinge. Then only loosen the two remaining screws while firmly holding the door to prevent damage to hinge, front panel or door. After the remaining screws are loosened continue to remove all. Figure 5 6 Pull handle away from door assembly. (Figure 5) Figure 6 7 Separate the outer door from the inner door assembly with a putty knife or flat screw driver. (Figure 6) Figure 3 3 Place door on a towel (handle side down) to prevent scratches to window. Remove all four remaining hinge screws on edge of door. (Figure 3) 4 Remove four screws from edge of door opposite hinges.

18 REVERSING DOOR Figure 7 8 Remove lens locating screw. (Figure 7) Figure 11 12 Reassemble outer door to inner door.

(Figure 11) 13 Install four screws securing hinge to door assembly in the new location, take note to place hinge in correct orientation. 14 Install four screws into holes that had secured the hinge. 15 Remove striker and discard. 16 Remove square plug and reinstall in hole striker was just removed from. 17 Install new striker (included in literature bag) into hole square plug was previously installed in.

Figure 8 9 Disengage several of the retention tabs and pull lens away from the transition ring. (Figure 8) Figure 9 Figure 10 Figure 12 10 Remove two transition ring plugs and reinstall on previous handle side. Figures 9 and 10) 11 Reassemble lens to transition ring with holes to install handle on right-hand side of door assembly. Ensure retention tabs on transition ring are snapped in place on top of lens. 18 Reinstall door handle by placing the handle mounting bosses through holes in lens and transition ring and installing screws through inner door and tighten into handle bosses.

(Figure 12) 19 Grasping firmly the top of the door, position the door near the door opening and align the top hinge hole to the top hole in the front panel door opening. Once the first screw is started, attach the second screw to the lower hinge. Once both screws are tightened, install the remaining two screws. 20

Install four plugs into the front panel door opening where hinges were originally installed. 19 ACCESSORIES MATCHING STORAGE PEDESTAL* Classic Classic Classic Classic White Pedestal - P/N CFPWD15W Blue Pedestal - P/N CFPWD15N Red Pedestal - P/N CFPWD15R Silver Pedestal - P/N CFPWD15A Black Pedestal - P/N CFPWD15B CAUTION Failure to use accessories manufactured by (or approved by) the manufacturer could result in personal injury, property damage or damage to the dryer. A storage pedestal accessory, specifically designed for this dryer may be used to elevate the dryer for ease of use. This pedestal will add about 15" (38 cm) to the height of your unit for a total height of 51.25" (130 cm). *Other colors may be available.

Contact the source where you purchased your dryer.

DRYER STACKING KIT P/N 134700600 27.0 (68.5 " cm) Depending on the model you purchased, a kit for stacking this dryer on top of matching washer may have been included in the initial purchase of your dryer. If your model did not include a stacking kit or you desire another stacking kit, you may order one. LP

CONVERSION KIT P/N PCK4200 15.0 (38 c " m) Gas dryers intended for use in a location supplied with LP must use a conversion kit prior to installation.

MOBILE HOME INSTALLATION KIT P/N 137067200 .5" 26 m) c (67 Installation in a mobile home requires the use of a MOBILE HOME INSTALLATION KIT. DRYING RACK P/N 137067300 Depending on the model you purchased, a drying rack may have been included in the initial purchase of your dryer. If your model did not include a drying rack or you desire another drying rack, you may order one.

UNIVERSAL APPLIANCE WRENCH P/N 137019200 A UNIVERSAL APPLIANCE WRENCH is available to aid in dryer/ washer/pedestal feet adjustment.

TOUCH UP PAINT PENS* Classic Classic Classic Classic Classic White Touch Up Pen - P/N 5304468812 Red Touch Up Pen - P/N 5304471227 Blue Touch Up Pen - P/N 5304471229 Silver Touch Up Pen - P/N 5304471228 Black Touch Up Pen - P/N 5304458932 *Other colors may be available. Contact the

source where you purchased your dryer. Replacement parts: If replacements parts are needed for your washer, contact the source where you purchased your washer or refer to your Use and Care Guide for more information. WARNING ELECTRICAL SHOCK HAZARD Label all wires prior to disconnection when servicing controls.

Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing. 20 Instalación Installation de su Secadora of your Dryer Todo acerca All about the del ÍNDICE Instrucciones importantes de seguridad ...

..... 22-23 Requisitos de instalación ..

.....
.....
.....
.....

. 24-30 Dimensiones de la secadora instalada

.....
.....

31 Instrucciones de instalación

.....
.....

... 32-37 Inversión de la puerta..

.....
.....
.....
.....

..... 38-39 Accesorios

.....
.....
.....
.....
.....

.....

... 40 www.frigidaire.com USA 1-800-944-9044 www.frigidaire.ca Canada 1-800-265-8352 21 **INSTRUCCIONES IMPORTANTES DE SEGURIDAD**
ADVERTENCIA Para su seguridad, debe seguir la información de esta guía para minimizar el riesgo de incendio o explosión o para evitar daños a la propiedad, lesiones personales o incluso la muerte. No almacene ni utilice gasolina ni otros líquidos o vapores inflamables cerca de este o de cualquier otro electrodoméstico. **ADVERTENCIA - PELIGRO DE INCENDIO** Lea las siguientes instrucciones antes de instalar y utilizar este electrodoméstico: · Después de desembalar la secadora, destruya los cartones y las bolsas de plástico.

Los niños podrían utilizarlos para jugar. Los cartones cubiertos con alfombras, cubrecamas, o láminas de plástico pueden convertirse en cámaras de aire herméticamente cerradas y provocar asfixia. Coloque todos los materiales en un basurero o manténgalos fuera del alcance de los niños. · La instalación y el servicio de la secadora de ropa deben ser llevados a cabo por un instalador calificado, agencia de servicios o proveedor de gas. · Instale la secadora de ropa de acuerdo con las instrucciones del fabricante y los códigos locales. · La reparación eléctrica de la secadora debe cumplir con los códigos y las ordenanzas locales y la última edición del Código Eléctrico Nacional (National Electrical Code), el ANSI/NFPA 70, o bien en Canadá, el CSA C22.1 del Código Eléctrico de Canadá (Canadian Electrical Code) Parte 1. · El servicio de gas de la secadora debe cumplir con los códigos y las ordenanzas locales, y la última edición del Código de Gas Nacional (National Fuel Gas Code), el ANSI Z223.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](#)

[FRQE7000LW user guide](#)

<http://yourpdfguides.com/dref/3671165>

CORRECTO INCORRECTO En instalaciones en las que el sistema de escape no se describa en las tablas, se debe utilizar el siguiente método para determinar si dicho sistema es aceptable: 1 Conecte un manómetro inclinado o digital entre la secadora y el punto donde el tubo de escape se conecta con la secadora.

2 Coloque el temporizador y la temperatura de la secadora en la opción Air fluff - cool down (Esponjado con aire, enfriamiento) y ponga en marcha la secadora. 3 Lea la medición del manómetro. 4 La contrapresión del sistema NO DEBE ser mayor que 2,5 cm (1 pulgada) de columna de agua. Si la contrapresión del sistema es menor que 2,5 cm (1 pulgada) de columna de agua, el sistema es aceptable. Si la lectura del manómetro es mayor que 2,5 cm (1 pulgada) de columna de agua, el sistema es demasiado restrictivo y la instalación es inaceptable.

Si bien la orientación vertical del sistema de escape es aceptable, ciertas circunstancias atenuantes podrían afectar el funcionamiento de la secadora: · Sólo se debe utilizar una red de conductos de metal rígido. · Si la ventilación se efectúa en forma vertical a través del techo, es posible que el sistema de escape se vea expuesto a ráfagas descendentes que restringirán la ventilación. · Si el sistema de escape se extiende a través de un área que no está aislada, puede producirse condensación y una acumulación más rápida de pelusa. · La compresión o los pliegues del sistema de escape aumentarán la restricción de la ventilación. · Se debe inspeccionar y limpiar el sistema de escape cada 18 meses como mínimo cuando se le da un uso normal. Cuanto más utilice la secadora, más a menudo deberá comprobar que el sistema de escape y la capucha de ventilación funcionan correctamente. Consulte también los REQUISITOS DE DESPEJE en la siguiente página. NOTA Utilice un codo de giro rápido de 90° para cumplir con la profundidad mínima de instalación de la secadora independiente. · La ventilación derecho hacia atrás permite la instalación de la secadora a 0" (0 cm) de la pared. · La ventilación hacia la derecha con un codo de 90° permite la instalación de la secadora a 0.

75" (2 cm) de la pared. · La ventilación hacia abajo con un codo de 90° permite la instalación de la secadora a 0.75" (2 cm) de la pared. · La ventilación hacia la izquierda con un adaptador recto corto y un codo de 90° permite la instalación a 3.75" (9.5 cm) de la pared. · La ventilación hacia arriba con un adaptador recto corto y un codo de 90° permite la instalación a 4" (10.2 cm) de la pared. 28 REQUISITOS DE INSTALACIÓN Instalación en una casa rodante 1 La instalación DEBE cumplir con la actual Norma de Seguridad y Construcción de Casas Rodantes, título 24 CFR, Parte 32-80 (que anteriormente se conocía como la Norma Federal de Seguridad y Construcción de Casas Rodantes [Federal Standard for Mobile Home Construction and Safety], título 24, HUD parte 280) o la Norma CAN/CSAZ240 MH. 2 La secadora DEBE tener evacuación al exterior (no a la parte de abajo de la casa rodante) mediante conductos metálicos que no admitan combustión.

Los conductos metálicos deben tener un diámetro de 10,16 cm (4 pulgadas) y no deben presentar obstrucciones. Se recomiendan los conductos de metal rígido. 3 Si la secadora tiene evacuación a través del piso, y el área debajo de la casa rodante es cerrada, el sistema de evacuación DEBE terminar fuera del espacio cerrado y el extremo debe quedar sujetado firmemente a la estructura de la casa rodante. 4 Para obtener información sobre otros requisitos importantes del sistema de escape, consulte las secciones anteriores de esta guía. 5 Cuando se instale una secadora a gas en una casa rodante, se debe dejar espacio en el exterior para la salida de aire.

Este espacio debe ser por lo menos el doble del área de la salida de escape de la secadora. 6 El técnico de instalación DEBE anclar esta secadora (1) o secadora sobre pedestal (2) al piso usando un kit de instalación para casas rodantes, pieza número 137067200. Requisitos de despeje ADVERTENCIA PELIGRO DE EXPLOSIÓN No instale la secadora en el mismo lugar en el que haya o se almacene gasolina u otros productos inflamables. Si la secadora se instala en un garaje, debe estar a una altura mínima de 45,7 cm (18 pulgadas) por encima del suelo. De lo contrario, podría producirse una explosión, un incendio, quemaduras o incluso la muerte.

IMPORTANTE NO INSTALE LA SECADORA: 1 En una zona expuesta a la humedad o a las condiciones climáticas externas. 2 En un área en la que esté en contacto con cortinas, telas colgantes o cualquier otra cosa que pueda obstruir el flujo de aire de ventilación y combustión. 3 Sobre una alfombra. El piso DEBE ser firme con una pendiente máxima de 2,54 cm (1 pulgada). 29 REQUISITOS DE INSTALACIÓN Requisitos de despeje (continuación) ESPACIOS MÍNIMOS PARA LA INSTALACIÓN: cm (pulgadas) Instalación en un Nicho o Armario 1 Una secadora instalada en un dormitorio, baño, nicho o armario, DEBE tener ventilación al exterior. 2 No se debe instalar ningún otro artefacto de combustión en el mismo armario que la secadora a gas. 3 La secadora necesita espacio a su alrededor para que la ventilación sea adecuada. NO instale la secadora en un armario con puerta maciza. 4 Ventilación requerida en la puerta del armario: Se necesita un mínimo de 774,2 cm² (120 pulgadas²) de abertura, dividido en partes iguales en la parte superior e inferior de la puerta. Las aberturas de ventilación deben estar ubicadas a 7,6 cm (3 pulgadas) de la parte superior e inferior de la puerta.

Es necesario que las aberturas de aire no estén obstruidas al instalar una puerta. Se acepta una puerta que tenga aberturas de ventilación distribuidas uniformemente en toda la superficie. Alcôve LATERALES PARTE TRASERA PARTE SUPERIOR PARTE DELANTERA 0 cm (0") 0 cm (0") 0 cm (0") 0 cm (0") 0 cm (0") 0 cm (0") n/d n/d Sous 0 cm (0") le comptoir Placard 0 cm (0") 0 cm (0") 2,54 cm (1") * La ventilación derecho hacia atrás permite la instalación de la secadora a 0" (0 cm) de la pared. 0" (0cm) 0" (0cm) 3" (7.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FRQE7000LW user guide](http://yourpdfguides.com/dref/3671165)
<http://yourpdfguides.com/dref/3671165>

6cm) 60 sq. in. (387.1cm²) 1" (2.54cm) 0" (0cm) 60 sq. in.

(387.1cm²) 3" (7.6cm) puerta del armario 30 DIMENSIONES DE LA SECADORA INSTALADA 48.25" (122.5cm)* para destapar abra la puerta 30.

5" (77.5cm)* al frente de la puerta cerrada 27.0" (68.5cm) 36.0" (91.

5cm) suministro eléctrico en la parte trasera de la unidad 51.25" (130cm) secadora independiente sobre el piso línea del piso tubería de suministro de gas en la parte trasera de la unidad de gas 1.6" (4cm) altura de la línea central para ventilación trasera 3.7" (9.5cm) secadora colocada sobre pedestal opcional 16.9" (43cm) 19.0" (48cm) línea del piso * Para obtener estas dimensiones mínimas de profundidad, la secadora debe ser ventilada 3.75" derecho hacia atrás. Si se usa un codo de giro rápido de 90° (hacia la derecha o hacia abajo) (9.5cm) 13.

50" en la secadora independiente), se agregan aproximadamente 0.75" (2.0 cm) a la profundidad (34.5cm) de instalación. Si se orienta el escape de la secadora independiente o sobre un pedestal hacia el centro de arriba, la profundidad de instalación aumentará aproximadamente en 4" (10.2 cm). Si se orienta la ventilación trasera escape de la secadora independiente o sobre un pedestal hacia la izquierda, la profundidad de instalación aumentará aproximadamente en 3.75" (9.5 cm). Si se orienta el escape de la secadora sobre un pedestal hacia abajo, la profundidad de instalación aumentará aproximadamente en 2.

25" (5.7 cm). 48.25" (122.5cm)* para destapar abra la puerta 30.

5" (77.5cm)* al frente de la puerta cerrada 27.0" (68.5cm) 71.5" (182cm) suministro eléctrico en la parte trasera de la unidad tubería de suministro de gas en la parte trasera de la unidad de gas altura de la línea central para ventilación trasera 37" (94cm) 39" (99cm) * Para obtener estas dimensiones mínimas de profundidad, la secadora debe ser ventilada derecho hacia atrás.

Si se usa un codo de 90° (hacia la derecha), se agregan aproximadamente 0.75" (2 cm) a la profundidad de instalación. Si se orienta el escape de la secadora instalada sobre la lavadora hacia arriba, la profundidad de instalación aumentará aproximadamente en 4" (10,2 cm). Si se orienta el escape de la secadora instalada sobre la lavadora hacia abajo, la profundidad de instalación aumentará aproximadamente en 2.25" (6.5 cm). Si se orienta el escape de la secadora instalada sobre la lavadora hacia la izquierda, la profundidad de instalación aumentará aproximadamente en 3.75" (9.5 cm). 31 INSTRUCCIONES DE INSTALACIÓN Instalación eléctrica Los siguientes son requisitos necesarios para la instalación eléctrica segura y correcta de su secadora.

El no seguir estas instrucciones puede producir una descarga eléctrica y/o incendio. ADVERTENCIA PELIGRO DE DESCARGA ELÉCTRICA · Debe instalarse, en el cable de alimentación, un dispositivo de liberación de tensión aprobado por U.L. Si no se coloca un dispositivo de liberación de tensión, el cable podría desenchufarse de la secadora y cortarse por cualquier movimiento, y provocar así una descarga eléctrica. · No utilice un receptáculo con cableado de aluminio para un enchufe y cable de alimentación con cables de cobre (o viceversa). La reacción química que tiene lugar entre el cobre y el aluminio puede causar cortocircuitos eléctricos. El receptáculo y el cableado correcto consiste en un cable de alimentación con alambres de cobre con un receptáculo de cables de cobre. ADVERTENCIA PELIGRO DE DESCARGA ELÉCTRICA · Este electrodoméstico DEBE estar debidamente conectado a tierra. Si la secadora no está conectada a tierra correctamente, se pueden producir descargas eléctricas. Siga las instrucciones de esta guía para ver cómo se realiza una correcta conexión a tierra.

· No utilice un cable de extensión con esta secadora. Algunos cables de extensión no están diseñados para soportar la cantidad de corriente eléctrica que utiliza esta secadora y pueden derretirse, lo que constituye un peligro de descarga eléctrica y/o incendio. Ubique la secadora en un lugar donde el cable de alimentación que compre esté al alcance del receptáculo, permitiendo que el cable quede holgado. Consulte los requisitos de preinstalación de esta guía para ver cuál es el cable de alimentación correcto que se debe comprar. NOTA Las secadoras que funcionan con 208 voltios de corriente eléctrica tendrán tiempos de secado más prolongados que las que funcionan con 240 voltios de corriente eléctrica.

Requisitos de conexión a tierra: secadora eléctrica (Estados Unidos) ADVERTENCIA PELIGRO DE DESCARGA ELÉCTRICA Una conexión incorrecta del conductor de conexión a tierra del equipo puede provocar un peligro de descarga eléctrica. Si no está seguro de haber realizado correctamente la conexión a tierra del artefacto, consulte a un electricista autorizado. Para una secadora conectada a tierra: 1 La secadora DEBE tener conexión a tierra. En el caso de que la secadora no funcione correctamente o se descomponga, la conexión a tierra reduce el riesgo de descarga eléctrica porque ofrece una trayectoria de menor resistencia para la corriente eléctrica. 2 Después de comprar e instalar un cable de alimentación trifilar o tetrafilar con un conductor de conexión a tierra, el enchufe DEBE estar conectado a un receptáculo adecuado con cable de cobre correctamente instalado y con conexión a tierra, de acuerdo con todos los códigos y las ordenanzas locales.

Ante cualquier duda, comuníquese con un electricista autorizado. 3 NO realice modificaciones al enchufe que se proporciona con este artefacto. Si no calza en el tomacorrientes, pídale a un electricista calificado que instale un tomacorrientes adecuado. Para una secadora conectada de forma permanente: 1 La secadora DEBE estar conectada a un sistema de cableado permanente de metal conectado a tierra, o bien se debe colocar un conductor de conexión a tierra con los conductores del circuito y debe estar conectado al terminal de conexión a tierra del equipo o al cable a tierra del artefacto. 32 INSTRUCCIONES DE INSTALACIÓN Requisitos de conexión a tierra: secadora eléctrica (Canadá) ADVERTENCIA PELIGRO DE DESCARGA ELÉCTRICA Una conexión incorrecta del conductor de conexión a tierra del equipo puede provocar un peligro de descarga eléctrica.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](http://yourpdfguides.com/dref/3671165)

[FRQE7000LW user guide](http://yourpdfguides.com/dref/3671165)

<http://yourpdfguides.com/dref/3671165>

Si no está seguro de haber realizado correctamente la conexión a tierra del artefacto, consulte a un electricista autorizado. Para una secadora conectada a tierra: 1 La secadora DEBE tener conexión a tierra. En el caso de que la secadora no funcione correctamente o se descomponga, la conexión a tierra reduce el riesgo de descarga eléctrica porque ofrece una trayectoria de menor resistencia para la corriente eléctrica. 2 Debido a que la secadora está equipada con un cable de alimentación eléctrica que cuenta con un conductor de conexión a tierra, el enchufe debe estar conectado a un tomacorriente correctamente instalado y con conexión a tierra, de acuerdo con todos los códigos y las ordenanzas locales. Ante cualquier duda, comuníquese con un electricista autorizado.

3 NO realice modificaciones al enchufe que se proporciona con este artefacto. Si no calza en el tomacorrientes, pídale a un electricista calificado que instale un tomacorrientes adecuado. Requisitos de conexión a tierra: secadora a gas (Estados Unidos y Canadá) 1 La secadora está equipada con un enchufe de tres patas (conexión a tierra) para evitar el peligro de electrocución y debe estar conectada directamente a un receptáculo de enchufe de tres patas que cuente con una conexión a tierra adecuada. 2 El enchufe debe estar conectado a un tomacorriente correctamente instalado y con conexión a tierra, de acuerdo con todos los códigos y las ordenanzas locales. Ante cualquier duda, comuníquese con un electricista autorizado. 3 NO realice modificaciones al enchufe que se proporciona con este artefacto. Si no calza en el tomacorrientes, pídale a un electricista calificado que instale un tomacorrientes adecuado. Tomacorriente Tomacorriente con puesta a tierra No corte, retire ni deshabilite la clavija de conexión a tierra bajo ninguna circunstancia. Cordón eléctrico de 3 clavijas con puesta a tierra 33 INSTRUCCIONES DE INSTALACIÓN Conexión de gas 1 Quite el tapón del tubo de gas en la parte trasera de la secadora. 3 Abra la válvula de cierre de la línea de suministro de gas para que el gas fluya a través de la tubería.

Espera unos minutos a que el gas fluya a través de la línea de suministro de gas. **IMPORTANTE NO conecte la secadora al servicio de gas LP sin convertir la válvula de gas. El kit de conversión a gas LP debe ser instalado por un técnico calificado.** 2 Conecte un tubo aprobado o uno semi-rígido de 1,27 cm (1/2 pulgada) de diámetro interior desde la línea de suministro de gas al tubo de 0,96 cm (3/8 pulgada) ubicado en la parte trasera de la secadora. Utilice un reductor de 1,27 cm a 0,96 cm (1/2 pulgada a 3/8 pulgada) para realizar la conexión.

Aplique un sellador para roscas que sea resistente a la acción corrosiva de los gases licuados en todas las conexiones de los tubos. **FLUJO DE GAS** Válvula Conector de cierre manual doble Conector doble la s eca do ra de sde el s u ni str od eg as Válvula de cierre: posición abierta 4 Utilice un manómetro para verificar que no haya fugas en el suministro de gas. Si no cuenta con un manómetro, pruebe todas las conexiones aplicando agua jabonosa en estas. Cerrado Tubo de admisión en la parte posterior de la secadora Todas las conexiones deben estar ajustadas con llave Conector Abierto Conector flexible **ADVERTENCIA PELIGRO DE EXPLOSIÓN NUNCA** compruebe si hay fugas de gas con una llama abierta. **IMPORTANTE** La línea de suministro de gas debe estar equipada con una válvula de cierre manual aprobada.

Esta válvula debe estar ubicada en la misma habitación que la secadora, en una ubicación que permita la facilidad de apertura y cierre. No bloquee el acceso a la válvula de cierre de gas. 34 INSTRUCCIONES DE INSTALACIÓN Conexión eléctrica (fuera de Canadá): trifilar Receptáculo trifilar (tipo NEMA 10-30R) 30 AMP NEMA 10-30 **ADVERTENCIA PELIGRO DE DESCARGA ELÉCTRICA** El no desconectar el suministro eléctrico antes de realizar cualquier reparación puede ocasionar lesiones personales o incluso la muerte. 1 Desconecte el suministro eléctrico del tomacorriente. 2 Extraiga el tornillo que sujeta la cubierta de acceso del bloque terminal que se encuentra en la esquina inferior de la parte trasera de la secadora. 3 Instale un dispositivo de liberación de tensión aprobado por U.L., de acuerdo con las instrucciones relativas al cable de alimentación/dispositivo de liberación de tensión del fabricante, en el orificio de entrada del cable de alimentación debajo del panel de acceso. En este momento, el dispositivo de liberación de tensión debe estar holgadamente en su lugar. 4 Pase un cable de alimentación aprobado por U.

L. **DESENCHUFADO**, de 30 amp. tipo NEMA 10-30, SRDT a través del dispositivo de liberación de tensión. 5 Conecte el conductor neutro (cable del centro) del cable de alimentación al terminal PLATEADO del centro del bloque terminal. Ajuste el tornillo con firmeza. 6 Conecte los dos conductores externos restantes del cable de alimentación a los terminales externos de color LATÓN del bloque terminal. Ajuste los dos tornillos con firmeza. Neutro (cable central) Tornillo de cubierto de acceso Tablero de terminales terminale Línea 2 (terminal de LATÓN) Neutro (terminal PLATEADA) Línea 1 (terminal de LATÓN) Conexión tierra interna (tornillo VERDE) Instale aquí un dispositivo de liberación de tensión aprobado por U.L. Ranura de recuperación de tornillos del terminal **NOTA** Si un tornillo del terminal se cae durante la instalación del cable, se puede recuperar en la ranura de recuperación de tornillos del terminal que se encuentra debajo del panel de acceso.

¡NO retire la conexión interna a tierra en los sistemas trifilares! Terminal neutro **ADVERTENCIA PELIGRO DE DESCARGA ELÉCTRICA** No forme un ángulo agudo con el cableado/conductor, ni los doble en el punto de conexión. 7 Siga las pautas del fabricante para sujetar firmemente el dispositivo de liberación de tensión y el cable de alimentación. 8 Vuelva a instalar la cubierta del bloque terminal. **IMPORTANTE** Para mover la secadora desde un sistema tetrafilar e instalarla en un sistema trifilar, mueva la conexión a tierra interna del terminal central nuevamente hacia el tornillo VERDE que se encuentra junto al bloque terminal. 35 INSTRUCCIONES DE INSTALACIÓN Conexión eléctrica (fuera de Canadá): tetrafilar Receptáculo tetrafilar (tipo NEMA 14-30R) **ADVERTENCIA PELIGRO DE DESCARGA ELÉCTRICA** El no desconectar el suministro eléctrico antes de realizar cualquier reparación puede ocasionar lesiones personales o incluso la muerte.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FRQE7000LW user guide](http://yourpdfguides.com/dref/3671165)
<http://yourpdfguides.com/dref/3671165>