



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for FUJITSU SIEMENS D1381. You'll find the answers to all your questions on the FUJITSU SIEMENS D1381 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual FUJITSU SIEMENS D1381
User guide FUJITSU SIEMENS D1381
Operating instructions FUJITSU SIEMENS D1381
Instructions for use FUJITSU SIEMENS D1381
Instruction manual FUJITSU SIEMENS D1381

COMPONENT



[You're reading an excerpt. Click here to read official FUJITSU SIEMENS D1381 user guide](http://yourpdfguides.com/dref/2234995)
<http://yourpdfguides.com/dref/2234995>

Manual abstract:

com COMPONENT Technisches Handbuch / Technical Manual Systembaugruppe / System board D1381 Are there ... any technical problems or other questions which you would like to be clarified? · · Please contact: your sales partner your sales outlet Further information can be found in the "Safety and Ergonomics" manual. The latest information on our products, tips, updates, etc., can be found on the internet under: <http://www.fujitsu-siemens.com>

Are there

· any technical problem or other question you need clarified? Please contact: · your sales partner · your sales outlet You will find further information in the manual "Safety and Ergonomics". The latest information on our products, tips, updates, etc., can be found on the Internet under: <http://www.fujitsu-siemens.com> Dieses Handbuch wurde auf Recycling-Papier gedruckt. This manual has been printed on recycled paper. Ce manuel est imprimé sur du papier recyclé. Este manual ha sido impreso sobre papel reciclado. Questo manuale è stato stampato su carta da riciclaggio. Denna handbok är tryckt på recyclingpapper.

Dit handboek werd op recycling-papier gedrukt. Herausgegeben von/Published by Fujitsu Siemens Computers GmbH Bestell-Nr./Order No.:

A26361-D1381-Z120-1-7419 Printed in the Federal Republic of Germany AG 0402 04/02 A26361-D1381-Z120-1-7419 German English Systembaugruppe D1381 System Board D1381 Technisches Handbuch Technical Manual Ausgabe April 2002 April 2002 edition Pentium and Celeron are registered trademarks of Intel Corporation, USA.

@@@All other trademarks referenced are trademarks or registered trademarks of their respective owners, whose protected rights are acknowledged. Copyright © Fujitsu Siemens Computers GmbH 2002 All rights, including rights of translation, reproduction by printing, copying or similar methods, in part or in whole, are reserved. Offenders will be liable for damages. @@Delivery subject to availability. Right of technical modification reserved. This manual was produced by cognitas. @@@@All other trademarks referenced are trademarks or registered trademarks of their respective owners, whose protected rights are acknowledged. All rights, including rights of translation, reproduction by printing, copying or similar methods, even of parts are reserved.

Offenders will be liable for damages. @@Delivery subject to availability.

Right of technical modification reserved. This manual was produced by cognitas. Gesellschaft für Technik-Dokumentation mbH www.cognitas.de Contents

Introduction.

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

1 Notational conventions

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

1 Important notes.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.4 Internal ports and connectors

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.5 Hard disk connection

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

....6 LAN connector.

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
.....
..6 Screen resolution...
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
..7 PCI bus interrupts
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
....7 Settings with switches and jumpers .
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
...8 Recovering System BIOS - switch 2

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....
.....
.....
..8 Add-on modules

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.9 Installing and removing processors.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.10 Upgrading main memory.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

..11 Replacing the lithium battery..

.....
.....
.....
.....
.....
.....



[SIEMENS D1381 user guide](http://yourpdfguides.com/dref/2234995)
<http://yourpdfguides.com/dref/2234995>

Remove the old processor from the socket (3). Insert the new processor in the socket so that the angled corner of the processor matches the coding on the socket (A) with regard to the position (4). ! Ê The angled corner of the processor may be covered by the heat sink. In this case let yourself be guided by the marking in the rows of pins on the underside of the processor. Push the lever back down until it clicks into place (5). 10 - English
A26361-D1381-Z120-1-7419 Add-on modules Upgrading main memory These slots are suitable for 128, 256, 512 and 1024 Mbyte DDR memory modules of the DIMM format. Memory modules with different memory capacities can be combined. ! You may only use unbuffered 2,5 V memory modules. Buffered memory modules are not supported.

@@Insert the memory module into the location (1). @@Carefully remove the memory module from the compartment (2). A26361-D1381-Z120-1-7419 English - 11 Add-on modules Replacing the lithium battery ! @@@@Do not throw lithium batteries into the household waste. They must be disposed of in accordance with local regulations concerning special waste. Ensure that you insert the battery the right way round. The plus pole must be on the top! The following graphic representation is also valid if the lithium battery is built-in vertically. + + 1 2 + + 3 Ê Ê Lift the contact (1) a few millimetres and remove the battery from its socket (2). Insert a new lithium battery of the same type into the socket (3). 12 - English A26361-D1381-Z120-1-7419 Glossary Glossary The technical terms and abbreviations given below represent only a selection of the full list of common technical terms and abbreviations. Not all technical terms and abbreviations listed here are valid for the described system board.

ACPI AC'97 AGP AMR AOL APM ATA BIOS CAN CPU CNR C-RIMM DIMM ECC EEPROM Advanced Configuration and Power Management Interface Audio Codec '97 Accelerated Graphics Port Audio Modem Riser Alert On LAN Advanced Power Management Advanced Technology Attachment Basic Input Output System Controller Area Network Central Processing Unit Communication Network Riser Continuity Rambus Inline Memory Module Dual Inline Memory Module Error Correcting Code Electrical Erasable Programmable Read Only Memory Floppy Disk Controller First-In First-Out Front Side Bus Firmware Hub Graphics and Memory Controller Hub Graphics Performance Accelerator Inter Integrated Circuit Instantly Available Power Managed Desktop PC Design I/O Controller Hub Intelligent Drive Electronics Internet Protocol Security ISA LAN LSA MCH MMX P64H PCI PXE RAM RAMDAC RDRAM RIMM RTC SB SDRAM Industrial Standard Architecture Local Area Network LAN Desk Service Agent Memory Controller Hub MultiMedia eXtension PCI64 Hub Peripheral Component Interconnect Preboot eXecution Environment Random Access Memory Random Access Memory Digital Analogue Converter Rambus Dynamic Random Access Memory Rambus Inline Memory Module Real Time Clock Soundblaster Synchronous Dynamic Random Access Memory Synchronous Graphic Random Access Memory Streaming Mode Instruction (Single Instruction Multiple Data) System Management Bus Super Video Graphic Adapter Universal Serial Bus Video Graphic Adapter FDC FIFO FSB FWH GMCH GPA I2C IAPC ICH IDE IPSEC SGRAM SIMD SMBus SVGA USB VGA A26361-D1381-Z120-1-7419 English - 13 .



[You're reading an excerpt. Click here to read official FUJITSU SIEMENS D1381 user guide](http://yourpdfguides.com/dref/2234995)
<http://yourpdfguides.com/dref/2234995>