



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for GARMIN APPROACH G6. You'll find the answers to all your questions on the GARMIN APPROACH G6 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual GARMIN APPROACH G6**  
**User guide GARMIN APPROACH G6**  
**Operating instructions GARMIN APPROACH G6**  
**Instructions for use GARMIN APPROACH G6**  
**Instruction manual GARMIN APPROACH G6**

**GARMIN.**

Approach® G6  
Owner's Manual



January 2012

190-01430-00\_0C

Printed in Taiwan



[You're reading an excerpt. Click here to read official GARMIN APPROACH G6 user guide](http://yourpdfguides.com/dref/5573870)  
<http://yourpdfguides.com/dref/5573870>

**Manual abstract:**

Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to [www.garmin.com](http://www.garmin.com) for current updates and supplemental information concerning the use of this product. Garmin, the Garmin logo, and Approach are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. These trademarks may not be used without the express permission of Garmin. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. Mac is a registered trademark of Apple Computer, Inc.

Other trademarks and trade names are those of their respective owners. Table of Contents Turning On the Approach....

.....  
.....

.....  
.....  
.....

..... 1 Charging the Battery ....

.....  
.....  
.....  
.....  
.....  
.....  
.....

.. 1 Registering Your Device .....

.....  
.....  
.....  
.....  
.....  
.....

.. 1 Finding Courses.....

.....  
.....  
.....  
.....  
.....  
.....

... @@@@1 Playing Golf with the Approach.....

.....  
.....  
.....

..... 2 Map Features .

.....  
.....  
.....  
.....  
.....  
.....

..... 2 Keeping Score ....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
*. 2 Handicap Scoring ....*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.. 3 Saving a Location .....*

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

*.. 3 Measuring a Shot .....*

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
*... 3 Appendix ..*

.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

*.....4 Device Care ....*

.....  
.....  
.....  
.....

.....  
.....

.....  
.....

*4 Calibrating the Touchscreen .....*

.....  
.....  
.....  
.....  
.....

*..... 4 Clearing User Data .*

.....  
.....  
.....  
.....  
.....

*.. 4 Settings ...*

.....  
.....  
.....  
.....  
.....  
.....

*... 4 Using the Clip ..*

.....  
.....  
.....  
.....  
.....  
.....  
.....

*4 Specifications .....*

.....  
.....  
.....  
.....  
.....

*.. 4 Index ...*

.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.....6 Table of Contents i Turning On the Approach The first time you use the device, you are prompted to choose your language. NOTE: The time of day and date are set automatically. 1 Hold to turn on your Approach.

2 Select your language. 3 Go play a round of golf (page2). 2 Select a course to preview. You can preview all holes on the selected course (page1). Finding a Course by City 1 2 3 4 Select Preview > Spell City.

Enter the name of the city, and select . Select a city. Select a course to preview. You can preview all holes on the selected course (page1). Charging the Battery WARNING This device contains a lithium-polymer battery.

See the Important Safety and Product Information guide in the product box for product warnings and other important information. NOTICE To prevent corrosion, thoroughly dry the mini-USB port, the weather cap, and the surrounding area before charging or connecting to a computer. The device is powered by a built-in lithium-polymer battery that you can charge using a standard wall outlet or a USB port on your computer. @@@@1 Begin playing a game (page2) or previewing a course (page1). @@Plug the large end of the USB cable into the AC charger. Plug the AC charger into a standard wall outlet. Charge the device completely. @@? Go to <http://my.garmin.com> .

? @1 Select Preview. 2 Select an option: ? @@? Select Spell City to find courses in a specific city (page1). ? Select Spell Course to find a course by name (page1). ? is the distance to the middle of the green from the target circle. ? is the distance from your current position to the target circle. @@? is the total of the two distances. 3 If necessary, select to zoom in on the target circle. @1 Begin playing a game (page2) or previewing a course (page1).

@@@@@2 Select an option: Displays the hole number. The number of dots indicates par.

Displays the distance to the middle of the green. @@@@Select Stroke Play for four-person regulation scoring. ? Select Stableford (page2). ? Select Match Play (page2). ? Select Skins Game (page2).

@@@On all other holes, select to view the previous hole. Hold or to select a specific hole. About Match Scoring When you select the Match scoring method (page2), one point is awarded at each hole to the player who has the fewest strokes. At the end of a round, the player who won the most holes wins. NOTE: Match scoring is available only for two players.

When you set the Approach to count strokes, the device determines the winner of each round. Otherwise, at the end of each hole, select the player who had the fewest strokes, or if the number of strokes was equal, select Halved. Moves you to the next hole. Displays layup arcs that indicate distance to pin. Four arcs display for par 5 or higher, three arcs display for par 4, and no arcs display for par 3. Keeping Score Before you begin keeping score, you must select the scoring method (page2). You can keep score for up to four players. 1 Begin playing a game (page2). 2 Select SCORE. 3 Select an option: ? Select a player's name to edit it.

? Select to enter the number of strokes for the selected hole. ? Select > Set Up Players to edit player handicaps. This selection is only displayed if you have enabled handicap scoring (page3). About Skins Scoring When you select the skins scoring method (page2), players compete for a prize on each hole. When you set the Approach to count strokes, the device determines the winner of each hole. Otherwise, at the end of each hole, select the player who had the fewest strokes. You can select multiple players if there is a tie for the win. About Stableford Scoring When you select the Stableford scoring method (page2), points are awarded based on the number of strokes taken relative to par. At the end of a round, the highest score wins. The Approach awards points as specified by the United States Golf Association.

Playing Golf with the Approach 2 NOTE: The scorecard for a Stableford scored game shows points instead of strokes. Points 0 1 2 3 4 5 Strokes Taken Relative to Par 2 or more over 1 over Par 1 under 2 under 3 under The device appears as a removable drive in My Computer in Windows computers, and as a mounted volume on Mac computers. 2 Open the Garmin Approach drive. 3 Select an option: ? Open Scorecard > ScorecardViewer.html to view scorecards.

? Open Club Averages > ClubAverageViewer.html to view club statistics. Viewing Round Statistics You can view statistics for the round you are currently playing. . 1 While playing a game, select SCORE > 2 Select an option: ? To view information for all players, select Round Details.

? To view more details about an individual player, select Round Details > > Player Details, select a player name, and select a statistic to view. Handicap Scoring You can set a handicap for the hole (page3) and for each player (page3). Enabling Handicap Scoring 1 Select Setup > Scoring > Scoring Handicap 2 Select On. Setting a Player Handicap Before you can score using handicaps, you must enable handicap scoring (page3). > Set Up 1 While playing a game, select SCORE > Players. 2 Select for the player whose handicap you want to enter or change. 3 Select an option: ? Select Local Handicap to enter the number of strokes that will be subtracted from the player's total score. ? Select Index\Slope Method to enter the player's handicap index and the course slope rating to calculate a course handicap for the player. About Individual Scorecards The individual scorecard features a hole-by-hole overview of a player's round. Four different symbols represent the number of strokes relative to par.

@@@@@> Change 1 While playing a game, select SCORE > Handicap. @@NOTE: You can clear all saved locations from a hole by selecting > > Clear Locations. 1 While playing a game, select > Save Location.



[You're reading an excerpt. Click here to read official GARMIN APPROACH G6 user guide](http://yourpdfguides.com/dref/5573870)  
<http://yourpdfguides.com/dref/5573870>

2 Select an option: ? Select Use Current Location to place a marker at your current location on the hole. ? Select Use Touch Targeting to select a location on the map. Viewing History You can veianing the Screen Before you can clean the screen, you should have a soft, clean, lint-free cloth and water, isopropyl alcohol, or eyeglass lens cleaner. Apply the liquid to the cloth, and gently wipe the screen with the cloth. Cleaning the Device 1 Wipe the device with a cloth dampened with a mild detergent solution. 2 Wipe it dry. Using the Backlight ? At any time, tap the touchscreen to turn on the backlight.

NOTE: Alerts and messages also activate the backlight. ? Press to turn on the backlight and adjust the brightness. ? Change the backlight timeout (page4). 3 To remove, pull up on the upper clip while pressing on the back of the device to release the top, and slide it out of the lower clips. Specifications Battery Type Battery Life Operating Temperature Range Lithium-polymer Up to 15 hours From -4F to 140F (from -20C to 60C) 4 Appendix Charging Temperature Range From 32F to 113F (from 0C to 45C) Water Resistance IPX7 Appendix 5 Index B battery, charging?1 belt clip?4 brightness?4 settings?4 display settings?4 distance, measuring?1 resetting the device?4 S saving locations?3 scorecards about individual?3 all players?2 viewing?3 scoring handicap?3 match?2 settings?2 skins?2 Stableford?2 screen brightness?4 calibration?4 cleaning?4 settings?4 shot measuring distance?3 recording distance?3 saving distance?3 simulation, hole?2 statistics current round?3 viewing on computer?3 E editing player names?2 C calibrating the screen?4 cleaning the device?4 clear, history?3 clip?4 clubs adding?4 deleting?4 editing?4 shot distance?3 viewing averages?4 viewing statistics?3 courses finding by city?1 finding by name?1 previewing?1 saving locations?3 searching near?1 G green, viewing?1 H handicap scoring enabling?3 hole?3 player?3 scorecard?2 history?3 M map symbols?2 updates?2 measurements settings?4 shot distance?3 P pin location setting?1 viewing?1 D device care?4 registration?1 U updates, course maps?2 user data, deleting?4 R registering the device?1 6 Index www.

garmin.com/support 913-397-8200 1-800-800-1020 00 32 2 672 52 54 0180 5 / 42 76 46 - 880 00800 4412 454 +44 2380 662 915 0808 2380000 +44 870 850 1242 00 45 4810 5050 00 39 02 3669 9699 00 35 1214 447 460 1-866-429-9296 00 358 9 6937 9758 0800-0233937 00 34 902 007 097 43 (0) 3133 3181 0 00 331 55 69 33 99 815 69 555 00 46 7744 52020 Garmin International, Inc. 1200 East 151st Street Olathe, Kansas 66062, USA Garmin (Europe) Ltd. Liberty House, Hounsdown Business Park Southampton, Hampshire, SO40 9LR UK Garmin Corporation No. 68, Zangshu 2nd Road, Xizhi Dist. New Taipei City, 221, Taiwan (R.O.C.) 2011?2012 Garmin Ltd. or its subsidiaries .



[You're reading an excerpt. Click here to read official GARMIN](#)

[APPROACH G6 user guide](#)

<http://yourpdfguides.com/dref/5573870>