



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for GARMIN NUVI 1450. You'll find the answers to all your questions on the GARMIN NUVI 1450 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual GARMIN NUVI 1450**  
**User guide GARMIN NUVI 1450**  
**Operating instructions GARMIN NUVI 1450**  
**Instructions for use GARMIN NUVI 1450**  
**Instruction manual GARMIN NUVI 1450**

**GARMIN.**

nüvi® 1100/1200/1300/1400 series  
owner's manual



for use with these nüvi models:

1100, 1200, 1210, 1240, 1250, 1245, 1255,  
1260, 1300, 1310, 1340, 1350, 1370, 1390,  
1410, 1440, 1450, 1490



[You're reading an excerpt. Click here to read official GARMIN NUVI 1450 user guide](#)

<http://yourpdfguides.com/dref/3659722>

**Manual abstract:**

1200 East 151st Street, Olathe, Kansas 66062, USA Tel. @@@@68 Jangshu 2nd Road, Sijih, Taipei County, Taiwan Tel. 886/2.2642.9199 Fax 886/2.2642.9099 All rights reserved. Except as expressly provided herein, no part of this manual may be reproduced, copied, transmitted, disseminated, downloaded or stored in any storage medium, for any purpose without the express prior written consent of Garmin. Garmin hereby grants permission to download a single copy of this manual onto a hard drive or other electronic storage medium to be viewed and to print one copy of this manual or of any revision hereto, provided that such electronic or printed copy of this manual must contain the complete text of this copyright notice and provided further that any unauthorized commercial distribution of this manual or any revision hereto is strictly prohibited. Information in this document is subject to change without notice.

Garmin reserves the right to change or improve its products and to make changes in the content without obligation to notify any person or organization of such changes or improvements. Go to the Garmin Web site ([www.garmin.com](http://www.garmin.com)) for current updates and supplemental information concerning the use and operation of this and other Garmin products. Garmin®, the Garmin logo, nüvi®, and MapSource® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Garmin Lock™, myGarmin™, myGarmin Agent™, ecoRoute™, cityXplorer™, and nüMaps Guarantee™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc.

, and any use of such name by Garmin is under license. Windows® is a registered trademark of Microsoft Corporation in the United States and/or other countries. Mac® is a registered trademark of Apple Computer, Inc. microSD™ is a trademark of SanDisk or its subsidiaries. January 2011 Part Number 190-01041-00 Rev. F Printed in Taiwan Table of Contents Table of Contents nüvi 1100/1200/1300/1400 Series Models .....

.....  
.....  
iv Getting Started.....

..... 1 Looking at Your nüvi .....

... 1 Using the Main Menu.....

.....  
1 Setting Up Your nüvi .....

..... 2 Using the Power Button ..

.....  
. 4 Adjusting the Volume ....

.....  
..... 4 Navigating the Screens ..

.....  
. 4 Finding Your Destination....

.....  
... 4 Navigating in Pedestrian Usage Mode .....

.....  
.....  
.....  
.....  
.. 6 Adding a Stop .....

.....  
7 Changing Destinations .....

..... 7 Taking a Detour .

.....  
.....  
.....  
..... 7 Stopping the Route .

.....  
.....  
.....  
..... 7 Finding an Address .

.....  
.....  
.....  
..... 8 Setting a Home Location .

	.....
	8 Using the Go! Page .....
	....
....	9 Providing Feedback on Points of Interest .
	.....
	.....
	....
....	10 Finding a Place by Spelling the Name .
	.....
	.....
	....
....	10 Searching Near Another Location .....
	.....
	....
.....	11 Finding Recently Found Places ...
	.....
	....
	.....
...11	Finding a Place Using the Map .....
	....
	....
	.....
	.....
..	13 Entering Coordinates ...
	....
.....	14 Using Photo Navigation ...
.....	14 Viewing the Trip Computer ..
... 16	Viewing the Turn List ..
	....
.....	16 Viewing the Next Turn Page ...
. 17	Viewing the Junction View Page.....
	....
	....
	.....
.....	17 Using the Pedestrian Map Page.
	....
	....
	.....
	.....
..	18 Using the Map Pages ...
.... 15	Where To? .....
	.....
	....
	....
. 8	nüvi 1100/1200/1300/1400 Series Owner's Manual i Table of Contents Pairing Your Phone .....
.....	19 Receiving a Call .
	....
	....
	.....



.. 26 Using the Picture Viewer ...	..... 27 Accessing My Data ....
.....	.....
.... 28 Using the World Clock .	.....
..... 28 Using the Calculator ....	.....
.....	.....
.. 28 Using the Unit Converter ...	.....
.....	28 Using ecoRoute™ .....
.....	.....
. 29 ii Using the Tools ....	.....
..... 26 Customizing the nüvi ..	.....
..... 38 Changing the System Settings .....	.....
.....	.....
.....	.....
..... 38 Changing the Navigation Settings ..	.....
.....	.....
.....	.....
. 39 Adjusting the Display Settings ....	.....
.....	.....
.....	.....
.... 39 Updating the Time Settings .	.... 40 Setting the Languages.
.....	.....
.. 40 nüvi 1100/1200/1300/1400 Series Owner's Manual Table of Contents Changing the Map Settings .....	41 Changing Security Settings ...
.. 41 Setting the Bluetooth Technology Options ...	.....
..... 42 Changing the Proximity Points Settings ....	.....
.....	.....
.....	.....
..... 43 Viewing Traffic Subscription Information .	.....
.....	.....
.....	.....
..... 43 Restoring All Settings ...	.....
.....	.....
. 44 Caring for Your nüvi ....	.....
.....	..... 45 Locking Your nüvi ...
.....	.....
.....	.....
.. 46 Calibrating the Screen ...	.....
.....	.....
47 Updating the Software .....	... 47 Clearing User Data ..
.....	.....
.....	.....

. 47 Battery Information .....	.....
... 48 Charging Your nüvi ..	.....
..... 48 Changing the Fuse ....	.....
.... 48 Removing the nüvi and Mount .....	.....
.....	.....
.....	.....
.....	.....
.....	.....
49 Mounting on Your Dashboard .....	.....
.....	.....
..... 49 Appendix ..	.....
.....	.....
.....	.....
..... 45 nüMaps Guarantee™.....	.....
.....	.....
. 49 Additional Maps ....	.....
.....	.....
.....	.....
.... 50 About GPS Satellite Signals .... 50 Extras and Optional Accessories..	.....
.....	.....
.....	.....
.....	.....
..... 50 Garmin Travel Guide .....	.....
.....	.....
.....	.....
52 Contact Garmin .....	.....
.....	.....
... 52 Registering Your nüvi..	.....
.....	.....
..... 52 Specifications ..	.....
.....	.....
.....	.....
.....	.....
.... 53 Declaration of Conformity .....	.....
.. 56 Software License Agreement... 56 Troubleshooting .....	.....
.....	.....
.....	.....
..... 57 Index ...	.....
.....	.....
.....	.....
.....	.....

. 60 nüvi 1100/1200/1300/1400 Series Owner's Manual iii nüvi 1200/1300/1400 Series Models nüvi 1100/1200/1300/1400 Series Models Model 1100 1200 1210/1260 1240/1250 1245/1255/ 1350 1300 1310 1340 1370 1410 1440/1450 1390/1490 Bluetooth® Lane Junction Speaks Speed Limits Technology Assist View Street Names on Map Europe only Europe only Europe only Europe only Note: Go to [www.garmin.com](http://www.garmin.com) or see the packaging contents on your product box for more information. iv nüvi 1100/1200/1300/1400 Series Owner's Manual Getting Started Looking at Your nüvi Getting Started Power button: Press to turn the nüvi on and off. Using the Main Menu GPS satellite strength. Bluetooth technology status. Touch to select a usage mode. Current time. Touch to change time settings.

*Battery status. Touch to find a destination. Touch to view the map. Touch to make a call when connected to a compatible mobile phone on some models. Touch to adjust the volume.*

*Touch to use the tools such as settings and Help. 1 Speaker Mini-USB connector microSDTM card slot Microphone Note: Depending on your nüvi model, some images and screen shots could look different. nüvi 1100/1200/1300/1400 Series Owner's Manual Getting Started Setting Up Your nüvi Before mounting the nüvi, see the Important Safety and Product Information guide for information about laws pertaining to windshield mounting. Mounting Your nüvi 1.*

*Remove the clear plastic from the suction cup.*

*Place the suction cup on the windshield. Suction cup mount 2. Flip the lever back toward the windshield. 3. Snap the cradle onto the suction cup arm. 4. Plug the vehicle power cable into the back of your nüvi. 5. Plug the other end of the vehicle power Cradle cable into a power outlet in your vehicle. Your unit should turn on automatically if it is plugged in and the vehicle is running.*

*Follow the on-screen instructions.*



[You're reading an excerpt. Click here to read official GARMIN NUVI 1450 user guide](http://yourpdfguides.com/dref/3659722)

<http://yourpdfguides.com/dref/3659722>

6. Fit the bottom of your nüvi into the cradle. 7. Tilt your nüvi back until it snaps into place. 8. If you are using a traffic receiver in Europe, connect the external antenna to the traffic receiver and secure it to the windshield using Vehicle power the suction cups. (Traffic receivers are included cable in some nüvi packages. See page iv.) WarNiNg: This product contains a lithium-ion battery.

To prevent damage, remove the unit from the vehicle when exiting or store it out of direct sunlight. 2 nüvi 1100/1200/1300/1400 Series Owner's Manual Getting Started Acquiring Satellites 1. Go outdoors to an open area, away from tall buildings and trees. 2. Turn on your nüvi. Acquiring satellite signals can take a few minutes. The bars indicate satellite strength. When at least one of the bars is green, your nüvi has acquired satellite signals. Selecting a Usage Mode Pedestrian Bicycle Automobile combination of public transit options, such as riding a bus or subway, and walking. cityXplorer maps are not included with your nüvi.

See [www.garmin.com](http://www.garmin.com) to purchase cityXplorer maps. To change your usage mode: 1. From the Main menu, touch the usage mode icon on the upperleft corner.

2. Select a mode, and touch OK. 3. Touch Yes, and follow the on-screen instructions to configure your settings. Your nüvi offers several usage modes for navigation methods.

Routing is calculated differently based on your usage mode. For example, in Pedestrian usage mode with cityXplorer™ maps loaded, your nüvi calculates a route that uses a Navigating Off Road If you are not following roadways as you navigate, use Off Road mode. Touch tools > Settings > Navigation > route Preference > off road > oK. nüvi 1100/1200/1300/1400 Series Owner's Manual 3 Getting Started Using the Power Button Press and quickly release the Power button to view additional options: · Touch and to adjust the screen brightness. · Touch Lock Screen to prevent accidental screen touches. · Touch Power off to turn off your nüvi. You can also turn off the nüvi by holding the power button for approximately three seconds. Resetting Your nüvi If your nüvi stops functioning, reset your nüvi by pressing and holding the Power button. From the Main menu, touch Volume. Touch and to adjust the volume. Touch the box next to Mute to mute all audio. 4 Navigating the Screens · To quickly return to the Main menu, touch and hold . · Touch and to see more choices. Touch and hold to scroll faster. Finding Your Destination The Where To? menu provides several different categories for you to use when searching for addresses, cities, and other locations.

The detailed maps loaded in your nüvi contain millions of points of interest, such as restaurants, hotels, and auto services. Adjusting the Volume nüvi 1100/1200/1300/1400 Series Owner's Manual Getting Started 1. Touch Where To?. 4. Select a destination. 2. Select a category. 5. Touch Go!. 3. Select a subcategory. nüvi 1100/1200/1300/1400 Series Owner's Manual 5 Getting Started Navigating in Pedestrian Usage Mode Using the Itinerary Page In Pedestrian usage mode, the Itinerary page appears after you touch go!. Select a leg of the route to view more detailed instructions, or touch Start to create a route. 1. Select a route from · Edit Rating--touch a circle to give the point of interest (POI) a rating from 1 to 5 stars.

· Report Error--the item will be removed from future searches. Reports will be sent to Garmin when your nüvi is connected to a computer. See page 24. · Edit Phone Number--use the keyboard to change the phone number. 10 Using the On-Screen Keyboard When an on-screen keyboard appears, touch a letter or number to enter it. nüvi 1100/1200/1300/1400 Series Owner's Manual Where To? · · Touch to add a space. Touch and to move the cursor (available on some nüvi models). Touch to delete a character. Touch and hold to erase the entire entry. Touch Mode to select the keyboard language mode.

Touch to enter special characters, such as punctuation marks. To change the keyboard layout, see page 38. · · A Different City--search near the city you enter. A Recent Destination-- search near recent destination A Favorite Destination-- select a destination from Favorites. My Current Route--search along your active route.

My Destination--search near your current destination. Finding Recently Found Places Searching Near Another Location 1. Touch Where To? > Near. 2. Select an option: · Where I Am Now--search near your current location.

Your nüvi stores the last 50 of your recent finds in the Recently Found list. The most-recently viewed places appear at the top of the list. Touch Where to? > recently Found to view your recently found items. nüvi 1100/1200/1300/1400 Series Owner's Manual 11 Where To? Deleting Recently Found Places To remove all places from the Recently Found list, touch Clear > Yes. All items from the list are removed, but this does not delete the actual place from your nüvi. Using Favorites You can save places in your Favorites so you can quickly find them and create routes to them. Your home location is also stored in Favorites. Saving Your Current Location From the Map page, touch . Touch Save Location to save your current location. Saving Places You Find 1.

From the Go! page, touch Save. 2. Touch OK. The place is saved in Favorites. 12 Finding Saved Places 1. Touch Where To?. 2. Touch Favorites. 3. Select a category.

Your saved locations are listed. Editing Saved Places 1. Touch Where To? > Favorites. 2. Select the category and the location you want to edit. 3. Touch Edit. 4. Touch an item to edit: · Change Name--enter a new name, and touch Done. · Attach Photo--select a picture that you have loaded on your nüvi or on a memory card to assign to the location.

· Change Map Symbol--touch a new symbol used to mark this location on the map. · Change Phone Number-- enter a phone number, and touch Done. nüvi 1100/1200/1300/1400 Series Owner's Manual Where To? · · Change Categories--select another category for the location. Delete--touch Yes to remove this item from the Favorites list. Creating and Taking Routes Touch Where to? > routes. Select the route you want to take and touch Go!. 5. Find a location as your ending point, and touch Select. 6. Touch to add another location to your route.

Touch to remove a location. 7. Touch Next to calculate your route and view it on the map. 8. Touch Save to save the route and exit. Creating a Saved Route On some models, you can use your nüvi to create and save routes before your next trip. You can save up to 10 routes. 1. With a route active, touch Where to? (or Tools) > Routes > New.



[You're reading an excerpt. Click here to read official GARMIN NÜVI 1450 user guide](http://yourpdfguides.com/dref/3659722)  
<http://yourpdfguides.com/dref/3659722>



*Touch Add New Start Point. 3. Find a location as your starting point, and touch Select. 4. Touch Add New End Point.*

*Finding a Place Using the Map Use the Browse Map page to view different parts of the map. Touch Where to? > Browse Map. Tips for Browsing the Map ·*

*Touch the map, and drag to view different parts of the map. · Touch and to zoom in and out. · Touch any object on the map.*

*An arrow appears, pointing at the object, and a box displays 13 nüvi 1100/1200/1300/1400 Series Owner's Manual Where To? information on the location.*

*When the box displays Press for more, several POIs exist at that location. Press to see the list of POIs. · Touch Save to save this location. · Touch go! to navigate to the location. · If the GPS simulator is on, touch Set Location to set your location to the selected location. See page 38. 2. Touch the coordinate you want to adjust. 3.*

*Touch Format to select the correct coordinate format for the type of map you are using. 4. Enter the coordinates, and touch Next. Using Photo Navigation You can load pictures with location information onto your nüvi and then create routes to them. 1. Go to <http://connect.garmin.com/photos> (not available in all areas) to download pictures with location information. 2. Follow instructions on the Web site to select and load pictures.*

*3. Touch Where To? > Favorites > Photos. Pictures with location information are listed. 4. Touch a picture.*

*Entering Coordinates If you know the geographic coordinates of your destination, you can use your nüvi to navigate to your destination using the latitude and longitude coordinates. This can be especially helpful when geocaching. 1. Touch Where To? > Coordinates. 14 nüvi 1100/1200/1300/1400 Series Owner's*

*Manual Using the Map Pages Using the Map Pages Your route is marked with a magenta line.*

*As you travel, your nüvi guides you to your destination with voice prompts, arrows on the map, and directions at the top of the map. A checkered flag marks your destination. If you depart from the original route, your nüvi recalculates the route and provides new directions. A speed limit icon may appear as you travel on major roadways. This icon displays the current speed limit of the roadway. On some models, the turn indicator also includes Lane Assist, which tells you which lane you should be in to prepare for your next maneuver. See page iv to view a list of models that include Lane Assist. Touch to view the next turn.*

*Touch to view the turn list. Touch to zoom in and zoom out.*

*Touch to return to the Main menu. Touch to display a different data field. Touch to view the Where Am I? page. Touch to view the trip computer. nüvi 1100/1200/1300/1400 Series Owner's Manual 15 Using the Map Pages Viewing the Trip Computer Touch reset > reset Max to reset the maximum speed. Touch reset > reset Fuel Price to reset the fuel price. Viewing the Turn List The trip computer displays your current speed and provides statistics about your trip. To view the trip computer, touch the Speed field on the map. Note: If you make frequent stops, leave the nüvi turned on so it can accurately measure elapsed time during the trip. When you are navigating a route, the turn list displays turn-by-turn instructions for your entire route and the distance between turns.*

*Touch the text bar on the top of the map to open the turn list. Touch a turn on the list to view the next turn for that route. Touch Show Map to view the entire route on the Browse Map page. Resetting Trip Computer Information From the map, touch the Speed field. Touch reset > reset trip Data to reset the information on the trip computer.*

*16 nüvi 1100/1200/1300/1400 Series Owner's Manual Using the Map Pages Viewing the Next Turn Page Viewing the Junction View Page When you are navigating a route, the next turn shows the turn on the map and the distance and time left before you reach the turn. To view an upcoming turn on the map, touch the turn indicator in the top left corner of the map, or touch any turn from the turn list. On some nüvi models, the Junction View page displays a view of some upcoming junctions and in which lane you should be driving. To view the Junction View page, touch the upper-left corner of the Map page. To access the Junction View page from the Next Turn page, touch Junction View.*

*See page iv to view which nüvi models include Junction View. nüvi 1100/1200/1300/1400 Series Owner's Manual 17 Using the Map Pages Using the Pedestrian Map Page In Pedestrian usage mode, your route is displayed on a two-dimensional map. The , , , , , and icons indicate the navigation method for that section of the route. For example, when you see , board a bus at that point in the route. Touch to toggle between legs of the route. The nüvi zooms in and out on each leg of your route, but it does not automatically move to the next leg. Touch to view the route itinerary. Touch to zoom in and zoom out. Touch to recenter the map on your current location. 18 nüvi 1100/1200/1300/1400 Series Owner's Manual Making Hands-Free Phone Calls Making Hands-Free Phone Calls Bluetooth wireless technology is available on some nüvi models.*

*See page iv. Bluetooth wireless technology establishes a wireless link between two devices, such as a mobile phone and your nüvi. To determine whether your mobile phone with Bluetooth technology is compatible with the nüvi, go to [www.garmin.com/bluetooth](http://www.garmin.com/bluetooth). The first time you use two devices together you must "pair" them by establishing a relationship using a PIN or passkey. After the initial pairing, the two devices can connect automatically each time you turn them on. Note: You might have to set your mobile phone to connect to the nüvi automatically when it is turned on. Pairing Your Phone To pair and connect, your phone and the nüvi must be turned on and be within 33 ft. (10 m) of each other.*

*Initiate pairing from your nüvi or from your phone. Refer to your phone instructions. Pairing Using Your Phone Settings 1. Touch Tools > Settings > Bluetooth. 2.*

*Select Enabled. nüvi 1100/1200/1300/1400 Series Owner's Manual 19 Making Hands-Free Phone Calls 3. Enable the Bluetooth component on your phone.*

*This might be in a menu called Settings, Bluetooth, Connections, or Hands-free. 4.*

*Initiate a search for Bluetooth devices. 5. Select the nüvi from the list of devices. 6. Enter the nüvi Bluetooth PIN (1234) into your phone. When your phone is connected to your nüvi, you are ready to make phone calls. Touch Phone on the Main menu to access the Phone menu. When you turn on the nüvi, it tries to connect to the last phone to which it was connected. Pairing Using the nüvi Settings Receiving a Call 1. From the Main menu, touch Tools > Settings >*

*Bluetooth > Add.*



[You're reading an excerpt. Click here to read official GARMIN NÜVI](http://yourpdfguides.com/dref/3659722)

[1450 user guide](http://yourpdfguides.com/dref/3659722)

<http://yourpdfguides.com/dref/3659722>

2. Enable the Bluetooth component on your phone, and enable Find Me/Discoverable/Visible mode. These settings might be in a Bluetooth, a Connections, or a Hands-free menu. 3. Touch OK on the nüvi. 4. Select your phone, and touch OK. 5. Enter the nüvi Bluetooth PIN (1234) in your phone. 20 When you get a call, the Incoming Call window opens.

Touch answer to answer the call. Touch ignore to ignore the call and stop your phone from ringing. The internal microphone is in the front of the nüvi; speak normally. nüvi 1100/1200/1300/1400 Series Owner's Manual Making Hands-Free Phone Calls During a call, the In Call icon appears. Touch > end Call to hang up.

Touch > Call options for the following options: · touch tones--displays a keypad page so that you can use automated systems, such as voice mail. · transfer audio to Phone--this is helpful if you want to turn off the nüvi but remain on the call, or if you need privacy. To switch back, touch transfer audio to Device. · Mute Microphone. Note: Depending on the screen that appears on your nüvi, the In Call icon could look different.

In a Call Using Call Waiting When you are on a call and you receive a second call (call waiting), the Incoming Call window appears. Touch answer to answer the call. The first call is placed on hold. Switching Between Calls 1. Touch > Switch To. 2. Touch End Call to hang up. This does not disconnect the call on hold. Accessing the Phone Menu From the Main menu, touch Phone to open the Phone menu. Note: Not all phones support all features of the nüvi Phone menu.

nüvi 1100/1200/1300/1400 Series Owner's Manual 21 Making Hands-Free Phone Calls Using Your Phone Book Each time your phone connects with the nüvi, the phone book is automatically loaded into the nüvi. It can take a few minutes for the phone book to be available. Phone book transfer is not available on all phones. 1. Touch Phone > Phone Book. 2. Touch the phone book entry (contact) you want to call. 3. Touch Call to call the contact. Viewing Your Call History Each time your phone connects to the nüvi, your call history is automatically transferred to the nüvi.

It can take a few minutes to transfer this data to the nüvi. 1. Touch Phone > Call History. 2. Touch a category to view those calls.

The calls are listed in chronological order. The most recent calls are at the top of the list. 3. Touch an entry, and touch Dial. Dialing a Point of Interest 1. Touch Phone > Points of Interest. 2. Search for the point of interest you want to call. 3. Touch Call or touch the phone number. Calling Home Enter a phone number for your home location so you can quickly call home. 1. Touch Phone > Call Home. 2. The nüvi dials your home phone number.

Dialing a Number 1. Touch Phone > Dial. 2. Enter the number, and touch Dial. 22 nüvi 1100/1200/1300/1400 Series Owner's Manual Making Hands-Free Phone Calls Entering Your Phone Number 1. Touch Phone > Call Home. 2. Touch Enter Phone Number to use the keypad page or Select From Phonebook (only available if your phone supports phone book transfer). 3. Touch Done > Yes.

The nüvi dials your home phone number. Note: To edit your home location or phone number, touch Where to? > Favorites > Home > edit. Placing Calls Using Voice Dial You can place calls by speaking the contact's name. You might need to "train" your phone to recognize your voice dial commands. Refer to your phone instructions.

1. Touch Phone > Voice Dial. 2. Speak the contact name. Checking the Phone Status Check the battery level and signal strength for your phone by touching Phone > Status.

nüvi 1100/1200/1300/1400 Series Owner's Manual 23 Managing Files Managing Files You can store files, such as JPEG image files, in the internal memory on the nüvi or on a memory card. Note: The nüvi is not compatible with Windows® 95, 98, Me, Windows NT®, and Mac® OS 10.3 and earlier. monitors your computer USB ports and allows you to easily check for available updates. See page 52 for more information. 1. Insert a memory card (optional). Press it in until it clicks. 2. Connect the mini-USB connector to the back of the nüvi.

3. Connect the larger end of the cable to an available USB port on your computer. Supported File Types · JPEG and JPG image files: see page 27 · Maps and GPX waypoint files from MapSource®: see page 49 · GPI custom POI files from Garmin POI Loader: see page 50 Your nüvi and memory card appear as removable drives in My Computer in Windows and as mounted volumes on Mac computers. Note: Some computers with multiple network drives can not display nüvi drives. See your operating system Help file to learn how to map the drives. Connecting Your nüvi to Your Computer When you connect your nüvi to your computer, you will see an option to install myGarmin Agent™, which 24 nüvi 1100/1200/1300/1400 Series Owner's Manual Managing Files 1.

Browse your computer for the file you want to copy. 2. Highlight the file., and click Edit > Copy.

3. Open the "Garmin" or memory card drive/volume. 4. Click Edit > Paste. The file appears in the list of files in the nüvi memory or on the memory card. 5. When you are finished transferring files, click in your toolbar (system tray), or drag the volume icon to the Trash on Mac computers. 6. Unplug your nüvi from your computer. Transferring Files Deleting Files 1.

Connect the nüvi to your computer, and open the nüvi or memory card drive/volume. 2. Highlight the file you want to delete. 3. Press the Delete key on the computer keyboard. Caution: If you do not know the purpose of a file, do not delete it. Your nüvi memory contains important system files that should not be deleted. nüvi 1100/1200/1300/1400 Series Owner's Manual 25 Using the Tools Using the Tools The Tools menu provides many features that are helpful when you are traveling. From the Main menu, touch tools. 1.

From the Main menu, touch Tools > Where Am I?. 2. Touch a button on the right to view the nearest locations in that category. 3. Touch Save Location to save your current location. Accessing the Settings For information about the settings, see pages 3844. Accessing Help Touch Help to get information about using your nüvi. Touch Search to search help topics for a keyword. Using the Where Am I? Page Use the Where Am I? page to view current location information, including hospitals, police stations, and fuel. This feature is helpful if you need to tell emergency personnel your location.

26 nüvi 1100/1200/1300/1400 Series Owner's Manual Using the Tools Using the Picture Viewer Use the picture viewer to view pictures that you have stored in your nüvi or on a memory card. 1. Touch Tools > Picture Viewer.



[You're reading an excerpt. Click here to read official GARMIN NÜVI 1450 user guide](http://yourpdfguides.com/dref/3659722)  
<http://yourpdfguides.com/dref/3659722>



To stop receiving offers, turn off the traffic feature. See page 33. *nüvi 1100/1200/1300/1400 Series Owner's Manual 37 Customizing the nüvi Customizing the nüvi 1. Touch Tools > Settings. usage Mode--specify how you will be navigating to optimize routes: automobile, Pedestrian, or Bicycle. Keyboard--touch QWERTY for a layout similar to a computer keyboard, or touch aBCDe for an alphabetical layout (only available on the nüvi 1300 and 1400 series). units--change units of measure to Kilometers or Miles. about--display the nüvi software version number, the unit ID number, and information on several other software features. You need this information when you update the system software or purchase additional map data (see page 50). restore--restore the system settings.*

2. Touch the setting you want to change. 3. Touch the button under the setting name to change it. Changing the System Settings Touch tools > Settings > System.

gPS Simulator--turn on the simulator to turn off the GPS mode and simulate navigation, and to save battery power. 38 *nüvi 1100/1200/1300/1400 Series Owner's Manual Customizing the nüvi Changing the Navigation Settings Touch tools > Settings > Navigation. route Preference--select a preference for calculating your route: · Faster time--to calculate routes that are faster to drive but can be longer in distance. · Shorter Distance--to calculate routes that are shorter in distance but can take more time to drive. · off road--to calculate point-topoint routes (without roads). · Less Fuel-- to calculate routes that could use less fuel than other routes. The route calculation is based on road speeds and vehicle acceleration data for a given route. avoidances--select the road types you want to avoid on your routes. transit types--select which mode of public transit you would like your nüvi to avoid when calculating routes. Available when cityXplorer maps are loaded.*

See page 6. restore--restore the original navigation settings. Adjusting the Display Settings Touch tools > Settings > Display. Color Mode--select Day for a light background, Night for a dark background, or auto to automatically switch between the two. Screen Shot--turn on Screen Shot mode. Touch to take a screen shot. The picture bitmap file is saved in the screenshots folder on the nüvi drive. 39 *nüvi 1100/1200/1300/1400 Series Owner's Manual Customizing the nüvi Brightness--adjust the backlight brightness level. Reducing the backlight brightness increases your battery life. restore--restore the original display settings.*

Setting the Languages Voice Language--change the language for voice prompts. Touch tools > Settings > Language. Updating the Time Settings Touch tools > Settings > time. Select a time format--select a 12hour, 24-hour, or UTC time format. Current time--manually set the time on your nüvi. Select automatic to have the nüvi set the time based on your location. restore--restore the original time settings. text Language--change all onscreen text to the selected language. Changing the text language does not change the language of user-entered data or map data, such as street names. Keyboard--select the keyboard for your language.

Touch Mode on any keyboard to change the keyboard language. restore--restore the original language settings. 40 *nüvi 1100/1200/1300/1400 Series Owner's Manual Customizing the nüvi Changing the Map Settings Touch tools > Settings > Map. Map Detail--adjust the amount of detail shown on the map. Showing more detail can cause the map to redraw slower. Map View--select a map perspective. · track up--display the map in two dimensions (2D) with your direction of travel at the top. · North up--display the map in 2D with North at the top. · 3D--display the map in three dimensions (3D) in Track Up. Note: In Pedestrian usage mode, North Up is the only map view.*

want to use, and then touch oK. Download additional vehicle icons at [www.garmin.com](http://www.garmin.com). trip Log--show or hide the log of your travels. To clear trip log, touch tools > My Data > Clear trip Log. Map info--view the maps and the version of each map loaded on your nüvi. Touch a map to enable (check mark) or disable (no check mark) that map. restore--restore the original map settings. Changing Security Settings Touch tools > Settings > Security. garmin Lock--turn on Garmin LockTM to lock your nüvi. Enter a 4-digit PIN, and set a security location. For more information, see page 46. 41 Vehicle--touch Change to change the icon used to display your position on the map. Touch the icon you nüvi 1100/1200/1300/1400 Series Owner's Manual Customizing the nüvi Safe Mode--turn safe mode on or off.

When your vehicle is moving, Safe mode disables all functions that require significant operator attention and could become a distraction while driving. restore--restore the original security settings. Note that restoring the security settings will not clear your Garmin Lock PIN or security location. Setting the Bluetooth Technology Options · Drop--select the phone you want to disconnect, and touch Yes. · remove--select the phone you want to delete from the nüvi memory, and touch Yes.

Bluetooth--turn the Bluetooth component on and off. The Bluetooth icon appears on the Main menu if the Bluetooth component is turned on. To prevent a phone from automatically connecting, touch Disabled. Friendly Name--enter a friendly name that identifies your nüvi on devices with Bluetooth technology. Touch Done. restore--restore the original Bluetooth settings. This does not clear the pairing information. Touch tools > Settings > Bluetooth. Connections--touch add > oK to pair with a phone that has Bluetooth wireless technology. See pages 1923.

Touch Change to connect with a different phone. 42 *nüvi 1100/1200/1300/1400 Series Owner's Manual Customizing the nüvi Changing the Proximity Points Settings You must have proximity points (such as custom POIs or a safety camera database) loaded to adjust the proximity points settings. See page 50. Touch tools > Settings > Proximity Points. North American Options Your FM traffic subscriptions and expiration dates are listed. Touch add to add a subscription. Non-North America Options Current--select which provider to use. Touch auto to use the best provider for the area, or select a specific provider to use. Find More--search for additional TMC traffic providers. To increase the search time, touch Yes to clear the provider table. Subscriptions--view your FM traffic subscriptions and expiration dates. Touch add to add a subscription. Proximity alerts--turn the alerts on or off when you approach custom POIs or safety cameras. restore--restore the proximity points settings. Viewing Traffic Subscription Information The traffic receiver is included in some nüvi packages.*



[You're reading an excerpt. Click here to read official GARMIN NÜVI 1450 user guide](http://yourpdfguides.com/dref/3659722)  
<http://yourpdfguides.com/dref/3659722>



Touch tools > Settings > traffic. nüvi 1100/1200/1300/1400 Series Owner's Manual 43 Customizing the nüvi Adding a Subscription You can purchase additional subscriptions or a renewal if your subscription expires. Go to [www.garmin.com/fmtraffic](http://www.garmin.com/fmtraffic).

Note: You do not need to activate the subscription included with your FM traffic receiver (if it came with one). The subscription activates automatically after your nüvi acquires satellite signals while receiving traffic signals from the service provider. 1. From the Main menu, touch Tools > Settings > Traffic. 2. For non-North American units, touch Subscriptions > Add. For North American units, touch Add. 3. Write down the FM traffic receiver unit ID. 4.

Go to [www.garmin.com/fmtraffic](http://www.garmin.com/fmtraffic) to purchase a subscription and get a 25-character code. 44 5. Touch Next on the nüvi, enter the code, and touch Done. The traffic subscription code cannot be reused. You must obtain a new code each time you renew your service. If you own multiple FM traffic receivers, you must obtain a new code for each receiver. Restoring All Settings 1. Touch Tools > Settings.

2. Touch Restore. 3. Touch Yes. nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix Appendix Caring for Your nüvi Your nüvi contains sensitive electronic components that can be permanently damaged if exposed to excessive shock or vibration.

To minimize the risk of damage to your nüvi, avoid dropping your unit and operating it in high-shock and highvibration environments. Cleaning the Unit The nüvi is constructed of highquality materials and does not require user maintenance other than cleaning. Clean the outer casing of the unit (not the touchscreen) using a cloth dampened with a mild detergent solution, and then wipe it dry. Avoid chemical cleaners and solvents that can damage plastic components. Cleaning the Touchscreen Clean the touchscreen with a soft, clean, lint-free cloth.

Use water, isopropyl alcohol, or eyeglass cleaner, if needed. Apply the liquid to the cloth, and then gently wipe the touchscreen. Protecting Your nüvi · Do not store the nüvi where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage. · Do not expose the nüvi to water.

Contact with water can cause this unit to malfunction. · Although a PDA stylus can be used to operate the touchscreen, never attempt this while operating a vehicle. Never use a hard or sharp object to operate the touchscreen because damage might result. 45 nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix Avoiding Theft · To avoid theft, remove the unit and mount from sight when not in use. Remove the residue left on the windshield by the suction cup. · Do not keep your unit in the glove compartment.

· Register your product at <http://my.garmin.com>. · Use the Garmin Lock feature. See below for more information. 1. Touch Tools > Settings > Security. 2. Touch the button below Garmin Lock. 3.

Enter a 4-digit PIN and drive to a security location. Locking Your nüvi What is a Security Location? Your security location should be a location you return to often, such as your home. If the nüvi has satellite signals and you are at the security location, you do not need to enter the PIN. Note: If you forget your PIN and your security location, you must send your nüvi to Garmin to get it unlocked. You must also send a valid product registration or proof of purchase.

Garmin Lock is a theft-deterrent system that locks your nüvi. Each time you turn on the nüvi, enter the PIN or drive to the security location. 46 nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix Calibrating the Screen 1. Turn off the nüvi. 2.

Hold the upper-left corner of the screen while turning on the nüvi. 3. Release the Power button when the Garmin screen appears. 4. Continue to hold the upper-left corner of the touch screen for 30 seconds until a white screen with "Press dot" appears. 1. Connect the nüvi to your computer using the mini-USB cable. The AutoPlay menu opens. 2. Double-click on to open the myGarmin Agent download page.

If the AutoPlay menu does not open, or you are on a Mac computer, go to [www.garmin.com/agent](http://www.garmin.com/agent). 3. Follow the on-screen instructions. open myDashboard when you connect your nüvi to your computer. myDashboard checks your nüvi for current software and provides additional information about your nüvi. Clearing User Data iMPortaNt: This deletes all user-entered information. 1. Hold your finger on the lower-right corner of the nüvi screen while turning on the nüvi.

2. Keep your finger pressed until the pop-up window appears. 3. Touch Yes to clear all user data. Updating the Software All original settings are restored. Any items that you have saved are erased. After you have installed myGarmin Agent, you will be prompted to nüvi 1100/1200/1300/1400 Series Owner's Manual 47 Appendix Battery Information To maximize the lifetime of the battery, do not leave your nüvi in direct sunlight, and avoid prolonged exposure to excessive heat. The battery icon in the corner of the Main menu indicates the status of the nüvi battery. To increase the accuracy of the battery gauge, fully discharge the battery and then fully charge it. Do not unplug the nüvi until it is totally charged.

Changing the Fuse Caution: When replacing the fuse, do not lose any of the small pieces, and ensure they are put back in the proper place. If your unit will not charge in your vehicle, you might need to replace the fuse located at the tip of the vehicle adapter. 1. Unscrew the black, round end piece, and remove it.

End piece Silver tip Fuse Charging Your nüvi Charge your nüvi for at least 4 hours before using on battery power. · Connect the vehicle power cable. · Connect the USB cable (included in some packages). · Connect an AC adapter (optional accessory). 48 tiP: You may need to use a coin to remove the end piece. 2.

Remove the fuse (glass and silver cylinder), and replace it with the appropriate fuse type, which can be found on the side of the vehicle adapter. nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix 3. Ensure that the silver tip is placed in the black end piece. Screw on the black end piece. Removing the nüvi and Mount iMPortaNt: The permanent mounting adhesive is extremely difficult to remove after it is installed. 1. Clean and dry the dashboard where you are placing the disk. 2. Remove the backing from the adhesive on the bottom of the disk. 3.

Place the disk on the dashboard. 4. Remove the clear plastic cover from the top of the disk. 5. Place the suction cup mount on top of the disk. Flip the lever down (toward the disk). To remove the nüvi from the cradle, press the tab of the cradle while tilting the nüvi forward.



[You're reading an excerpt. Click here to read official GARMIN NUVI 1450 user guide](http://yourpdfguides.com/dref/3659722)

<http://yourpdfguides.com/dref/3659722>

To remove the cradle from the mount, turn the cradle to the right or left. Apply pressure in that direction until the cradle snaps off the mount. To remove the suction cup mount from the windshield, flip the lever toward you.

Pull the tab on the suction cup toward you. *nüMaps Guarantee™ Mounting on Your Dashboard* Use the enclosed mounting disk to mount your unit to the dashboard and comply with certain state regulations. To receive one free map update (if available), register your nüvi at <http://my.garmin.com> within 60 days of acquiring satellites and driving with your nüvi. You are not eligible for the free map update if you register by phone or wait longer than 49 nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix 60 days after the first time you drive with your nüvi. Additional Maps bars on the Main menu are green . When it loses satellite signals, the bars turn red or clear . For more information about GPS, go to [www.garmin.com](http://www.garmin.com).

[com/aboutGPS](http://www.garmin.com/aboutGPS). You can purchase additional maps for your nüvi. To see a list of maps that are compatible with your nüvi, go to your nüvi product page on the Garmin Web site ([www.garmin.com](http://www.garmin.com)), and click the Maps tab. Extras and Optional Accessories About GPS Satellite Signals For more information about optional accessories, go to <http://buy.garmin.com> or [www.garmin.com/extras](http://www.garmin.com/extras), or contact your Garmin dealer.

Custom Points of Interest Use the POI Loader to load custom points of interest (POIs) onto your nüvi. POI databases are available from various companies on the Internet. Some custom databases contain alert information for points, such as safety cameras and school zones. Your nüvi must acquire GPS (Global Positioning System) satellite signals in order to navigate. If you are indoors, near tall buildings or trees, or in a parking garage, your nüvi may not acquire satellites.

Go outside to an area free from tall obstructions to use your nüvi. When your nüvi has acquired satellite signals, the signal strength 50 nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix Go to [www.garmin.com/extras](http://www.garmin.com/extras), and click POI Loader to install the POI Loader onto your computer.

For more information, refer to the POI Loader Help file.

Press F1 to open the Help file. To view your Custom POIs, touch Where to? > extras > Custom Pois. To change the proximity alert settings, touch tools > Settings > Proximity Points > Proximity alerts. To delete the Custom POIs from your nüvi, connect your nüvi to your computer. Open the POI folder in the nüvi drive or the memory card drive. Delete the file titled poi.gpi. Safety Cameras Safety camera information is available in some locations. Check <http://my.garmin.com>

for availability. For these locations, the nüvi includes the locations of hundreds of safety cameras. Your nüvi alerts you when you are approaching a safety camera and can warn you if you are driving too fast. The data is updated at least weekly, so you always have access to the most up-to-date information. You can purchase a new region or extend an existing subscription at any time. Each region that you purchase has an expiration date. Caution: Garmin is not responsible for the accuracy of, or the consequences of using, a custom POI or safety camera database. nüvi 1100/1200/1300/1400 Series Owner's Manual 51 Appendix Garmin Travel Guide The Garmin Travel Guide provides detailed information about places, such as restaurants and hotels. To purchase an

accessory, go to <http://buy.garmin.com>

or contact your Garmin dealer. To use the travel guide, insert the memory card into your nüvi. Touch Where to? > extras. Touch the name of your travel guide to open it. In Europe, go to [www.garmin.com/support](http://www.garmin.com/support)

and click Contact Support for in-country support information, or contact Garmin (Europe) Ltd. by phone at +44 (0) 870.8501241.

Registering Your nüvi Go to <http://my.garmin.com>

to register your nüvi. See page 24 for information about connecting your nüvi to your computer. 1. Plug in your nüvi. You will see an option to install the myGarmin Agent (optional). 2. Follow the online instructions to install myGarmin Agent and register your nüvi. Contact Garmin Contact Garmin Product Support if you have questions. In the USA, go to [www.garmin.com/support](http://www.garmin.com/support)

, or contact Garmin USA by phone at (913) 397-8200 or (800) 800-1020. In the UK, contact Garmin (Europe) Ltd. by phone at 0808 2380000. After you have registered your nüvi, you can subscribe to the latest Garmin online services. 52 nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix Specifications nüvi 1100/1200 Series Physical size (W × H × D): 3.7 × 2.9 × 0.6 in. (9.

3 × 7.5 × 1.6 cm) Weight: 4 oz. (113.4 g) Display: 3.

5 in. diagonal, 320 × 240 pixels; 64K colors; bright QVGA TFT landscape display; white backlight; touchscreen Case: Not waterproof (IPXO) operating temperature range: 32°F140°F (0°C60°C) Charging temperature range: 32°F113°F (0°C45°C) Data storage: Internal memory and optional removable microSD card. Data stored indefinitely. Computer interface: USB 2.0 full speed mass storage operating system: Garmin Charge time: Up to 4 hours Power input: Vehicle power using included vehicle power cable or AC power using an optional accessory usage: 5 W max.

Battery life: Up to 3 hours Battery type: Non-user-replaceable rechargeable lithium-ion battery gPS receiver: High-sensitivity with HotFix™ acquisition times\*: Warm: <1 second Cold: <38 second Factory Reset: <45 second \*Average acquisition times for a stationary receiver with a clear view of the sky. nüvi 1100/1200/1300/1400 Series Owner's Manual 53 Appendix nüvi 1300 Series Physical size (W × H × D): 4.8 × 2.9 × 0.6 in. (12.2 × 7.5 × 1.6 cm) Weight: 5.7

oz.

(161.6 g) Display: 4.3 in. diagonal, 480 × 272 pixels; 64K colors; bright WQVGA TFT landscape display; white backlight; touchscreen Case: Not waterproof (IPXO) operating temperature range: 32°F140°F (0°C60°C) Charging temperature range: 32°F113°F (0°C45°C) Data storage: Internal memory and optional removable microSD card. Data stored indefinitely. Computer interface: USB 2.0 full speed mass storage operating system: Garmin Charge time: Up to 4 hours 54 Power input: Vehicle power using included vehicle power cable or AC power using an optional accessory usage: 5 W max. Battery life: Up to 3 hours Battery type: Non-user-replaceable rechargeable lithium-ion battery gPS receiver: High-sensitivity with HotFix™ acquisition times\*: Warm: <1 second Cold: <38 second Factory Reset: <45 second \*Average acquisition times for a stationary receiver with a clear view of the sky. nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix nüvi 1400 Series Physical size (W × H × D): 5.



[You're reading an excerpt. Click here to read official GARMIN NÜVI](http://yourpdfguides.com/dref/3659722)

[1450 user guide](http://yourpdfguides.com/dref/3659722)

<http://yourpdfguides.com/dref/3659722>

4 × 3.

4 × 0.6 in. (13.7 × 8.6 × 1.

6 cm) Weight: 7.8 oz. (221.1 g) Display: 5.0 in.

diagonal, 480 × 272 pixels; 64K colors; bright WQVGA TFT landscape display; white backlight; touchscreen Case: Not waterproof (IPX0) operating temperature range: 32°F/140°F (0°C/60°C) Charging temperature range: 32°F/113°F (0°C/45°C) Data storage: Internal memory and optional removable microSD card. Data stored indefinitely. Computer interface: USB 2.0 full speed mass storage operating system: Garmin Charge time: Up to 4 hours Power input: Vehicle power using included vehicle power cable or AC power using an optional accessory usage: 5 W max. Battery life: Up to 3 hours Battery type: Non-user-replaceable rechargeable lithium-ion battery gPS receiver: High-sensitivity with HotFix acquisition times\*: Warm: <1 second Cold: <38 second Factory Reset: <45 second \*Average acquisition times for a stationary receiver with a clear view of the sky. nüvi 1100/1200/1300/1400 Series Owner's Manual 55 Appendix Declaration of Conformity Hereby, Garmin declares that this nüvi product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. To view the full Declaration of Conformity, go to the Web site for your Garmin product at [www.garmin.com](http://www.garmin.com). Software License Agreement BY USING THE nüvi, YOU AGREE TO BE BOUND BY THE TERMS AND CONDITIONS OF THE FOLLOWING SOFTWARE

#### LICENSE AGREEMENT.

PLEASE READ THIS AGREEMENT CAREFULLY. Garmin grants you a limited license to use the software embedded in this device (the "Software") in binary executable form in the normal operation of the product. Title, ownership rights, and intellectual property rights in and to the Software remain in Garmin. 56 You acknowledge that the Software is the property of Garmin and is protected under the United States of America copyright laws and international copyright treaties. You further acknowledge that the structure, organization, and code of the Software are valuable trade secrets of Garmin and that the Software in source code form remains a valuable trade secret of Garmin. @@@@The suction cup will not stay on my windshield. My nüvi does not charge in my vehicle. @@Remain stationary for several minutes. Clean the suction cup and windshield with rubbing alcohol. Dry with a clean, dry cloth. Mount the suction cup as described on page 2. Check the fuse in the vehicle power cable (see page 48). @@Your nüvi can only charge between 32°F and 113°F (between 0°C and 45°C). If the nüvi is placed in direct sunlight or in a hot environment, it cannot charge. To maximize the time between charges, turn down the backlight.

Touch Tools > Settings > Display > Brightness. Hold your finger on the lower-right corner of the nüvi screen while it is turning on. Keep your finger pressed until the message appears. Touch Yes to clear all user data. 57 My battery does not stay charged for very long.

How do I clear all of my user data? nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix Problem/Question My battery gauge does not seem accurate. The touchscreen is not responding to my touches. How do I know my nüvi is in USB mass storage mode? My computer never senses that the nüvi is connected. Solution/Answer Allow the unit to fully discharge, and fully charge it (without interrupting the charge cycle). Calibrate the touchscreen as described on pages 4445. When your nüvi is in USB mass storage mode, a picture of a nüvi connected to a computer is shown. Also, you should see two new removable disk drives listed in My Computer. 1. Unplug the USB cable from your computer. 2.

Turn off the nüvi. 3. Plug the USB cable into a USB port on your computer and into your nüvi. The nüvi automatically turns on and goes into USB mass storage mode. Ensure your nüvi is connected to a USB port and not a USB hub. 58 nüvi 1100/1200/1300/1400 Series Owner's Manual Appendix Problem/Question I cannot see any new removable drives in my list of drives. Solution/Answer If you have several network drives mapped on your computer, Windows can have trouble assigning drive letters to your nüvi drives. See your operating system Help file to learn how to map or assign drive letters. Save the hotel in your Favorites. See page 12 for more information on Favorites.

You can then search near the hotel for restaurants. 1. Touch Where To? > Near. 2. Select A Favorite Destination.

3. Select a destination. 4. Touch Points of Interest > Food and Drink. 5.

Select a category. Your nüvi searches for locations near the hotel. 6. Select a restaurant. Ensure you have a nüvi with Bluetooth. See page iv. Touch Tools > Settings > Bluetooth. Verify that the Bluetooth field is set to Enabled. Ensure your phone is turned on and is less than 33 feet (about 10 meters) away from your nüvi. See [www.garmin.com/bluetooth](http://www.garmin.com/bluetooth) for more help.

How can I find restaurants near the hotel I will be staying at in the future? My phone will not connect to the nüvi. nüvi 1100/1200/1300/1400 Series Owner's Manual 59 Index Index Symbols 2-D, 3-D map view 41 A acceleration score 31 accessories 50, 51 additional maps 50 addresses 8 advertisements disabling 33 alarm clock 52 alerts safety camera 51 anti-theft feature 41, 46 attaching a photo to a location 13 audio version 38 avoiding road types 39 theft 46 B background color 39 60 battery 48, 57 battery information 48 bicycle navigation 38 Bluetooth technology 1923 calling from Go! page 9 deleting a phone 42 on nüvi models iv pairing with phone 19 settings 42 brightness 40 browsing the map 13 C calculator 28 call answering 20 call waiting 21 hanging up 21 history 22 home 22 muting 21 caring for your nüvi 45 charging your nüvi 48, 57 city maps 3, 6 converting currency 28 units 28 coordinates 14 current location, save 12 customizing the nüvi 3844 custom POIs 51 D dashboard disk 49 deceleration score 31 Declaration of Conformity 56 deleting all user data 47 character 11 custom POIs 51 Favorites 13 recent finds list 12 detail maps 41 detour 7 diacritical characters 11 display settings 39 nüvi 1100/1200/1300/1400 Series Owner's Manual Index Driving Challenge 31 driving directions 16 E ecoRoute™ 2932 calibrate fuel economy 30 Driving Challenge 31 fuel report 30 mileage report 32 tips 32 vehicle profile 29 editing saved places change categories 13 change map symbol 13 change name 12 change phone number 13 extras 5051 F Favorites 12 feedback on POI's 10 files 2425 deleting 25 supported types 24 finding places 4 by address 8 by coordinates 14 by name 10 by postal code 8 near another location 11 recent selections 12 saved places (Favorites) 12 using photos 1415 free map update 49 fuel price, adjusting 30 fuel report 30 fuse, changing 48 G Garmin Lock 41, 46 Garmin Travel Guide 52 geocaching 14 Go! page options 9 go home 8 GPS about GPS 50 off/on 38 H Help 26 home phone number 22 setting a location 8 I incoming call 20 itinerary page 6 J JPEG image files 24 Junction View 17 on nüvi models iv K keyboard 10 language mode 11, 40 layout 38 kilometers 38 L Lane Assist on nüvi models iv using 15 61 nüvi 1100/1200/1300/1400 Series Owner's Manual Index language settings 40 latitude 14 lithium-ion battery 48, 53, 54, 55 lock the nüvi 46 the screen 4 longitude 14 M map adding 50 browsing 13 detail level 41 enabling detail maps 41 Map Info button 41 pedestrian 18 settings 41 version 41 viewing 41 zooming 13 MapSource 24, 50 max speed, reset 16 measurements, convert62 ing 28 mileage report 32 miles 38 mounting on dashboard 49 on windshield 57 removing from mount 49 mute audio 4 phone call 21 My Data 27 N navigation 15 mode 38 settings 39 next turn 17 nüMaps Guarantee 49 nüvi case 1 charging 48 cleaning 45 models iv mounting 49 protecting 45 resetting 4 nüvi models 1100 iv 1200 iv 1300 iv 1400 iv O off road, routing 3, 39 on-screen keyboard 10 output, audio 4 P pairing a mobile phone 19 pedestrian navigation mode 38 itinerary 6 route options 6 phone book 22 PIN Bluetooth 20 Garmin Lock 46 points of interest 10 custom 50 edit phone number 10 nüvi 1100/1200/1300/1400 Series Owner's Manual Index edit star rating 10 POI loader 24 report error 10 position icon 41 power button 4 proximity points alerts 43 settings 43 public transit avoidances 39 city maps 3, 6 Q QWERTY keyboard 38 R recalculating routes 7 recently found locations 12 registering 46 removing the mount 49 resetting the max speed 16 trip data 16 your nüvi 4 route options page 6 routes mode 38 off road 39 preferences 39 simulating 38 stopping 7 S safe mode 42 safety camera database 51 satellite signals 50 saving places you find 12 your current location 12, 13 school zone

database 50 screen brightness 40 screen shots 39 search area 11 security location 46 settings 41 settings 3843 restoring 44 setting your location 13  
simulating a route 38 software license agreement 56 updating 47 version 38 specifications nüvi 1100 series 53 nüvi 1200 series 53 nüvi 1300 series 54 nüvi  
1400 series 55 speed limit icon 15 on nüvi models iv speed score 31 storing the nüvi 45 supported file types 24 system settings 38 T text language 40 time  
settings 40 time zone 40 tools 2631 touchscreen calibrating 47, 58 63 nüvi 1100/1200/1300/1400 Series Owner's Manual Index cleaning 45 settings 40 Track  
Up 41 traffic 34 adding traffic subscriptions 43 incidents 36 transferring files 25 trip computer 16 trip log 41 troubleshooting 57 turn-by-turn directions 16  
turn list 16 U unit converter 28 unit ID 38 updating maps 49, 50 software 47 usage mode 3, 38 USB 58 mass-storage mode 24 user data, delete 47 64 V  
vehicle icon 41 vehicle profile 31 voice dial 23 voice language 40 voice mail 21 W walking route 38 WebUpdater 47 Where Am I? 26 Where to? 814 world  
clock 28 Z zoom 13 nüvi 1100/1200/1300/1400 Series Owner's Manual For the latest free software updates (excluding map data) throughout the life of your  
Garmin products, visit the Garmin Web site at [www.garmin.com](http://www.garmin.com).



[You're reading an excerpt. Click here to read official GARMIN NÜVI  
1450 user guide](http://www.garmin.com)  
<http://yourpdfguides.com/dref/3659722>