



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for KODAK C180. You'll find the answers to all your questions on the KODAK C180 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual KODAK C180
User guide KODAK C180
Operating instructions KODAK C180
Instructions for use KODAK C180
Instruction manual KODAK C180


1 Installing the software



Before connecting any cables, install the software that was included with your camera. Follow the on-screen instructions.

After installing the software, return to this user guide.

2 Loading the batteries



See the Extended user guide

www.kodak.com/go/c160support,
www.kodak.com/go/c180support

www.kodak.com/go/c180support

1

ENGLISH



[You're reading an excerpt. Click here to read official KODAK C180 user guide](http://www.kodak.com/go/c180support)

<http://yourpdfguides.com/dref/2702015>

Manual abstract:

Follow the on-screen instructions. After installing the software, return to this user guide. Loading the batteries See the Extended user guide www.kodak.com/go/c160support, www.kodak.com/go/c180support www.kodak.com/go/c180support 1 ENGLISH ENGLISH 2 Turning on the camera Press the Power button. Setting the language and date/time Language: to change.

OK to accept. Date/Time: At the prompt, press OK. to change current field. for previous/next field. OK to accept.

OK (press) See the Extended user guide www.kodak.com/go/c160support, www.kodak.com/go/c180support www.kodak.com/go/easysharecenter

Taking a picture 1 Turn the Mode dial to Auto Compose the picture. . 2 Press the Shutter button halfway to focus and set exposure. When the framing marks turn green, press the Shutter button completely down. Framing marks To learn more about Auto and other modes, see page 10. See the Extended user guide www.kodak.com/go/c160support, www.kodak.com/go/c180support

3 ENGLISH ENGLISH 4 Reviewing pictures/videos Press the Review button to enter/exit Review. View previous/next picture/video. OK Play a video. Review See the Extended user guide www.kodak.com/go/c160support, www.kodak.com/go/c180support www.kodak.com/go/easysharecenter Transferring pictures/videos 1 Connect a KODAK USB Cable, Model U-8. 2 Turn on the camera. See the Extended user guide Purchase accessories www.kodak.com/go/c160support, www.kodak.com/go/c180support www.kodak.com/go/c160accessories, www.kodak.com/go/c180accessories

5 ENGLISH ENGLISH Getting help from your camera You want the most from your camera. You want to understand: What it can do for you And how to take the best possible pictures and videos Great news! Your camera offers a built-in Help system. It describes every setting for every menu choice. If you learn nothing else about your camera, learn how to use on-camera Help. Because the more you know your camera, the more confident you become. 1 Press the Menu button then highlight a menu choice. 2 Press the Info button.

Scroll through a Help topic See the Extended user guide www.kodak.com/go/c160support, www.kodak.com/go/c180support 6 www.kodak.com/go/easysharecenter Keep learning about your camera! Congratulations! @@@@The scene is analyzed for other content and for lighting. @@needs--just press the Menu Close range. Use available light instead of flash, if possible. Subjects that are in motion. Point-and-shoot simplicity when taking pictures in practically any situation. (See page 11.) Blur Reduction Reducing blur caused by camera shake or subject motion. Video Capturing video with sound. (See page 11.)

) NOTE: Sound cannot be played on the camera. Sound is heard after the video is transferred to your computer. 10 www.kodak.com/go/easysharecenter Doing more with your camera Taking a video 1 Turn the Mode dial to Video .

2 Press the Shutter button completely down, then release it. To stop recording, press and release the Shutter button again. To review videos, see page 18. Using Scene (SCN) modes Choose a Scene mode--for great pictures in practically any situation. 1 Turn the Mode dial to SCN. 2 Press to view scene mode descriptions. If the mode description turns off before you finish reading it, press OK. 3 Press OK to choose a Scene mode. SCN mode Portrait Landscape Flower Sunset Backlight For Full-frame portraits of people. Distant scenes.

Close-ups of flowers or other small subjects in bright light. Subjects at dusk. Subjects that are in shadow or "backlit" (when light is behind the subject). www.kodak.com/go/c180support 11 Doing more with your camera SCN mode Candle Light Children Manner/ Museum Text Beach Snow Fireworks SelfPortrait Night Portrait Night Landscape High ISO For Subjects illuminated by candle light. Action pictures of children in bright light. Quiet occasions, like a wedding or lecture. Flash and sound are disabled. Place the camera on a steady surface or tripod.

Documents. Place the camera on a steady surface or tripod. Bright beach scenes. Bright snow scenes. Fireworks. Place the camera on a steady surface or tripod. Close-ups of yourself. Assures proper focus and minimizes red eye. Reduces red eye of people in night scenes or low-light conditions. Distant scenery at night.

Flash does not fire. People indoors, in low-light scenes. 12 www.kodak.com/go/easysharecenter Doing more with your camera Using the optical zoom 1 Use the LCD to frame your subject. 2 To zoom in, press Telephoto (T). To zoom out, press Wide Angle (W). 3 Take the picture. Using digital zoom Use digital zoom to get up to 5X magnification beyond optical zoom. Press Telephoto (T) until the slider on the LCD is at the maximum optical zoom range.

Release Telephoto (T), then press it again. NOTE: You may notice decreased image quality when using digital zoom. The slider pauses and turns red when the picture quality reaches the limit for an acceptable 4 x 6-in. (10 x 15 cm) print. www.kodak.com/go/c180support 13 Doing more with your camera Using the flash Press the flash button repeatedly to scroll through flash modes. The current flash mode is shown on the LCD. Flash modes Auto Fill (Flash On) Flash fires When the lighting conditions require it. Every time you take a picture, regardless of the lighting conditions.

Use when the subject is in shadow or is "backlit" (when the light is behind the subject). In low light, hold the camera steady or use a tripod. A preflash fires, shrinking the eye pupil, before the picture is taken. @@@@The shortcuts appear. @@@@To get the most from your camera, see page 6. You can change settings to get the best results from your camera. NOTE: Some modes offer limited settings. @@@@to choose a 3 Press 4 Highlight an option, then press OK. @@@@The camera shows the last picture that was taken. @@@@3 To see a single picture/video, press to highlight it. @@@@and each begins with a picture. How do you tell yours? @@@@1 Load KODAK EASYSHARE Software. @@@@ Take another picture. Continue taking pictures. @@@@Refer servicing to qualified service personnel. KODAK AC Adapters and Battery Chargers are intended for indoor use only. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards. If the LCD breaks, do not touch the glass or liquid. Contact Kodak customer support. The use of an accessory that is not recommended by Kodak may cause fire, electric shock, or injury.

For approved accessories, visit www.kodak.com/go/accessories. Use only a USB-certified computer equipped with a current-limiting motherboard. Contact your computer manufacturer if you have questions. If using this product in an airplane, observe all instructions of the airline. When removing the battery, allow it to cool; it may be hot. Follow all warnings and instructions supplied by the battery manufacturer.



[You're reading an excerpt. Click here to read official KODAK C180 user guide](http://yourpdfguides.com/dref/2702015)

<http://yourpdfguides.com/dref/2702015>

Use only batteries approved for this for such damages resulting from the purchase, use, or failure of the product), regardless of cause or for breach of any written or implied warranty is expressly disclaimed. Your rights Some states or jurisdictions do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Some states or jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific rights, and you may have other rights which vary from state to state or by jurisdiction. 24 www.kodak.com/go/easysharecenter Appendix Outside the United States and Canada In countries other than the United States and Canada, the terms and conditions of this warranty may be different.

Unless a specific Kodak warranty is communicated to the purchaser in writing by a Kodak company, no warranty or liability exists beyond any minimum requirements imposed by law, even though defect, damage, or loss may be by negligence or other act. FCC compliance and advisory KODAK EASYSHARE C160/C180 Digital Camera This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. @@@@ Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation. Canadian DOC statement DOC Class B Compliance--This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes--Classe B--Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. www.kodak.com/go/c180support 25

Appendix FCC and Industry Canada This device complies with Industry Canada RSS-210 and FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Waste Electrical and Electronic Equipment labeling In Europe: For human/environmental protection, it is your responsibility to dispose of this equipment at a collection facility established for this purpose (separate from municipal waste). For more information, contact your retailer, collection facility, or appropriate local authorities; or visit www.kodak.com/go/recycle. VCCI Class B ITE Australian C-Tick N137 26 www.kodak.com/go/easysharecenter

Appendix Korean Class B ITE China RoHS Eastman Kodak Company Rochester, New York 14650 © Eastman Kodak Company, 2008 Kodak, EasyShare, and Perfect Touch are trademarks of Eastman Kodak Company. 4H5116_en www.kodak.com/go/c180support 27 .



[You're reading an excerpt. Click here to read official KODAK C180 user guide](#)

<http://yourpdfguides.com/dref/2702015>