



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for LA CROSSE TECHNOLOGY WM5014. You'll find the answers to all your questions on the LA CROSSE TECHNOLOGY WM5014 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual LA CROSSE TECHNOLOGY WM5014
User guide LA CROSSE TECHNOLOGY WM5014
Operating instructions LA CROSSE TECHNOLOGY WM5014
Instructions for use LA CROSSE TECHNOLOGY WM5014
Instruction manual LA CROSSE TECHNOLOGY WM5014

WEATHER FORECAST CENTER Instruction manual

INTRODUCTION

The Meteorologic Weather Forecast Center provides a professional weather forecast for the current and the next three days. The weather forecasts are made by professional meteorologists and are sent out with the radio time signal generator DG F77 in Germany and HBG in Switzerland and can be received in almost all of Europe. The reception area for the radio time signal generator is divided into a total of 90 meteorological regions (60 regions with 4-day forecast, 30 regions with 2-day forecast). The desired region for the local or holiday location is simply selected and the respectively current weather forecast is shown on the display. This gives you a quick overview of the weather situation for the following days at any time. Updating the weather data is done every day.

You will also be able to consult the local outside temperature, thanks to the transmitter which you will install in a place of your choice.

Please read the operating instructions carefully and completely before using for the first time, to prevent function errors and incorrect operation. Keep the instructions handy for consulting.

WEATHER FORECAST CENTER



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WM5014 user guide](http://yourpdfguides.com/dref/1116258)
<http://yourpdfguides.com/dref/1116258>

Manual abstract:

The weather forecasts are made by professional meteorologists and are sent out with the radio-time signal generator DCF77 in Germany and HBG in Switzerland and can be received in almost all of Europe. The reception area for the radio-time signal generator is divided into a total of 90 meteorological regions (60 regions with 4 day forecast, 30 regions with 2 day forecast). @@@@Updating the weather data is done every day. @@@@Keep the instructions handy for consulting. WEATHER FORECAST CENTER 6 DISPLAY Time reception signal Alarm ON icon Time Calendar Alarm time Reception indicator for weather data Weather forecast icon (day) Indoor temperature MIN/MAX temperature Weather forecast icon (night) Today Tomorrow (Day 1) Day 2 Day 3

Outdoor temperature with min/max Reception indicator for weather data · Symbol on Weather data completely received · Symbol flashing Weather data incomplete Reception indicator for radio-time signal generator Initial reception of date and time · Symbol flashing · Symbol on Time and date are current ·

Symbol off Time and date have not been updated Alarm symbol · Symbol on · Symbol off · Symbol flashing Alarm function switched on Alarm function switched off Alarm active or temporarily switched off (Snooze) CHOOSING THE INSTALLATION LOCATION Similar to a mobile telephone network or radio/TV reception, the reception of the radio-time receiver may not be perfect in all locations. Just a couple of notes to make sure that your device works with no problems. 7 The location of the weather station is very important. This is the reason for the new test function that allows the quality of reception to be checked in the surrounding area and to position the device in a location that has the best possible conditions. · Switch on all potential sources of interference

(e.g. television) in the area that you want to install the station during the test! · Position the device in the location, oriented as you prefer, but at least one meter from the possible source of interference. · Activate test mode as described. · Monitor the reception display on the weather station. If you have found a location that has good reception, you can leave the device there and it will retrieve data automatically from the transmitter. Note! · The time and date appear within a few minutes.

Local outside temperature will appear just after the set up (see detail below). · The transfer of larger quantities of data for the forecast takes much longer: In order to receive all data, the station requires 24 hours after start-up. POSSIBLE SOURCES OF INTERFERENCE Interferences as with a radio transmitter can occur and could be caused by the following influences: · In buildings with a lot of concrete, metal parts and electrical systems, reception problems can occur (e.g. Mall).

· Electrical devices such as television, computer, house-hold devices, etc. or transformers, land lines, radio transmitters and railways are possible direct sources of interference. · Atmospheric influences and geographical features (mountains, etc.) can affect the propagation of the radio waves. · The distance from the transmitter does also influence the reception. Areas such as Southern Italy or Northern Scandinavia are also critical areas because of the great distances from the transmitter. @@@@All internal data is deleted when you change the batteries. @@@@The text "loc" is shown on the display. The currently defined region is shown directly to the right. @@For regions 60 89, the forecast is limited to 2 days.

@@The data is synchronized again after changing the region. @@The text "ti" is shown on the display. The currently defined time zone is shown directly to the right. Use the <+> button to select the desired time zone. Note! @@@@The text "con" appears. The currently set value is displayed in the field on the right. @@Pressing the <SET> button again ends configuration mode. @@The text "test" is shown on the display. @@@@The reception test is either ended after approx. @@The text "ALM" and the hours display flash.

Use the <+> button for the hour setting. @@The minute display flashes. Use the <+> button for the minutes setting. @@Use the <ALARM> button to activate or deactivate the alarm. When the alarm is active, the alarm symbol "((()))" is shown on the display. The alarm signal can be interrupted with the <ALARM> button. Use the <SNOOZE> button to stop the alarm signal for five minutes. During this time, the alarm signal "((()))" flashes. Outdoor temperature : Min/Max can be reset by pressing the SNOOZE key during 3 seconds. Show current weather region Press the <SET> button to show the current weather region.

The text „loc" appears with the currently defined region on the display. An overview of the coding of all available regions can be found under Appendix. INTENDED USAGE, EXCLUSION OF WARRANTY, AND SAFETY INFORMATION This weather station is intended for private usage as an indicator for future weather. The forecasts of this device are to be used as orientation values and do not represent absolute, precise forecasts. The manufacturer or distributor of this weather station assumes no responsibility for incorrect values or any results that may occur because of these values. The weather station is not intended for medical purposes or for the information to the public. The manufacturer or distributor has no influence on the transferred weather data or forecasts. The capabilities of the weather station depend on the operational functionality of the transmission media, which the manufacturer or distributor has no influence on. Failures in the transmission media cannot be ruled out. This device is not a toy and contains breakable and small parts.

Install the device out of the reach of children. Improper handling or unauthorized opening of the device voids the guarantee. @@@@0 to 50° C

Accuracy:.....

.....
.....
.....

..... ±1° C Resolution:

.....
.....
.....

..... @@-39.9 / +59.9 ° C Accuracy:..

.....
.....
.....

... ±1° C Resolution: ..

.....
.....

.....
... 0,1° C Weather data updating:

.....
..... Every 24 hours Power consumption: ...

.....
.... @@Transmitter : 2 x Battery LR3/Mignon/AAA Dimensions (L x W x H) : .

.....
.... Station : 135 x 28 x 166 mm

.....
.....
.....
.....

.....
... Transmitter : 32 x 14 x 86 mm 11 .



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WM5014 user guide](http://yourpdfguides.com/dref/1116258)
<http://yourpdfguides.com/dref/1116258>