




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for LA CROSSE TECHNOLOGY WS-9245UBK-IT. You'll find the answers to all your questions on the LA CROSSE TECHNOLOGY WS-9245UBK-IT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual LA CROSSE TECHNOLOGY WS-9245UBK-IT
User guide LA CROSSE TECHNOLOGY WS-9245UBK-IT
Operating instructions LA CROSSE TECHNOLOGY WS-9245UBK-IT
Instructions for use LA CROSSE TECHNOLOGY WS-9245UBK-IT
Instruction manual LA CROSSE TECHNOLOGY WS-9245UBK-IT



- FEATURES:**
- The Temperature Station:**
- Manual time set (hour and minute)
 - 24 Hour Time Format
 - Temperature Display in Fahrenheit (°F)
 - Indoor and Outdoor Temperature with MAX/MIN Records
 - Low Battery Indication
 - Wireless Transmission at 915 MHz
 - 0 Second Signal Reception Interval
 - Wall Mount or Table Stand
- The Outdoor Temperature Transmitter:**
- Wireless 915 MHz Outdoor Temperature Transmitter
 - Temperature Gauge
 - Wall Mounting or Table Stand
- Note:** Mount in a sheltered place. Avoid direct rain and sunlight.

- SETUP:**
- Note:** The temperature station can only receive one transmitter only.
1. First, insert batteries into the transmitter case. **How to install and replace batteries in the Temperature Transmitter:** Refer to the diagram below.
 2. Within 30 seconds of powering up the transmitter, insert batteries into the Temperature Station case. **How to install and replace batteries in the Temperature Station:** Refer to the diagram below. Once the batteries are replaced, all segments of the LCD will light up briefly. Following the power temperature, the time as 0:00 will be displayed. If they are not shown in the LCD after 60 seconds, remove the batteries and wait for at least 60 seconds before reinserting them. Check the polarity details if applicable you may proceed to the next step.
 3. After the batteries are inserted, the Temperature Station will start receiving outdoor temp data from the transmitter. The outdoor temperature should then be displayed on the Temperature Station. If the time not happen after 2 minutes, connect the battery between both units and start again from step 1.
 4. To receive accurate outdoor 915 MHz transmission, the station transmitter should be placed a distance of 100 meters (300 feet) from the Temperature Station and the transmitter (see section "Placement" and "915 MHz Frequency").

- HOW TO INSTALL AND REPLACE BATTERIES IN THE TEMPERATURE STATION**
- The Temperature Station uses 2 x AA, IEC LR06 1.5V batteries. When batteries are used to be replaced, the low battery icon will appear on the LCD. To install and replace the batteries, please follow the steps below:
1. Lift up the battery compartment cover.
 2. Insert batteries observing the correct polarity (see marking).
 3. Replace compartment cover.

- HOW TO INSTALL / REPLACE BATTERIES IN THE OUTDOOR TRANSMITTER**
- The Temperature transmitter uses 2 x AAA, IEC LR03 1.5V batteries. When batteries need to be replaced, the low battery icon will appear on the LCD of the Temperature Station. To install and replace the batteries, please follow the steps below:
1. Remove the battery compartment cover.



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS-9245UBK-IT user guide](http://yourpdfguides.com/dref/3643522)
<http://yourpdfguides.com/dref/3643522>

Manual abstract:

With two easy to use function keys, this innovative product is ideal for use in the home or office. Hanging hole LCD display Battery compartment The Temperature Station Manual time set (hour and minute) 24-Hour Time Format Temperature Display in Fahrenheit (°F) Indoor and Outdoor Temperature with MIN/MAX Records Low Battery Indicator Wireless Transmission at 915 MHz 8 Second Signal Reception Interval Wall Mount or Table Stand The Outdoor Temperature Transmitter Wireless 915 MHz Outdoor Temperature Transmitter Rain-resistant Casing Wall Mounting or Table Stand Note: Mount in a sheltered place. Avoid direct rain and sunshine. Function keys Stand SETUP: Note: this temperature station can only receive one transmitter only. 1. 2. First, insert batteries into the transmitter (see "How to install and replace batteries in the Temperature transmitter" below). Within 30 seconds of powering up the transmitter, insert batteries into the Temperature Station (see "How to install and replace batteries in the Temperature station" below). Once the batteries are in place, all segments of the LCD will light up briefly. Following the indoor temperature, the time as 0:00 will be displayed. If they are not shown in the LCD after 60 seconds, remove the batteries and wait for at least 60 seconds before reinserting them. Once the indoor data is displayed you may proceed to the next step. After the batteries are inserted, the Temperature Station will start receiving outdoor temp data from the transmitter. The outdoor temperature should then be displayed on the Temperature station. @@@@ @@@@2.

3. Lift up the battery compartment cover. Insert batteries observing the correct polarity (see marking). Replace compartment cover. 3. HOW TO INSTALL / REPLACE BATTERIES IN THE OUTDOOR TRANSMITTER The Temperature transmitter uses 2 x AAA, IEC LR3 1.5V batteries. When batteries need to be replaced, the low battery icon will appear on the LCD of the Temperature Station. @@ Remove the battery compartment cover. 4. 2. 3. Insert the batteries, observing the correct polarity (see marking). Replace the battery holder to the unit. FUNCTION KEYS: The Temperature Station has only two easy to use function keys: SET key + key Note: When changing batteries in either of the units, all units need to be reset by following the setup procedures.

This is because a random security code is assigned by the transmitter at start-up and this code must be received and stored by the Temperature Station in the first few minutes of power supplying. BATTERY CHANGE: It is recommended to replace the batteries in all units regularly to ensure optimum accuracy of these units. (Battery life see Specifications) Please participate in the preservation of the environment. Return used batteries to an authorized depot. SET key Press and hold for about 3 seconds to enter the Manual setting mode. + key Press to make adjustment in the setting mode. Press and hold to reset all MIN/MAX records LCD SCREEN AND SETTINGS: Time Low Battery indicator (temp station) Indoor Temperature in °C MIN/MAX Indoor temperature Low Battery indicator (transmitter) Outdoor Temp in °C MIN/MAX Outdoor temperature * When the signal from the transmitter is successfully received by the Temperature Station, this icon will be switched on. (If not successful, the icon will not be shown on the LCD). User can therefore easily see whether the last reception was successful ("ON" icon) or not ("OFF" icon). On the other hand, the short blinking of the icon shows that a reception is being done at that time. @@2. 3. @@ The hour digit of the time display will be flashing. @@ Press SET key to confirm and go to the minute setting. The minute digit will be flashing. @@@@ @@@@3. 4. metal window frames. @@@@ @@@@2. @@@@ @@@@ The transmission range is about 200 ft. from the transmitter to the Temperature Station (in open space). @@@@ @@@@2. Hang the Temperature Station onto the screw. @@@@ @@@@2. Clip the remote temperature transmitter onto the bracket. Note: The mounting surface can affect the transmission range. If, for instance, the unit is attached to a piece of metal, it may then either reduce or increase the transmitting range. For this reason, we recommend not to place the unit on any metal surfaces or in any position where a large metal or highly polished surface is in the immediate vicinity (garage doors, double glazing, etc.). Before securing in place, please ensure that the Temperature Station can receive the 915MHz signal from the temperature transmitter at the positions that you wish to place them.

CARE AND MAINTENANCE: Extreme temperatures, vibrations and shocks should be avoided as these may cause damage to the unit and give inaccurate forecasts and readings. When cleaning the display and casings, use a soft damp cloth only. Do not use solvents or scouring agents as they may mark the LCD and casings. Do not submerge the units in water. Furthermore, fix all parts in place where the units are adequately protected against moisture and rain. Immediately remove all low powered batteries to avoid leakage and damage. Replace only with new batteries of the recommended type. Do not make any repair attempts to the unit. Return them to their original point of purchase for repair by a qualified engineer. Opening and tampering with the unit may invalidate their guarantee.

Do not expose the units to extreme and sudden temperature changes, this may lead to rapid changes in forecasts and readings and thereby reduce their accuracy. SPECIFICATIONS: Temperature measuring range Indoor : 14.5°F to 139.5°F with 0.5°F resolution ("OF.L" displayed if outside this range) Outdoor : -39.8°F to +139.8°F with 0.2°F resolution ("OF.L" displayed if outside this range) Indoor Temperature checking interval : every 20 seconds Outdoor data checking interval : every 8 seconds Power consumption Temperature Station : 2 x AA, IEC LR6, 1.5V Outdoor Temperature Transmitter : 2 x AAA, IEC LR3, 1.5V Battery life cycle (Alkaline batteries recommended): Temperature Station : approximately 24 months Outdoor Temperature Transmitter : approximately 12 months Dimensions (L x W x H) Temperature Station : 3.14" X 5.00" X 1.14" Outdoor Temperature Transmitter : 1.27" X 3.40" X 0.55" WARRANTY La Crosse Technology, Ltd provides a 1-year limited warranty on this product against manufacturing defects in materials and workmanship. This limited warranty begins on the original date of purchase, is valid only on products purchased and used in North America and only to the original purchaser of this product. To receive warranty service, the purchaser must contact La Crosse Technology, Ltd for problem determination and service procedures.

@@@@ @@@@ Replacement parts and products assume the remaining original warranty, or ninety (90) days, whichever is longer. La Crosse Technology, Ltd will pay all expenses for labor and materials for all repairs covered by this warranty.



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS-9245UBK-IT user guide](http://yourpdfguides.com/dref/3643522)
<http://yourpdfguides.com/dref/3643522>

If necessary repairs are not covered by this warranty, or if a product is examined which is not in need of repair, you will be charged for the repairs or examination. The owner must pay any shipping charges incurred in getting your La Crosse Technology, Ltd product to a La Crosse Technology, Ltd authorized service center. La Crosse Technology, Ltd will pay ground return shipping charges to the owner of the product to a USA address only. Your La Crosse Technology, Ltd warranty covers all defects in material and workmanship with the following specified exception.



[You're reading an excerpt. Click here to read official LA CROSSE TECHNOLOGY WS-9245UBK-IT user guide](http://yourpdfguides.com/dref/3643522)
<http://yourpdfguides.com/dref/3643522>